

Operating Instructions – Description of Instrument Functions Cerabar S PMC71, PMP71/75 Deltabar S FMD77, FMD78, PMD75 Deltapilot S FMB70

Process pressure / Differential pressure, Flow / Hydrostatic







BA00274P/00/EN/17.14 71270402 valid from Software version: 02.20.zz



Table of contents

1	Notes on use 4
1.1 1.2 1.3	Finding parameter description using ID numbers 4 Finding function group using graphic representation 4 Finding parameter description using parameter names (index)
2	Finding parameter description using ID numbers 5
3	Graphic representation of function groups 10
4	Pressure measurement 11
4.1 4.2	Calibration with reference pressure
5	Level measurement 14
5.1 5.2 5.3	Overview of level measurement 14 "Level Easy Pressure" level selection 15 "Level Easy Height" level selection 19 "Lavel Standard" level selection 19
5.5	"Linear" level type
5.6	"Level Standard" level selection, "Height Linearized" level type
6	Flow measurement 40
6.1 6.2	Calibration40Totalizers43
7	Description of parameters 44
8	Trouble-shooting 132
8.1 8.2 8.3	Messages132Response of outputs to errors141Confirming messages142
9	Appendix 142
9.1	Operating menu for on-site display, Digital communication
Inde	x 151

1 Notes on use

Section 7 describes all the parameters in order of how they appear in the menu. Sections 4 to 6 provide typical examples of configuration.

Sections 1.1 to 1.3 describe ways of finding a certain parameter description more easily.

1.1 Finding parameter description using ID numbers

Each parameter is shown on the on-site display with a unique identification number (ID). Section 2 lists all the parameters in numerical order. The page reference/link takes you to the parameter in question.

In the Operating program, additional parameters and, to an extent, other parameters are displayed. These parameters are not listed in Section 2. You can find these parameters by means of the index. \rightarrow See also Section 1.3.

1.2 Finding function group using graphic representation

All the function groups are shown in table form in Section 3. The page reference/link takes you to the function group in question. In Section 7, all the parameters of a function group are compiled in a table.

1.3 Finding parameter description using parameter names (index)

The index lists all the parameters in alphabetical order. The page reference/link takes you to the parameter in question.

2 Finding parameter description using ID numbers

ID number	Parameter name	Description, see page
001	DENSITY UNIT – Level Selection "Level Easy Pressure"	64 or 97
003	HEIGHT UNIT	64
004	FULL CALIB. – QUICK SETUP	51
004	FULL CALIB Level Selection "Level Easy Pressure"	61
004	FULL CALIB Level Selection "Level Easy Height"	65
005	FULL PRESSURE	61
006	FULL HEIGHT	66
007	ADJUST DENSITY - Level Selection "Level Easy Height"	64 or 97
008	CALIBRATION MODE - Level Selection "Level Easy Pressure"	60
008	CALIBRATION MODE - Level Selection "Level Easy Height"	64
009	EMPTY HEIGHT	65
010	EMPTY CALIB. – QUICK SETUP	50
010	EMPTY CALIB Level Selection "Level Easy Pressure"	60 or 61
010	EMPTY CALIB. – Level Selection "Level Easy Height"	65
011	EMPTY PRESSURE	61
012	SET URV - Level Selection "Level Easy Pressure"	61
012	SET URV – Level Selection "Level Easy Height"	66
013	SET LRV – Level Selection "Level Easy Pressure"	61
013	SET LRV – Level Selection "Level Easy Height"	66
014	DOWNLOAD SELECT	126
015	FULL PRESSURE	See ¹
016	EMPTY PRESSURE	See ¹
017	FULL CALIB.	See ¹
018	EMPTY CALIB.	See ¹
020	LEVEL SELECTION	46
021	SET LRV	See ¹
022	SET URV	See ¹
023	OUTPUT UNIT – Level Selection "Level Easy Pressure"	60
023	OUTPUT UNIT – Level Selection "Level Easy Height"	64
025	PROCESS DENSITY – Level Selection "Level Easy Pressure"	97
036	PREAMBLE NUMBER	115
042	CURR. I RIM 20mA	131
043	OFFSET 4MA TRIM	131
044	OFFSET ZUMA TRIM	131
045	CURK. I RIM 4MA	131
040	ALARM STATUS	128
047	ENTER RESET CODE	120
040		120
050		123
055	DESS ENC UNIT	11/ 56 50 62 67 er 02
000	CUSTOMED UNIT D	56, 50, 63, 68 or 02
073		50, 59, 03, 08 01 92
245	SET LDV "Processo" moon mode	44 48 or 56
245	SET LRV - "Pressure" measuring mode	48 or 57
240		48 51 53 57 61 66 77 81 00 or 05
247	SENSOR SER No	110
251	Pmin SENS DAMAGE	120
251	Pmax SENS DAMAGE	120
252		111
264	SOFTWARE VERSION	117
264	HARDWARE REV	117
270	SIM CURRENT	128
271	HART MESSAGE	116
271		117
301	DDE LIOIAL INTO, DDESSI IDE - "Prossura" massuring mode	11/
301	PRESSURE - "Level" measuring mode	122
	PRESSURE - "Flow" measuring mode	122
305		12.5
505	FOLIQ LYQ HOLMDEK	11/

1) See Safety Manual SD00189P for Deltabar S, SD00190P for Cerabar S and SD00213P for Deltapilot S.

ID number	Parameter name	Description, see page
309	GET LRV	57
310	GET URV	57
311	MAX. FLOW	52 or 95
313	UNIT VOLUME – "Linear" level type	71 or 75
	UNIT VOLUME - "Pressure Linearized" level type	79
	UNIT VOLUME – "Height Linearized" level type	84
314	EMPTY CALIB. – QUICK SETUP	50
	EMPTY CALIB. – "Linear" level type	73
	EMPTY CALIB. – "Height Linearized" level type	87
315	FULL CALIB. – QUICK SETUP	51
	FULL CALIB. – "Pressure Linearized" level type	74
216	FULL CALIB. – "Height Linearized" level type	8/
310	ADJUST DENSITY - "Linear" level type	74
	ADJOST DENSITY - Treight Linearized level type	07
317	CUST UNIT FACT P	56 68 or 93
318	TEMP. ENG. UNIT – "Pressure" measuring mode	96
	TEMP. ENG. UNIT – "Level" measuring mode	97
	TEMP. ENG. UNIT – "Flow" measuring mode	99
319	CALIB. OFFSET	54
323	SET. L. FL. CUT-OFF	99
329	FACT. U. U. TOTAL. 1	108
330	FACT. U. U. TOTAL. 2	109
331	RESET TOTALIZER1	109
332	Pmin ALARM WINDOW	130
333	Pmax ALARM WINDOW	130
334	Tmin ALARM WINDOW	130
335	I max Alarm WINDOW	130
330	ALAKIM DELAY	129
342	SET MAY ALARM	111
343	SET MIN, ALARM	113
345	BUS ADDRESS	115
350	DEVICE DESIGN.	117
351	DEVICE TYPE, Deltabar S	115
352	CONFIG RECORDER	117
354	DEVICE SERIAL No	117
357	PCB TEMPERATURE	117
358	ALLOWED MIN. TEMP	117
359	ALLOWED MAX. TEMP	117
360	MAT. PROC. CONN. +	118
361	MAI. PROC. CONN	118
302	SEAL TYPE	118
365	MAT MEMBRANE	120
366	FILLING FLUID	120
367	SENSOR TEMP.	122 or 123
368	Tmin SENSOR	120
369	Tmax SENSOR	120
370	TANK CONTENT	123
375	SUPPRESSED FLOW	123
378	MEAS. VAL. TREND	122 or 123
380	COUNTER:P > Pmax	124
382	RESET PEAKHOLD	125
383	MAX. MEAS. PRESS.	124
380	ELECTK. SEKIAL NO	117
380		112
309		113
301	LINERIV SCROOT	03
392	CALIBRATION MODE – "Linear" level type	73
	CALIBRATION MODE – "Height Linearized" level type	87
397	LIN. EDIT MODE	101
398	TOTALIZER 1 UNIT – "Volume p. cond." flow type	108
399	TOTALIZER 2 UNIT - "Volume p. cond." flow type	109
400	NEG. FLOW TOT. 1	108
401	ACK. ALARM MODE	128

ID number	Parameter name	Description, see page
404	COUNTER:T > Tmax	124
409	OPERATING HOURS	126
413	SIMULATION MODE	127
414	SIM. PRESSURE	127
416	NEG. FLOW TOT. 2	109
419	MENU DESCRIPTOR	110
423	ALTERNATE DATA	110
432	MANUFACTOR ID	116
434	CORRECTED PRESS. – "Pressure" measuring mode	122
	CORRECTED PRESS "Level" measuring mode	122
	CORRECTED PRESS "Flow" measuring mode	123
442	LOW FLOW CUT-OFF	99
467	COUNTER:P < Pmin	124
469	MIN. MEAS. PRESS.	124
471	MAX. MEAS. TEMP.	124
472	COUNTER:T < Tmin	124
474	MIN. MEAS. TEMP.	124
476	SIM. ERROR NO.	128
480	ALARM DISPL. TIME	129
401	PROC CONN TYPE	110
402	PRESS SENSIOUM	110
485	PRESS. SENS HILIM	119
487	SENS H/WARE REV	120
488	PCB COUNT:T > Tmax	124
490	PCB MAX. TEMP.	124
492	PCB COUNT:T < Tmin	124
494	PCB MIN. TEMP.	124
500	ACK. ALARM	129
052	CURRENT MODE	115
549	MEASURING TABLE (display)	103
549	EDITOR TABLE, LINE-NUMB (enter values)	102
550	EDITOR TABLE, X-VAL. (enter values)	102
551	EDITOR TABLE, Y-VAL. (enter values)	102, 102
563	POS. INPUT VALUE	48, 50 or 54
504	LASI DIAG. CODE	128
570	PMAX PROC. CONN.	04
581	SENSOR MEAS TYPE	120
584	SENSOR PRESSURE - "Pressure" measuring mode	120
	SENSOR PRESSURE – "Level" measuring mode	122
	SENSOR PRESSURE – "Flow" measuring mode	123
585	HART VERSION	114
591	MINIMUM SPAN	119
595	SELECT ALARMTYPE	129
597	ALT. CURR. OUTPUT	113
600	SELECT ALARMTYPE	129
603	RESET ALL ALARMS	129
607	CUST. UNIT FACT. V – "Linear" level type	72
	CUST. UNIT FACT. V – "Pressure Linearized" level type	79
(00	CUST. UNIT FACT. V – "Height Linearized" level type	85
608	CUSTOMER UNIT V – "Linear" level type	71
	CUSTOMER UNIT V – Pressure Linearized level type	79 05
600	CUST LINIT FACT F	05
610	CUSTOMER UNIT F	0/
627	TOT 1 LISER LINIT	108
628	TOT. 2 USER UNIT	109
634	MAX PRESS. FLOW	53 or 95
637	SET LRV – "Flow" extended setup	99
638	SET URV – "Flow" extended setup	100
639	SIM.FLOW VALUE	127
640	FLOW-MEAS. TYPE	93
652	TOTALIZER 1	124
655	TOTAL. 1 OVERFLOW	124
657	TOTALIZER 2	124
058	IOIAL. 2 OVERFLOW	124
000	SID. FLOW UNII	94

661	NORM FLOW UNIT	93
ID number	Parameter name	Description, see page
662	TOTALIZER 1 UNIT – "Mass" flow type	108
663	TOTALIZER 2 UNIT – "Mass" flow type	109
664	TOTALIZER 1 UNIT - "Gas. std. conditions" flow type	108
665	TOTALIZER 2 UNIT - "Gas. std. conditions" flow type	109
666	TOTALIZER 1 UNIT - "Gas. norm conditions" flow type	108
667	TOTALIZER 2 UNIT – "Gas. norm conditions" flow type	109
679	MEASURED VALUE – "Pressure"	121
	MEASURED VALUE – "Level"	122
	MEASURED VALUE – "Flow"	123
685	POS. ZERO ADJUST	48, 50, 52 or 54
688	MAIN DATA FORMAT	110
694	CURR. CHARACI. – "Pressure"	112
695	CURR. CHARACI "FIOW"	112
600	CURR. CHARACI. – Height	112
703	CUST LINIT FACT M - "Linear" level time	73
705	CUST. UNIT FACT. $M = $ "Pressure Linearized" level type	80
	CUST. UNIT FACT. $M =$ "Height Linearized" level type	86
704	CUSTOMER UNIT M = "Linear" level type	72
	CUSTOMER UNIT M – "Pressure Linearized" level type	80
	CUSTOMER UNIT M – "Height Linearized" level type	86
705	CUST. UNIT FACT. H – "Linear" level type	71 or 76
	CUST. UNIT FACT. H – "Height Linearized" level type	84 or 89
706	CUSTOMER UNIT H – "Linear" level type	70 or 76
	CUSTOMER UNIT H – "Height Linearized" level type	84 or 89
708	HEIGHT UNIT – "Linear" level type	70 or 76
	HEIGHT UNIT – "Height Linearized" level type	83 or 88
709	MASS UNIT – "Linear" level type	72
	MASS UNIT – "Pressure Linearized" level type	80
	MASS UNIT – "Height Linearized" level type	85
710	EMPTY PRESSURE – "Linear" level type	74
	EMPTY PRESSURE – "Height Linearized" level type	87
711	FULL PRESSURE – "Linear" level type	74
710	FULL PRESSURE – "Height Linearized" level type	87
712	LEVEL MAX	80
713		101
714	SIM TANK CONT	127
717	MEASURING TABLE (selection)	103
718	LEVEL MODE	68
719	SET LRV – "Level" basic setup	77
720	SET URV – "Level" basic setup	77
755	LEVEL MIN	86
759	TANK CONTENT MIN	101
760	ASSIGN CURRENT	113
761	HYDR. PRESS MAX.	81
762	SET LRV – "Level" extended setup	98
763	SET URV – "Level" extended setup	98
764	CURR. CHARACT. – "Tank content"	112
770	EDITOR TABLE (continue entry)	103
775	HYDR. PRESS MIN.	80
802	DEVICE 1YPE, Cerabar S	115
804	LIN. MEASUKAND	70
806		/7 93
808		0.5
800	EDITOR TABLE (select table)	102
810	ADILISTED DENSITY - "Linear" level type	74
010	ADILISTED DENSITY - "Height Linearized" level type	87
811	PROCESS DENSITY	97
812	DENSITY UNIT – "Linear" level type	74
	DENSITY UNIT – "Height Linearized" level type	88
813	100 % POINT – "Linear" level type	77
	100 % POINT – "Height Linearized" level type	89

ID number	Parameter name	Description, see page
814	ZERO POSITION – "Linear" level type	77
	ZERO POSITION – "Height Linearized" level type	90
815	TANK DESCRIPTION	103
831	HistoROM AVAIL.	126
832	HistoROM CONTROL	127
836	SAFETY LOCKSTATE	See 1)
	SAFETY LOCK	
838	SAFETY PASSWORD	See ¹
840	DIGIT SETS	111
841	DIGIT SETS	See ¹
844	ACK. ALARM MODE	See ¹
845	MEASURING MODE	See ¹
847	CALIB. OFFSET	See ¹
848	MAX. FLOW	See ¹
849	MAX PRESS. FLOW	See ¹
850	LOW FLOW CUT-OFF	See ¹
851	SET. L. FL. CUT-OFF	See ¹
852	SET LRV	See ¹
853	SET URV	See ¹
854	LINEAR/SQROOT.	See ¹
855	DAMPING VALUE	See ¹
856	CONF. PASSWORD	See ¹
858	TANK VOLUME	75
859	TANK HEIGHT	76
875	CURRENT OUTPUT	See ¹

1) See Safety Manual SD00189P for Deltabar S, SD00190P for Cerabar S and SD00213P for Deltapilot S.



Graphic representation of function groups

Note!

3

The "Flow" measuring mode is only available for the Deltabar S differential pressure transmitter. The groups marked with "*" are only displayed for Deltabar S.

1st selection level	2nd selection level (groups)	Function groups	De see	scription, e page
LANGUAGE	LANGUAGE (079)		\rightarrow	44
MEASURING MODE	MEASURING MODE (389)		\rightarrow	45
QUICK SETUP pressure			\rightarrow	47
QUICK SETUP level			\rightarrow	49
QUICK SETUP flow*			\rightarrow	52
OPERATING MENU (555)	\rightarrow SETTINGS (557)	\rightarrow POSITION ADJUSTMENT	\rightarrow	53
		\rightarrow BASIC SETUP pressure	\rightarrow	55
		→ BASIC SETUP level, "Level Easy Pressure"	\rightarrow	58
		→ BASIC SETUP level, "Level Easy Height"	\rightarrow	62
		→ BASIC SETUP level, "Level Easy Standard"	\rightarrow	67
		\rightarrow BASIC SETUP flow*	\rightarrow	91
		\rightarrow EXTENDED SETUP pressure	\rightarrow	96
		\rightarrow EXTENDED SETUP level	\rightarrow	96
		→ EXTENDED SETUP flow*	\rightarrow	98
		→ LINEARISATION – on-site display	\rightarrow	100
		→ LINEARISATION – Digital communication	\rightarrow	104
		\rightarrow TOTALIZER SETUP *	\rightarrow	107
	\rightarrow SAFETY CONFIRM.		\rightarrow	See 1)
	\rightarrow DISPLAY (558)		\rightarrow	110
	\rightarrow OUTPUT (559)		\rightarrow	111
	\rightarrow TRANSMITTER INFO (560)	\rightarrow HART DATA	\rightarrow	114
		\rightarrow TRANSMITTER DATA	\rightarrow	117
		\rightarrow PROCESS CONNECTION	\rightarrow	117
		\rightarrow SENSOR DATA	\rightarrow	119
	\rightarrow PROCESSINFO (561)	\rightarrow PROCESS VALUES pressure	\rightarrow	121
		→ PROCESS VALUES level	\rightarrow	122
		\rightarrow PROCESS VALUES flow*	\rightarrow	123
		\rightarrow PEAK HOLD INDICATOR	\rightarrow	124
	→ OPERATING		\rightarrow	126
	\rightarrow DIAGNOSTICS (562)	\rightarrow SIMULATION	\rightarrow	127
		→ MESSAGES	\rightarrow	128
		\rightarrow USER LIMITS	\rightarrow	130
	\rightarrow SERVICE (561)	\rightarrow SYSTEM 2	\rightarrow	131

1) See Safety Manual SD00189P for Deltabar S, SD00190P for Cerabar S and for SD00213P Deltapilot S.

4 Pressure measurement

4.1 Calibration with reference pressure

Example:

In this example, a device with a 500 mbar (7.5 psi) sensor is configured for the 0...+300 mbar (4.5 psi)measuring range, i.e. 0 mbar and 300 mbar (4.5 psi) are assigned to the 4 mA value and 20 mA value respectively.

Prerequisite:

• The pressure values 0 mbar and 300 mbar (4.5 psi) can be specified. The device is already installed, for example.



Note!

- See also Operating Instructions Deltabar S (BA00270P), Section 6.6 "Differential pressure measurement", Cerabar S (BA00271P), Section 6.4 "Pressure measurement" or Deltapilot S (BA00332P), Section 6.5 "Pressure measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 55, Table 7: BASIC SETUP.
- For a description of further relevant parameters, see
 - Page 96, Table 15: EXTENDED SETUP
 - Page 121, Table 25: PROCESS VALUES.



Warning!

	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and filled with fluid. See Operating Instructions BA00270P, Section 6.6.	
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
3	If necessary, select the "Pressure" measuring mode via the MEASURING MODE parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	P01-PMD75xxx-19-xx-xx-000
4	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	2 20
5	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
6	The pressure for the lower range value (4 mA value) is present at the device, here 0 mbar for example.	
	Select GET LRV parameter.	
	Confirm value present. The pressure value present is assigned to the lower current value (4 mA).	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
		P01-xxxxxxx-05-xx-xx-010
		<i>Fig. 1: Calibration with reference pressure</i>
		1See table, step 6.2See table, step 7.
7	The pressure for the upper range value (20 mA value) is present at the device, here 300 mbar (4.5 psi) for example.	
	Select GET URV parameter.]
	Confirm value present. The pressure value present is assigned to the upper current value (20 mA).]
8	Result: The measuring range is set for 0+300 mbar (4.5 psi).	



 You can also specify a customer-specific unit. See parameter description for PRESS. ENG. UNIT (→ Page 56).

4.2 Calibration without reference pressure

Example:

In this example, a device with a 400 mbar (6 psi) sensor is configured for the 0...+300 mbar (4.5 psi) measuring range, i.e. 0 mbar and 300 mbar (4.5 psi) are assigned to the 4 mA value and 20 mA value respectively.

Prerequisite:

• This is a theoretical calibration, i.e. the pressure values for the lower range and upper range value are known.



- See also Operating Instructions Deltabar S (BA00270P), Section 6.6 "Differential pressure measurement", Cerabar S (BA00271P), Section 6.4 "Pressure measurement" or Deltapilot S (BA00332P), Section 6.5 "Pressure measurement".
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page 53, Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 55, Table 7: BASIC SETUP.
- For a description of further relevant parameters, see
 - Page 96, Table 15: EXTENDED SETUP
 - Page 121, Table 27: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" \rightarrow "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	If necessary, select the "Pressure" measuring mode via the MEASURING MODE parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	
2	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	P01-PMP71xxx-19-xx-xx-000
3	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
4	Select SET LRV parameter.	2) 20
	Enter value, here 0 mbar, for the SET LRV parameter and confirm. This pressure value is assigned to the lower current value (4 mA).	
5	Select SET URV parameter.	
	Enter value, here 300 mbar (4.5 psi), for the SET URV parameter and confirm. This pressure value is assigned to the upper current value (20 mA).	
6	Result: The measuring range is set for 0+300 mbar (4.5 psi).	[mbar]
		P01-xxxxxxx-05-xx-xx-010
		Fig. 2: Calibration without reference pressure
		1See table, step 4.2See table, step 5.



Note!

- You can also perform calibration without reference pressure by means of the QUICK SETUP menu. → See Page 47 ff, Table 3: QUICK SETUP menu.
- You can also specify a customer-specific unit. See parameter description for PRESS. ENG. UNIT (→ Page 56).

5 Level measurement

5.1 Overview of level measurement

Measuring task	LEVEL SELECTION/ LEVEL MODE	Measured variable options	Description	Comment	Measured value display
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering two pressure- level value pairs.	LEVEL SELECTION: Level Easy Pressure	Via OUTPUT UNIT parameter: %, level, volume or mass units.	 Calibration with reference pressure – wet calibration, see Page 15, Section 5.2.1 Calibration without reference pressure – dry calibration, see Page 17, Section 5.2.2 	 Incorrect entries are possible SIL mode possible Customised units are not possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering the density and two height-level value pairs.	LEVEL SELECTION: Level Easy Height	Via OUTPUT UNIT parameter: %, level, volume or mass units.	 Calibration with reference pressure – wet calibration, see Page 19, Section 5.3.1 Calibration without reference pressure – dry calibration, see Page 22, Section 5.3.2 	 Incorrect entries are possible SIL mode not possible Customised units are not possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is in direct proportion to the measured pressure.	LEVEL SELECTION: Level standard/ LEVEL MODE: Linear	Via LIN. MEASURAND parameter: – % (Level) – Level – Volume – Mass	 Calibration with reference pressure – wet calibration, see Page 24, Section 5.4.1 Calibration without reference pressure – dry calibration, see Page 26, Section 5.4.2 	 Incorrect entries are rejected by the device SIL mode not possible Customised level, volume and mass units are possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is not in direct proportion to the measured pressure as, for example, with containers with a conical outlet. A linearisation table must be entered for the calibration.	LEVEL SELECTION: Level standard/ LEVEL MODE: Pressure Linearized	Via LINd MEASURAND parameter: – Pressure + % – Pressure + Volume – Pressure + Mass	 Calibration with reference pressure: semiautomatic entry of linearisation table, see Page 28, Section 5.5.1 Calibration without reference pressure: manual entry of linearisation table, see Page 31, Section 5.5.2 	 Incorrect entries are rejected by the device SIL mode not possible Customised level, volume and mass units are possible 	The measured value display and the TANK CONTENT parameter show the measured value.
 Two measured variables are required or The container shape is given by value pairs, such as height and volume. The 1st measured variable %-height or height must be in direct proportion to the measured pressure. The 2nd measured variable volume, mass or % must not be in direct proportion to the measured pressure. A linearisation table must be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table. 	LEVEL SELECTION: Level standard/ LEVEL MODE: Height Linearized	Via COMB. MEASURAND parameter: - Height + Volume - Height + Mass - %-Height + Volume - %-Height + Mass - %-Height + %	 Calibration with reference pressure: wet calibration and semiautomatic entry of linearisation table, see Page 33, Section 5.6.1 Calibration without reference pressure: dry calibration and manual entry of linearisation table, see Page 37, Section 5.6.2 	 Incorrect entries are rejected by the device SIL mode not possible Customised level, volume and mass units are possible 	The measured value display and the TANK CONTENT parameter show the 2nd measured value (volume, mass or %). The LEVEL BEFORE LIN parameter displays the 1st measured value (%-height or height).

5.2 "Level Easy Pressure" level selection

5.2.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0 to 300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled or emptied.



- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB. and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
- Page 58, Table 8: LEVEL SELECTION "Level Easy Pressure"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



		Description	
-	1	Deltabar S: Before you configure the device for your application, the pressure piping must be cleaned and filled with medium. See Operating Instructions BA00270P, Section 6.5.1	② 300 mbar 3 m
	2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
	3	If necessary, select the "Level" measuring mode via the MEASURING MODE parameter.	
		On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	0 m
		Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	P01-PMP75xxx-19-xx-xx-008
	4	If necessary, select "Level Easy Pressure" level mode using the LEVEL SELECTION parameter.	<i>Fig. 3: Calibration with reference pressure – wet calibration</i>
		On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	 See Table, Step 9. See Table, Step 10.
		Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select a level unit via the OUTPUT UNIT parameter, here m for example.	
8	Select the "Wet" option by means of the CALIBRATION MODE parameter.	
9	Hydrostatic pressure for the lower calibration point is present at the device, here 0 mbar for example.	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
	Select EMPTY CALIB. parameter.	P01-xxxxxxx-05-xx-xx-011
	Enter the level value, here 0 m for example. Confirm the value to assign the pressure value present to the lower level value. Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then	1 [mA] ④ 20
	press the "E" button to save the value.	
10	Hydrostatic pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example.	
	Select FULL CALIB. parameter.	
	Enter the level value, here 3 m (9.8 ft) for example. Confirm the value to assign the pressure value present to the upper level value.	0 3 <u>h</u> [m]
	Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	Fig. 4: Calibration with reference pressure – wet calibration 1 See Table, Step 9. 2 See Table, Step 10.
11	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	<i>3 See Table, Step 11.</i> <i>4 See Table, Step 12.</i>
12	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
13	Result: The measuring range is set for 0 to 3 m (9.8 ft).	



- 1. You can also perform calibration with reference pressure by means of the QUICK SETUP menu. \rightarrow See Page 49 ff, Table 4: QUICK SETUP menu.
- 2. For this level mode, the measured variables %, level, volume and mass are available. \rightarrow See also parameter description for OUTPUT UNIT, Page 60.
- 3. For operation using the on-site display, the parameters EMPTY CALIB. (→ Page 61) and FULL CALIB. (→ Page 61) also show the respective pressure present at the device. For operation using Digital communication, the pressure present at the device is displayed in the PROCESS VALUES group (menu path: OPERATING MENU→ PROCESSINFO → PROCESS VALUES).

5.2.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in litres. The maximum volume of 1000 litres (264 US gal) corresponds to a pressure of 450 mbar (6.75 psi). The minimum volume of 0 litres corresponds to a pressure of 50 mbar (0.75 psi), as the device is mounted below the level lower range value. The device is mounted below the level lower range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.



- Note!
- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB. and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page 53, Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 58, Table 8: LEVEL SELECTION "Level Easy Pressure"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter.	2 1000
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	450 mba
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	
2	If necessary, select "Level Easy Pressure" level mode using the LEVEL SELECTION parameter.	$\rho = 1 \frac{kg}{kg}$ 50 mbar
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	dm ³
	Digital communication:	P01-PMC71xxx-19-xx-xx-000
	Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	Fig. 5: Calibration without reference pressure – dry calibration 1 See Table. Steps 7 and 8.
3	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	2 See Table, Steps 9 and 10.

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
5	Select a volume unit via the OUTPUT UNIT parameter, here l (litres) for example	3 1000
6	Select the "Dry" option by means of the CALIBRATION MODE parameter.	
7	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example.	
8	Enter the pressure value for the lower calibration point via the EMPTY PRESSURE parameter, here 50 mbar (0.75 psi) for example.	
9	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (264 gal) for example.	(2) (mbar] P01-xxxxxx-05-xx-xx-026
10	Enter the pressure value for the upper calibration point via the FULL PRESSURE parameter, here 450 mbar (6.75 psi) for example.	6 20
11	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
12	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
13	Result: The measuring range is set for 0 to 1000 l (264 gal).	
		Fig. 6: Calibration with reference pressure – wet calibration I See Table, Step 7. See Table, Step 8. See Table, Step 9. See Table, Step 10. See Table, Step 11. See Table, Step 12.



1. For this level mode, the measured variables %, level, volume and mass are available. \rightarrow See also parameter description for OUTPUT UNIT, Page 60.

5.3 "Level Easy Height" level selection

5.3.1 Calibration with reference pressure – wet calibration

Example:

In this example, the volume in a tank should be measured in litres. The maximum volume of 1000 litres (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 litres corresponds to a level of 0.5 m (1.6 ft), as the device is mounted below the level lower range value. The density of the medium is 1 kg/dm³.

Prerequisite:

Note!

- The measured variable is in direct proportion to the pressure.
- The tank can be filled or emptied.



- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Height" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
- Page 62, Table 9: LEVEL SELECTION "Level Easy Height"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

	Description	
1	Deltabar S: Before you configure the device for your application, the pressure piping must be cleaned and filled with medium. See Operating Instructions BA00270P, Section 6.5.1	3 1000 I
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	4,5 m
3	Select the "Level" measuring mode via the MEASURING MODE parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	$\rho = 1 \frac{\text{kg}}{\text{dm}^3} \qquad \qquad$
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	F01-PMC71xxx-19-xx-xx-001
4	If necessary, select the "Level Easy Height" level mode using the LEVEL SELECTION parameter.	Fig. 7: Calibration with reference pressure – wet calibration
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	 See Table, Steps 10 and 11. See Table, Step 12. See Table, Step 13.
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	

	Description	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	$\frac{h}{[m]} h = \frac{p}{2 + 2}$
7	Select a volume unit via the OUTPUT UNIT parameter, here l (litres) for example	4.5
8	Select a height unit via the HEIGHT UNIT parameter, here m for example.	
9	Select the "Wet" option via the CALIBRATION MODE parameter.	$\rho = 1 \frac{g}{cm^3}$
10	Select a density unit via the DENSITY UNIT parameter, here kg/dm ³ for example.	0.5
11	Enter the density of the fluid using the ADJUST DENSITY parameter, here kg/dm^3 for example.	49 441 <u>P</u> [mbar]
12	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example. (The currently measured hydrostatic pressure is displayed as height, here 0.5 m (1.6 ft) for example.) Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	3 1000
13	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (264 US gal) for example. (The currently measured hydrostatic pressure is displayed as height, here 4.5 m (15 ft) for example.) Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	(2) 0 0 0 0 0 0 0 1 1 1 1 1 1 1 1 1 1
14	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	[mA] (5) 20
15	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
16	Result: The measuring range is set for 0 to 1000 l (264 US gal).	
		Fig. 8: Calibration with reference pressure – wet calibration 1 See Table, Steps 10 and 11. 2 See Table, Step 12. 3 See Table, Step 13. 4 See Table, Step 14.



1. For this level mode, the measured variables %, level, volume and mass are available. \rightarrow See

also parameter description for OUTPUT UNIT, Page 64.

5.3.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in litres. The maximum volume is 1000 l (264 US gal), and the maximum height is 4.5 m (15 ft). The minimum volume of 0 litres corresponds to a level of 0.5 m (1.6 ft), as the device is mounted below the level lower range value. The density of the fluid is 1 kg/dm³.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the height and volume values for the lower and upper calibration point must be known.



- Note!
- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Height" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page, Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
- Page 62, Table 9: LEVEL SELECTION "Level Easy Height"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter.	3
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	4,5 m
	Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP→ MEASURING MODE	
2	If necessary, select "Level Easy Height" level mode using the LEVEL SELECTION parameter.	0,5 m
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	dm ³
	Digital communication:	P01-PMC71xxx-19-xx-xx-007
	Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow	Fig. 9: Calibration without reference pressure – dry calibration
	LEVEL SELECTION	1 See Table, Steps 8 and 9.
3	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	 See Table, Steps 10 and 11. See Table, Steps 12 and 13.

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	$\frac{h}{[m]} h = \frac{p}{p \cdot q}$
5	Select a volume unit via the OUTPUT UNIT parameter, here l (litres) for example.	4.5
6	Select a height unit via the HEIGHT UNIT parameter, here m for example.	
7	Select the "Dry" option via the CALIBRATION MODE parameter.	$\rho = 1 \frac{g}{cm^3}$
8	Select a density unit via the DENSITY UNIT parameter, here kg/dm^3 for example.	0.5
9	Enter the density of the fluid using the ADJUST DENSITY parameter, here kg/dm^3 for example.	49 441 <u>p</u> [mbar]
10	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example.	P01-xxxxxxx-05-xx-xx-024
11	Enter the height value for the lower calibration point via the EMPTY HEIGHT parameter, here 0.5 m (1.6 ft) for example.	[I] ④ 1000
12	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 10001 (litres) (264 US gal) for example.	
13	Enter the height value for the upper calibration point via the FULL HEIGHT parameter, here 4.5 m (15 ft) for example.	$h = \frac{p}{p \cdot g}$
14	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	0.5 4.5 <u>h</u> 3 5 [m]
15	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	P01-xxxxxxx-05-xx-xx-032
16	Result: The measuring range is set for 0 to 10001 (litres) (264 US gal).	[mA] ⑦ 20
		Fig. 10: Calibration with reference pressure – wet calibration
		 See Table, Steps 8 and 9. See Table, Step 10. See Table, Step 11. See Table, Step 12. See Table, Step 13. See Table, Step 14. See Table, Step 15.



1. For this level mode, the measured variables %, level, volume and mass are available. \rightarrow See also parameter description for OUTPUT UNIT, Page 64.

5.4 "Level Standard" level selection, "Linear" level type

5.4.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0 to 300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled or emptied.

Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
- Page 70, Table 11: BASIC SETUP "Linear" level type.
- For a description of further relevant parameters, see
- Page 96, Table 16: EXTENDED SETUP
- Page 122, Table 28: PROCESS VALUES.

$\underline{\mathbb{N}}$

	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00270P, Section 6.5.1	② 450 mbar
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	3 m
3	If necessary, select the "Level" measuring mode via the MEASURING MODE parameter.	1 (1) #10 mbar
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	$\rho = 1 \frac{\text{kg}}{\text{dm}^3} \qquad \qquad$
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	P01-PMC71xxx-19-xx-xxxxx.000
4	If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter.	Fig. 11: Calibration with reference pressure – wet calibration
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	 See table, step 11. See table, step 12.
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Linear" option by means of the LEVEL MODE parameter.	
8	Select the "Level" option by means of the LIN. MEASURAND parameter.	
9	Select a level unit via the HEIGHT UNIT parameter, here m for example.	$(1) 0 \downarrow $
10	Select the "Wet" option by means of the CALIBRATION MODE parameter.	P01-xxxxxxxx-05-xx-xx-034
11	The pressure for the lower calibration point is present at the device, here 0 mbar for example.	I [mA]
	Select EMPTY CALIB. parameter.	④ 20
	Enter the level value, here 0 m for example. Confirm the value to assign the pressure value present to the lower level value.	
12	The pressure for the upper calibration point is present at the device, here 450 mbar (6.75 psi) for example.	
	Select FULL CALIB. parameter.	
	Enter the level value, here 3 m (9.8 ft) for example. Confirm the value to assign the pressure value present to the upper level value.	0 3 <u>h</u> [m]
13	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	Fig. 12: Calibration with reference pressure – wet calibration
14	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	1See table, step 11.2See table, step 12.3See table, step 13.
15	Result: The measuring range is set for 03 m (9.8 ft).	4 See table, step 14.



1. You can also perform calibration with reference pressure by means of the QUICK SETUP menu. \rightarrow See Page 49 ff, Table 4: QUICK SETUP menu.

- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 70), UNIT VOLUME (→ Page 71) and MASS UNIT (→ Page 72).
- 3. For this level type, the measured variables %, level, volume and mass are available. \rightarrow See Page 70 ff.
- 4. The EMPTY PRESSURE (→ Page 74) and FULL PRESSURE (→ Page 74) parameters display the pressure values belonging to the EMPTY CALIB. and FULL CALIB. parameters.

5.4.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in m^3 . The maximum volume is 5 m^3 and the maximum height 4 m (13 ft). The density of the fluid is 1 kg/dm³. The device is mounted below the level lower range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration, i.e. the tank volume, tank height and density of the fluid are known.

Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page, Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 67, Table 10: BASIC SETUP
 - Page 70, Table 11: BASIC SETUP "Linear" level type.
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 26: PROCESS VALUES.



Warning!

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	3 4 m
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	(2) V = 5 m ³
2	If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter.	$1 \qquad -0.5 \text{ m}$
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	
	Digital communication:	P01-PMP75xxx-19-xx-xx-003
	Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	Fig. 13: Calibration without reference pressure – dry calibration
3	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	 See table, step 9. See table, step 10. See table, step 11. See table, step 12.

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
5	Select the "Linear" option by means of the LEVEL MODE parameter.	2 20
6	Select the "Volume" option by means of the LIN. MEASURAND parameter.	
7	Select a volume unit via the UNIT VOLUME parameter, here m^3 for example.	
8	Select the "Dry" option by means of the CALIBRATION MODE parameter. See also the following note, point 3.	
9	Enter the value for density via the ADJUST DENSITY parameter, here 1 kg/dm ³ for example.	0 5 <u>V</u> [m ³]
10	Enter the tank volume via the TANK VOLUME parameter, here 5 m^3 for example.	Fig. 14: Current output calibration
11	Enter the tank height via the TANK HEIGHT parameter, here 4 m (13 ft) for example.	5 See table, step 13. 6 See table, step 14.
12	Enter the level offset via the ZERO POSITION parameter, here -0.5 m (-1,6 ft) for example.	
13	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
14	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
15	Result: The measuring range is set for 05 m ³ .	



- 1. For this level type, the measured variables %, level, volume and mass are available. \rightarrow See Page 70 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 70), UNIT VOLUME (→ Page 71) and MASS UNIT (→ Page 72).
- 3. A level value is assigned to the lower and upper current value by means of the SET LRV (→ Page 77) and SET URV (→ Page 77) parameters respectively. Once you have selected the "Dry" calibration mode, the error message A711 "LRV or URV out of edit limits" can appear. The error message goes out as soon as level values which are within the editing limits are entered for the SET LRV and SET URV parameters. By means of the ENTER RESET CODE parameter (→ Page 126), you can use the code 2710 to automatically set the SET LPV and SET URV parameters to level values which are within

to automatically set the SET LRV and SET URV parameters to level values which are within the editing limits.

5.5 "Level Standard" level selection, "Pressure Linearized" level type

5.5.1 Semiautomatic entry of the linearisation table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m^3 .

Prerequisite:

- The tank can be filled. The linearisation characteristic must rise continuously.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.



Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 78, Table 11: BASIC SETUP "Pressure Linearized" level type
 - Page 100, Table 18: LINEARISATION on-site operation
 - Page 104, Table 19: LINEARISATION Digital communication.
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 26: PROCESS VALUES.



Warning!

	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and filled with fluid. See Operating Instructions BA00270P, Section 6.5.1.	V [m ³] 3.5
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
	Carry out basic setup:	
3	If necessary, select the "Level" measuring mode via the MEASURING MODE parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	P01-PMP75xxx-19-xx-xx-xx-002
4	If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION	

	Description
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.
7	Select the "Pressure Linearized" option by means of the LEVEL MODE parameter. See also the following note, point 3.
8	Select the "Volume" option by means of the LINd. MEASURAND parameter.
9	Select a volume unit via the UNIT VOLUME parameter, here m^3 for example.
10	Select HYDR. PRESS MIN. parameter.
	Enter the minimum hydrostatic pressure to be expected, here 0 mbar for example.
11	Select HYDR. PRESS MAX .
	Enter the maximum hydrostatic pressure to be expected.
	Carry out linearisation:
12	Change the function group: Menu path: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION
13	Select TANK CONTENT MIN parameter.
	Specify the minimum tank contents to be expected, here 0 $\ensuremath{\mathrm{m}^3}$ for example.
14	Select TANK CONTENT MAX parameter.
	Specify the maximum tank contents to be expected, here 3.5 m^3 for example.
15	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.
16	Select the "Semiautomatic" option by means of the LIN. EDIT MODE parameter.
17	Select the "New table" option by means of the EDITOR TABLE parameter.

	Description	
18	Enter linearisation table (min. 2 points, max. 32 points).	V A
	Fill the tank to the height of the 1st point.	
	LINE-NUMB: confirm value displayed.	(4) 3.5
	X-VAL.: the hydrostatic pressure present is displayed.	
	On-site display, Digital communication: The X-VAL. displayed is saved by confirming the Y- value. See following line, Y-VAL.	5
	HART handheld terminal: Confirm X-VAL. displayed.	
	Y-VAL.: enter the volume value, here 0 m^3 for example, and confirm the value.	
19	On-site display: If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 18. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option. Digital communication: You can enter further points for the linearisation table as explained in step 18. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	() (mbar) () (mbar)
19	Result: The linearisation table has been entered.	6 4 0 3.5 V [m ³]
		<i>Fig. 15: Semiautomatic entry of the linearisation table</i>
		 See table, step 10. See table, step 11. See table, step 13. See table, step 14. See table, steps 15 – 19. See the following note, point 4. See the following note, point 4



- 1. For this level type, the measured variables %, volume and mass are available. \rightarrow See Page 78 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 79), UNIT VOLUME (→ Page 79) and MASS UNIT (→ Page 80).

- 3. Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (→ MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.
- 4. A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters. If you enter values for TANK CONTENT MIN (→ Page 101 or 104) and TANK CONTENT MAX (→ Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5.5.2 Manual entry of the linearisation table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m^3 .

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearisation table are known.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.



Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 78, Table 12: BASIC SETUP "Pressure Linearized" level type
 - Page 100, Table 18: LINEARISATION on-site operation
 - Page 104, Table 19: LINEARISATION Digital communication.
- For a description of further relevant parameters, see
- Page 96, Table 16: EXTENDED SETUP
- Page 122, Table 28: PROCESS VALUES.

Warning!

	Description	
1	Perform basic setup as per Section 5.3.1, steps 2 to 10.	
	Carry out linearisation:	^V [m ³] 3.5−−−−−−
2	Change the function group: Menu path: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION	
3	Select TANK CONTENT MIN parameter .	
	Specify the minimum tank contents to be expected, here 0 $\ensuremath{m^3}$ for example.	
4	Select TANK CONTENT MAX parameter .	
	Specify the maximum tank contents to be expected, here 3.5 m^3 for example.	P01-PMP75xxx-19-xx+xx+002

	Description	
5	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.	V [m ³] (4) 3.5
6	Select the "Manual" option by means of the LIN. EDIT MODE parameter.	
7	Select the "New table" option by means of the EDITOR TABLE parameter.	5
8	Enter linearisation table (min. 2 points, max. 32 points).	
	LINE-NUMB: confirm value displayed.	
	X-VAL.: enter the pressure value and confirm.	
	Y-VAL.: enter the volume value, here 0 m^3 for example, and confirm.	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
9	On-site display If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 8. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option. Digital communication: You can enter further points for the linearisation table as explained in step 8. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	7) 20
10	Result: The linearisation table has been entered.	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
		Fig. 16: Manual entry of the linearisation table
		 See Section 5.3.1, table, step 9. See Section 5.3.1, table, step 10. See table, step 3. See table, step 4. See table, steps 5 - 9. See the following note, point 4. See the following note, point 4.



- 1. For this level type, the measured variables %, volume and mass are available. \rightarrow See Page 78 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 79), UNIT VOLUME (→ Page 79) and MASS UNIT (→ Page 80).
- 3. Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (\rightarrow MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.
- 4. A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters. If you enter values for TANK CONTENT MIN (→ Page 101 or 104) and TANK CONTENT MAX (→ Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

"Level Standard" level selection, 5.6 "Height Linearized" level type

5.6.1 Wet calibration and semiautomatic entry of the linearisation table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:

- The tank can be filled. The linearisation characteristic must rise continuously.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. - TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX - LEVEL MIN; TANK CONTENT MAX. - TANK CONTENT MIN.



- Note!
- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 83, Table 13: BASIC SETUP "Height Linearized" level type
 - Page 100, Table 18: LINEARISATION on-site operation
 - Page 104, Table 19: LINEARISATION Digital communication.
- For a description of further parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.

	Description
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and filled with fluid. See Operating Instructions BA00270P, Section 6.5.1
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.
	Perform calibration for the 1st measured variable:
3	If necessary, select the "Level" measuring mode via the MEASURING MODE parameter.
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE
4	If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter.
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE "Level" \rightarrow LEVEL SELECTION

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	2 ④
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Height Linearized" option by means of the LEVEL MODE parameter.	
8	Select the "Height + Volume" option by means of the COMB. MEASURAND parameter.	
9	Select the unit for the 1st measured value via the HEIGHT UNIT parameter, here m for example.	P01-PMP75xxx-19-xx-xx-004
10	Select the unit for the 2nd measured variable via the UNIT VOLUME parameter, here m3 for example.	
11	Select LEVEL MIN parameter.	2 ④ 3
	Enter the minimum level to be expected, here 0 m for example.	
12	Select LEVEL MAX parameter.	
	Enter the maximum level to be expected, here 3 m (9.8 ft) for example.	
13	Select the "Wet" option via the CALIBRATION MODE parameter (calibration mode for the 1st measured variable).	① ③ 0 0 300 p [mbar]
14	The pressure for the lower calibration point is present at the device, here 0 mbar for example.	Fig. 17: Calibrating the 1st measured variable
	Select EMPTY CALIB. parameter.	1 See table, step 11.
	Enter the level value, here 0 m for example. Confirm the value to assign the pressure value present to the lower level value.	3 See table, step 12. 4 See Table, step 15.
15	The pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example.	
	Select FULL CALIB. parameter.	
	Enter the level value, here 3 m (9.8 ft) for example. Confirm the value to assign the pressure value present to the upper level value.	
16	Result: The calibration for the 1st measured variable is carried out.	

	Description	
	Perform linearisation (calibration for the 2nd measured variable)	<u>V</u>
17	Change the function group. Menu path: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION	5
18	Select TANK CONTENT MIN parameter.	
	Specify the minimum tank contents to be expected, here 0 m^3 for example.	
19	Select TANK CONTENT MAX parameter.	
	Specify the maximum tank contents to be expected, here 5 $\ensuremath{m^3}$ for example.	
20	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.	P01-PMP75xxx-19-xx-xx-005
21	Select the "Semiautomatic" option by means of the LIN. EDIT MODE parameter.	6 5
22	Select the "New table" option by means of the EDITOR TABLE parameter.	
23	Enter linearisation table (min. 2 points, max. 32 points).	
	Fill the tank to the height of the 1st point.	
	LINE-NUMB: confirm value displayed.	
	X-VAL.: the hydrostatic pressure present is measured and converted to the corresponding level and displayed.	$ \begin{array}{c} (5) 0 4 1 1 1 1 1 1 1 1 1$
	On-site display, Digital communication: The X-VAL. displayed is saved by confirming the Y-value. See following line, Y-VAL.	P01-xxxxxxx-05-xx-xx-018
	HART handheld terminal: Confirm X-VAL. displayed.	
	Y-VAL.: enter the volume value, here 0 m^3 for example, and confirm the value.	(9) 20
24	On-site display If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 23. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option.	
	Digital communication: You can enter further points for the linearisation table as explained in step 23. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	0 5 V [m ³] ^{P01-XXXXX-05-XX-010} Fig. 18: Calibrating the 2nd measured variable 5 See table, step 18. 6 See table, step 19. 7 See table, steps 20 – 24. 8 See the following note, point 4. 9 See the following note, point 4.
25	 Result: The linearisation table has been entered. The measured value display and the TANK CONTENT parameter display the 2nd measured value (here the volume). The LEVEL BEFORE LIN parameter displays the 1st measured value (here the height). See also the following note, point 5. 	



- 1. For this level type, the measured variables "Height + %", "Height + Volume", "Height + Mass", "%-Height + %", "%-Height + Volume" and "%-Height + Mass" are available. \rightarrow See Page 79 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 83), UNIT VOLUME (→ Page 84) and MASS UNIT (→ Page 85).
- 3. Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (\rightarrow MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.
- 4. A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters. You can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable. Depending on the setting of the ASSIGN CURRENT parameter, enter the following values for SET LRV and SET URV:
 - ASSIGN CURRENT = tank content (factory setting) \Rightarrow %-value, volume value or mass value
 - ASSIGNMENT = height \Rightarrow level value

The following applies for the setting ASSIGN CURRENT "Tank content": If you enter values for TANK CONTENT MIN (\rightarrow Page 101 or 104) and TANK CONTENT MAX (\rightarrow Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

The following applies for the setting ASSIGN CURRENT "Height":

If you enter values for LEVEL MIN (\rightarrow Page 86) and LEVEL MAX (\rightarrow Page 86), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for LEVEL MIN and LEVEL MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5. You can use the MENU DESCRIPTOR parameter (\rightarrow Page 110) to specify which measured value should be displayed on the on-site display.
5.6.2 Dry calibration and manual entry of the linearisation table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearisation table are known.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.



- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 67, Table 10: BASIC SETUP
 - Page 83, Table 12: BASIC SETUP "Height Linearized" level type
 - Page 100, Table 18: LINEARISATION on-site operation
- Page 104, Table 19: LINEARISATION Digital communication.
- For a description of further parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.

Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" \rightarrow "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
	Perform calibration for the 1st measured variable:	
1	Perform calibration as per Section 5.4.1, steps 3 to 12.	[m³] 5
2	Select the "Dry" option via the CALIBRATION MODE parameter (calibration mode for the 1st measured variable).	
3	Enter the density of the fluid via the ADJUST DENSITY parameter, here 1 kg/dm ^{3} for example.	
4	If necessary, enter a level offset via the ZERO POSITION parameter, here 0 m for example.	
5	Result: The calibration for the 1st measured variable is carried out.	F01-PMP75xxx-19-xx-xx-005

	Description	
	Perform linearisation (calibration for the 2nd measured variable)	
6	Change the function group. Menu path: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION	
7	Select TANK CONTENT MIN parameter.	
	Specify the minimum tank contents to be expected, here 0 m^3 for example.	
8	Select TANK CONTENT MAX parameter.	
	Specify the maximum tank contents to be expected, here 5 $\ensuremath{m^3}$ for example.	
9	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
10	Select the "Manual" option by means of the LIN. EDIT MODE parameter.	
11	Select the "New table" option by means of the EDITOR TABLE parameter.	[mA] (9) 20
12	Enter linearisation table (min. 2 points, max. 32 points).	
	LINE-NUMB: confirm value displayed.	
	X-VAL.: enter the height value and confirm.	
	Y-VAL.: enter the volume value, here 0 $\ensuremath{\mathrm{m}}^3$ for example, and confirm.	
13	On-site display If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 12. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option. Digital communication: You can enter further points for the linearisation table as explained in step 12. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	 (8) 4 0 5 V [m³] Fig. 19: Calibrating the 2nd measured variable 5 See table, step 7. 6 See table, step 8. 7 See table, steps 9 – 13. 8 See the following note, point 4. 9 See the following note, point 4.
14	 Result: The linearisation table has been entered. The measured value display and the TANK CONTENT parameter display the 2nd measured value (here the volume). The LEVEL BEFORE LIN parameter displays the 1st measured value (here the height). See also the following note, point 5. 	



Note!

- For this level type, the measured variables "Height + %", "Height + Volume", "Height + Mass", "%-Height + %", "%-Height + Volume" and "%-Height + Mass" are available. → See Page 79 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 83), UNIT VOLUME (→ Page 84) and MASS UNIT (→ Page 85).
- 3. Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (→ MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.

4. A level value is assigned to both the lower and upper current value with the SET LRV $(\rightarrow$ Page 98) and SET URV $(\rightarrow$ Page 98) parameters.

You can use the ASSIGN CURRENT parameter (\rightarrow Page 113) to specify whether the current output should depict the 1st or 2nd measured variable. Depending on the setting of the ASSIGN CURRENT parameter, enter the following values for SET LRV and SET URV:

- ASSIGN CURRENT = tank content (factory setting) \Rightarrow %- value, volume value or mass value
- ASSIGNMENT = height \Rightarrow level value

The following applies for the setting ASSIGN CURRENT "Tank content": If you enter values for TANK CONTENT MIN (\rightarrow Page 101 or 104) and TANK CONTENT MAX (\rightarrow Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

The following applies for the setting ASSIGN CURRENT "Height":

If you enter values for LEVEL MIN (\rightarrow Page 86) and LEVEL MAX (\rightarrow Page 86), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for LEVEL MIN and LEVEL MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5. You can use the MENU DESCRIPTOR parameter (\rightarrow Page 110) to specify which measured value should be displayed on the on-site display.

6 Flow measurement

6.1 Calibration

Example:

Note!

In this example, a volume flow should be measured in m^3/s .



- The "Flow measurement" measuring mode is only available for the Deltabar S differential pressure transmitter.
- See also Operating Instructions BA00270P Deltabar S, Section 6.4 "Flow measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 91 ff, Table 12: BASIC SETUP
 - Page 98 ff, Table 15: EXTENDED SETUP.
- For a description of further parameters, see
 - Page 98, Table 15: EXTENDED SETUP
 - Page 123, Table 29: PROCESS VALUES.



If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" \rightarrow "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00270P, Section 6.4.1.	<u>v</u> [m ³ /h]
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
3	If necessary, select the "Flow" measuring mode via the MEASURING MODE parameter.	
	On-site display: Menu path: GROUP SELECTION \rightarrow MEASURING MODE	
	Digital communication: Menu path: OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP \rightarrow MEASURING MODE	[mA] ↓
4	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION \rightarrow OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP	④ 20
5	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
6	Select the "Volume p. cond." option by means of the FLOW-MEAS. TYPE parameter.	
7	Select a flow unit via the UNIT FLOW parameter, here $\rm m^3/h$ for example.	0 6000 <u>v</u> [m ³ /h]
8	Select MAX. FLOW parameter.	P01-xxxxxxx-19-xx-xx-013
	Enter the maximum flow value of the primary element, here $6000 \text{ m}^3/\text{h}$ for example. See also layout sheet of primary element.	Fig. 20:Flow measurement calibration1See table, step 8.2See table, step 9.
9	Select MAX PRESS. FLOW parameter.	3 See the following note, point 4. 4 See the following note, point 4.
	Enter the maximum pressure, here 400 mbar (6 psi) for example. See also layout sheet of primary element.	
10	Result: The device is configured for flow measurement.	



Note!

- 1. You can also perform calibration by means of the QUICK SETUP menu. \rightarrow See Page 52 ff, Table 5: QUICK SETUP menu.
- 2. Using the FLOW-MEAS. TYPE parameter, you can choose between the following flow types: Volume p. cond. (volume under operating conditions)
 - Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0°C))
 - Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288. 15 K (15°C/59°F))
 - Mass
- Depending on the flow type selected, you can choose between various units. You can also specify a customer-specific unit.
 See parameter description for PRESS. ENG. UNIT (→ Page 92), UNIT FLOW (→ Page 93), NORM FLOW UNIT (→ Page 93), STD. FLOW UNIT (→ Page 94) and MASS FLOW UNIT (→ Page 94).
- 4. A flow value or a pressure value is assigned to both the lower and upper current value with the SET LRV (\rightarrow Page 99) and SET URV (\rightarrow Page 100) parameters.

You can use the LINEAR/SQROOT parameter (\rightarrow Page 113) to specify whether the current output should depict the linear pressure signal or the Flow (square root) flow signal. Depending on the setting of the LINEAR/SQROOT parameter, enter the following values for SET LRV and SET URV:

```
- LINEAR/SQROOT = Flow (square root) (factory setting) \Rightarrow flow value
```

- LINEAR/SQROOT = Differential pres. \Rightarrow pressure value

The following applies for the setting LINEAR/SOROOT "Flow (square root)": As per the factory settings, the lower current value is set to equal zero and the upper current value is set to the MAX. FLOW value. If you enter a value for MAX. FLOW, the SET URV parameter is also changed. If you want to assign values other than zero and MAX. FLOW to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

The following applies for the setting LINEAR/SQROOT "Differential pres.": As per the factory settings, the lower current value is set to equal zero and the upper current value is set to the MAX. PRESS. FLOW value. If you enter a value for MAX PRESS. FLOW, the SET URV parameter is also changed. If you want to assign values other than zero and MAX PRESS. FLOW to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

 In the lower measuring range, small flow quantities (creepages) can lead to large measured value fluctuations. You can activate low flow cut-off via the LOW FLOW CUT-OFF parameter (→ Page 99).

6.2 Totalizers

Example:

Note!

In this example, the volume flow should be totalised and displayed in the unit m^3E^3 . Negative flows should be added to the flow rate.



- For a description of the parameters mentioned, see
 - Page 107 ff, Table 18: TOTALIZER SETUP
 - Page 123 ff, Table 29: PROCESS VALUES
- Totalizer 1 can be reset. Totalizer 2 cannot be reset.

	Description
1	Calibrate the device as per Section 6.1.
2	Change the function group: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow TOTALIZER SETUP
3	Select a flow unit via the TOTALIZER 1 UNIT parameter, here $m^3 E^3$ for example.
4	Use the NEG. FLOW TOT. 1 parameter to specify the totalising mode for negative flows, here the "Positive" option for example.
5	Reset totalizer 1 to zero via the RESET TOTALIZER parameter.
6	Result: The TOTALIZER 1 and TOTAL. 1 OVERFLOW parameters display the totalised volume flow.



Note!

- You can also specify a customer-specific unit. \rightarrow See parameter description for TOTALIZER 1 UNIT (\rightarrow Page 108) and TOTALIZER 2 UNIT (\rightarrow Page 109).
- The TOTALIZER 1 and TOTAL. 1 OVERFLOW parameters display the totalised flow value of the first totalizer. The TOTALIZER 2 and TOTAL. 2 OVERFLOW parameters display the totalised flow value of the second totalizer. → See Page 123 ff, PROCESS VALUES function group.
- You can use the MENU DESCRIPTOR parameter (→ Page 110) to specify which measured value should be displayed on the on-site display.



Description of parameters

Note!

7

- The following tables list all the parameters as per the menu structure. Each table corresponds to a function group in the menu tree. The overall menu structure is illustrated in Section 9.1.
- The menu structure for on-site operation and the digital communication are slightly different. The differences mainly affect the MEASURING MODE and LANGUAGE parameters and the LINEARISATION function group.
- In the operating program or HART handheld terminal, additional parameters are displayed. These parameters are marked accordingly.
- The menu path is indicated in the header of each table. You can use this path to get to the parameters in question.
- The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. the "LINEARISATION" function group for the "Level" measuring mode. If certain requirements have to be met for a function group, these are listed in the first row of the table.
- Some parameters are only displayed if other parameters are appropriately configured. For example, the EMPTY CALIB. parameter is not displayed in the Quick Setup menu ("Level" measuring mode) unless the "Linear" option was selected for the LEVEL MODE parameter and the "Wet" option was selected for the CALIBRATION MODE parameter. There is a comment in the parameter description here stating: Note: prerequisite: LEVEL MODE = Linear and CALIBRATION MODE = Wet.
- Parameter names are written in upper case in the text.
- In the "Parameter name" column, the unique identification number (ID) of the parameter is indicated in brackets. This ID only appears on the on-site display.



Fig. 21: 1st selection level in menu, LANGUAGE (→ see Page 44, Table 1) and MEASURING MODE (→ see Page 45, Table 2)

Table 1: GROUP SELECTION \rightarrow LANGUAGE – on-site operation		
Parameter name	Description	
LANGUAGE (079) Selection	 Select the menu language for the on-site display. Note! In the operating program and in the HART handheld terminal, the LANGUAGE parameter is arranged in the DISPLAY function group. Select the menu language for FieldCare via the "Options" menu → "Settings" → "Language" tab → "Tool language" field. Factory setting: English 	



Fig. 22: "Level" measuring mode, LEVEL SELECTION parameter

Table 2: GROUP SELECTION \rightarrow MEASURING MODE – on-site operation		
Parameter name	Description	
MEASURING MODE (389) Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode.	
	 Note! The MEASURING MODE parameter is displayed in the operating program and in the HART handheld terminal in the OUICK SETUP menus and in the BASIC SETUP function group (OPERATING MENU → SETTINGS → BASIC SETUP). Marning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured. 	
	Options: Pressure Level Deltabar S: Flow	
	Factory setting:Cerabar S and Deltabar S: PressureDeltapilot S: Level	

Endress+Hauser

Faralleter halle	Description
LEVEL SELECTION (020)	Select level mode.
Options	Prerequisite:MEASURING MODE = Level
	 Note! In the "Level Easy Pressure" and "Level Easy Height" level modes, the values entere are not tested as extensively as in the "Level Standard" level mode. The values entere for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of for the "Level Easy Pressure" and "Level Easy Height" level modes. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor are the measuring task so that the measuring device can measure correctly. → For an overview of the different level modes and types, see Page 14, Section 5.1 "Overview of level measurement". The "Level Easy Pressure" and "Level Easy Height" level modes encompass fewer parameters than the "Level Standard" mode and are used for quick and easy configuration of a level application. Customer-specific units of fill level, volume and mass or a linearization table may or be entered in the "Level Standard" level mode. Where the device is intended for use as a subsystem in a safety function (SIL), a "Device configuration with enhanced parameter security" (SAFETY CONFIRM.) is or possible for the "Level" operating mode in the "Level Easy Pressure" level mode. All parameters previously entered are checked after a password is entered. Once the "Level Easy Height" or "Level Standard" has been selected, the configuration will firshave to be reset to the ex-works setting using the RESET parameter (menu path: (GROUP SELECTION →) OPERATING MENU → OPERATION) using the reset co "7864". → For additional information, see the Safety Manual for Deltabar S (SD00189), Cerabar S (SD00190) or Deltapilot S (SD00213P).
	 Options: Level Easy Pressure Specify two pressure-level value pairs for this level mode. The pressure measured valies converted directly to the unit which is selected via the OUTPUT UNIT parameter (→ Page 60). Two calibration modes, "Wet" and "Dry", are available. Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the select of the select of
	 the pressure measured at this point in time. Dry calibration is a theoretical calibration. For this calibration, specify two pressu level value pairs via the EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE parameters. → Parameter descriptions see Page 61 ff. Level Fast Height
	 For this level mode, specify a height unit, density and two height-level value pairs. T pressure measured value is converted to a height value using the density entered an the height unit. Two calibration modes, "Wet" and "Dry", are available. Wet calibration takes place by filling and emptying the container. In the case of tw different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. Dry calibration is a theoretical calibration. For this calibration, specify two height
	 level value pairs via the EMPTY CALIB., EMPTY HEIGHT, FULL CALIB. and FU HEIGHT parameters. → Parameter descriptions see Page 65 ff. Level standard Once you have selected this level mode, you can use the LEVEL MODE parameter (→ Page 68) to choose between "Linear", "Pressure Linearized" and "Height Linearized".
	Factory setting:



Fig. 23: Quick Setup menu for the "Pressure" measuring mode

Table 3: (GROUP SELECTION \rightarrow) QUICK SETUP "Pressure"		
Parameter name	Description	
This menu displays the most in	nportant parameters for the "Pressure" measuring mode.	
Prerequisite:MEASURING MODE = Pre	ssure (\rightarrow see also Page 45).	
Note: See also - Page 55 ff, Table 7: BASIC - Page 96, Table 15: EXTENT - Page 121 ff, Table 27: PRO - Page 11 ff, Section 4 "Press	SETUP DED SETUP CESS VALUES ure measurement".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. Murning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.	
	Prerequisite: Digital communication	
	Options: Pressure Level Deltabar S: Flow	
	Factory setting:Cerabar S and Deltabar S: PressureDeltapilot S: Level	

Table 3: (GROUP SELECTION →) QUICK SETUP "Pressure"		
Parameter name	Description	
POS. ZERO ADJUST (685) Entry	 Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. 	
	 Example: MEASURED VALUE = 2.2 mbar (0.033 psi) Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The current value is also corrected. 	
	The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.	
	Prerequisite:This parameter is displayed for Deltabar S, Cerabar S with gauge pressure sensor and Deltapilot S.	
	Options: Abort Confirm	
	Factory setting: 0.0	
POS. INPUT VALUE (563) Entry	 Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device). Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero or the desired value. 	
	 Example: MEASURED VALUE = 0.5 mbar (0.0075 psi) For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2 mbar. (MEASURED VALUE, after entry for POS. INPUT VALUE) MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. CALIB. OFFSET = MEASURED VALUE _{old} - POS. INPUT VALUE, here: CALIB. OFFSET = 0.5 mbar (0.0075 psi) - 2.0 mbar (0.03 psi) = -1.5 mbar (0.0225 psi)) The current value is also corrected. 	
	Prerequisite:This parameter is displayed for Cerabar S with absolute pressure sensors.	
	Factory setting: 0.0	
SET LRV (245) Entry	Set lower range value – without reference pressure. Enter pressure value for the lower current value (4 mA).	
	Factory setting:0.0 or as per order specifications	
SET URV (246) Entry	Set upper range value – without reference pressure. Enter pressure value for the upper current value (20 mA).	
	Factory setting: High sensor limit (\rightarrow see PRESS. SENS HILIM, Page 119) or as per order specifications	
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.	
	Input range: 0.0999.0 s	
	Factory setting: 2.0 s or as per order specifications	



Fig. 24: Quick Setup menu for the "Level" measuring mode

Table 4: (GROUP SELECTION \rightarrow) QUICK SETUP "Level"		
Parameter name	Description	
This menu displays the most im	This menu displays the most important parameters for the "Level" measuring mode.	
Prerequisite:MEASURING MODE = Leve	el (\rightarrow see also Page 45).	
Note: See also - Page 67 ff, Tables 10 to 13: - Page 96 ff, Table 16: EXTEN - Page 100 ff, Table 18: LINE - Page 104 ff, Table 19: LINE - Page 122 ff, Table 28: PROC - Page 14 ff, Section 5 "Level 1	BASIC SETUP IDED SETUP ARISATION – on-site operation ARISATION – Digital communication CESS VALUES measurement".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. Marning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured. Prerequisite:	
	 Digital communication Options: Pressure Level Deltabar S: Flow Factory setting: Cerabar S and Deltabar S: Pressure 	
LEVEL SELECTION (020) Options	 Deltapilot S: Level Select level mode. → Parameter description, see Page 46. Factory setting: Level Easy Pressure 	

Table 4: (GROUP SELECTION \rightarrow) QUICK SETUP "Level"			
Parameter name	Description		
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero.		
	 Example: MEASURED VALUE = 2.2 mbar (0.033 psi) Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The current value is also corrected. 		
	The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.		
	Prerequisite:This parameter is displayed for Deltabar S, Cerabar S with gauge pressure sensor and Deltapilot S.		
	Options: Abort Confirm		
	Factory setting: 0.0		
POS. INPUT VALUE (563) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device). Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero or the desired value.		
	 Example: MEASURED VALUE = 0.5 mbar (0.0075 psi) For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). (MEASURED VALUE , e.g. 2.0 mbar (0.03 psi). MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. CALIB. OFFSET = MEASURED VALUE vas corrected. CALIB. OFFSET = 0.5 mbar (0.0075 psi) - 2.0 mbar (0.03 psi) = -1.5 mbar (0.0225 psi)) The current value is also corrected. 		
	Prerequisite:This parameter is displayed for Cerabar S with absolute pressure sensors.		
	Factory setting: 0.0		
EMPTY CALIB. (314)/(010) Entry	Enter level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device.		
	 Prerequisite: LEVEL SELECTION = Level Easy Pressure (→ see also Page 46), CALIBRATION MODE = Wet (→ see also Page 60) LEVEL SELECTION = Level Standard (→ see also Page), LEVEL MODE = Linear (→ see also Page 68), CALIBRATION MODE = Wet (→ see also Page 73) 		
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.		
	Factory setting: 0.0		

Table 4: (GROUP SELECTION \rightarrow) QUICK SETUP "Level"		
Parameter name	me Description	
FULL CALIB. (315)/(004) Entry	Enter level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device.	
	 Prerequisite: LEVEL SELECTION = Level Easy Pressure (→ see also Page 46), CALIBRATION MODE = Wet (→ see also Page 60) LEVEL SELECTION = Level Standard, LEVEL MODE = Linear (→ see also Page 68), CALIBRATION MODE = Wet (→ see also Page 73) Note! 	
	For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.	
	Factory setting: 100.0	
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.	
	Input range: 0.0999.0 s	
	Factory setting: 2.0 s or as per order specifications	





Table 5: (GROUP SELECTION \rightarrow) QUICK SETUP "Flow"		
Parameter name	Description	
 This menu displays the most important parameters for the "Flow" measuring mode. Prerequisite: Deltabar S differential pressure transmitter MEASURING MODE = Flow (→ see also Page 45). 		
Note: See also - Page 91, Table 14: BASIC - Page 98, Table 17: EXTEN - Page 107, Table 20: TOTA - Page 40 ff, Section 6 "Flow	SETUP DED SETUP LIZER SETUP " measurement".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. Marning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.	
	Prerequisites: • Digital communication Options: • Pressure • Level • Deltabar S: Flow	
	Factory setting:Cerabar S and Deltabar S: PressureDeltapilot S: Level	
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. (A reference pressure is present at the device.) Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero.	
	 Example: MEASURED VALUE = 2.2 mbar (0,033 psi) Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The current value is also corrected. 	
	The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. Selection:	
	AbortConfirm	
	Factory setting: 0.0	
MAX. FLOW (311) Entry	Enter maximum flow of primary element. See also layout sheet of primary element. The maximum flow is assigned to the maximum pressure which you enter via MAX PRESS. FLOW.	
	Note! Use the LINEAR/SOROOT parameter (\rightarrow Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Flow (square root)" setting: If you enter a new value for MAX. FLOW, the value for SET URV is also changed. Use SET URV to assign a flow to the upper current value. If you want to assign the upper current value a value other than that for MAX. FLOW, you must enter the desired value for SET URV. (\rightarrow SET URV, Page 100).	
	Factory setting: 1.0	

Table 5: (GROUP SELECTION \rightarrow) QUICK SETUP "Flow"	
Parameter name	Description
MAX PRESS. FLOW (634) Entry	Enter maximum pressure of primary element. \rightarrow See layout sheet of primary element. This value is assigned to the maximum flow value (\rightarrow see MAX. FLOW).
	Note! Use the LINEAR/SOROOT parameter (\rightarrow Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Differential pres." setting: If you enter a new value for MAX PRESS. FLOW, the value for SET URV is also changed. Use SET URV to assign a pressure value to the upper current value. If you want to assign the upper current value a value other than that for MAX PRESS. FLOW, you must enter the desired value for SET URV. (\rightarrow SET URV, Page 100).
	Factory setting: High sensor limit (→ See PRESS. SENS HILIM, Page 119)
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.
	Input range: 0.0999.0 s
	Factory setting: 2.0 s or as per order specifications





Table 6: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow POSITION ADJUSTMENT	
Parameter name	Description

Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the measured value does not display zero. Deltabar S and Cerabar S offer three different ways of performing a position adjustment.

Recommendation:

- The pressure difference between zero (set point) and the measured pressure need not be known.
- POS. ZERO ADJUST: Deltabar S or Cerabar S with gauge pressure sensor or Deltapilot S.
 - POS. INPUT VALUE: Cerabar S with absolute pressure sensor.
- The pressure difference between zero (set point) and the measured pressure is known.
- CALIB. OFFSET: Deltabar S, Cerabar S with gauge pressure sensor, Cerabar S with absolute pressure sensor or Deltapilot S.

Table 6: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow POSITION ADJUSTMENT		
Parameter name	Description	
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known.	
	 Example: MEASURED VALUE = 2.2 mbar (0.033 psi) Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The current value is also corrected. 	
	The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.	
	Selection: Abort Confirm	
	Factory setting: 0.0	
POS. INPUT VALUE (563) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device).	
	 Example: MEASURED VALUE = 0.5 mbar (0.0075 psi) For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). (MEASURED VALUE_{new} = POS. INPUT VALUE) MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. CALIB. OFFSET = MEASURED VALUE_{old} - POS. INPUT VALUE, here: CALIB. OFFSET = 0.5 mbar (0.0075 psi) - 2.0 mbar (0.03 psi) = -1.5 mbar (0.0225 psi)) The current value is also corrected. 	
	Factory setting: 0.0	
CALIB. OFFSET (319) Entry	Position adjustment - the pressure difference between zero (set point) and the measured pressure is known.	
	 Example: MEASURED VALUE = 2.2 mbar (0.033 psi) Via the CALIB. OFFSET parameter, enter the value by which the MEASURED VALUE should be corrected. To correct the MEASURED VALUE to 0.0 mbar, you must enter the value 2.2 here. (MEASURED VALUE_new = MEASURED VALUE_old - CALIB. OFFSET) MEASURED VALUE (after entry for calib. offset) = 0.0 mbar The current value is also corrected. 	
	Factory setting: 0.0	



Fig. 27: BASIC SETUP function group for the "Pressure" measuring mode

Table 7: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Pressure"		
Parameter name	Description	
Prerequisite:MEASURING MODE = Pre	ssure (\rightarrow see also Page 45).	
Note: See also – Page 47, Table 3: OUICK S – Page 96, Table 15: EXTENI – Page 121 ff, Table 27: PRO – Page 11 ff, Section 4 "Pressi	ETUP DED SETUP CESS VALUES ure measurement".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. Multiple Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.	
	Prerequisite:Digital communication	
	Options: Pressure Level Deltabar S: Flow	
	Factory setting:Cerabar S and Deltabar S: PressureDeltapilot S: Level	

Table 7: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Pressure"		
Parameter name	Description	
PRESS. ENG. UNIT (060) Selection	Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.	
	Options: • mbar, bar • mmH2O, mH2O, inH2O, ftH2O ¹) • Pa, hPa, kPa, MPa • psi	
	 mmHg, inHg ²) Torr g/cm², kg/cm² lb/ft² atm gf/cm², kgf/cm² User unit, -> See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. 	
	 The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F). 	
	Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications	
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. P.	
	Prerequisite:PRESS. ENG. UNIT = User unit	
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".	
	Factory setting:	
CUST. UNIT FACT. P (317) Entry	Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". \rightarrow See also CUSTOMER UNIT P.	
	Prerequisite:PRESS. ENG. UNIT = User unit	
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE =10000 Pa ≈ 1 PU Entry CUSTOMER UNIT P: PU Entry CUST. UNIT FACT. P: 0.0001 Result: MEASURED VALUE = 1 PU 	
	Factory setting: 1.0	
SET LRV (245) Entry	Set lower range value – without reference pressure. Enter pressure value for the lower current value (4 mA).	
	Factory setting: 0.0 or as per order specifications	

Г

Table 7: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Pressure"	
Parameter name	Description
SET URV (246) Entry	Set upper range value – without reference pressure. Enter pressure value for the upper current value (20 mA).
	Factory setting: High sensor limit (\rightarrow See PRESS. SENS HILIM, Page 119)
GET LRV (309) Entry	Set lower range value – reference pressure is present at device. The pressure for the lower current value (4 mA) is present at device. With the "Confirm" option, you assign the lower current value to the pressure value present. On-site display: the pressure value present is displayed in the bottom line.
	Options: Abort Confirm
GET URV (310) Entry	Set upper range value – reference pressure is present at device. The pressure for the upper current value (20 mA) is present at device. With the "Confirm" option, you assign the upper current value to the pressure value present. On-site display: the pressure value present is displayed in the bottom line.
	Options: Abort Confirm
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.
	Input range: 0.0999.0 s
	Factory setting: 2.0 s or as per order specifications

able 7: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Pressure"	



Fig. 28: BASIC SETUP function group for the "Level" measuring mode and "Level Easy Pressure" level selection

Table 8: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL SELECTION "Level Easy Pressure"

The following parameters are displayed if you have selected the "Level Easy Pressure" option for the LEVEL SELECTION parameter. Specify two pressure-level value pairs for this level mode. Two calibration modes, "Wet" and "Dry", are available.

Prerequisite:

- MEASURING MODE = Level (\rightarrow see also Page 45.)
- LEVEL SELECTION = Level Easy Pressure (\rightarrow See also Page 46.)

LEVEL SELECTION "Level Easy Pressure"		
PRESS. ENG. UNIT (060) Selection	Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.	
	 Options: mbar, bar mmH2O, mH2O, inH2O, ftH2O ¹) Pa, hPa, kPa, MPa psi mmHg, inHg ²) Torr g/cm², kg/cm² lb/ft² atm gf/cm², kgf/cm² User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. 	
	1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F).	
	Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications	
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. P.	
	Prerequisite:PRESS. ENG. UNIT = User unit	
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".	
	Factory setting:	
CUST. UNIT FACT. P (317) Entry	Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". \rightarrow See also CUSTOMER UNIT P.	
	Prerequisite: ■ PRESS. ENG. UNIT = User unit	
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE =10000 Pa ≅ 1 PU Entry CUSTOMER UNIT P: PU Entry CUST. UNIT FACT. P: 0.0001 Result: MEASURED VALUE = 1 PU 	
	Factory setting: 1.0	

Table 8: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level",

Table 8: (GROUP SELECTION LEVEL SELECTION	ON→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", Easy Pressure"
OUTPUT UNIT (023) Selection	Select unit for measured value display and MEASURED VALUE parameter (\rightarrow Page 122). Note!
	selecting a new output unit, the measured value is not converted. Example:
	 current measured value: 0.3 ft new output unit: m new measured value: 0.3 m (9.8 ft)
	Options
	 mm, cm, dm, m ft, inch
	 cm³, dm³, m³, m³ E³ l, hl ft³, ft³ E³
	gal, bbl, Igalg, kg, t
	Factory setting:
CALIBRATION MODE (008)	Select calibration mode.
Selection	 Options: Wet Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the
	 pressure measured at this point in time. (→ See also this table, parameter descriptions for EMPTY CALIB. and FULL CALIB.) Dry
	Dry calibration is a theoretical calibration. For this calibration, specify two pressure- level value pairs via the following parameters: EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE.
	Factory setting: Wet
EMPTY CALIB. (010) Entry	Enter level, volume, mass or percentage value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you assign a level, volume, mass or percentage value to the pressure present at the device.
	 Prerequisite: CALIBRATION MODE = Wet
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.
	Factory setting: 0.0
FULL CALIB. (004) Entry	Enter height, volume or mass value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you assign a height, volume or mass value to the pressure present at the device. The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 60).
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.
	Factory setting: 100.0

Table 8: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL SELECTION "Level Easy Pressure"	
EMPTY CALIB. (010) Entry	Enter level, volume, mass or percentage value for the lower calibration point (container empty). The values entered for the EMPTY CALIB. and EMPTY PRESSURE parameters form the pressure-level value pair for the lower calibration point. The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 60).
	Prerequisite: • CALIBRATION MODE = Dry
	Factory setting: 0.0
EMPTY PRESSURE (011) Entry	Enter pressure value for the lower calibration point (container empty). \rightarrow See also EMPTY CALIB.
	<pre>Prerequisite: CALIBRATION MODE = Dry</pre>
	Factory setting: 0.0
FULL CALIB. (004) Entry	Enter height, volume, mass or percentage value for the upper calibration point (container full). The values entered for the FULL CALIB. and FULL PRESSURE parameters form the pressure-level value pair for the upper calibration point. The unit is selected via the COLTENUT UNUT assumption (). Page 60
	 Prerequisite: CALIBRATION MODE = Dry
	Factory setting: 100.0
FULL PRESSURE (005) Entry	Enter pressure value for the upper calibration point (container full). \rightarrow See also FULL CALIB.
	Prerequisite: • CALIBRATION MODE = Dry
	Factory setting: 100.0
SET LRV (013) Entry	Enter value for the lower current value (4 mA). The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 60).
	Factory setting: 0.0
SET URV (012) Entry	Enter value for the upper current value (20 mA). The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 60).
	Factory setting: 100.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.
	Input range: 0.0 to 999.0 s
	Factory setting: 2.0 s or as per order specifications



Fig. 29: BASIC SETUP function group for "Level" measuring mode and "Level Easy Height" level selection

Table 9: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"

The following parameters are displayed if you have selected the "Level Easy Height" option for the LEVEL SELECTION parameter. For this level mode, specify a height unit, density and two height-level value pairs. The pressure measured value is converted to a height value using the density entered and the height. Two calibration modes, "Wet" and "Dry", are available.

Prerequisite:

• MEASURING MODE = Level (\rightarrow see also Page 45.)

• LEVEL SELECTION = Level Easy Height (\rightarrow See also Page 46.)

LEVEL SELECTION "Level Easy Height"		
PRESS. ENG. UNIT (060) Options	Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.	
	<pre>Options: mbar, bar mmH2O, mH2O, inH2O, ftH2O ¹) Pa, hPa, kPa, MPa psi mmHg, inHg ²) Torr g/cm², kg/cm² lb/ft² atm gf/cm², kgf/cm² User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P.</pre>	
	 The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F). 	
	Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications	
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customised pressure unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. P.	
	 Prerequisite: PRESS. ENG. UNIT = User unit 	
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customised unit is displayed only in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".	
	Factory setting:	
CUST. UNIT FACT. P (317) Entry	Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". \rightarrow See also CUSTOMER UNIT P.	
	<pre>Prerequisite: PRESS. ENG. UNIT = User unit</pre>	
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE =10000 Pa ≈ 1 PU Entry CUSTOMER UNIT P: PU Entry CUST. UNIT FACT. P: 0.0001 Result: MEASURED VALUE = 1 PU 	
	Factory setting: 1.0	

Table 9: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level",

Table 9: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"	
OUTPUT UNIT (023) Options	Select unit for measured value display and MEASURED VALUE parameter (\rightarrow Page 122). Note! The selected unit is used only to describe the measured value. This means that when selecting a new output unit, the measured value is not converted. Example: • current measured value: 0.3 ft • new output unit: m • new measured value: 0.3 m (9.8 ft) Options: • % • mm, cm, dm, m • ft, inch • cm ³ , dm ³ , m ³ , m ³ E ³ • 1, hl • ft ³ , ft ³ E ³ • gal, bbl, Igal • g, kg, t • lb, ton, oz Factory setting:
HEIGHT UNIT (003) Options	% Select height unit. The measured pressure is converted to the chosen height unit using the DENSITY UNIT and ADJUST DENSITY parameters.
	Options: mm cm dm m inch ft Factory setting:
	m
CALIBRATION MODE (008) Options	 Select calibration mode. Options: Wet Wet calibration takes place by filling and emptying the container. The measured pressure is converted to the chosen height unit using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. Dry Dry calibration is a theoretical calibration. For this calibration, specify two height-level value pairs via the EMPTY CALIB., EMPTY HEIGHT, FULL CALIB. and FULL HEIGHT parameters.
	Factory setting: Dry
DENSITY UNIT (001) Options	Select density unit. The measured pressure is converted to a height using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters.
	Options: g/cm ³ kg/dm ³ kg/m ³ US lb/in ³ US lb/ft ³ Factory setting: kg/dm ³
ADJUST DENSITY (007) Entry	Enter density of fluid. The measured pressure is converted to a height using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters.
	Factory setting: 1.0

LEVEL SELECTION "Lev	vel Easy Height"
EMPTY CALIB. (010) Entry	Enter level, volume, mass or percentage value for the lower calibration point (container empty). The container is either empty or part full. The measured pressure is converted to a heigh value using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters and displayed. Using the parameter EMPTY CALIB., you assign a level, volume, mass or percentage value to the height value. The unit is selected via the OUTPUT UNIT parameter (→ Page 64).
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.
	Factory setting: 0.0
FULL CALIB. (004) Entry	Enter level, volume, mass or percentage value for the upper calibration point (container full). The container is either completely or almost full. Using the parameters HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY, the measured pressure is converted to a height value and displayed. Using the parameter FULL CALIB., you assign a level, volume, mass or percentage value to the height value. The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 64).
	Prerequisite:CALIBRATION MODE = Wet
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.
	Factory setting: 100.0
EMPTY CALIB. (010) Entry	Enter level, volume, mass or percentage value for the lower calibration point (container empty). The values entered for the EMPTY CALIB. and EMPTY HEIGHT parameters form the height-level value pair for the lower calibration point. The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 64).
	Prerequisite:CALIBRATION MODE = Dry
	Factory setting: 0.0
EMPTY HEIGHT (009) Entry	Height value for the lower calibration point (container empty). The unit is selected via the HEIGHT UNIT parameter (\rightarrow Page 64). \rightarrow See also EMPTY CALIB.
	<pre>Prerequisite: CALIBRATION MODE = Dry</pre>
	Factory setting: Upper range limit (URL) coverted to an height unit
FULL CALIB. (004) Entry	Enter level, volume, mass or percentage value for the upper calibration point (container full). The values entered for the FULL CALIB. and FULL HEIGHT parameters form the heigh level value pair for the upper calibration point. The unit is selected via the OUTPUT UNI parameter (\rightarrow Page 64).
	Prerequisite:CALIBRATION MODE = Dry
	Factory setting:

Table 9: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"	
FULL HEIGHT (006) Entry	Enter height value for the upper calibration point (container full). The unit is selected via the HEIGHT UNIT parameter (\rightarrow Page 64). \rightarrow See also FULL CALIB.
	Prerequisite: • CALIBRATION MODE = Dry
	Factory setting: 0.0
SET LRV (013) Entry	Enter level, volume, mass or percentage value for the lower current value (4 mA). The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 64).
	Factory setting: 0.0
SET URV (012) Entry	Enter level, volume, mass or percentage value for the upper current value (20 mA). The unit is selected via the OUTPUT UNIT parameter (\rightarrow Page 64).
	Factory setting: 100.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.
	Input range: 0.0 to 999.0 s
	Factory setting: 2.0 s or as per order specifications



Fig. 30: BASIC SETUP function group for the "Level" measuring mode,

- depending on the setting for the LEVEL MODE parameter
- \rightarrow See Page 69, Fig. 31 for LEVEL MODE = Linear,

 \rightarrow See Page 78, Fig. 33 for LEVEL MODE = Pressure Linearized,

 \rightarrow See Page 82, Fig. 34 for LEVEL MODE = Height Linearized

Table 10: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level"			
Parameter name	Description		
Prerequisite:MEASURING MODE = lev	Prerequisite: ■ MEASURING MODE = level (→ see also Page 45).		
Note: See also - Page 70 ff, Tables 11 to 13: - Page 96 ff, Table 16: EXTE - Page 100 ff, Table 18: LINH - Page 104 ff, Table 19: LINH - Page 122 ff, Table 28: PRO - Page 14 ff, Section 5 "Level	: BASIC SETUP – contd. NDED SETUP EARISATION – on-site operation EARISATION – Digital communication CESS VALUES I measurement".		
MEASURING MODE	Select the measuring mode. The operating menu is structured according to the selected measuring mode		
	Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" \rightarrow "Basic Setup" operating menu and, if necessary, reconfigured.		
	Prerequisite: Digital communication		
	Options: Pressure Level Deltabar S: Flow		
	Factory setting: Pressure		
PRESS. ENG. UNIT (060) Selection	Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.		
	<pre>Options: mbar, bar mmH2O, mH2O, inH2O, ftH2O¹⁾ Pa, hPa, kPa, MPa psi mmHg, inHg²⁾ Torr g/cm², kg/cm² lb/ft² atm gf/cm², kgf/cm² User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. 1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F).</pre>		
	Depends on the sensor nominal measuring range mbar or bar or as per order specifications		

Table 10: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level"	
Parameter name	Description
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. P.
	 Prerequisite: PRESS. ENG. UNIT = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:
CUST. UNIT FACT. P (317) Entry	Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". \rightarrow See also CUSTOMER UNIT P.
	Prerequisite:PRESS. ENG. UNIT = User unit
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE =10000 Pa ≈ 1 PU Entry CUSTOMER UNIT P: PU Entry CUST. UNIT FACT. P: 0.0001 Result: MEASURED VALUE = 1 PU
	Factory setting: 1.0
LEVEL MODE (718)	Select level type.
Selection	 Options: Linear: the measured variable (level, volume, mass or %) is in direct proportion to the measured pressure. → See also Page 70 ff, Table 9. Pressure Linearized: the measured variable (volume, mass or %) is not in direct proportion to the measured pressure such as in the case of containers with a conical outlet. For the calibration, enter a linearisation table with at least 2 and not more than 32 points. → See also Page 78 ff, Table 10. Height Linearized: select this level type if you require two measured variables or if the container shape is given with value pairs, e.g. height and volume. The following combinations are possible:
	 Height + Volume Height + Mass Height + % %-Height + Volume %-Height + Mass %-Height + % Perform two calibrations for this level type. First for the measured variable height or %-height like for the "Linear" option and then for the measured variable volume, mass or % like for the "Pressure Linearized" option. → See also Page 83 ff, Table 11.
	Factory setting: Linear
 → For LEVEL MODE = Linear, see Page 70, Table 9. → For LEVEL MODE = Pressure Linearized, see Page 78, Table 10. → For LEVEL MODE = Height Linearized, see Page 83, Table 11. 	



Fig. 31: BASIC SETUP function group for the "Level" measuring mode and "Linear" level type

Parameter name	Description
The following parameters are type, the measured variable (l	displayed if you selected the "Linear" option for the LEVEL MODE parameter. For this level evel, volume, mass or %) is in direct proportion to the measured pressure.
Prerequisite: MEASURING MODE = Le LEVEL SELECTION = Leve LEVEL MODE = Linear (vel (\rightarrow see also Page 45). el Standard (\rightarrow see also Page 46). es see also Page 68).
Note: See also – Page 67 ff, Table 10: BASIG – Page 96 ff, Table 16: EXTE – Page 122 ff, Table 28: PRC – Page 14 ff, Section 5 "Leve	C SETUP – general NDED SETUP CESS VALUES I measurement".
LIN. MEASURAND (804)	Select measured variable.
Selection	Options: • Level • Volume • Mass • % (Level)
	Factory setting: % (Level)
HEIGHT UNIT (708) Selection	Select level unit. Prerequisite: I.IN. MEASURAND = Level
	Options: • mm • cm • dm • m • inch • ft • User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H.
	Factory setting:
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. H.
	Prerequisite:LIN. MEASURAND = Level, HEIGHT UNIT = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:

LEVEL MODE "Linear"	
Parameter name	Description
CUST. UNIT FACT. H (705) Entry	Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". \rightarrow See also CUSTOMER UNIT H.
	Prerequisite: ■ LIN. MEASURAND = Level, HEIGHT UNIT = User unit
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE = 0.5 m (1.6 ft) ≅ 1 PU Entry CUSTOMER UNIT H: PU Entry CUST. UNIT FACT. H: 2 Result: MEASURED VALUE = 1 PU
	Factory setting: 1.0
UNIT VOLUME (313) Selection	Select volume unit. Prerequisite: IIN. MEASURAND = Volume
	Options: 1 hl cm ³ dm ³ m ³ E ³ ft ft ³ E ³ gal Igal bbl User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V.
	Factory setting: m ³
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V
	Prerequisite:LIN. MEASURAND = Volume, UNIT VOLUME = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:

Table 11: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Linear"

٦

Table 11: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
CUST. UNIT FACT. V (607) Entry	Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m ³ ". \rightarrow See also CUSTOMER UNIT V.
	Prerequisite: ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit
	 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 0.01 m3 ≈ 1 bucket Entry CUSTOMER UNIT V: bucket Entry CUST. UNIT FACT. V: 100 Result: MEASURED VALUE = 1 bucket
	Factory setting: 1.0
MASS UNIT (709)	Select mass unit.
Selection	Prerequisite: • LIN. MEASURAND = Mass
	Options: g kg t oz lb ton User unit, → see also the following parameter description for CUSTOMER UNIT M and CUST. UNIT FACT. M.
	Factory setting: kg
CUSTOMER UNIT M (704) Entry	 Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. M. Prerequisite: LIN. MEASURAND = Mass, MASS UNIT = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT M parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:
Parameter name	Description
-------------------------------------	---
CUST. UNIT FACT. M (703) Entry	Enter conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M.
	Prerequisite: ■ LIN. MEASURAND = Mass, MASS UNIT = User unit
	 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 10 kg ≈ 1 bucket Entry CUSTOMER UNIT M: bucket Entry CUST. UNIT FACT. M: 0.1 Result: MEASURED VALUE = 1 bucket
	Factory setting: 1.0
CALIBRATION MODE (392) Selection	Select calibration mode. Options:
	 Wet Wet alibration takes place by filling and emptying the container. This calibration mode requires two pressure-level value pairs to be entered. In the case of two different levels, the level value is entered and the pressure measured at this moment is assigned to the level value. → See also the following parameter description for EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. Drv
	 Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. For the "Level" measured variable, the density of the fluid (→ see Page 74, ADJUST DENSITY) must be entered. For the "Volume" measured variable, the density of the fluid and the tank volume and tank height must be entered (→ see Page 74, ADJUST DENSITY, TANK VOLUME and TANK HEIGHT).
	 For the "Mass" measured variable, the tank volume and the tank height must be entered (→ see Page 75, TANK VOLUME and TANK HEIGHT). The density must also be entered in the case of a zero point shift (level offset) (→ see Page 74, ADJUST DENSITY). For the "%" measured variable, the density of the fluid must be entered and a level assigned to the 100 % point (→ see Page 74 and 77, ADJUST DENSITY and 100% POINT).
	If the measurement should not start at the mounting location of the device, a level offset must be entered (\rightarrow see Page 77, ZERO POSITION).
	Note! LIN. MEASURAND: "% (Level)", "Mass" and "Volume": If the change to dry calibration is made after a wet calibration, the density must be entered correctly using the ADJUST DENSITY and DENSITY PROCESS parameter before changing the calibration mode. \rightarrow See also Page 97.
	Factory setting: Wet
EMPTY CALIB. (314) Entry	Enter level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. \rightarrow See also EMPTY PRESSURE.
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.
	Factory setting: 0.0

Table 11: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level",

Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"		
Parameter name	Description	
EMPTY PRESSURE (710) Display	Displays the pressure value for the lower calibration point (container empty). \rightarrow See also EMPTY CALIB.	
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>	
	Factory setting: 0.0	
FULL CALIB. (315) Entry	Enter level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. \rightarrow See also FULL PRESSURE.	
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>	
	Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.	
	Factory setting: 100.0	
FULL PRESSURE (711) Display	Displays the pressure value for the upper calibration point (container full). \rightarrow See also FULL CALIB.	
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>	
	Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119)	
ADJUSTED DENSITY (810)	Displays the density calculated from the upper and lower level point.	
Display	Prerequisite: • CALIBRATION MODE = Wet, LIN. MEASURAND = Level	
DENSITY UNIT (812)	Select density unit.	
Selection	 Prerequisite: LIN. MEASURAND = Level, CALIBRATION MODE = Dry LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry LIN. MEASURAND = Volume, CALIBRATION MODE = Dry LIN. MEASURAND = Mass, CALIBRATION MODE = Dry 	
	Options: g/cm ³ kg/dm ³ kg/m ³ US lb/in ³ US lb/ft ³	
	Factory setting: kg/dm ³	
ADJUST DENSITY (316)	Enter density of fluid.	
Entry	 Prerequisite: LIN. MEASURAND = Level, CALIBRATION MODE = Dry LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry LIN. MEASURAND = Volume, CALIBRATION MODE = Dry LIN. MEASURAND = Mass, CALIBRATION MODE = Dry 	
	Factory setting: 1000.0	

74

Parameter name	Description
UNIT VOLUME (313)	Select volume unit.
Selection	<pre>Prerequisite: LIN. MEASURAND = Volume</pre>
	Options:
	 1 h1 cm³ dm³
	 m³ m³ E³ ft
	 ft³ E³ gal Igal
	 Igai bbl User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V.
	Factory setting: m ³
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V
	<pre>Prerequisite: LIN. MEASURAND = Volume, UNIT VOLUME = User unit</pre>
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:
CUST. UNIT FACT. V (607) Entry	 Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V.
	Prerequisite: ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit
	 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 0.01 m3 ≈ 1 bucket Entry CUSTOMER UNIT V: bucket Entry CUST. UNIT FACT. V: 100 Result: MEASURED VALUE = 1 bucket
	Factory setting: 1.0
TANK VOLUME (858)	Enter tank volume.
Entry	 Prerequisite: LIN. MEASURAND = Volume, CALIBRATION MODE = Dry LIN. MEASURAND = Mass, CALIBRATION MODE = Dry
	Factory setting: 1.0 m ³

Table 11: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Linear"

Г

_

Parameter name	Description
HEICHT UNIT (708)	Select level unit
Selection	Prerequisite:
	■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry
	Options:
	■ mm ■ dm
	cm
	■ m ■ inch
	ft
	 User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H.
	Factory setting:
	m
CUSTOMER UNIT H (706)	Enter text (unit) for customer-specific level unit.
Lifti y	\rightarrow See also CUST. UNIT FACT. H.
	Prerequisite:
	 LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry, HEIGHT UNIT = User unit
	Only the first five characters are shown on the on-site display. For example, if "crates" is
	specified as the customer-specific unit, "crate" is displayed.
	The maximum number of characters in the counter is again limited to five. For example,
	if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the
	In the HART handheld terminal, the customer-specific unit is only displayed in the
	CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:
CUST. UNIT FACT. H (705)	Enter conversion factor for a customer-specific level unit.
	\rightarrow See also CUSTOMER UNIT H.
	Prerequisite:
	 LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry, HEIGHT UNIT = User unit
	Example:
	- You want the measured value to be displayed in "PU" (PU: packing unit). - MEASURED VALUE - 0.5 m (1.6 ft) \approx 1 PU
	– Entry CUSTOMER UNIT H: PU
	 Entry CUST. UNIT FACT. H: 2 Result: MEASURED VALUE = 1 PU
	Factory setting:
	1.0
TANK HEIGHT (859)	Enter tank height.
Entry	Prerequisite:
	 LIN. IVIEASURAIND = VOIUIIIE, CALIBRATION MODE = DIY LIN. MEASURAND = Mass, CALIBRATION MODE = Dry
	Factory setting:
	1.0 m

	Description
Parameter name	
100% POINT (813) Entry	Enter level value for 100% point. Prerequisite: • LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry Example: - The 100 %-point should correspond to 4 m (13 ft). - Select the "m" unit via the HEIGHT UNIT parameter. - Enter the value "4" for this parameter (100% POINT). Factory setting: 1.0
ZERO POSITION (814) Entry	 Enter value for level offset. If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset). Prerequisite: CALIBRATION MODE = Dry Factory setting: 0.0 Fig. 32: Zero point shift 1 Device is mounted above the level lower range value: a positive value has to be entered for ZERO POSITION. 2 Device is mounted below the level lower range value: a negative value has to be entered for ZERO POSITION.
SET LRV (719) Entry	Enter level value for the lower current value (4 mA). Factory setting: 0.0
SET URV (720) Entry	Enter level value for the upper current value (20 mA). Factory setting: 100.0
DAMPING VALUE (247) Entry	 Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure. Input range: 0.0999.0 s Factory setting: 2.0 s or as per order specifications

Table 11: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Linear"



Fig. 33: BASIC SETUP function group for the "Level" measuring mode and the "Pressure Linearized" level type, continue calibration with LINEARISATION function group
 → See Page 100 ff for on-site operation and Page 104 ff for operation with digital communication.

Table 12: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"

Parameter name	Description
The following parameters are displayed if you selected the "Pressure Linearized" option for the LEVEL MODE parameter For this level type, the measured variable (volume, mass or %) is not in direct proportion to the measured pressure. For the calibration, enter a linearisation table with at least 2 and not more than 32 points.	
Prerequisite: MEASURING MODE = Lev LEVEL SELECTION = Level LEVEL MODE = Pressure L	tel (\rightarrow see also Page 45). I Standard (\rightarrow see also Page 46). inearized (\rightarrow see also Page 68).
Note: See also - Page 67 ff, Table 10: BASIC SETUP – general - Page 96 ff, Table 16: EXTENDED SETUP	

- Page 100 ff, Table 18: LINEARISATION on-site operation
- Page 104 ff, Table 19: LINEARISATION Digital communication
- Page 122 ff, Table 28: PROCESS VALUES
- Page 14 ff, Section 5 "Level measurement".

Parameter name Description LINd. MEASURAND (805) Select measured vatable. Selection • Pressure and Volume • Pressure and % • Pressure and % UNIT VOLUME (313) Select volume unit. Selection • Pressure and % UNIT VOLUME (313) Select volume unit. Precequisite: • I.I.M. MEASURAND = Pressure and Volume Options: • I • I • I • I • I • I • I • I • I • I • I • I • II • I • II • II • III • III • III • III • IIII • IIIII • IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII				
LINA.MEASURAND (805) Select measured variable. Selection Options: • Pressure and Mass • Pressure and %. Factory setting: Pressure and %. INIT VOLUME [313) Select volume unit. Precequisite: • LINA.MEASURAND = Pressure and Volume Options: • I • In • In • In • In • In • In • Ini • Ini	Parameter name	Description		
Factory setting: Pressure and % UNIT VOLUME (313) Selection Select volume unit. Prerequisite: • LINA. MEASURAND = Pressure and Volume Options: • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1	LINd. MEASURAND (805) Selection	Select measured variable. Options: Pressure and Volume Pressure and Mass Pressure and %		
UNIT VOLUME (313) Select volume unit. Selection Precequisite: • LINd. MEASURAND = Pressure and Volume Options: • • In • • m ³ • • m ³ • • m ³ • • m ³ • • gal • • la • • bit • • bit • • bit • • User unit, -> see also the following parameter description for CUSTOMER UNIT V CUST. UNIT FACT. V. Factory setting: m ³ CUSTOMER UNIT V (608) Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here> See also CUST. UNIT FACT. V VINT FACT. V Prerequisite: • • I.M.M.MEASURAND = Pressure and Volume, UNIT VOLUME = User unit Superiod as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display The maximum number of characters in the counter is again limited to five. For example, if "crates: specifie as the customer-specific unit, "crate: maif" crates:ma'ma' is displayed.		Factory setting: Pressure and %		
Selection Prerequisite: • LINd. MEASURAND = Pressure and Volume Options: • 1 • hi • cm ³ • m ³ • m ³ • gal • gal • gal • bil • User unit, → see also the following parameter description for CUSTOMER UNIT V CUST. UNIT FACT. V. Factory setting: m ³ CUSTOMER UNIT V (608) Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V Prerequisite: • LINd. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit South the first five characters are shown on the on-site display. For example, if "crates specified as the customer-specific unit, "crate/m2" is displayed. In the maximum number of characters in the counter is again limited to five. For example, the first five characters are displayed. If the unit contains a slash, up to eight characters is a be shown on the on-site display in the maximum set display in the customer-specific unit, "crate/m2" is displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT V. Featory setting:	UNIT VOLUME (313)	Select volume unit.		
Options: 1 h1 n1 n3 m3 m3 gal igal	Selection	Prerequisite:LINd. MEASURAND = Pressure and Volume		
CUSTOMER UNIT V (608) Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V Prerequisite: • LING. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit Image: Specified as the customer-specific unit, "crate" is display. For example, if "crates specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. For example, if "crates specified as the customer-specific unit, "crate" is displayed. In the unit contains a slash, up to eight characters can be shown on the on-site display. If "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed in the CUSTOMER UNIT V parameter. The measured value is displayed in the additional "User Unit". Factory setting: CUST. UNIT FACT. V (607) Enter conversion factor for a customer-specific volume unit. The conversion factor for a customer-specific volume unit. The conversion factor for a customer-specific volume unit. The conversion factor for a customer-specific volume unit. In the MART NUIT V. Preequisite: • INA. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit Entry • Preequisite: • • INA. MEASURAND = Pressure and Volume, UNIT VOLUME = USER UNIT V. •		Options: 1 hl cm^3 dm^3 m^3 $m^3 E^3$ ft ft^3 E^3 gal Igal bbl User unit, \rightarrow see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V.		
CUSTOMER UNIT V (608) Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V Prerequisite: • LINd, MEASURAND = Pressure and Volume, UNIT VOLUME = User unit If the unit contains a slash, up to eight characters can be shown on the on-site display. For example, if "crates specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheid terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT V parameter. The measured value is displayed with the additional "User Unit". Factory setting: CUST. UNIT FACT. V (607) Entry Entry VIOT Prerequisite: • LINd. MEASURAND = Pressure and Volume, UNIT WOLUME = User unit "The conversion factor for a customer-specific volume unit. The conversion factor for a customer-specific volume unit. The conversion factor for a customer. UNIT VOLUME = User unit UNIT VOLUME = User unit <t< td=""><td></td><td>Factory setting: m³</td></t<>		Factory setting: m ³		
CUST. UNIT FACT. V (607) Entry Entry CUST. UNIT FACT. V (607) Entry Entry CUST. UNIT FACT. V (607) Entry Entry Dialy Entry Dialy Entry CUSTOMER UNIT V. Prerequisite: • • Example: • You want the measured value to be displayed in "buckets". • MEASURED VALUE = 0.01 m3 ≅ 1 bucket Entry Entry	CUSTOMER UNIT V (608) Entry	 Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V Prerequisite: LINd. MEASURAND = Pressure and Volume, LINDT VOLUME - User unit 		
Factory setting:		Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT V parameter. The measured value is displayed with the additional text "User Unit".		
CUST. UNIT FACT. V (607) Entry Entry Entry Description Entry Entry Description Entry UNIT VOLUME Entry UNIT VOLUME UNIT VOLUME UNIT VOLUME Example: You want the measured value to be displayed in "buckets". MEASURED VALUE Entry CUSTOMER Entry CUSTOMER UNIT VOLUME Entry CUST UNIT		Factory setting:		
 Prerequisite: LINd. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 0.01 m3 ≈ 1 bucket Entry CUSTOMER UNIT V: bucket Entry CUST. UNIT FACT. V: 100 Result: MEASURED VALUE = 1 bucket Factory setting: 	CUST. UNIT FACT. V (607) Entry	 Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m ³ ". → See also CUSTOMER UNIT V.		
 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 0.01 m3 ≈ 1 bucket Entry CUSTOMER UNIT V: bucket Entry CUST. UNIT FACT. V: 100 Result: MEASURED VALUE = 1 bucket Factory setting: 		 Prerequisite: LINd. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit 		
Factory setting:		 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 0.01 m3 ≈ 1 bucket Entry CUSTOMER UNIT V: bucket Entry CUST. UNIT FACT. V: 100 Result: MEASURED VALUE = 1 bucket 		
1.0		Factory setting: 1.0		

Table 12: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"

Table 12: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"		
Parameter name	Description	
MASS UNIT (709) Selection	Select mass unit.	
	<pre>Prerequisite: LINd. MEASURAND = Pressure and Mass</pre>	
	Options: 9 g kg 1 t 0 z 1b 1 ton User unit, → see also the following parameter description for CUSTOMER UNIT M and CUST. UNIT FACT. M.	
	Factory setting: kg	
CUSTOMER UNIT M (704) Entry	Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. M.	
	 Prerequisite: LINd. MEASURAND = Pressure and Mass, MASS UNIT = User unit 	
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT M parameter. The measured value is displayed with the additional text "User Unit".	
	Factory setting:	
CUST. UNIT FACT. M (703) Entry	Enter conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". \rightarrow See also CUSTOMER UNIT M.	
	 Prerequisite: LINd. MEASURAND = Pressure and Mass, MASS UNIT = User unit 	
	 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 10 kg ≈ 1 bucket Entry CUSTOMER UNIT M: bucket Entry CUST. UNIT FACT. M: 0.1 Result: MEASURED VALUE = 1 bucket 	
	Factory setting: 1.0	
HYDR. PRESS MIN. (775) Entry	Enter the minimum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum hydrostatic pressure to be expected, the more accurate the measurement result.	
	Factory setting: 0.0	

TEATE MODE LIESSUIE FUIGAIRED		
Parameter name	Description	
HYDR. PRESS MAX. (761) Entry	Enter the maximum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum hydrostatic pressure to be expected, the more accurate the measurement result.	
	Factory setting: High sensor limit (→ See PRESS. SENS HILIM, Page 119)	
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.	
	Input range: 0.0999.0 s	
	Factory setting: 2.0 s or as per order specifications	

Table 12: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"



Fig. 34: BASIC SETUP function group for the "Level" measuring mode and the "Height Linearized" level type, continue calibration with LINEARISATION function group → See Page 100 ff for on-site operation and Page 104 ff for operation with digital communication.

Parameter name	Description
The following parameters are d	lisplayed if you selected the "Height Linearized" option for the LEVEL MODE parameter.
Select this level type if you requand volume. The following combinations are Height + Volume Height + Mass Height + % %-Height + Volume %-Height + Mass %-Height + %	uire two measured variables or if the container shape is given with value pairs, e.g. heigh e possible:
The 1st measured variable (%-I measured variable (Volume, M 2nd measured variable. The 2n	Height or Height) must be in direct proportion to the measured pressure. The 2nd ass or %) must not be in direct proportion. A linearisation table must be entered for the nd measured variable is assigned to the 1st measured variable by means of this table.
 Prerequisite: MEASURING MODE = Level LEVEL SELECTION = Level LEVEL MODE = Height Line 	el (\rightarrow see also Page 45). l Standard (\rightarrow see also Page 46). earized (\rightarrow see also Page 68).
See also - Page 67 ff, Table 10: BASIC - Page 96 ff, Table 16: EXTEN - Page 100 ff, Table 18: LINE. - Page 104 ff, Table 19: LINE. - Page 122 ff, Table 28: PROC - Page 14 ff, Section 5 "Level	SETUP – general NDED SETUP ARISATION – on-site operation ARISATION – Digital communication CESS VALUES measurement".
COMB. MEASURAND (806) Selection	Select measured variable. Options: • Height and Volume • Height and Mass • Height and % • %-Height and Volume • %-Height and Mass • %-Height and % Factory setting: %-Height and %
HEIGHT UNIT (708) Selection	Select level unit for the 1st measured variable. Prerequisite: COMB. MEASURAND = Height and Volume, Height and Mass or Height and % Options: mm dm dm cm m inch ft User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H.

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Height Linearized"		
Parameter name	Description	
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. H.	
	 COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit COMB. MEASURAND = Height and Mass, HEIGHT UNIT = User unit COMB. MEASURAND = Height and %, HEIGHT UNIT = User unit 	
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".	
	Factory setting:	
CUST. UNIT FACT. H (705) Entry	Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". \rightarrow See also CUSTOMER UNIT H.	
	 Prerequisite: COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit COMB. MEASURAND = Height and Mass, HEIGHT UNIT = User unit COMB. MEASURAND = Height and %, HEIGHT UNIT = User unit 	
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE = 0.5 m (1,6 ft) ≈ 1 PU Entry CUSTOMER UNIT H: PU Entry CUST. UNIT FACT. H: 2 Result: MEASURED VALUE = 1 PU 	
	Factory setting: 1.0	
UNIT VOLUME (313) Selection	Select the volume unit for the 2nd measured value. Prerequisite:	
	 Options: 1 h1 cm³ dm³ m³ E³ ft ft³ E³ gal Igal bbl User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V. Factory setting: m³ 	

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level".

Parameter name	Description	
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. V	
	 Prerequisite: COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit COMB. MEASURAND = %-Height and Volume, HEIGHT UNIT = User unit 	
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT V parameter. The measured value is displayed with the additional text "User Unit".	
	Factory setting:	
CUST. UNIT FACT. V (607) Entry	Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit " m^{3} ". \rightarrow See also CUSTOMER UNIT V.	
	 Prerequisite: COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit COMB. MEASURAND = %-Height and Volume, HEIGHT UNIT = User unit 	
	 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 0.01 m3 ≈ 1 bucket Entry CUSTOMER UNIT V: bucket Entry CUST. UNIT FACT. V: 100 Result: MEASURED VALUE = 1 bucket 	
	1.0	
MASS UNIT (709) Selection	Select the mass unit for the 2nd measured value.	
	 COMB. MEASURAND = Height and Mass or %-Height and Mass 	
	Options: 9 g kg 1 t 0 oz 1 b 1 ton 1 User unit, → see also the following parameter description for CUSTOMER UNIT M and CUST. UNIT FACT. M.	
	kg	

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Height Linearized"

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Height Linearized"	
Parameter name	Description
CUSTOMER UNIT M (704) Entry	Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. M.
	 Prerequisite: COMB. MEASURAND = Height and Mass, MASS UNIT = User unit COMB. MEASURAND = %-Height and Mass, MASS UNIT = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT M parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:
CUST. UNIT FACT. M (703) Entry	Enter conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". \rightarrow See also CUSTOMER UNIT M.
	 Prerequisite: COMB. MEASURAND = Height and Mass, MASS UNIT = User unit COMB. MEASURAND = %-Height and Mass, MASS UNIT = User unit
	 Example: You want the measured value to be displayed in "buckets". MEASURED VALUE = 10 kg ≈ 1 bucket Entry CUSTOMER UNIT M: bucket Entry CUST. UNIT FACT. M: 0.1 Result: MEASURED VALUE = 1 bucket
	Factory setting: 1.0
LEVEL MIN (755) Entry	Enter the minimum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum level to be expected, the more accurate the measurement result.
	 Note! The following applies for the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear": If you enter a new value for LEVEL MIN, the value for SET LRV is also changed. Use SET LRV to assign a height to the lower current value. If you want to assign the lower current value a value other than that for LEVEL MIN, you must enter the desired value for SET LRV. (→ SET LRV, Page 98 and ASSIGN CURRENT, Page 113)
	Factory setting: 0.0
LEVEL MAX (712) Entry	Enter the maximum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum level to be expected, the more accurate the measurement result.
	 The following applies for the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear": If you enter a new value for LEVEL MAX, the value for SET URV is also changed. Use SET URV to assign a height to the upper current value. If you want to assign the upper current value a value other than that for LEVEL MAX, you must enter the desired value for SET URV. (→ SET URV, Page 98 and ASSIGN CURRENT, Page 113)
	Factory setting: 100.0

Table 13. (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level".

Parameter name	Description
CALIBRATION MODE (392)	Select the calibration mode for the calibration of the 1st measured variable.
Selection	 Options: Wet Wet calibration takes place by filling the container. This calibration mode requires two pressure-level value pairs to be entered. In the case of two different levels, the level value is entered and the pressure measured at this moment is assigned to the level value. → See also the following parameter description for EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. Dry Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. For the "Level" measured variable, the density of the fluid (→ see Page 88, ADJUST DENSITY) must be entered. For the "%" measured variable, the density of the fluid must be entered and a level assigned to the 100 % point (→ see Page 88, ADJUST DENSITY and 100% POINT). If the measurement should not start at the mounting location of the device, a level offset must be entered (→ see Page 90, ZERO POSITION). Note! If the change to dry calibration is made after a wet calibration, the density must be entered correctly using the ADJUST DENSITY and DENSITY PROCESS parameter before changing the calibration mode. → See also Page 97.
	Factory setting: Wet
EMPTY CALIB. (314) Entry	Enter level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. \rightarrow See also EMPTY PRESSURE.
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>
	Factory setting: 0.0
EMPTY PRESSURE (710) Display	Displays the pressure value for the lower calibration point (container empty). \rightarrow See also EMPTY CALIB.
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>
FULL CALIB. (315) Entry	Enter level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. \rightarrow See also FULL PRESSURE.
	<pre>Prerequisite: CALIBRATION MODE = Wet</pre>
	Factory setting: 100.0
FULL PRESSURE (711) Display	Displays the pressure value for the upper calibration point (container full). \rightarrow See also FULL CALIB.
	<pre>Prerequisite: • CALIBRATION MODE = Wet</pre>
	Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119)
ADJUSTED DENSITY (810)	Displays the density calculated from the upper and lower level point.
Display	 Prerequisite: COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Wet COMB. MEASURAND = Height and Mass, CALIBRATION MODE = Wet COMB. MEASURAND = Height and %, CALIBRATION MODE = Wet

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Height Linearized"

Parameter name	Description
DENSITY UNIT (812) Selection	Select density unit.
	 Prerequisite: COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry COMB. MEASURAND = Height and %, CALIBRATION MODE = Dry COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = Height and Mass, CALIBRATION MODE = Dry
	Options: • g/cm^3 • kg/dm^3 • kg/m^3 • US lb/in^3 • US lb/ft^3
	Factory setting: kg/dm ³
ADJUST DENSITY (316)	Enter density of fluid.
Entry	 Prerequisite: COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry COMB. MEASURAND = Height and %, CALIBRATION MODE = Dry COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = Height and Mass, CALIBRATION MODE = Dry
	Factory setting: 1.0
HEIGHT UNIT (708)	Select level unit.
Selection	 Prerequisite: COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height + %, CALIBRATION MODE = Dry
	 Options: mm dm cm m inch ft User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H.
	Factory setting:
	m

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level",

Parameter name	Description
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. H.
	 Prerequisite: COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:
CUST. UNIT FACT. H (705) Entry	Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". \rightarrow See also CUSTOMER UNIT H.
	 Prerequisite: COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE = 0.5 m (1.6 ft) ≏ 1 PU Entry CUSTOMER UNIT H: PU Entry CUST. UNIT FACT. H: 2 Result: MEASURED VALUE = 1 PU
	Factory setting: 1.0
100% POINT (813)	Enter level value for 100% point.
Entry	 Prerequisite: COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry COMB. MEASURAND = %-Height + %, CALIBRATION MODE = Dry
	 Example: The 100 %-point should correspond to 4 m (13 ft). Select the "m" unit via the HEIGHT UNIT parameter. Enter the value "4" for this parameter (100% POINT).
	Factory setting: 1.0

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level", LEVEL MODE "Height Linearized"

LEVEL MODE "Height L	inearized"
Parameter name	Description
ZERO POSITION (814) Entry	Enter value for level offset. If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset).
	Prerequisite:CALIBRATION MODE = Dry
	FOI-PMP75xxx-19-xx-xx-xx-001 Fig. 35: Zero point shift
	 Device is mounted above the level lower range value: a positive value has to be entered for ZERO POSITION. Device is mounted below the level lower range value: a negative value has to be entered for ZERO POSITION.
	Factory setting: 0.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.
	Input range: 0.0999.0 s
	Factory setting: 2.0 s or as per order specifications

Table 13: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Level",



Fig. 36: BASIC SETUP function group for the "Flow" measuring mode

Table 14: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Flow"		
Parameter name	Description	
 Prerequisite: ■ MEASURING MODE = Flow (→ see also Page 45). 		
Note:		
See also		
- Page 52, Table 5: OUICK SETUP		
– Page 98, Table 15: EXTENDED SETUP		
- Page 107, Table 18: TOTALIZER SETUP		
- Page 123, Table 27: PROCESS VALUES.		
 Page 40 ff, Section 6 "Flow measurement". 		

Table 14: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Flow"		
Parameter name	Description	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. Marning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured. Prerequisite: Digital communication	
	Options: Pressure Level Deltabar S: Flow Factory setting: Cerabar S and Deltabar S: Pressure Deltapilot S: Level 	
PRESS. ENG. UNIT (060) Selection	Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options: • mbar, bar • mmH2O, mH2O, inH2O, ftH2O ¹) • Pa, hPa, kPa, MPa • psi • mmHg, inHg ²) • Torr • g/cm ² , kg/cm ² • lb/ft ² • atm • gf/cm ² , kgf/cm ² • User unit, \rightarrow See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. 1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F). Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications	
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. P. Prerequisite: • PRESS. ENG. UNIT = User unit Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit". Factory setting:	

Table 14: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Flow"		
Parameter name	Description	
CUST. UNIT FACT. P (317) Entry	Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". \rightarrow See also CUSTOMER UNIT P.	
	Prerequisite:PRESS. ENG. UNIT = User unit	
	 Example: You want the measured value to be displayed in "PU" (PU: packing unit). MEASURED VALUE =10000 Pa ≈ 1 PU Entry CUSTOMER UNIT P: PU Entry CUST. UNIT FACT. P: 0.0001 Result: MEASURED VALUE = 1 PU 	
	Factory setting: 1.0	
FLOW-MEAS. TYPE (640)	Select the flow type.	
Selection	 Options: Volume p. cond. (volume under operating conditions) Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0°C)) Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288.15 K (15°C/59°F)) Mass (mass under operating conditions) 	
	Factory setting: Volume p. cond.	
UNIT FLOW (391) Selection	Select volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.	
	Prerequisite: ■ FLOW-MEAS. TYPE = Volume p. cond.	
	Options: m3/s, m3/min, m3/h, m3/day l/s, l/min, l/h hl/s, hl/min, hl/day ft3/s, ft3/min, ft3/h, ft3/day ACFS, ACFM, ACFH, ACFD ozf/s, ozf/min US Gal/s, US Gal/min, US Gal/h, US Gal/day Imp. Gal/s, Imp. Gal/min, Imp. Gal/h bbl/s, bbl/min, bbl/h, bbl/day User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F	
	Factory setting: m ³ /s	
NORM FLOW UNIT (661) Selection	Select norm volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.	
	Prerequisite:FLOW-MEAS. TYPE = Gas norm conditions	
	 Options: Nm3/s, Nm3/min, Nm3/h, Nm3/day User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F 	
	Factory setting: Nm ³ /s	

Table 14: (GROUP SELEC	$(100 \rightarrow) \text{ OPERATING MENU} \rightarrow 51111065 \rightarrow \text{BASIC SETUP "Flow"}$
Parameter name	Description
STD. FLOW UNIT (660) Selection	Select standard volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.
	Prerequisite:FLOW-MEAS. TYPE = Gas std. conditions
	 Options: Sm3/s, Sm3/min, Sm3/h, Sm3/day SCFS, SCFM, SCFH, SCFD User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F
	Factory setting: Sm ³ /s
MASS FLOW UNIT (571) Selection	Select mass flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.
	Prerequisite: • FLOW-MEAS. TYPE = Mass
	 Options: g/s, kg/s, kg/min, kg/min, kg/h t/s, t/min, t/h, t/day oz/s, oz/min lb/s, lb/min, lb/h ton/s, ton/min, ton/h, ton/day User unit, → see also the following parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F
	Factory setting: kg/s
CUSTOMER UNIT F (610) Entry	Enter text (unit) for customer-specific flow unit. You can enter a maximum of eight alphanumeric characters here. \rightarrow See also CUST. UNIT FACT. F.
	 Prerequisite: UNIT FLOW = User unit NORM FLOW UNIT = User unit STD. FLOW UNIT = User unit MASS FLOW UNIT = User unit
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT F parameter. The measured value is displayed with the additional text "User Unit".
	Factory setting:

Table 14: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow BASIC SETUP "Flow"		
Parameter name	Description	
CUST. UNIT FACT. F (609) Entry	Enter conversion factor for a customer-specific flow unit. The conversion factor must be entered in relation to an appropriate SI unit, e.g. m^3/s for the "Volume p. cond." flow mode. \rightarrow See also CUSTOMER UNIT F.	
	 Prerequisite: UNIT FLOW = User unit NORM FLOW UNIT = User unit STD. FLOW UNIT = User unit MASS FLOW UNIT = User unit 	
	 Example: You want the measured value to be displayed in "bucket/h". MEASURED VALUE =0.01 m3/s ≈ 3600 bucket/h Entry CUSTOMER UNIT F: bucket/h Entry CUST. UNIT FACT. F: 360000 Result: MEASURED VALUE = 3600 bucket/h 	
	Factory setting: 1.0	
MAX. FLOW (311) Entry	Enter maximum flow of primary element. \rightarrow See also layout sheet of primary element. The maximum flow is assigned to the maximum pressure which you enter via MAX PRESS. FLOW.	
	Note! Use the LINEAR/SOROOT parameter (\rightarrow Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Flow (square root)" setting: If you enter a new value for MAX. FLOW, the value for SET URV is also changed. Use SET URV to assign a flow to the upper current value. If you want to assign the upper current value a value other than that for MAX. FLOW, you must enter the desired value for SET URV. (\rightarrow SET URV, Page 100).	
	Factory setting: 1.0	
MAX PRESS. FLOW (634) Entry	Enter maximum pressure of primary element. \rightarrow See layout sheet of primary element. This value is assigned to the maximum flow value (\rightarrow see MAX. FLOW).	
	Note! Use the LINEAR/SQROOT parameter (\rightarrow Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Differential pres." setting: If you enter a new value for MAX PRESS. FLOW, the value for SET URV is also changed. Use SET URV to assign a pressure value to the upper current value. If you want to assign the upper current value a value other than that for MAX PRESS. FLOW, you must enter the desired value for SET URV. (\rightarrow SET URV, Page 100).	
	Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119)	
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.	
	Input range: 0.0999.0 s	
	Factory setting: 2.0 s or as per order specifications	



Fig. 37: EXTENDED SETUP function group

- \rightarrow For the "Pressure" measuring mode, see Page 96, Table 15
- \rightarrow For the "Level" measuring mode, see Page 96, Table 16
- \rightarrow For the "Flow" measuring mode, see Page 98, Table 17

Table 15: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Pressure"	
Parameter name	Description
Prerequisite:MEASURING MODE = Pre	essure (\rightarrow see also Page 45).
Note: See also Page 11 ff, Section	4 "Pressure measurement".
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured values. \rightarrow See also PCB TEMPERATURE (Page 117) and SENSOR TEMP. (Page 122).
	Options: • °C • °F • K • R
	Factory setting: °C

Table 16: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Level"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Level (→ see also Page 45).	
Note: See also Page 14 ff, Section 5 "Level measurement".	

Table 16: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Level"	
Parameter name	Description
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured values. → See also PCB TEMPERATURE (Page 117) and SENSOR TEMP. (Page 122). Options: • °C • °F • K • R Factory setting:
	°C
DENSITY UNIT (001)/(812) Options	Select density unit. Options: • g/cm ³ • kg/dm ³ • kg/m ³ • US lb/in ³ • US lb/ft ³
	Factory setting: kg/dm ³
ADJUST DENSITY (007)/(316) Entry	Enter density of fluid. Note! LIN. MEASURAND: "% (Level)", "Mass" and "Volume" and MEASUAND KOMB.: If a change to dry calibration is made after a wet calibration using the CALIBRATION MODE parameter (\rightarrow Page 73 or 87), the density for this parameter must be entered correctly before changing the calibration mode. In the event that the pressure falls with increasing levels (LIN. MEASURED: Volume), such as in the case of a residual volume measurement, a negative value shall be entered for this parameter. Factory setting: 1.0
PROCESS DENSITY (025)/(811) Entry	Enter a new density value for density correction. The calibration was carried out with the medium water, for example. Now the container is to be used for another fluid with another density. The calibration is corrected appropriately by entering the new density value in the PROCESS DENSITY parameter. Note! LIN. MEASURAND: "% (Level)", "Mass" and "Volume" and MEASUAND KOMB.: If a change to dry calibration is made after a wet calibration using the CALIBRATION MODE parameter (→ Page 73 or 87), the density for this parameter must be entered correctly before changing the calibration mode. In the event that the pressure falls with increasing levels (LIN. MEASURED: Volume), such as in the case of a residual volume measurement, a negative value shall be entered for this parameter. Factory setting: 1.0

able 16: (GROUP SELECTI	ON \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Level"

Table 16: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Level"		
Parameter name	Description	
SET LRV (762)	Enter value for the lower current value (4 mA).	
Entry	Prerequisite:LEVEL MODE = Pressure Linearized or Height Linearized	
	 Note! For the LEVEL MODE "Height Linearized", you can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable (height or tank content). Depending on the setting of the ASSIGN CURRENT parameter, enter the following value for SET LRV: ASSIGN CURRENT = tank content (factory setting) ⇒ %- value, volume value or mass value ASSIGN CURRENT = height ⇒ level value 	
	 The following applies for the LEVEL MODE "Pressure Linearized" or LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Tank content": If you enter a new value for TANK CONTENT MIN, the value for SET LRV is also changed. If you want to assign the lower current value a value other than that for TANK CONTENT MIN, you must enter the desired value for SET LRV. (→ TANK CONTENT MIN, Page 101 or 104.) 	
	The following applies for the LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Height".	
	 If you enter a new value for LEVEL MIN, the value for SET LRV is also changed. If you want to assign the lower current value a value other than that for LEVEL MIN, you must enter the desired value for SET LRV. (→ LEVEL MIN, Page 86.) 	
	Factory setting: 0.0	
SET URV (763)	Enter value for the upper current value (20 mA).	
Entry	Prerequisite:LEVEL MODE = Pressure Linearized or Height Linearized	
	 Note! For the LEVEL MODE "Height Linearized", you can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable (height or tank content). Depending on the setting of the ASSIGN CURRENT parameter, enter the following value for SET URV: ASSIGN CURRENT = tank content (factory setting) ⇒ %- value, volume value or mass value ASSIGN CURRENT = height ⇒ level value 	
	 The following applies for the LEVEL MODE "Pressure Linearized" or LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Tank content": If you enter a new value for TANK CONTENT MAX, the value for SET URV is also changed. If you want to assign the upper current value a value other than that for TANK CONTENT MAX, you must enter the desired value for SET URV. (→ TANK CONTENT MAX, Page 101 or 105.) 	
	 The following applies for the LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Height": If you enter a new value for LEVEL MAX, the value for SET URV is also changed. If you want to assign the lower current value a value other than that for LEVEL MAX, you must enter the desired value for SET URV. (→ LEVEL MAX, Page 86.) 	
	Factory setting: 100.0	

Table 17: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Flow"	
Parameter name	Description
 Prerequisite: MEASURING MODE = Flow (→ see also Page 45). 	
Note: See also Page 40 ff, Section 6 "Flow measurement".	

Table 17: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Flow"	
Parameter name	Description
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured value. → See also PCB TEMPERATURE (Page 117) and SENSOR TEMP. (Page 123). Options: • °C • °F • K • R Factory setting: °C
LOW FLOW CUT-OFF (442) Selection	 Switches "low flow cut-off" function on and off. In the lower measuring range, small flow quantities (creepages) can lead to large measured value fluctuations. Switching on this function stops these flow quantities from being recorded. → See also SET. L. FL. CUT-OFF. Options: Off On Factory setting: Off
SET. L. FL. CUT-OFF (323) Entry	Enter switch-off point of low flow cut-off. The hysteresis between the switch-on point and the switch-off point is always 1 % of the end flow value. \rightarrow See also LOW FLOW CUT-OFF. Prerequisite: • LOW FLOW CUT-OFF = on Input range: Switch-off point: 050 % of end flow value (\rightarrow MAX. FLOW). (1) Q Q Q max 6% 5% 0% LOW P01-PMD7zzzze-05-zze-zze-000 Factory setting: 5 % (of end flow value)
SET LRV (637) Entry	 Depending on the setting in the LINEAR/SQROOT parameter (→ Page 113), enter a flow value or a pressure value for the lower current value (4 mA) here. LINEAR/SQROOT = Flow (square root) (factory setting) ⇒ flow value LINEAR/SQROOT = Differential pres. ⇒ pressure value Factory setting: 0

able 17: (GROUP SELECT	ION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Flow"

Table 17: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow EXTENDED SETUP "Flow"	
Parameter name	Description
SET URV (638) Entry	Depending on the setting in the LINEAR/SQROOT parameter (\rightarrow Page 113), enter a flow value or a pressure value for the upper current value (20 mA) here.
	 LINEAR/SQROOT = Flow (square root) (factory setting) ⇒ flow value LINEAR/SQROOT = Differential pres. ⇒ pressure value
	 The following applies for the setting LINEAR/SQROOT "Flow (square root)": If you enter a new value for MAX. FLOW, the value for SET URV is also changed. If you want to assign the upper current value a value other than that for MAX. FLOW, you must enter the desired value for SET URV. (→ MAX. FLOW, Page 95).
	 The following applies for the setting LINEAR/SQROOT "Differential pres.": If you enter a new value for MAX PRESS. FLOW, the SET URV value is also changed. If you want to assign the upper current value a value other than that for MAX PRESS. FLOW, you must enter the desired value for SET URV. (→ MAX PRESS. FLOW, Page 95).
	Factory setting: MAX. FLOW



Fig. 38: LINEARISATION function group for on-site operation

Prerequisite:	
 Prerequisite: MEASURING MODE = Level (→ see also Page 45). LEVEL MODE = Pressure Linearized or Height Linearized (→ see also Page 68). 	

- on-site operation	
Parameter name	Description
TANK CONTENT MIN (759) Entry	 Enter the minimum tank contents to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result. Note! If you enter a new value for TANK CONTENT MIN, the value for SET LRV is also changed. Use SET LRV to assign a %-value, volume value or mass value to the lower current value. If you want to assign the lower current value a value other than that for TANK CONTENT MIN, you must enter the desired value for SET LRV. (→ SET LRV, Page 98). For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MIN parameter does not affect the SET LRV parameter. (→ SET LRV, Page 98 and ASSIGN CURRENT, Page 113)
	Factory setting: 0.0
TANK CONTENT MAX (713) Entry	Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result.
	 If you enter a new value for TANK CONTENT MAX, the value for SET URV is also changed. Use SET URV to assign a %-value, volume value or mass value to the upper current value. If you want to assign the upper current value a value other than that for TANK CONTENT MAX, you must enter the desired value for SET URV. (→ SET URV, Page 98.) For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MAX parameter does not affect the SET URV parameter. (→ SET URV, Page 98 and ASSIGN CURRENT, Page 113)
	Factory setting: 100.0
TABLE SELECTION (808) Selection	Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values.
	Options: View meas. table Editor table
	Factory setting: View meas. table
LIN. EDIT MODE (397)	Select the entry mode for the linearisation table.
Selection	Prerequisite: • TABLE SELECTION = Editor table
	 Options: Manual: the container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearisation table. Semiautomatic: the container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. Factory setting:
	Manual

Table 18: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION – on-site operation

Table 18: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION $-$ on-site operation		
Parameter name	Description	
EDITOR TABLE (809) Selection	 Select table. Prerequisite: TABLE SELECTION = editor table Options: New table: enter new linearisation table. Edit measure table: The measuring table is loaded as an editor table so that changes can be made. → See also TAB. SELECTION Continue edit: Edit an editor table that already exists. → See also TABLE EDITOR (770) Factory setting: New table 	
EDITOR TABLE Entry ("Semiautomatic" edit mode) – LINE-NUMB (549) – Y-VAL. (551)	 Enter table in the "Semiautomatic" editing mode. A linearisation table must have at least 2 points and may not have more than 32 points. A point consists of LINE-NUMB, X-VAL. and Y-VAL. For this editing mode, the container is filled or emptied in stages. Example: Enter point for LEVEL MODE = Pressure Linearized LINE-NUMB: confirm value displayed. Y-VAL.: depending on the setting in the LINd. MEASURAND parameter, enter the volume, mass or % value. X-VAL.: the hydrostatic pressure present is displayed and saved by confirming the Y-value. Example: Enter point for LEVEL MODE = Height Linearized LINE-NUMB: confirm value displayed. Y-VAL.: the hydrostatic pressure present is displayed and saved by confirming the Y-value. Example: Enter point for LEVEL MODE = Height Linearized LINE-NUMB: confirm value displayed. Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the volume, mass or % value. Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the volume, mass or % value. X-VAL: the hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, enter the volume, mass or % value. X-VAL: the hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, the measured pressure is converted to a level unit or a % and displayed. The value is saved by confirming the Y-value. Factory setting: LINE-NUMB = 1, X-VAL. = 0.0, Y-VAL. = 0.0 	
EDITOR TABLE Entry ("manual" edit mode) – LINE-NUMB (549) – Y-VAL. (551) – X-VAL. (550)	 Enter table in the "manual" editing mode. A linearisation table must have at least 2 points and may not have more than 32 points. A point consists of a line number, X-value and Y-value. The container neither has to be filled nor emptied for this editing mode. Example: Enter point for LEVEL MODE = Pressure Linearized LINE-NUMB: confirm value displayed. X-VAL.: enter pressure value. Y-VAL.: depending on the setting in the LINd. MEASURAND parameter, enter the related volume, mass or % value. Example: Enter point for LEVEL MODE = Height Linearized LINE-NUMB: confirm value displayed. X-VAL.: the point for LEVEL MODE = Height Linearized LINE-NUMB: confirm value displayed. X-VAL.: the hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, enter a level value or % value. Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the related volume, mass or % value. Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the related volume, mass or % value. 	

EDITOR TABLE (770) Options	Select the function for the editor table. Options: New point, enter point
Options	Options:
Options	 Next point: enter next point. Last input point: jump back to previous point to correct a mistake for example. Accept input table: save editor table as measuring table. This overwrites the old measuring table. Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. Insert point: see example below. Delete point: the current point is deleted. See example below.
	 Example: Add point, in this case between the 4th and 5th point for example Select point 5 via the EDITOR TABLE/LINE NUMB parameter. Confirm current X and Y values with Enter. Using the TABLE EDITOR (770) parameter, select the option "Insert point". Point 5 is displayed for the TABLE EDITOR/LINE NUMB parameter. New values for the X-VAL and Y-VAL parameters.
	 Example: delete point, in this case the 5th point for example Select point 5 via the EDITOR TABLE/LINE NUMB parameter. Using the TABLE EDITOR (770) parameter, select the option "Delete point". The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5.
	Factory setting: Next point
MEASURING TABLE (549) Display	A point of the linearisation table saved (measuring table) appears on the display The parameter first displays the first point of the linearisation table. By entering a line number, you can directly display the corresponding point in the linearisation table.
MEASURING TABLE (717)	Select the function for the measuring table.
Selection	 Options: Next point: view next point of the measuring table. Last input point: view previous point of the measuring table. Abort: cancel measuring table display. Display next parameter.
	Factory setting: Next point
TANK DESCRIPTION (815)	Enter tank description. (max. 32 alphanumeric characters)
Entry	Factory setting:

Table 18: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION – on-site operation



Fig. 39: LINEARISATION function group for digital communication

Table 19: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION – Digital communication	
Parameter name	Description
 Prerequisite: MEASURING MODE = Level (→ see also Page 45). LEVEL MODE = Pressure Linearized or Height Linearized (→ see also Page 68). 	
Note: – See also Page 14 ff, Section	5 "Level measurement".
TANK CONTENT MIN Entry	 Enter the minimum tank contents to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result. Note! If you enter a new value for TANK CONTENT MIN, the value for SET LRV is also changed. Use SET LRV to assign a %-value, volume value or mass value to the lower current value. If you want to assign the lower current value a value other than that for TANK CONTENT MIN, you must enter the desired value for SET LRV. (→ SET LRV, Page 98). For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MIN parameter does not affect the SET LRV parameter. (→ SET LRV, Page 98 and ASSIGN CURRENT, Page 113)
	Factory setting: 0.0

communication			
Parameter name	Description		
TANK CONTENT MAX Entry	 Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result. Note! If you enter a new value for TANK CONTENT MAX, the value for SET URV is also changed. Use SET URV to assign a %-value, volume value or mass value to the upper current value. If you want to assign the upper current value a value other than that for TANK CONTENT MAX, you must enter the desired value for SET URV. (→ SET URV, Page 98.) For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MAX parameter does not affect the SET URV parameter. (→ SET URV, Page 98 and ASSIGN CURRENT, Page 113) 		
	Factory setting: 100.0		
TABLE SELECTION Selection	Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values.		
	Options: • View meas. table • Editor table		
	Factory setting: View meas. table		
LIN. EDIT MODE	Select the entry mode for the linearisation table.		
Selection	Prerequisite:TABLE SELECTION = Editor table		
	 Options: Manual: The container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearisation table. Semiautomatic: the container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. 		
	Factory setting: Manual		
EDITOR TABLE	Select table.		
Selection	Prerequisite:TABLE SELECTION = Editor table		
	 Options: New table: Enter new linearisation table. View meas. table: View saved linearisation table and change points if necessary. Continue edit: 		
	Edit a linearisation table that already exists.		
	 Note! Operating program: If you select the "View meas. table" option, the saved measuring table is loaded in the operating priogram. Use the "LinTab." window to view the entire table, change values if necessary and write the modified table to the device. If you change a value via the X-VAL. or Y-VAL. parameters, the table in the "LinTab. window is not updated. To view the table saved in the device, this table must first be read out of the device. 		
	Factory setting: New table		

Table 19: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION – Digital communication

Table 19: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow LINEARISATION – Digital communication				
Parameter name	Description			
LINE-NUMB Entry	Enter the line number for the linearisation table. A linearisation table must have at least 2 points and may not have more than 32 points.			
	 TABLE SELECTION = View meas. table Via this parameter you can select the point of the linearisation table which should be displayed. TABLE SELECTION = Editor table Enter a point via the LINE-NUMB, X-VAL. and Y-VAL. parameters. → See also this table, parameter description for LIN. EDIT MODE, X-VAL. ("Manual" entry mode), X-VAL. ("Semiautomatic" entry mode) and Y-VAL. Note! In the operating program, you can enter a complete linearisation table in one go via the "Lin -Tab" window 			
X-VAL. ("Manual" entry mode) Entry	Enter the pressure value for the linearisation table. \rightarrow See also LIN. EDIT MODE, LINE-NUMB and Y-VAL.			
	Prerequisite:TABLE SELECTION = Editor table			
X-VAL. ("Semiautomatic" entry mode)	In the "Semiautomatic" entry mode, the container is filled or emptied in stages. The X-VAL. displays the measured hydrostatic pressure.			
	TABLE SELECTION = Editor table			
	Operating program The X-VAL. is saved by confirming the Y-value.			
	HART Handheld Confirm X-VAL. displayed.			
	\rightarrow See also LIN. EDIT MODE, LINE-NUMB and Y-VAL.			
Y-VAL. Entry	 Enter the volume, mass or %-value belonging to the X-VAL. for the linearisation table. Prerequisite: TABLE SELECTION = Editor table 			
	Depending on the setting in the LINd. MEASURAND or COMB. MEASURAND parameters, enter a volume, mass or %-value here. → See also this table, parameter description for LIN. EDIT MODE, LINE-NUMB, X-VAL. ("Manual" entry mode), X-VAL. ("Semiautomatic" entry mode).			
EDITOR TABLE Options	Select the function for the editor table. Prerequisite: TABLE SELECTION = Editor table			
	 Options: Next point: without function Last input point: without function Accept input table: save editor table as measuring table. This overwrites the old measuring table. Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. Insert point: see example below. Delete point: the current point is deleted. See example below. 			
	 Example: Add point, in this case between the 4th and 5th point for example Select point 5 via the LINE NUMB parameter. Using the TABLE EDITOR parameter, select the option "Insert point". Point 5 is displayed for the LINE NUMB parameter. New values for the X-VAL and Y-VAL parameters. 			
	 Example: delete point, in this case the 5th point for example Select point 5 via the LINE NUMB parameter. Using the TABLE EDITOR parameter, select the option "Delete point". The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5. 			
	Factory setting: Next point			

communication				
Parameter name	Description			
ACTIV LIN. TAB. X Display	An X-value of the linearisation table already saved appears on the display You can select a point of the linearisation table via the LINE-NUMB parameter.			
	Prerequisite:TABLE SELECTION = View meas. table			
	∞ Note! In the operating program, you can view the entire saved table in the "Tables" window.			
ACTIV LIN. TAB. Y Display	A Y-value of the linearisation table already saved appears on the display You can select a point of the linearisation table via the LINE-NUMB parameter.			
	Prerequisite:TABLE SELECTION = View meas. table			
	Note! In the operating program, you can view the entire saved table in the "Tables" window.			
TANK DESCRIPTION Entry	Enter tank description. (max. 32 alphanumeric characters)			
	Factory setting:			





Fig. 40: TOTALIZER SETUP function group

Table 20: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow TOTALIZER SETUP				
Parameter name	Description			
Prerequisite: ■ MEASURING MODE = Flow (→ see also Page 45).				
Note: • See also Page 40 ff, Section 6 "Flow measurement".				

Table 20: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow TOTALIZER SETUP						
Parameter name	Description					
TOTALIZER 1 UNIT (398), (666), (664), (662) Selection	 Select unit for totalizer 1. Depending on the setting in the FLOW-MEAS. TYPE parameter (→ Page 93) this parameter offers a list of volume, norm volume, standard volume and mass units. When a new volume or mass unit is selected, totalizer-specific parameters are converted and displayed with the new unit within a unit group. When the flow mode is changed, the totalizer value is not converted. The 3-digit ID number on the on-site display depends on the FLOW-MEAS. TYPE selected: (398): FLOW-MEAS. TYPE "Volume p. cond." (662): FLOW-MEAS. TYPE "Mass" (664): FLOW-MEAS. TYPE "Gas. std. cond." Factory setting: 					
	m ³					
TOT. 1 USER UNIT (627) Entry	Enter text (unit) for customer-specific unit for totalizer 1. You can enter a maximum of eight alphanumeric characters here. → See also FACT. U U. TOTAL. 1. Prerequisite: ■ TOTAUZER 1 UNIT – User unit					
	Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the TOT. 1 USER UNIT parameter. The measured value is displayed with the additional text "User Unit". Factory setting:					
FACT. U. U. TOTAL. 1 (329) Entry	 Enter conversion factor for a customer-specific unit for totalizer 1. The conversion factor must be entered in relation to an appropriate SI unit, e.g. m³ for the "Volume p. cond." FLOW-MEAS. TYPE. → See also TOT. 1 USER UNIT. Prerequisite: TOTALIZER 1 UNIT = User unit Example: You want the measured value to be displayed in "buckets". MEASURED VALUE =1 m3 ≏ 100 buckets Entry TOT. 1 USER UNIT: bucket Entry FACT. U. U. TOTAL. 1: 100 Result: MEASURED VALUE = 100 buckets Factory setting: 1.0 					
NEG. FLOW TOT. 1 (400) Selection	Specify way of countin	g negative flows for totalizer 1.				
	Options Inc. on. neg. flow Dec. on neg. flow Stop on neg. flow	positive flow Total increases Total increases Total increases	negative flow Total increases Total decreases Total remains constant			
	Factory setting:					
	Inc. on neg. flow					
Table 20: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SETTINGS \rightarrow TOTALIZER SETUP						
--	--	--				
Parameter name	Description					
RESET TOTALIZER1 (331) Selection	You reset totalizer 1 to zero with this parameter.					
	Options: Abort (do not reset) Reset					
	Factory setting: Abort					
TOTALIZER 2 UNIT (399), (663), (665), (667)	Select unit for totalizer 2. \rightarrow See also TOTAL 1. ENG. UNIT.					
Selection	The 3-digit ID number on the on-site display depends on the FLOW-MEAS. TYPE selected: - (399): FLOW-MEAS. TYPE "Volume p. cond." - (663): FLOW-MEAS. TYPE "Mass" - (665): FLOW-MEAS. TYPE "Gas. std. cond." - (667): FLOW-MEAS. TYPE "Gas. norm conditions"					
	Factory setting: m ³					
TOT. 2 USER UNIT (628) Entry	Enter text (unit) for customer-specific unit for totalizer 2. \rightarrow See also TOT. 1 USER UNIT.					
	Prerequisite: TOTALIZER 2 UNIT = User unit					
	Factory setting:					
FACT. U. U. TOTAL. 2 (330) Selection	Enter conversion factor for a customer-specific unit for totalizer 2. \rightarrow See also FACT. U. U. TOTAL. 1.					
	Prerequisite: ■ TOTALIZER 2 UNIT = User unit					
	Factory setting: 1.0					
NEG. FLOW TOT. 2 (416) Selection	Specify way of counting negative flows for totalizer 2. \rightarrow See NEG. FLOW TOT. 1.					
	Factory setting: Positive					



Fig. 41: DISPLAY group

Table 21: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow DISPLAY		
Parameter name	Description	
MENU DESCRIPTOR (419) Selection	Specify contents for the main line of the on-site display in the measuring mode. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.1 "On-site display".	
	Options: Main measured value (PV) Main measured value (%) Pressure Flow Level Tank content Current Temperature Error number Totalizer 1 Totalizer 2	
	The selection depends on the measuring mode chosen. Factory setting: Main measured value (PV)	
MAIN DATA FORMAT (688)	Specifies the number of places after the decimal point for the value displayed in the main	
Selection	Ine. \rightarrow See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or (BA00332P) Deltapilot S, Section 5.1 "On-site display".	
	Options: Auto x.x x.xx x.xxx x.xxxx x.xxxx x.xxxx	
	Factory setting: Auto	
ALTERNATE DATA (423) Selection	 Switch on "Alternating display" mode. In this display mode, the on-site display alternates between the following measured values depending on the measuring mode selected. Pressure: Main measured value (PV), Pressure, Temperature and Current Level Standard: Main measured value (PV), Pressure, Level, Tank content, Temperature and Current Level Easy: Main measured value (PV), Pressure, Temperature and Current Flow: Main measured value (PV), Pressure, Flow, Temperature, Current, Totalizer 1 and Totalizer 2 	
	Options: • Off • On Factory setting:	
	Off	
LANGUAGE Selection	 Select the menu language for the on-site display. Note! For on-site operation, the LANGUAGE parameter is arranged directly under GROUP SELECTION (menu path: GROUP SELECTION → LANGUAGE, see also Page 44). Select the menu language for FieldCare via the "Options" menu → "Settings" → "Language" tab → "Tool language" field. 	
	English	

Г

Table 21: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow DISPLAY	
Parameter name	Description
DISPLAY CONTRAST (339) Entry	Adjust contrast of on-site display. You specify the contrast of the display with a number. Changes are only accepted as single steps, i.e. to change the value from "8" to "4", you need to save four times. You can also adjust the contrast of the display by means of the keys on the electronic insert or at the device. \rightarrow See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.2.3 "Function of operating keys". Input range: 413, 4: contrast weaker (brighter), 13: contrast stronger (darker).
	Factory setting: 8
DIGITS SETS (840) Display	This parameter is used to check the correct display of characters and digits on the user interface. If the characters and digits are displayed correctly, this parameter displays the string "0123456789".



Fig. 42: OUTPUT group

Table 22: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow OUTPUT	
Parameter name	Description
OUTPUT CURRENT (254) Display	Displays the current current value.

Table 22: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow OUTPUT		
Parameter name	Description	
CURR. CHARACT. (694), (695), (696), (764) Selection	Select curve of current output. Options:	
	LRV 0 URV	
	Fig. 43: Illustration of current output curves 1 Linear: lower range value = 4 mA, upper range value = 20 mA 2 Pi linear: lower range value = 4 mA, centre er pare 20 mA	
	 2 Divinteal: lower range value = 4 mA, centre of 2ero = 20 mA, upper range value = 4 mA 3 Linear inverse: lower range value = 20 mA, upper range value = 4 mA 4 Bi-linear inverse: lower range value = 20 mA, centre or zero = 4 mA, upper range value = 20 mA LRV Lower range value = 20 mA LRV Upper range value URV Upper range value I Current X Measured value (Pressure/Level/Flow) The "CURR. CHARACT." function refers to the operating mode previously selected. 	
	 The 3-digit ID number on the on-site display depends on the MEASURING MODE selected: (694): MEASURING MODE "Pressure" or MEASURING MODE "Flow" with the setting for LINEAR/SQROOT "Differential pres. (695): MEASURING MODE "Flow" with the setting LINEAR/SQROOT "Flow (square) 	
	 root)" (696): MEASURING MODE "Level", LEVEL MODE "Linear" or "Pressure Linearized" and LEVEL MODE "Height Linearized" with the setting for ASSIGN CURRENT "Level" (764): MEASURING MODE "Level", LEVEL MODE "Height Linearized" with the setting for ASSIGN CURRENT "Tank content" 	
	Factory setting: Linear	
OUTPUT FAIL MODE (388) Entry	Select the current value in the event of an alarm. In the event of an alarm, the current and the bargraph assume the current value specified with this parameter.	
	 Max. alarm (110%): can be set between 2123 mA Hold meas. value: last measured value is kept. Min. alarm (-10%): 3.6 mA 	
	→ See also this table SET MAX. ALARM and Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 8.2.1. "Setting current output for alarm".	
	Factory setting: Max. alarm 110% (22 mA)	

Г

Table 22: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow OUTPUT	
Parameter name	Description
ALT. CURR. OUTPUT (597) Selection	 Set current output if sensor limits undershot or overshot. Options: Normal: the current output assumes the value set via the OUTPUT FAIL MODE and SET MAX. ALARM parameters. Special: Lower sensor limit undershot (E120): Current output = 3.6 mA Upper sensor limit overshot (E115): current output assumes the value set via the SET MAX. ALARM parameter. Attention : when using the case "special", the behavior is limited to an over/underpressure in a range LRL -10%, URL +10%.
	Normal
SET MAX. ALARM (342) Entry	Enter current value for maximum alarm current. → See also OUTPUT FAIL MODE. Input range: 2123 mA
	Factory setting: 22 mA
SET MIN. CURRENT (343) Entry	Enter lower current limit. Some switching units sometimes do not accept currents less than 4.0 mA. Options: • 3.8 mA • 4.0 mA Factory setting:
	3.8 mA
ASSIGN CURRENT (760) Selection	Specify current signal for the "Level" measuring mode. See also SET LRV (→ Page 98) and SET URV (→ Page 98). Prerequisite: MEASURING MODE = Level, LEVEL MODE = Height Linearized Options: Height Tank content Factory setting: Tank content
LINEAR/SQROOT (390) Selection	 Specify current signal for the "Flow" measuring mode. See also SET LRV (→ Page 99) and SET URV (→ Page 100). Prerequisite: MEASURING MODE = Flow Options: Differential pres.: the linear pressure signal is used for the current output. Flow (square root): the root flow signal is used for the current output. The "Flow (square root)" current signal is indicated on the on-site display with a root symbol. Factory setting: Flow (square root)



Fig. 44: TRANSMITTER INFO group

 \rightarrow For the HART DATA function group, see Page 114, Table 23

 \rightarrow For the TRANSMITTER DATA function group, see Page 117, Table 24

 \rightarrow For the PROCESS CONNECTION function group, see Page 117, Table 25

 \rightarrow For the SENSOR DATA function group, see Page 119, Table 26

Table 23: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow HART DATA	
Parameter name	Description
HART VERSION (585) Display	Displays the HART Version.

Table 23: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow HART DATA		
Parameter name	Description	
CURRENT MODE (052)	Set the current mode for HART communication.	
Selection	 Selection via on-site display and FieldCare: Signaling Measured value transmission by the current value Fixed Fixed Fixed current 4.0 mA (multidrop mode) (Measured value transmission only via HART digital communication) 	
	Factory setting: Signaling	
	 Selection via HART Handheld Terminal: enabled Measured value transmission by the current value disabled Fixed current 4.0 mA (multidrop mode) (Measured value transmission only via HART digital communication) 	
	Factory setting: enabled	
BUS ADDRESS (345) Entry	Enter the address for the exchange of data with the HART protocol. (HART 5.0: range 0 to 15, wherein if the address = 0 this produces the "Signaling" setting; HART 6.0/7.0: range 0 to 63)	
	Factory setting: 0	
DEVICE TYPE (351) Display	Displays the device type in decimal numerical format, here Deltabar S: 23 The extended device type is a composition of the manufacturer number (17) and the device type (23).	
	Prerequisite:Deltabar S differential pressure transmitter	
DEVICE TYPE (802) Display	Displays the device type in decimal numerical format, here Cerabar S: 24 The extended device type is a composition of the manufacturer number (17) and the device type (24).	
	Prerequisite:Pressure transmitter Cerabar S	
DEVICE TYPE (002) Display	Displays the device type in decimal numerical format, here Deltapilot S: 26 The extended device type is a composition of the manufacturer number (17) and the device type (26).	
	Prerequisite:Pressure transmitter Deltapilot S	
DEVICE REVISION (699) Display	Displays the device revision	
BURST MODE	Switches "Burst Mode" function on and off.	
Selection	Selection: • On • Off	
	Prerequisite: Digital communication	
BURST OPTION	Use this parameter to specify which command is sent to the master.	
Entry	Voraussetzung: ■ Digital communication	
	Factory setting: 3 (HART commando 3)	
PREAMBLE NUMBER (036) Entry	Enter the number of preambles in the HART protocol. (Synchronisation of the modem modules along a transmission path, each modem module could "swallow" a byte – at least 2 bytes must arrive.)	
	Input range: 220	
	Factory setting: 5	

Table 23: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow HART DATA		
Parameter name	Description	
MANUFACTOR ID (432) Display	Displays the manufacturer number in a decimal numerical format. Here: 17 Endress+Hauser	
HART MESSAGE (271) Entry	Enter message (max. 32 alphanumeric characters). On command from the master, this message is sent via the HART protocol.	
	Factory setting:	
	or as per order specifications	
HART DATE (481)	Enter the date of the last configuration change.	
Entry	Factory setting: DD.MM.YY (date of final test)	
PRIMARY VALUE IS Display	 This parameter displays the following measured value depending on the measuring mode selected: Measuring mode "Pressure": PRESSURE "Level" measuring mode, "Linear" or "Pressure Linearized" level type: LEVEL BEFORE LIN Measuring mode "Level", level type "Height Linearized": TANK CONTENT Measuring mode "Flow": SUPPRESSED FLOW → See also PRIMARY VALUE. Prerequisite: Digital communication 	
PRIMARY VALUE	Displays the primary value.	
Display	\rightarrow See also PRIMARY VALUE IS.	
	Prerequisite:Digital communication	
SECONDARY VAL. IS	Select second process value.	
	You can choose between the following process values depending on the measuring mode selected: - PRESSURE - CORRECTED PRESS. - SENSOR PRESSURE - SENSOR TEMP. - PCB TEMPERATURE - SUPPRESSED FLOW - TOTALIZER 1 - TOTALIZER 2 - LEVEL BEFORE LIN - TANK CONTENT	
	Prerequisite: Digital communication 	
SECONDARY VALUE	Display second process value. \rightarrow See also SECONDARY VAL. IS.	
	Prerequisite: Digital communication 	
THIRD VALUE IS	Select third process value. \rightarrow See also SECONDARY VAL. IS.	
	Prerequisite:Digital communication	
THIRD VALUE	Display third process value. \rightarrow See also SECONDARY VAL. IS.	
	Prerequisite:Digital communication	
4TH VALUE IS	Select fourth process value. \rightarrow See also SECONDARY VAL. IS.	
	Prerequisite:Digital communication	
4TH VALUE	Display fourth process value. \rightarrow See also SECONDARY VAL. IS.	
	Prerequisite:Digital communication	

Parameter name	Description
DEVICE SERIAL No (354) Display	Displays the serial number of the device (11 alphanumeric characters).
ELECTR. SERIAL No (386) Display	Displays the serial number of the main electronics (11 alphanumeric characters).
CUST. TAG NUMBER (055)	Enter TAG number (max. 8 alphanumeric characters).
Entry	Factory setting:
LONG TAG NUMBER (305)	Enter TAG number (max. 32 alphanumeric characters).
Entry	Factory setting:
	or as per order specifications
ADDITIONAL INFO. (272)	Enter tag description (max. 16 alphanumeric characters).
Entry	Factory setting:
	or as per order specifications
DEVICE DESIGN. (350) Display	Displays the device designation and order code.
HARDWARE REV. (266) Display	Displays the revision number of the main electronics e.g.: V02.00
SOFTWARE VERSION (264) Display	Displays the software version e.g.: V02.10
CONFIG RECORDER (352) Display	Displays the configuration counter. This counter is increased by one with each change to a parameter or group. The counter counts to 65535 and then starts again at zero. Changes in the parameters of the DISPLAY function group do not increase the counter.
PCB TEMPERATURE (357) Display	Displays the measured temperature of the main electronics.
ALLOWED MIN. TEMP (358) Display	Displays the lower temperature limit of the main electronics.
ALLOWED MAX. TEMP (359) Display	Displays the upper temperature limit of the main electronics.
DIP STATUS (363) Display	Displays the status of DIP switch 1 on the electronic insert. You can lock or unlock parameters relevant to the measured value with DIP switch 1. If operation is locked by means of the INSERT PIN No. parameter, you can only unlock operation again by means of this parameter. (→ INSERT PIN NO, see Page 126.) → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.9 "Locking/unlocking operation". Display: • On (locking switched on)
	 Off (locking switched off)
	Factory setting: Off (locking switched off)

Table 24: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow TRANSMITTER DATA

CONNECTION	
Parameter name	Description
Pmax PROC. CONN. (570) Entry	For entering and displaying the maximum permitted pressure of the process connectio Factory setting: In accordance with nameplate data (\rightarrow see also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 2.1.1 nameplate)

Table 25: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow PROCESS CONNECTION		
Parameter name	Description	
PROC. CONN. TYPE (482) Selection	For selecting and displaying the process connection type. Options: Not used Unknown Special Oval flange Thread female Thread male Flange Remote seal	
MAT. PROC. CONN. + (360) Selection	For selecting and displaying the material of the process connection (P+). → See also parameter description for MAT. PROC. CONN Options: Not used Unknown Special Steel 304 st. steel 316 st. steel Alloy C Monel Tantalum Titanium PTFE (Teflon) 316L st. steel PVC Inconel PVDF ECTFE Factory setting: As per order specifications	
MAT. PROC. CONN (361) Selection	 For selecting and displaying the material of the process connection (P−). → See also parameter description for MAT. PROC. CONN. + Prerequisite: Deltabar S differential pressure transmitter 	
SEAL TYPE (362) Selection	For selecting and displaying the material of the process seal. Options: Not used Unknown Special FKM Viton NBR EPDM Urethane IIR Kalrez FKM Viton oxyg CR MVQ PTFE glass PTFE graphite PTFE graphite PTFE oxygen Copper Copper f. oxygen Factory setting: As per order specifications	
BOLTS MATERIAL	For selecting and displaying the material of the bolts.Prerequisite:Digital communication	

CONNECTION	
Parameter name	Description
NUTS MATERIAL	For selecting and displaying the material of the nuts.
	Prerequisite:
	Digital communication
DRAIN VENT MAT.	For selecting and displaying the material of the vent valves.
	Prerequisite:Digital communication
DRAIN VENT POS.	For selecting and displaying the position of the vent valves.
	Prerequisite:Digital communication
THREAD	For selecting and displaying the process connection thread.
	Prerequisite:Digital communication
MOUNTING THREAD	For selecting and displaying the ways of securing the device.
	Prerequisite:Digital communication
REMOTE SEAL +	For selecting and displaying the diaphragm seal type on the positive side.
	Prerequisite:Digital communication
REMOTE SEAL –	For selecting and displaying the diaphragm seal type on the negative side.
	Prerequisite:Digital communication
DIAPHRAG. MAT. +	For selecting and displaying the material of the process isolating diaphragm on the positive side.
	Prerequisite:Digital communication
DIAPHRAG. MAT. –	For selecting and displaying the material of the process isolating diaphragm on the negative side.
	Prerequisite:Digital communication
NR OF REMOTE SEAL	For selecting and displaying the number of diaphragm seals.
	Prerequisite:Digital communication
FILL FLUID	For selecting and displaying the diaphragm seal fill fluid.
	Prerequisite:Digital communication

Table 25: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow PROCESS	
CONNECTION	

Table 26: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow TRANSMITTER INFO \rightarrow SENSOR DATA (all measuring modes)		
Parameter name	Description	
SENSOR SER. No. (250) Display	Displays the serial number of the sensor (11 alphanumeric characters).	
PRESS. SENS LOLIM (484) Display	Displays the lower measuring limit of the sensor.	
PRESS. SENS HILIM (485) Display	Displays the upper measuring limit of the sensor.	
MINIMUM SPAN (591) Display	Displays the smallest possible span.	

(all measuring modes)			
Parameter name	Description		
SENSOR MEAS.TYPE (581) Display	Displays the sensor type.		
	 Deltabar S = differential Cerabar S with gauge pressure sensor = relative Cerabar S with absolute pressure sensor = absolute Deltapilot S = relative 		
Pmin SENS. DAMAGE (251) Display	Displays the minimum permissible absolute pressure of the sensor (vacuum-proofing).		
Pmax SENS. DAMAGE (252) Display	DAMAGE (252) Displays the maximum permissible absolute pressure of the sensor (overpressure- proofing).		
MAT. MEMBRANE (365)	Displays the material of the process isolating diaphragm.		
Display	Factory setting: As per version in the order code → For Deltabar S, see Technical Information TI00382P, for Cerabar S, see Technical Information TI00383P or for Deltapilot S, see Technical Information TI00416P, "Ordering information" section.		
FILLING FLUID (366) Display	Displays the filling fluid.		
Tmin SENSOR (368) Display	Displays the lower nominal temperature limit of the sensor.		
Tmax SENSOR (369) Display	Displays the upper nominal temperature limit of the sensor.		
SENS H/WARE REV (487) Display	Displays the revision number of the sensor hardware. e.g.: 1		



- Fig. 45: PROCESSINFO group
 - \rightarrow For the PROCESS VALUES function group, "Pressure" measuring mode, see Page 121, Table 27
 - \rightarrow For the PROCESS VALUES function group, "Level" measuring mode, see Page 122, Table 28
 - \rightarrow For the PROCESS VALUES function group, "Flow" measuring mode, see Page 123, Table 29
 - → For the PEAK HOLD INDICATOR function group, see Page 124, Table 30

Table 27: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Pressure"				
Parameter name	Description			
Prerequisite:MEASURING MODE = pre	ssure (\rightarrow see also Page 45).			
MEASURED VALUE (679)	Displays the measured value In the "Pressure" measuring mode, this value corresponds to the PRESSURE parameter.			
	Prerequisite: Digital communication 			
	On-site operation:For on-site operation, the MEASURED VALUE parameter is displayed on the 1st level.			

Table 27: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Pressure"					
Parameter name	Description				
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.				
	SENSOR CORRECTED PRESSURE PRESSURE PRESS.				
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. \rightarrow See also PRESSURE diagram.				
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. \rightarrow See also PRESSURE diagram.				
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This temperature can deviate from the process temperature.				
MEAS. VAL. TREND (378) Display	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant				

fable 27: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Pressure"							
Parameter name	Description						
	D						

Table 28: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Level"			
Parameter name	Description		
Prerequisite: ■ MEASURING MODE = Level (→ see also Page 45).			
MEASURED VALUE (679)	Displays the measured value In the "Level" measuring mode with "Linear" or "Pressure Linearized" level type, this value corresponds to the LEVEL BEFORE LIN parameter In the "Level" measuring mode with "Height Linearized" level type, this value corresponds to the TANK CONTENT parameter.		
	Prerequisite: Digital communication 		
	On-site operation:For on-site operation, the MEASURED VALUE parameter is displayed on the 1st level.		
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.		
CORRECTED PRESS. (434)	Displays the measured pressure after sensor trim and position adjustment and before		
Display	damping. \rightarrow See also PRESSURE diagram.		
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. \rightarrow See also PRESSURE diagram.		
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This temperature can deviate from the process temperature.		

Г

Table 28: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Level"		
Parameter name	Description	
MEAS. VAL. TREND (378) Display	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant	
LEVEL BEFORE LIN (050) Display	Displays the level value prior to linearisation.	
	Prerequisite: ■ LEVEL MODE = Linear or Height Linearized	
	Depending on the setting for the LIN. MEASURAND or COMB. MEASURAND parameter, this parameter displays the current level in % or in a unit of level.	
TANK CONTENT (370) Display	Displays the level value after linearisation.	
	Prerequisite:LEVEL MODE = Pressure Linearized or Height Linearized	
	Depending on the settings for the LINd. MEASURAND or COMB. MEASURAND parameter, the current tank content is displayed in % or in a unit of volume or mass. This value corresponds to the MEASURED VALUE.	

	Depending on the settings for the LINd. MEASURAND or COMB. MEASURAND parameter, the current tank content is displayed in % or in a unit of volume or mass. This value corresponds to the MEASURED VALUE.		
Table 29: (GROUP SELEC	TION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Flow"		
Parameter name	Description		
Prerequisite: • MEASURING MODE = F.	low (\rightarrow see also Page 45).		
MEASURED VALUE (679)	Displays the measured value In the "Flow" measuring mode, this value corresponds to the SUPPRESSED FLOW parameter.		
	Prerequisite: Digital communication 		
	On-site operation:For on-site operation, the MEASURED VALUE parameter is displayed on the 1st level.		
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.		

	Pressure -
Sensor Sensor trim	Position adjust- ment Damping P - Level Current output
	Flow
SENSOR PRESSURE	CORRECTED PRESSURE PRESS.

	P01-xMx7xxxx-05-xx-xx-xx-011
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. \rightarrow See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. \rightarrow See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This temperature can deviate from the process temperature.
MEAS. VAL. TREND (378) Display	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant
SUPPRESSED FLOW (375) Display	Displays the current flow. Depending on the flow mode selected (\rightarrow FLOW-MEAS. TYPE), a volume flow, mass flow, standard volume flow or corrected volume flow is displayed.

Table 29: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PROCESS VALUES "Flow"		
Parameter name	Description	
TOTALIZER 1 (652) Display	Displays the total flow value of totalizer 1. You can reset the value with the RESET TOTALIZER 1 parameter. The TOTAL. 1 OVERFLOW parameter displays the overflow.	
	Example: The value 123456789 m ³ is displayed as follows: - TOTALIZER 1: 3456789 m ³ - TOTAL. 1 OVERFLOW: 12 E7	
TOTAL. 1 OVERFLOW (655) Display	Displays the overflow value of totalizer 1. \rightarrow See also TOTALIZER 1.	
TOTALIZER 2 (657) Display	Displays the total flow value of totalizer 2. You cannot reset totalizer 2. The TOTAL. 2 OVERFLOW parameter displays the overflow. \rightarrow See also example for TOTALIZER 1.	
TOTAL. 2 OVERFLOW (658) Display	Displays the overflow value of totalizer 2. \rightarrow See also TOTALIZER 2 and example for TOTALIZER 1.	

Table 30: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow PROCESSINFO \rightarrow PEAK HOLD INDICATOR		
Parameter name	Description	
COUNTER:P > Pmax (380) Display	Displays the overpressure counter of the sensor The limit value is: upper nominal pressure limit of sensor + 10 % of upper nominal pressure limit of sensor. You can reset this counter by means of the RESET PEAKHOLD parameter.	
MAX. MEAS. PRESS. (383) Display	Displays the largest measured pressure value (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.	
COUNTER P < Pmin (467) Display	Displays the vacuum pressure counter of the sensor The limit value is: lower nominal pressure limit of sensor – 10 % of upper nominal pressure limit of sensor. You can reset this counter by means of the RESET PEAKHOLD parameter.	
MIN. MEAS. PRESS. (469) Display	Displays the smallest measured pressure value (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.	
COUNTER:T > Tmax (404) Display	Displays the number of times the specified temperature range of the sensor has been overshot. You can reset this counter by means of the RESET PEAKHOLD parameter.	
MAX. MEAS. TEMP. (471) Display	Displays the largest measured temperature in the sensor (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.	
COUNTER:T < Tmin (472) Display	Displays the number of times the specified temperature range of the sensor has been undershot. You can reset this counter by means of the RESET PEAKHOLD parameter.	
MIN. MEAS. TEMP. (474) Display	Displays the smallest measured temperature in the sensor (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.	
PCB COUNT:T > Tmax (488) Display	Displays the number of times the specified temperature range of the electronics has been overshot.	
PCB MAX. TEMP. (490) Display	Displays the largest electronics temperature measured.	
PCB COUNT:T < Tmin (492) Display	Displays the number of times the specified temperature range of the electronics has been undershot.	
PCB MIN. TEMP. (494) Display	Displays the smallest electronics temperature measured.	

Table 20.	CDOUD SELECTION	ODEDATINIC MENILI	DDOCESSINEO	DEAK HOLD INDICATOR
Table 30.	GROUP SELECTION -) OF ERATING WIENU	\rightarrow r ROCESSINFO \rightarrow	FLAK HOLD INDICATOR

Parameter name	Description
RESET PEAKHOLD (382) Selection	This parameter lists all the peak hold indicator parameters that can be reset. You can select the peak hold indicators you want to reset.
	Options: None Max. pressure Min. pressure Pmax history Pmin history Max. temp. Min. temp. Tmax history Tmin history Reset all Factory setting: None



 \rightarrow For the OPERATING group, see Page 126, Table 31

 \rightarrow For the SIMULATION function group, see Page 127, Table 32

 \rightarrow For the MESSAGES function group, see Page 128, Table 33

 \rightarrow For the USER LIMITS function group, see Page 130, Table 34

Table 31: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow OPERATING		
Parameter name	Description	
ENTER RESET CODE (047) Entry	Reset parameters completely or partially to factory values or delivery status. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.10 "Factory setting" (reset).	
	Factory setting: 0	
OPERATING HOURS (409) Display	Displays the hours of operation. This parameter cannot be reset.	
INSERT PIN NO (048) Entry	 For entering a code to lock or unlock operation. Note! The	
	 site display or using remote operation. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.9 "Locking/unlocking operation". Options: Lock: enter a number between 09999 which is ≠100. 	
	 Unlock: enter the number 100. Factory setting: 100 	
HistoROM AVAIL. (831) Display	Indicates whether the optional HistoROM®/M-DAT memory module is connected to the electronic insert. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.5 "HistoROM®/M-DAT (optional)".	
	 Options: Yes (HistoROM[®]/M-DAT is attached to the electronic insert) No (HistoROM[®]/M-DAT is not attached to the electronic insert) 	
DOWNLOAD SELECT (014) Options	Select download function from HistoROM to device. The selection has no effect on an upload from the device to the HistoROM.	
	 A HistoROM[®]/M-DAT is attached to the electronic insert (HistoROM AVAIL. = yes) 	
	 Options: Configuration copy: For this option, all parameters apart from the DEVICE SERIAL No, DEVICE DESIGN., CUST. TAG NUMBER, LONG TAG NUMBER, ADDITIONAL INFO., BUS ADDRESS, CURRENT MODE and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. Device replacement: With this option, all parameters except for DEVICE SERIAL No, DEVICE DESIGN. and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION ADJUSTMENT and PROCESS CONNECTION group are overwritten. Electronics replace: With this option, all parameters except for the parameters of the POSITION ADJUSTMENT group are overwritten. Eactory setting: 	
	Copy config. (if HistoROM [®] /M-DAT is attached to the electronic insert)	

Table 31: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow OPERATING		
Parameter name	Description	
HistoROM CONTROL (832) Selection	For selecting the direction for copying the data. \rightarrow See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.5. "HistoROM [®] /M-DAT (optional)".	
	 Prerequisite: A HistoROM[®]/M-DAT is attached to the electronic insert (HistoROM AVAIL. = yes) 	
	Options: ■ Abort ■ HistoROM → Device ■ Device → HistoROM	
	Factory setting: Abort (if HistoROM [®] /M-DAT is connected to the electronic insert)	

Parameter name	Description
SIMULATION MODE (413) Selection	Switch on simulation and select simulation type. Any simulation running is switched off if the measuring mode or level type is changed.
	 Options: None Pressure, → see also this table parameter description for SIM. PRESSURE Flow (only differential pressure transmitter), → see also this table parameter description for SIM. FLOW VALUE Level, → see also this table parameter description for SIM. LEVEL Tank content, → see also this table parameter description for SIM. TANK CONT. Current, → see also this table parameter description for SIM. CURRENT Note: The "Flow" measuring mode has to be selected in the LINEAR/SQROOT parameter to ensure the current output corresponds to the simulated flow value. Alarm/warning, , → see also this table parameter description for SIM. ERROR NO.
	 Sensor Sensor Position adjust- trim Sensor Bensor Position adjust- ment Damping Performance Development Development Development Simulation value <
	None
SIM. PRESSURE (414) Entry	Enter simulation value. \rightarrow See also SIMULATION MODE.
	<pre>Prerequisite: SIMULATION MODE = Pressure</pre>
	Factory setting: Current pressure measured value
SIM. FLOW VALUE (639) Entry	Enter simulation value. \rightarrow See also SIMULATION MODE.
	 Prerequisite: MEASURING MODE = Pressure and SIMULATION MODE = Flow MEASURING MODE = Flow and SIMULATION MODE = Flow

Table 32: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow DIAGNOSTICS \rightarrow SIMULATION		
Parameter name	Description	
SIM. LEVEL (714) Entry	Enter simulation value. \rightarrow See also SIMULATION MODE.	
	Prerequisite:MEASURING MODE = Level and SIMULATION MODE = Level	
SIM. TANK CONT. (715) Entry	Enter simulation value. \rightarrow See also SIMULATION MODE.	
	 Prerequisites: MEASURING MODE = Level, LEVEL MODE = Pressure Linearized and SIMULATION MODE = Tank content MEASURING MODE = Level, LEVEL MODE = Height Linearized and SIMULATION MODE = Tank content 	
SIM. CURRENT (270) Entry	Enter simulation value. \rightarrow See also SIMULATION MODE.	
	Prerequisite: ■ SIMULATION MODE = Current value	
	Factory setting: Current value	
SIM. ERROR NO. (476) Entry	Warning! The SIMULATION parameter overwrites fault states (alarm/warning) that are actually present. When the simulation is ended, the fault states (alarm/warning) still persist but are no longer displayed! When the device is restarted it returns to its fault state.	
	Enter message number. → See also SIMULATION MODE. → See also these Operating Instructions, Section 8.1 "Messages", "Code" table column.	
	Prerequisite: SIMULATION MODE = Alarm/Warning 	
	Factory setting: 613 (simulation active)	

Table 33: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow DIAGNOSTICS \rightarrow MESSAGES		
Parameter name	Description	
ALARM STATUS (046) Display	Displays the current messages present. \rightarrow See also these Operating Instructions, Section 8.1. "Messages" and Section 8.3 "Confirming messages".	
	 On-site display The measured value display shows the message with the highest priority. The ALARM STATUS parameter shows all the messages in descending order of priority. You can scroll through all the messages present with the + or - key. 	
	Operating programThe "Status" field and the ALARM STATUS parameter show the message with the highest priority.	
LAST DIAG. CODE (564) Display	 Displays the last messages that occurred and were eliminated. Note! On-site display: you can scroll through the last 15 messages with the + or - key. Digital communication: the last message appears on the display. Use the RESET ALL ALARMS parameter to delete the messages listed in the LAST DIAG. CODE parameter. 	
ACK. ALARM MODE (401) Selection	Switch on acknowledge alarm mode. \rightarrow See also ACK. ALARM.	
	Options: • On • Off	
	Factory setting: Off	

Table 33: (GROUP SELECT	(ION \rightarrow) OPERATING MENU \rightarrow DIAGNOSTICS \rightarrow MESSAGES
Parameter name	Description
ACK. ALARM (500) Selection	Acknowledge alarm.
	Prerequisite: ■ ACK. ALARM MODE = on
	Options: Abort Confirm
	The cause of the alarm must be eliminated, the message must be acknowledged via the ACK. ALARM parameter and, where applicable, the ALARM DISPL. TIME (\rightarrow Page 129) has to have elapsed before the device starts measuring again following an alarm. \rightarrow See also these Operating Instructions, Section 8.3 "Confirming messages".
	Factory setting: Abort
RESET ALL ALARMS (603)	Use this parameter to reset all the messages of the LAST DIAG. CODE parameter.
Selection	Options: Abort Confirm
	Factory setting: Abort
ERROR No. Entry	For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). Enter the corresponding message number for this parameter. \rightarrow See also SELECT ALARMTYPE. \rightarrow See also these Operating Instructions, Section 8.1 "Messages" and Section 8.2 "Response of outputs to errors".
	Prerequisite: Digital communication
SELECT ALARMTYPE (595) – Entry (600) – Selection	For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). \rightarrow See also ERROR No. \rightarrow See also these Operating Instructions, Section 8.2 "Response of outputs to errors".
	 Options: Alarm (A): output current assumes a defined value. Warning (W): device continues measuring
	On-site operation:
	1. Enter the corresponding message number for ERROR No. field.
	2. Select "Alarm" or "Warning" option.
	Digital communication:
	1. Enter the corresponding message number via the ERROR No. parameter.
	2. Use the SELECT ALARMTYPE parameter to select the "Alarm" or "Warning" option.
ALARM DELAY (336)	Enter alarm response time for all "Error" messages.
Entry	Note! There is no alarm if the cause of the error is eliminated within the alarm delay time.
	Input range: 0100 s
	Factory setting: 0.0 s
ALARM DISPL. TIME (480) Entry	Enter alarm display time for all "Error" messages. Once the cause of the error is rectified, the alarm display time starts running.
	Note! The following applies if the setting for ACK. ALARM MODE = on: If an alarm appears and the alarm display time elapses before the alarm has been acknowledged, the message will be cleared once it has been acknowledged. → See also these Operating Instructions, Section 8.3 "Confirming messages".
	Input range: 0999.9 s
	Factory setting: 0.0 s

Table 34: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow DIAGNOSTICS \rightarrow USER LIMITS		
Parameter name	Description	
Pmin ALARM WINDOW (332) Entry	Customer-specific process monitoring – enter lower pressure limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E730 and Section 8.2. "Response of outputs to errors".	
	Factory setting: Low sensor limit ■1.1 (→ For the low sensor limit, see PRESS. SENS LOLIM.)	
Pmax ALARM WINDOW (333) Entry	Customer-specific process monitoring – enter upper pressure limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E731 and Section 8.2. "Response of outputs to errors".	
	Factory setting: High sensor limit ■1.1 (→ For the high sensor limit, see PRESS. SENS HILIM.)	
Tmin ALARM WINDOW (334) Entry	Customer-specific process monitoring – enter lower temperature limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E732 and Section 8.2. "Response of outputs to errors".	
	Factory setting: Lower sensor temperature application limit -10 K (\rightarrow For the lower temperature application limit, see Tmin SENSOR)	
Tmax ALARM WINDOW (335) Entry	Customer-specific process monitoring – enter upper temperature limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E733 and Section 8.2. "Response of outputs to errors".	
	Factory setting: Upper sensor temperature application limit $+10$ K (\rightarrow For the upper temperature application limit, see Tmax SENSOR)	



Fig. 47: SYSTEM 2 group

Table 35: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow SERVICE \rightarrow SYSTEM 2		
Parametername	Beschreibung	
CURR. TRIM 4mA (045) Entry	Enter current value for the lower point (4 mA) of the current output trim line. You can adapt the current output to the transmission conditions with this parameter and CURR. TRIM 20mA.	
	Perform current trim for the lower point as follows:	
	1. Select SIMULATION group. (Menu path: (GROUP SELECTION) \rightarrow OPERATING MENU \rightarrow DIAGNOSTICS \rightarrow SIMULATION)	
	2. Select option "Current" via SIMULATION parameter.	
	3. Enter "4 mA" for SIM. CURRENT parameter.	
	4. Select SYSTEM 2 group. (Menu path: (GROUP SELECTION) → OPERATING MENU → SERVICE)	
	5. Enter the current value measured with the switching unit for the CURR. TRIM 4mA parameter.	
	Input range: Measured current ±0.2 mA	
	Factory setting: 4 mA	
CURR. TRIM 20mA (042) Entry	Enter current value for the upper point (20 mA) of the current output trim line. You can adapt the current output to the transmission conditions with this parameter and CURR. TRIM 4mA.	
	Perform current trim for the upper point as follows:	
	 Select SIMULATION group. (Menu path: (GROUP SELECTION) → OPERATING MENU → DIAGNOSTICS → SIMULATION) 	
	2. Select option "Current" via SIMULATION parameter.	
	3. Enter "20 mA" for SIM. CURRENT parameter.	
	 Select SYSTEM 2 group. (Menu path: (GROUP SELECTION) → OPERATING MENU → SERVICE) 	
	5. Enter the current value measured with the switching unit for the CURR. TRIM 20mA parameter.	
	Input range: Measured current ±0.2 mA	
	Factory setting: 20 mA	
OFFSET 4mA TRIM (043) Display	Displays the difference between 4 mA and the value entered for the CURRENT TRIM 4mA parameter.	
	Factory setting: 0	
OFFSET 20mA TRIM (044) Display	Displays the difference between 20 mA and the value entered for the CURRENT TRIM 20mA parameter.	
	Factory setting: 0	

8 Trouble-shooting

8.1 Messages

The following table lists all the possible messages that can occur.

The device differentiates between the error types "Alarm", "Warning" and "Error". You may specify whether the instrument should react as if for an "Alarm" or "Warning" for "Error" messages. \rightarrow See "Error type/NA 64" column and parameter descriptions for ERROR No. and SELECT

ALARMTYPE (\rightarrow Page 129).

In addition, the "Error type/NA 64" column classifies the messages in accordance with NAMUR Recommendation NA 64:

- Break down: indicated with "B"
- Maintenance need: indicated with "C" (check request)
- Function check: indicated with "I" (in service)

Error message display on the on-site display:

- The measured value display shows the message with the highest priority. \rightarrow See "Priority" column.
- The ALARM STATUS (→ Page 128) parameter shows all the messages present in descending order of priority. You can scroll through all the messages present with the □-key or +-key.

Message display via the digital communication:

• The ALARM STATUS (\rightarrow Page 128) parameter shows the message with the highest priority. \rightarrow See "Priority" column.

Note!

- If the device detects a defect in the on-site display during initialization, special error messages are generated. → For the error messages, see Page 139, Section 8.1.1 "On-site display error messages".
- For support and further information, please contact Endress+Hauser Service.
- \rightarrow See also Section 8.4, 8.5 and 8.6.

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
101 (A101)	Alarm B	Failure (F)	B>Sensor electronic EEPROM error	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). This message normally only appears briefly. 	 Wait a few minutes. Restart the device. Perform reset (Code 62). Block off electromagnetic effects or eliminate source of disturbance. 	17
				 Sensor defect. 	 Replace sensor. 	
102 (W102)	Warning C	Maintenance request (M)	C>Checksum error in EEPROM: peakhold segment	 Main electronics defect. Correct measurement can continue as long as you do not need the peak hold indicator function. 	 Replace main electronics. 	53
106 (W106)	Warning C	Funktion check (C)	C>Downloading - please wait	– Downloading.	- Wait for download to complete.	52

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
110 (A110)	Alarm B	Failure (F)	B>Checksum error in EEPROM: configuration segment	 The supply voltage is disconnected when writing. 	 Reestablish supply voltage. Perform reset (Code 7864) if necessary. Carry out calibration again. 	6
				 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). 	 Block off electromagnetic effects or eliminate sources of disturbance. 	
				- Main electronics defect.	- Replace main electronics.	
113 (A113)	Alarm B	Failure (F)	B>ROM failure in transmitter electronic	– Main electronics defect.	- Replace main electronics.	1
115 (E115)	Error B	Out of specification	B>Sensor overpressure	– Overpressure present.	 Reduce pressure until message disappears. 	29
	setting: Warning C	(3)		 Sensor defect. 	 Replace sensor. 	
116 (W116)	Warning	Maintenance	C>Download error, repeat	– The file is defect.	– Use another file.	36
	С	request (M)	download	 During the download, the data are not correctly transmitted to the processor, e.g. because of open cable connections, spikes (ripple) on the supply voltage or electromagnetic effects. 	 Check cable connection PC – transmitter. Block off electromagnetic effects or eliminate sources of disturbance. Perform reset (Code 7864) and carry out calibration again. 	
120 (E120)	Error	Out of	B>Sensor low pressure	- Pressure too low.	 Increase pressure until message 	30
	B factory setting: Warning C	specification (S)		 Sensor defect. 	disappears. Replace sensor. 	
121 (A121)	Alarm B	Failure (F)	B>Checksum error in factory segment of EEPROM	– Main electronics defect.	 Replace main electronics. 	5
122 (A122)	Alarm B	Failure (F)	B>Sensor not connected	 Cable connection sensor –main electronics disconnected. 	 Check cable connection and repair if necessary. 	13
				 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). 	 Block off electromagnetic effects or eliminate source of disturbance. 	
				- Main electronics defect.	- Replace main electronics.	
				 Sensor defect. 	 Replace sensor. 	
130 (A130)	Alarm B	Failure (F)	B>EEPROM is defect.	– Main electronics defect.	 Replace main electronics. 	10
131 (A131)	Alarm B	Failure (F)	B>Checksum error in EEPROM: min/max segment	- Main electronics defect.	 Replace main electronics. 	9
132 (A132)	Alarm B	Failure (F)	B>Checksum error in totalizer EEPROM	– Main electronics defect.	– Replace main electronics.	7
133 (A133)	Alarm B	Failure (F)	B>Checksum error in History EEPROM	– An error occurred when writing.	 Perform reset (Code 7864) and carry out calibration again. 	8
				- Main electronics defect.	 Replace electronics. 	
602 (W602)	Warning C	Funktion check (C)	C>Linearisation curve not monotone	 The linearisation table is not monotonic increasing or decreasing. 	 Add to linearisation table or perform linearisation again. 	57

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
604 (W604)	Warning C	Funktion check (C)	C>Linearisation table not valid. Less than 2 points or points too close	Note! From software version "02.10.xx" or Y-points.	wards, there is no min. span for the	
				 The linearisation table consists of less than 2 points. 	 Add to linearisation table. If necessary, perform linearisation again. 	58
				 At least 2 points in the linearisation table are too close together. A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN. 	 Correct linearisation table and accept again. 	
613 (W613)	Warning I	Funktion check (C)	I>Simulation is active	 Simulation is switched on, i.e. the device is not measuring at present. 	 Switch off simulation. 	60
620 (E620)	Error C Factory setting: Warning C	Out of specification (S)	C>Current output out of range	 The current is outside the permitted range 3.8 to 20.5 mA. The pressure applied is outside the set measuring range (but within the sensor range). Loose connection at sensor cable 	 Check pressure applied, reconfigure measuring range if necessary (→ See also these Operating Instructions, chapter 4 to 6.) Perform reset (Code 7864) and carry out calibration again. Wait a short period of time and tighten the connection, or avoid 	49
					loose connection.	
700 (W700)	Warning C	Maintenance request (M)	C>Last configuration not stored	 An error occurred when writing or reading configuration data or the power supply was disconnected. 	 Perform reset (Code 7864) and carry out calibration again. 	54
				– Main electronics defect.	 Replace main electronics. 	
701 (W701)	Warning C	Funktion check (C)	C>Measuring chain config. exceeds sensor range	 The calibration carried out would result in the sensor nominal operating range being undershot or overshot. 	 Carry out calibration again. 	50
702 (W702)	Warning C	Maintenance request (M)	C>HistoROM data not consistent.	 Data were not written correctly to the HistoROM, e.g. if the HistoROM was detached during the writing process. 	 Repeat upload. Perform reset (Code 7864) and carry out calibration again. 	55
				 HistoROM does not have any data. 	 Copy suitable data to the HistoROM. (→ See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.5.1 "Copying configuration data".) 	
703 (A703)	Alarm B	Failure (F)	B>Measurement error	– Fault in the main electronics.	 Briefly disconnect device from the power supply. 	22
				- Main electronics defect.	 Replace main electronics. 	

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
704 (A704)	Alarm B	Funktion check (C)	B>Measurement error	- Fault in the main electronics.	 Briefly disconnect device from the power supply. 	12
				– Main electronics defect.	- Replace main electronics.	
705 (A705)	Alarm B	Failure (F)	B>Measurement error	- Fault in the main electronics.	 Briefly disconnect device from the power supply. 	21
				– Main electronics defect.	- Replace main electronics.	
706 (W706)	Warning C	Maintenance request (M)	C>Configuration in HistoROM and device not identical	 Configuration (parameters) in the HistoROM and in the device is not identical. 	 Copy data from the device to the HistoROM. Copy data from the HistoROM to the device. The message remains if the HistoROM and the device have different software versions. The message goes out if you copy the data from the device to the HistoROM. Device reset codes such as 7864 do not have any effect on the HistoROM. That means that if you do a reset, the configurations in the HistoROM and in the device may not be the same. → See also Operating Instructions BA00270P (Deltabar S), BA00332P (Deltapilot S) Section 5.5 1. "Conving configuration data" 	59
707 (A707)	Alarm B	Funktion check (C)	B>X-VAL. of lin. table out of edit limits.	 At least one X-VALUE in the linearisation table is either below the value for HYDR. PRESS MIN. or MIN. LEVEL or above the value for HYDR. PRESS. MAX. or LEVEL MAX. 	 Carry out calibration again. (→ See also these Operating Instructions, chapter 5.) 	38
710 (W710)	Warning C	Funktion check (C)	B>Set span too small. Not allowed.	 Values for calibration (e.g. lower range value and upper range value) are too close together. 	 Adjust calibration to suit sensor. (→ See also Page 119, parameter description MINIMUM SPAN.) 	51
				 The sensor was replaced and the customer-specific configuration does not suit the sensor. 	 Adjust calibration to suit sensor. Replace sensor with a suitable sensor. 	
				– Unsuitable download carried out.	 Check configuration and perform download again. 	
711 (A711)	Alarm B	Funktion check (C)	B>LRV or URV out of edit limits	 Lower range value and/or upper range value undershoot or overshoot the sensor range limits. 	 Reconfigure lower range value and/or upper range value to suit the sensor. Pay attention to position factor. 	37
				 The sensor was replaced and the customer-specific configuration does not suit the sensor. 	 Reconfigure lower range value and/or upper range value to suit the sensor. Pay attention to position factor. Replace sensor with a suitable sensor. 	
				 Unsuitable download carried out. 	 Check configuration and perform download again. 	
713 (A713)	Alarm B	Funktion check (C)	B>100% POINT level out of edit limits	 The sensor was replaced. 	 Carry out calibration again. 	39

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
715 (E715)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor over temperature	 The temperature measured in the sensor is greater than the upper nominal temperature of the sensor. (→ See also Page 120, parameter description Tmax SENSOR.) 	 Reduce process temperature/ ambient temperature. 	32
				- Unsuitable download carried out.	 Check configuration and perform download again. 	
716 (E716)	Error B Factory setting: Alarm B	Failure (F)	B>Process isolating diaphragm broken	– Sensor defect.	 Replace sensor. Reduce pressure. 	24
717 (E717)	Error C Factory setting:	Out of specification (S)	C>Transmitter over temperature	 The temperature measured in the electronics is greater than the upper nominal temperature of the electronics (+88 °C). 	 Reduce ambient temperature. 	34
	warning C			- Unsuitable download carried out.	 Check configuration and perform download again. 	
718 (E718)	Error C Factory setting:	Out of specification (S)	C>Transmitter under temperature	 The temperature measured in the electronics is smaller than the lower nominal temperature of the electronics (-43 °C). 	 Increase ambient temperature. Insulate device if necessary. 	35
	Warning C			- Unsuitable download carried out.	 Check configuration and perform download again. 	
719 (A719)	Alarm B	Funktion check (C)	B>Y-VAL of lin. table out of edit limits	 At least on Y-VALUE in the linearisation table is below the MIN. TANK CONTANT or above the MAX. TANK CONTENT. 	 Carry out calibration again. (→ See also Operating Instructions BA00274P, chapter 5 or these Operating Instructions, Page 2.) 	40
720 (E720)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor under temperature	 The temperature measured in the sensor is smaller than the lower nominal temperature of the sensor. (→ See also Page 120, parameter description Tmin SENSOR.) 	 Increase process temperature/ ambient temperature. 	33
				- Unsuitable download carried out.	 Check configuration and perform download again. 	
				 Loose connection at sensor cable 	 Wait a short period of time and tighten the connection, or avoid loose connection. 	
721 (A721)	Alarm B	Funktion check (C)	B>ZERO POSITION level out of edit limits	 LEVEL MIN or LEVEL MAX has been changed. 	 Perform reset (Code 2710) and carry out calibration again. 	41
722 (A722)	Alarm B	Funktion check (C)	B>EMPTY CALIB. or FULL CALIB. out of edit limits	 LEVEL MIN or LEVEL MAX has been changed. 	 Perform reset (Code 2710) and carry out calibration again. 	42
723 (A723)	Alarm B	Funktion check (C)	B>MAX. FLOW out of edit limits	 FLOW-MEAS. TYPE has been changed. 	 Carry out calibration again. 	43

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
725 (A725)	Alarm B	Failure (F)	B>Sensor connection error, cycle disturbance	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). Setscrew loose. 	 Block off electromagnetic effects or eliminate source of disturbance. 	25
					 Retighten setscrew with 1 Nm (0,74 lbf ft) (see chapter "Rotating the housing" in BA00270P (Deltabar S), BA00271P (Cerabar S), BA00332P (Deltapilot S). 	
				 Sensor or main electronics defect. 	 Replace sensor or main electronics. 	
726 (E726)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor temperature error - overrange	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). 	 Block off electromagnetic effects or eliminate source of disturbance. 	31
				 Process temperature is outside permitted range. 	 Check temperature present, reduce or increase if necessary. 	
				 Sensor defect. 	 If the process temperature is within the permitted range, replace sensor. 	
727 (E727)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor pressure error - overrange	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). 	 Block off electromagnetic effects or eliminate source of disturbance. 	28
				 Pressure is outside permitted range. 	 Check pressure present, reduce or increase if necessary. 	
				– Sensor defect.	 If the pressure is within the permitted range, replace sensor. 	
728 (A728)	Alarm B	Failure (F)	B>RAM error	– Fault in the main electronics.	 Briefly disconnect device from the power supply. 	2
				 Main electronics defect. 	 Replace main electronics. 	
729 (A729)	Alarm B	Failure (F)	B>RAM error	 Fault in the main electronics. 	 Briefly disconnect device from the power supply. 	3
				 Main electronics defect. 	 Replace main electronics. 	
730 (E730)	Error C Factory setting: Warning C	Out of specification (S)	C>LRV user limits exceeded	 Pressure measured value has undershot the value specified for the Pmin ALARM WINDOW parameter. 	 Check system/pressure measured value. Change value for Pmin ALARM WINDOW if necessary. (→ See also Page 130, parameter description Pmin ALARM WINDOW.) 	46
				 Loose connection at sensor cable 	 Wait a short period of time and tighten the connection, or avoid loose connection. 	

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
731 (E731)	Error C Factory setting: Warning C	Out of specification (S)	C>URV user limits exceeded	 Pressure measured value has overshot the value specified for the Pmax ALARM WINDOW parameter. 	 Check system/pressure measured value. Change value for Pmax ALARM WINDOW if necessary. (→ See also Page 130, parameter description Pmax ALARM WINDOW.) 	45
		Out of specification (S)		 Loose connection at sensor cable 	 Wait a short period of time and tighten the connection, or avoid loose connection. 	
732 (E732)	Error C Factory setting: Warning C		C>LRV Temp. User limits exceeded	 Temperature measured value has undershot the value specified for the Tmin ALARM WINDOW parameter. 	 Check system/temperature measured value. Change value for Tmin ALARM WINDOW if necessary. (→ See also Page 130, parameter description Tmin ALARM WINDOW.) 	48
733 (E733)	Error C Factory setting: Warning C	Out of specification (S)	C>URV Temp. User limits exceeded	 Temperature measured value has overshot the value specified for the Tmax ALARM WINDOW parameter. 	 Check system/temperature measured value. Change value for Tmax ALARM WINDOW if necessary. (→ See also Page 130, parameter description Tmax ALARM WINDOW.) 	47
736 (A736)	Alarm B	Failure (F)	B>RAM error	 Fault in the main electronics. 	 Briefly disconnect device from the power supply. 	4
				 Main electronics defect. 	 Replace main electronics. 	
737 (A737)	Alarm B	Failure (F)	B>Measurement error	 Fault in the main electronics. 	 Briefly disconnect device from the power supply. 	20
				 Main electronics defect. 	 Replace main electronics. 	
738 (A738)	Alarm B	Failure (F)	B>Measurement error	 Fault in the main electronics. 	 Briefly disconnect device from the power supply. 	19
				- Main electronics defect.	 Replace main electronics. 	
739 (A739)	Alarm B	Failure (F)	B>Measurement error	 Fault in the main electronics. 	 Briefly disconnect device from the power supply. 	23
				- Main electronics defect.	 Replace main electronics. 	
740 (E740)	Error C Factory setting: Warning C	Maintenance request (M)	C>Calculation overflow, bad configuration	 Level measuring mode: the measured pressure has undershot the value for HYDR. PRESS. MIN. or overshot the value for HYDR. PRESS MAX. 	 Check configuration and carry out calibration again if necessary. Select a device with a suitable measuring range. 	27
				 Level measuring mode: The measured level did not reach the LEVEL MIN value or exceeded the LEVEL MAX value. 	 Check configuration and carry out calibration again if necessary. (→ See also parameter description LEVEL MIN., Page 86.) 	
				 Flow measuring mode: the measured pressure has undershot the value for MAX. PRESS FLOW. 	 Check configuration and carry out calibration again if necessary. Select a device with a suitable measuring range. 	
741 (A741)	Alarm B	Funktion check (C)	B>TANK HEIGHT out of edit limits	 LEVEL MIN or LEVEL MAX has been changed. 	 Perform reset (Code 2710) and carry out calibration again. 	44

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
742 (A742)	Alarm B	Failure (F)	B>Sensor connection error (upload)	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). This message normally only appears briefly. 	 Wait a few minutes. Perform reset (Code 7864) and carry out calibration again. 	18
				 Cable connection sensor – main electronics disconnected. 	 Check cable connection and repair if necessary. 	
				 Sensor defect. 	 Replace sensor. 	
743 (E743)	Alarm B	Failure (F)	B>Electronic PCB error during initialisation	 This message normally only appears briefly. 	Wait a few minutes.Restart the device. Perform reset (Code 62).	14
				- Main electronics defect.	 Replace main electronics. 	
744 (A744)	Alarm B	Failure (F)	B>Main electronic PCB error	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). 	 Restart the device. Perform reset (Code 62). Block off electromagnetic effects or eliminate source of disturbance. 	11
				- Main electronics defect.	 Replace main electronics. 	
745 (W745)	Warning C	Maintenance request (M)	C>Sensor data unknown	 Sensor does not suit the device (electronic sensor nameplate). Device continues measuring. 	 Replace sensor with a suitable sensor. 	56
746 (W746)	Warning C	Funktion check (C)	C>Sensor connection error - initialising	 Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). 	 Wait a few minutes. Restart the device. Perform reset (Code 7864). Block off electromagnetic effects or eliminate source of disturbance. 	26
				 Overpressure or low pressure present. 	 Reduce or increase pressure. 	
747 (A747)	Alarm B	Failure (F)	B>Sensor software not compatible to electronics	 Sensor does not suit the device (electronic sensor nameplate). 	 Replace sensor with a suitable sensor. 	16
748 (A748)	Alarm B	Failure (F)	B>Memory failure in signal processor	 Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). Main electronics defect. 	 Block off electromagnetic effects or eliminate source of disturbance. Replace main electronics. 	15

8.1.1 On-site display error messages

If the device detects a defect in the on-site display during initialization, the following error messages can be displayed:

Message	Measure
Initialization, VU Electr. Defect A110	Exchange on-site display.
Initialization, VU Electr. Defect A114	
Initialization, VU Electr. Defect A281	
Initialization, VU Checksum Err. A110	
Initialization, VU Checksum Err. A112	
Initialization, VU Checksum Err. A171	

8.2 Response of outputs to errors

The device differentiates between the error types Alarm, Warning and Error. \rightarrow See also Section 8.1 "Messages" und Page 111 ff, Table 20: OUTPUT and Page 111 ff, Table 31: MESSAGES the following table and Page 132, Section 8.1 "Messages".

Output	A (Alarm)	W (Warning)	E (Error: Alarm/Warning)
Current output	Assumes the value specified via the OUTPUT FAIL MODE ¹ , ALT. CURR. OUTPUT ¹ and SET MAX. ALARM ¹ parameter. \rightarrow See also the following section "Configuring current output for an alarm".	Device continues measuring.	For this error, you can enter whether the device should react as in the event of an alarm or as in the event of a warning. See corresponding "Alarm" or "Warning" column. (\rightarrow See also these Operating Instructions, parameter description SELECT ALARM TYPE.)
Bargraph (on-site display)	The bargraph adopts the value defined by the OUTPUT FAIL MODE 1 parameter.	The bargraph adopts the value which corresponds to the current value.	\rightarrow See this table, column "Alarm" or "Warning".
On-site display	 The measured value and message are displayed alternately Measured value display: permanently displayed. 	 The measured value and message are displayed alternately Measured value display: In -symbol flashes. 	 The measured value and message are displayed alternately Measured value display: see corresponding "Alarm" or "Warning" column
	Message display – 3-digit number such as A122 and description	Message display: – 3-digit number such as W613 and description	Message display: – 3-digit number such as E731 and description
Remote operation (Digital communication)	In the case of an alarm, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 122 for "Sensor not connected".	In the case of a warning, the ALARM STATUS ² parameter displays a 3-digit number such as 613 for "Simulation is active".	In the case of an error, the ALARM STATUS ² parameter displays a 3- digit number such as 731 for "URV user limits exceeded".

1) Menu path: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow OUTPUT

2) Menu path: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow MESSAGES

8.3 Confirming messages

Depending on the settings for the ALARM DISPL. TIME (\rightarrow Page 129) and ACK. ALARM MODE (\rightarrow Page 128) parameters, the following measures should be taken to clear a message:

Settings 1)	Measures
ALARM DISPL. TIME = 0 sACK. ALARM MODE = off	 Rectify cause of the message (see also Section 8.1).
ALARM DISPL. TIME > 0 sACK. ALARM MODE = off	Rectify cause of the message (see also Section 8.1).Wait for the alarm display time to elapse.
ALARM DISPL. TIME = 0 sACK. ALARM MODE = on	 Rectify cause of the message (see also Section 8.1). Confirm message using ACK. ALARM parameter.
 ALARM DISPL. TIME > 0 s ACK. ALARM MODE = on 	 Rectify cause of the message (see also Section 8.1). Confirm message using ACK. ALARM parameter. Wait for the alarm display time to elapse. If a message appears and the alarm display time elapses before the message has been acknowledged, the message will be cleared once it has been acknowledged.

1) Menu path for ALARM DISPL. TIME and ACK. ALARM MODE: (GROUP SELECTION \rightarrow) OPERATING MENU \rightarrow DIAGNOSTICS \rightarrow MESSAGES

If the on-site display displays a message, you can delete it with the \mathbb{E} -key. If there are several messages, the on-site display shows the message which has the highest priority (see also Section 8.1). Once you have deleted this message using the \mathbb{E} -key, the message with the next highest priority is displayed. You can use the \mathbb{E} -key to delete each message, one after the other. The ALARM STATUS parameter continues to display all the messages present.

9 Appendix

9.1 Operating menu for on-site display, Digital communication



Note!

- The entire menu is depicted on the following pages.
- The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. "LINEARISATION" function group for the Level measuring mode (Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP).
- In addition, there are also parameters that are only displayed if other parameters are appropriately configured. For example the Customer Unit P parameter is only displayed if the "User unit" option was selected for the PRESS. ENG. UNIT parameter. These parameters are indicated with a "*".
- For a description of the parameters, please refer to chapter 7 "Description of parameters". The exact dependency of individual parameters on one another is explained here.



1) Display via on-site display only

2) Display via digital communication

3) Cerabar S with gauge pressure sensor, Deltabar S or Deltapilot S

4) Cerabar S with absolut pressure sensor

 * There are parameters that are only displayed if other parameters are appropriately configured.
 For example the CUSTOMER UNIT P parameter is only displayed if the "User unit" option was selected for the PRESS. ENG. UNIT parameter. These parameters are indicated with a "*".

P01-xxxxxxx-19-xx-xx-138



2) Display via digital communication

* There are parameters that are only displayed if other parameters are appropriately configured.

For example the CUSTOMER UNIT P parameter is only displayed if the "User unit" option was selected for the PRESS. ENG. UNIT parameter. These parameters are indicated with a "*".

P01-xxxxxxx-19-xx-xx-xx-139


* There are parameters that are only displayed if other parameters are appropriately configured.

For example the CUST. UNIT FACT. H parameter is only displayed if the "User unit" option was selected for the HEIGHT UNIT parameter. These parameters are indicated with a "*".

P01-xxxxxxx-19-xx-xx-140

Appendix

DAMPING VALUE



* There are parameters that are only displayed if other parameters are appropriately configured. For example the TOT. 1 USER UNIT parameter is only displayed

if the "User unit" option was selected for the TOTALIZER 1 UNIT parameter. These parameters are indicated with a "*".

P01-xxxxxxx-19-xx-xx-101



2) Display via digital communication

3) Level measuring mode only

4) Flow measuring mode only

5) only LEVEL SELECTION = Level Easy Pressure

- There are parameters that are only displayed if other parameters are appropriately configured.
 These parameters are indicated with a "*".
- ** See Safety Manual SD190P for Cerabar S, SD189P for Deltabar S or SD213P for Deltapilot S.

P01-xxxxxxx-19-xx-xx-141



2) Display via digital communication

 There are parameters that are only displayed if other parameters are appropriately configured.
These parameters are indicated with a "*".

P01-xxxxxxxx-19-xx-xx-142



(1)						
none	Pressure	Flow	Level	▼ Tank con	tent 🚽 Current	Alarm Warning
	SIM. PRESSURE	SIM. FLOW VALUE	SIM. LEVEL	SIM. TANK CONT.	SIM. CURRENT	SIM. ERROR NO.

 There are parameters that are only displayed if other parameters are appropriately configured.
These parameters are indicated with a "*".

P01-xxxxxxx-19-xx-xx-143

Index

Numerics

100% POINT (813), "Height linearized" level type	89
100% POINT (813), "Linear" level type	77
4TH VALUE	116
4TH VALUE IS	116

Α

ACK. ALARM (500) 129
ACK. ALARM MODE (401) 128
ACK ALARM MODE (844). "Safety confirm." group 9
ACTIV LIN TAB X 107
ACTIVIIN TAB Y 107
$\Delta \text{DDITIONAL INFO} (272) \qquad 117$
ADDITIONAL INTO. (272)
61
$\Delta DIJIST DENSITY (007) / (216) "I over over and even of a setum 07$
ADJUST DENSITY (216) "Usight linearized" level true
ADJUST DENSITY (S10), Height integrized level type oo
ADJUST DENSITY (310), "Linear" level type
ADJUSTED DENSITY (810), "Height linearized" level type. 87
ADJUSTED DENSITY (810), "Linear" level type
ALARM DELAY (336) 129
ALARM DISPL. TIME (480) 129
ALARM STATUS (046) 128
ALLOWED MAX. TEMP (359) 117
ALLOWED MIN. TEMP (358) 117
ALT. CURR. OUTPUT (597) 113
ALTERNATE DATA (423)
ASSIGN CURRENT (760) 113

B

BOLTS MATERIAL	118
BURST MODE	115
BURST OPTION	115
BUS ADDRESS (345)	115

С

CALIB. OFFSET (319) 54
CALIB. OFFSET (847), "Safety confirm." group
CALIBRATION MODE (008), "Level Easy Height" level selec-
tion
CALIBRATION MODE (008), "Level Easy Pressure" level selec-
tion
CALIBRATION MODE (392), "Height linearized" level type 87
CALIBRATION MODE (392), "Linear" level type 73
COMB. MEASURAND (806) 83
CONF. PASSWORD (856)
CONFIG RECORDER (352) 117
CORRECTED PRESS. (434), "Flow" measuring mode 123
CORRECTED PRESS. (434), "Level" measuring mode 122
CORRECTED PRESS. (434), "Pressure" measuring mode . 122
COUNTER P > Pmax (380) 124
COUNTER P Pmin (467) 124
COUNTER T > Tmax (404) 124
COUNTER T Tmin (472) 124
CURR. CHARACT. (694), (695), (696), (764) 112
CURR. TRIM 20mA (042) 131
CURR. TRIM 4mA (045) 131

CURRENT MODE (052) 115 CURRENT OUTPUT (875) 9 CUST. TAG NUMBER (055) 117 CUST. UNIT FACT. F (609) 95 CUST. UNIT FACT. H (705), "Height linearized" level type 84,
89 CUST. UNIT FACT. H (705), "Linear" level type 71, 76 CUST. UNIT FACT. M (703), "Height linearized" level type 86 CUST. UNIT FACT. M (703), "Linear" level type 73 CUST. UNIT FACT. M (703), "Pressure linearized" level type.
CUST. UNIT FACT. P (317) 56, 59, 63, 68, 93 CUST. UNIT FACT. V (607), "Height linearized" level type 85 CUST. UNIT FACT. V (607), "Linear" level type 72, 75 CUST. UNIT FACT. V (607), "Pressure linearized" level type . 79
CUSTOMER UNIT F (610)
CUSTOMER UNIT H (706), "Linear" level type 70, 76 CUSTOMER UNIT M (704), "Height linearized" level type. 86 CUSTOMER UNIT M (704), "Linear" level type 72 CUSTOMER UNIT M (704), "Pressure linearized" level type . 80
CUSTOMER UNIT P (075)
D DAMPING VALUE (247) 48, 51, 53, 57, 61, 66, 77, 81, 90, 95 DAMPING VALUE (855), "Safety confirm." group

Ε

EDITOR TABLE (770), on-site operation	103
EDITOR TABLE (809), on-site operation	102
EDITOR TABLE, digital communication 1	05-106
ELECTR. SERIAL No (386)	117

EMPTY CALIB. (010), "Level Easy Height" level selection . 65 EMPTY CALIB. (010), "Level Easy Pressure" level selection 60–61
EMPTY CALIB. (314), "Height linearized" level type 87 EMPTY CALIB. (314), "Linear" level type 73 EMPTY CALIB. (314)/(010), QUICK SETUP 50 EMPTY HEIGHT. (009), "Level Easy Height" level selection 65 EMPTY PRESSURE (011), "Level Easy Pressure" level selection 61
EMPTY PRESSURE (710), "Height linearized" level type
F FACT. U. U. TOTAL. 1 (329) 108 FACT. U. U. TOTAL. 2 (330) 109 FILL FLUID 119 FILLING FLUID (366) 120 FLOW-MEAS. TYPE (640) 93 FULL CALIB. (004), "Level Easy Height" level selection 65 FULL CALIB. (004), "Level Easy Pressure" level selection. 60-
FULL CALIB. (315), "Height linearized" level type 87 FULL CALIB. (315), "Linear" level type
FULL PRESSURE (711), "Height linearized" level type87FULL PRESSURE (711), "Linear" level type74
G GET LRV (309), "Pressure" measuring mode
H HARDWARE REV. (266) 117 HART DATE (481) 116 HART MESSAGE (271) 116 HART VERSION (585) 114 HEIGHT UNIT (011), "Level Easy Height" level selection 64 HEIGHT UNIT (708), "Height linearized" level type 83, 88 HEIGHT UNIT (708), "Linear" level type 70, 76 HistoROM AVAIL. (831) 126 HistoROM CONTROL (832) 127 HYDR. PRESS MAX. (761) 81 HYDR. PRESS MIN. (775) 80
I INSERT PIN NO (048) 126
L LANGUAGE (079)

	Index
LEVEL SELECTION (020) LIN. EDIT MODE (397), on-site operation LIN. EDIT MODE, digital communication LIN. MEASURAND (804)	. 46, 49 101 105 70 79
LINEAR/SQROOT (390) LINEAR/SQROOT (854), "Safety confirm." group LINE-NUMB (549), on-site operation	113 9 102
LINE-NUMB, digital communication LONG TAG NUMBER (305) LOW FLOW CUT-OFF (442) LOW FLOW CUT-OFF (850), "Safety confirm." group	106 117 99 9
M	
MAIN DATA FORMAT (688)	110 116 94 85 72 80 120 118 118 . 53, 95 9
MAX. FLOW (311) MAX. FLOW (348), "Safety confirm." group MAX. FLOW (848), "Safety confirm." group	. 52, 95 9
MAX. MEAS. TEMP. (471). MAX. MEAS. TEMP. (471). MEAS. VAL. TREND (378). MEASURED VALUE "Flow" measuring mode	··· 124 ··· 124 122–123
MEASURED VALUE, HOW INEASURING MOUCH	123

67,92

Ν

O

GET LRV (309),	"Pressure" measuring mode	57
GET URV (310).	"Pressure" measuring mode	57

LEVEL MIN (755)..... 86 LEVEL MODE (718) 68

0
OFFSET 20mA TRIM (044) 131
OFFSET 4mA TRIM (043) 131
OPERATING HOURS (409) 126
OUTPUT CURRENT (254) 111
OUTPUT FAIL MODE (388) 112
OUTPUT UNIT (023), "Level Easy Height" level selection . 64
OUTPUT UNIT (023), "Level Easy Pressure" level selection 60

MEASURED VALUE, "Level" measuring mode 122 MEASURED VALUE, "Pressure" measuring mode 121 MEASURING MODE (389), on-site display..... 45 MEASURING MODE (845), "Safety confirm" group 9 MEASURING MODE, digital communication . 47, 49, 52, 55,

MENU DESCRIPTOR (419) 110 MIN. MEAS. PRESS. (469) 124 MIN. MEAS. TEMP. (474) 124 MINIMUM SPAN (591) 119

NEG. FLOW TOT. 1 (400) 108 NEG. FLOW TOT. 2 (416) 109 NORM FLOW UNIT (661) 93 NR OF REMOTE SE 119 NUTS MATERIAL 119

P

1
PASSWORD (836)
PCB COUNT
T Tmin (492) 124
PCB COUNT T 124
PCB COUNT T > Tmax (488) 124
PCB MAX. TEMP. (490) 124
PCB MIN. TEMP. (494) 124
PCB TEMPERATURE (357) 117
Pmax ALARM WINDOW (333) 130
Pmax PROC. CONN. (570) 117
Pmax SENS. DAMAGE (252) 120
Pmin ALARM WINDOW (332) 130
Pmin SENS. DAMAGE (251) 120
POS. INPUT VALUE (563) 48, 50, 54
POS. ZERO ADJUST (685) 48, 50, 52, 54
PREAMBLE NUMBER (036) 115
PRESS. ENG. UNIT (060) 56, 59, 63, 67, 92
PRESS. SENS HILIM (485) 119
PRESS. SENS LOLIM (484) 119
PRESSURE (301), "Flow" measuring mode 123
PRESSURE (301), "Level" measuring mode 122
PRESSURE, "Pressure" measuring mode 122
PRIMARY VALUE 116
PRIMARY VALUE IS 116
PROC. CONN. TYPE (482) 118
PROCESS DENSITY (025)/(811)

Q

Quick Setup "Flow" menu	52
Quick Setup "Level" menu	49
Quick Setup "Pressure" menu	47

R

REMOTE SEAL	119
REMOTE SEAL +	119
RESET ALL ALARMS (603)	129
RESET PEAKHOLD (382)	125
RESET TOTALIZER1 (331)	109

S

SET LRV (852), "Safety confirm." group
SET MAX. ALARM (342) 113
SET MIN. CURRENT (343) 113
SET URV (012), "Level Easy Height" level selection 66
SET URV (012), "Level Easy Pressure" level selection 61
SET URV (246), "Pressure" measuring mode
SET URV (638), "Flow" extended setup 100
SET URV (720), "Level" basic setup
SET URV (763), "Level" extended setup
SET URV (853), "Safety confirm." group
SET. L. FL. CUT-OFF (323)
SET. L. FL. CUT-OFF (851), "Safety confirm." group 9
SIM. CURRENT (270) 128
SIM. ERROR NO. (476) 128
SIM. LEVEL (714) 128
SIM. PRESSURE (414) 127
SIM. TANK CONT. (715) 128
SIM.FLOW VALUE (639) 127
SIMULATION MODE (413) 127
SOFTWARE VERSION (264) 117
STD. FLOW UNIT (660) 94
SUPPRESSED FLOW (375) 123

Т

U

UNIT FLOW (391)	. 93
UNIT VOLUME (313), "Height linearized" level type	. 84
UNIT VOLUME (313), "Linear" level type 71	, 75
UNIT VOLUME (313), "Pressure linearized" level type	. 79

Х

X-VAL. (550), on-site operation	102
X-VAL., digital communication	106

Y Y-VAL. (551), on-site operation	102 106
Z ZERO POSITION (814), "Height linearized" level type	. 90
ZERO POSITION (814), "Linear" level type	. 77

www.endress.com/worldwide



People for Process Automation



BA00274P/00/EN/17.14 71270402 CCS/FM+SGML 9