



Level



Pressure



Flow



Temperature



Liquid  
Analysis



Registration



Systems  
Components



Services




Solutions

## Description of Device Functions

# Proline Promag 50

## Electromagnetic Flow Measuring System





## Contents

<b>1</b>	<b>Function matrix Promag 50</b>	<b>5</b>	<b>21</b>	<b>Factory settings</b>	<b>58</b>
1.1	The function matrix: layout and use	5	21.1	SI units (not for USA and Canada)	58
1.2	Illustration of the function matrix	6	21.2	US units (only for USA and Canada)	60
<b>2</b>	<b>Group MEASURING VALUES</b>	<b>7</b>	<b>22</b>	<b>Index of key words</b>	<b>61</b>
<b>3</b>	<b>Group SYSTEM UNITS</b>	<b>8</b>			
<b>4</b>	<b>Group QUICK SETUP</b>	<b>10</b>			
<b>5</b>	<b>Group OPERATION</b>	<b>11</b>			
<b>6</b>	<b>Group USER INTERFACE</b>	<b>13</b>			
<b>7</b>	<b>Group TOTALIZER 1/2</b>	<b>16</b>			
<b>8</b>	<b>Group HANDLING TOTALIZER</b>	<b>18</b>			
<b>9</b>	<b>Group CURRENT OUTPUT</b>	<b>19</b>			
<b>10</b>	<b>Group PULSE/FREQUENCY OUTPUT</b>	<b>23</b>			
<b>11</b>	<b>Group STATUS OUTPUT</b>	<b>34</b>			
11.1	Information on the response of the status output	37			
11.2	Switching response of the status output	38			
<b>12</b>	<b>Group STATUS INPUT</b>	<b>40</b>			
<b>13</b>	<b>Group COMMUNICATION</b>	<b>42</b>			
<b>14</b>	<b>Group PROCESS PARAMETER</b>	<b>43</b>			
<b>15</b>	<b>Group SYSTEM PARAMETERS</b>	<b>49</b>			
<b>16</b>	<b>Group SENSOR DATA</b>	<b>52</b>			
<b>17</b>	<b>Group SUPERVISION</b>	<b>54</b>			
<b>18</b>	<b>Group SIMULATION SYSTEM</b>	<b>56</b>			
<b>19</b>	<b>Group SENSOR VERSION</b>	<b>57</b>			
<b>20</b>	<b>Group AMPLIFIER VERSION</b>	<b>57</b>			

**Registered trademarks**

HART®  
Registered trademark of the HART Communication Foundation, Austin, USA

HistoROM™, S-DAT®, FieldCare®  
Registered trademarks of Endress+Hauser Flowtec AG, Reinach, CH

# 1 Function matrix Promag 50

## 1.1 The function matrix: layout and use

The function matrix is a two-level construct: the groups form one level and the groups' functions the other.

The groups are the highest-level grouping of the operating options for the measuring device. A number of functions is assigned to each group.

You select a group in order to access the individual functions for operating and parameterizing the measuring device.


An overview of all the groups available is provided in the table of contents on Page 3 and in the graphical representation of the function matrix on Page 6.

An overview of all the functions available is provided on Page 6, complete with page references to the detailed function descriptions.

The descriptions of the individual functions start on Page 7.

Example of how to parameterize a function (in this case changing the language for the UI):


1. Enter into the function matrix (E-key).
2. Select the OPERATION group.
3. Select the LANGUAGE function, change the setting from ENGLISH to DEUTSCH with +/- and save with E (all text on the display now appears in German).
4. Exit the function matrix (ESC > 3 seconds).




1.2 Illustration of the function matrix

Function groups ▶	Functions →										
MEASURING VALUES (P. 7)	VOLUME FLOW (P. 7)										
SYSTEM UNITS (P. 8)	UNIT VOL. FLOW (P. 8)	UNIT VOLUME (P. 8)	UNIT LENGTH (P. 9)	FORMAT DATE/TIME (P. 9)							
QUICK SETUP (P. 10)	QUICK SETUP COMMISSION (P. 10)										
OPERATION (P. 11)	LANGUAGE (P. 11)	ACCESS CODE (P. 12)	PRIVATE CODE (P. 12)	STATUS ACCESS (P. 12)	ACCESS CODE COUNTER (P. 12)						
USER INTERFACE (P. 13)	ASSIGN LINE 1 (P. 13)	ASSIGN LINE 2 (P. 13)	100% VALUE (P. 13)	FORMAT (P. 14)	DISPL. DAMPING (P. 14)	CONTRAST LCD (P. 14)	BACKLIGHT (P. 15)	DISPLAY TEST (P. 15)			
TOTALIZER 1/2 (P. 16)	ASSIGN TOTALIZER (P. 16)	SUM (P. 16)	OVERFLOW (P. 16)	UNIT TOTALIZER (P. 16)	TOTALIZER MODE (P. 17)	RESET TOTALIZ. (P. 17)					
HANDLING TOTALIZ. (P. 18)	RESET ALL TOTAL. (P. 18)	FAILSAFE MODE (P. 18)									
CURRENT OUTPUT (P. 19)	ASSIGN CURRENT OUTP. (P. 19)	CURRENT SPAN (P. 20)	VALUE 20 mA (P. 21)	TIME CONSTANT (P. 21)	FAILSAFE MODE (P. 21)	ACTUAL CURRENT (P. 21)	SIMUL. CURRENT (P. 22)	VALUE SIM. CURRENT (P. 22)			
PULSE/FREQ. OUTP. (P. 23)	OPERATION MODE (P. 23)	ASSIGN FREQ. (P. 23)	END VALUE FREQ. (P. 23)	VALUE-f HIGH (P. 24)	OUTPUT SIGNAL (P. 25)	TIME CONSTANT (P. 27)	FAILSAFE MODE (P. 27)	FAILSAFE VALUE (P. 27)	ACTUAL FREQ. (P. 27)	SIMUL. FREQ. (P. 28)	
	VALUE SIM. FREQ. (P. 28)	ASSIGN PULSE (P. 28)	PULSE VALUE (P. 29)	PULSE WIDTH (P. 29)	OUTPUT SIGNAL (P. 30)	FAILSAFE MODE (P. 32)	SIMULATION PULSE (P. 32)	VALUE SIM. PULSE (P. 33)			
STATUS OUTPUT (P. 34)	ASSIGN STATUS (P. 34)	ON-VALUE (P. 34)	OFF-VALUE (P. 35)	TIME CONSTANT (P. 35)	ACTUAL STATUS (P. 35)	SIM. SWITCH POINT (P. 35)	VAL. SIM. SWIT. PT. (P. 36)				
STATUS INPUT (P. 40)	ASSIGN STATUS (P. 40)	ACTIVE LEVEL (P. 40)	MIN. PULSE WIDTH (P. 40)	SIM. STATUS INP. (P. 40)	VALUE SIM. STATUS (P. 41)						
COMMUNICATION (P. 42)	TAG NAME (P. 42)	TAG DESCR. (P. 42)	BUS ADDRESS (P. 42)	HART PROTOCOL (P. 42)	MANUFACT. ID (P. 42)	DEVICE ID (P. 42)	DEVICE REVISION (P. 42)				
PROCESS PARAM. (P. 43)	ASSIGN LF CUT OFF (P. 43)	ON-VALUE (P. 43)	OFF-VALUE (P. 43)	EMPTY PIPE DET. (P. 44)	EPD/OED ADJ. (P. 46)	EPD/OED RES.TIME (P. 47)	ECC (P. 47)	ECC DURATION (P. 47)	ECC RECOVERY TIME (P. 48)	ECC CLEAN. CYCL. (P. 48)	
SYSTEM PARAM. (P. 49)	INSTALL. DIRECT. (P. 49)	MEASURING MODE (P. 49)	POS. ZERO RETURN (P. 50)	SYSTEM DAMPING (P. 51)	INTEGRAT. TIME (P. 51)						
SENSOR DATA (P. 52)	CALIBRATION DATE (P. 52)	K-FACTOR (P. 52)	ZERO POINT (P. 52)	NOM. DIAMETER (P. 52)	MEAS. PERIOD (P. 53)	OVERVLTG TIME (P. 53)	EPD ELECTRODE (P. 53)	POLARITY ECC (P. 53)			
SUPERVISION (P. 54)	CURR. SYS. COND. (P. 54)	PREV. SYS. COND. (P. 54)	ASSIGN SYS. ERR. (P. 54)	ERROR CATEG. (P. 54)	ASSIGN PROC. ERR. (P. 54)	ERROR CATEG. (P. 55)	ALARM DELAY (P. 55)	SYSTEM RESET (P. 55)	OPERAT. HRS. (P. 55)		
SIMULAT. SYSTEM (P. 56)	SIM. FAILS. MODE (P. 56)	SIM. MEAS. VARIAB. (P. 56)	VAL.SIM.MEAS.VAR. (P. 56)								
SENSOR VERSION (P. 57)	SERIAL NUMBER (P. 57)	SENSOR TYPE (P. 57)	HW REV. SENS. (P. 57)	SW REV. NO. S-DAT (P. 57)							
AMPLIFIER VERS. (P. 57)	DEVICE SOFTWARE (P. 57)	SW REV. AMPL. (P. 57)	LANGUAGE GROUP (P. 57)	I/O MODULE TYPE (P. 57)	SW REV. I/O MOD. (P. 57)						

## 2 Group MEASURING VALUES

Function description MEASURING VALUES	
<p> Note!</p> <ul style="list-style-type: none"> <li>■ The engineering unit of the measured variable displayed here can be set in the SYSTEM UNITS group, (see Page 8).</li> <li>■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.</li> </ul>	
<p><b>VOLUME FLOW</b></p>	<p>The volume flow currently measured appears on the display.</p> <p><b>User interface:</b>                      5-digit floating-point number, including unit and sign                      (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p>

### 3 Group SYSTEM UNITS

<b>Function description SYSTEM UNITS</b>	
Use this function group to select the unit for the measured variable.	
<b>UNIT VOLUME FLOW</b>	<p>Use this function to select the unit for displaying the volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> <li>■ Current output</li> <li>■ Frequency output</li> <li>■ Switch points (limit value for volume flow, flow direction)</li> <li>■ Low flow</li> </ul> <p><b>Options:</b></p> <p>Metric:</p> <p>Cubic centimeter → cm<sup>3</sup>/s; cm<sup>3</sup>/min; cm<sup>3</sup>/h; cm<sup>3</sup>/day  Cubic decimeter → dm<sup>3</sup>/s; dm<sup>3</sup>/min; dm<sup>3</sup>/h; dm<sup>3</sup>/day  Cubic meter → m<sup>3</sup>/s; m<sup>3</sup>/min; m<sup>3</sup>/h; m<sup>3</sup>/day  Milliliter → ml/s; ml/min; ml/h; ml/day  Liter → l/s; l/min; l/h; l/day  Hectoliter → hl/s; hl/min; hl/h; hl/day  Megaliter → Ml/s; Ml/min; Ml/h; Ml/day</p> <p>US:</p> <p>Cubic centimeter → cc/s; cc/min; cc/h; cc/day  Acre foot → af/s; af/min; af/h; af/day  Cubic foot → ft<sup>3</sup>/s; ft<sup>3</sup>/min; ft<sup>3</sup>/h; ft<sup>3</sup>/day  Fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day  Gallon → gal/s; gal/min; gal/h; gal/day  Kilo gallon → Kgal/s; Kgal/min; Kgal/h; Kgal/day  Million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day  Barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day  Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day  Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day  Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Imperial:</p> <p>Gallon → gal/s; gal/min; gal/h; gal/day  Mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day  Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day  Barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p><b>Factory setting:</b>  Depends on nominal diameter and country (see Page 58 ff.).</p>
<b>UNIT VOLUME</b>	<p>Use this function to select the unit for displaying the volume.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> <li>■ Pulse weighting (e.g. m<sup>3</sup>/p)</li> </ul> <p><b>Options:</b></p> <p>Metric → cm<sup>3</sup>; dm<sup>3</sup>; m<sup>3</sup>; ml; l; hl; Ml Mega  US → cc; af; ft<sup>3</sup>; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer);  bbl (petrochemicals) → bbl (filling tanks)  Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p><b>Factory setting:</b>  Depends on nominal diameter and country (see Page 58 ff.).</p> <p> <b>Note!</b>  The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.</p>




<b>Function description SYSTEM UNITS</b>	
<b>UNIT LENGTH</b>	<p>Use this function to select the unit for displaying the length of the nominal diameter.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> <li>■ Nominal diameter of sensor (see function NOMINAL DIAMETER on Page 48)</li> </ul> <p><b>Options:</b> MILLIMETER INCH</p> <p><b>Factory setting:</b> MILLIMETER (SI units: not for USA and Canada) INCH (US units: only for USA and Canada)</p>
<b>FORMAT DATE/TIME</b>	<p>Use this function to select the format for the date and the time.</p> <p>The unit you select here is also valid for:</p> <p>Displaying the current calibration date (function CALIBRATION DATE on Seite 52)</p> <p><b>Options:</b> DD.MM.YY 24H MM/DD/YY 12H A/P DD.MM.YY 12H A/P MM/DD/YY 24H</p> <p><b>Factory setting:</b> DD.MM.YY 24H (SI units) MM/DD/YY 12H A/P (US units)</p>

# 4 Group QUICK SETUP

Function description QUICK SETUP	
<b>QUICK SETUP COMMISSION</b>	Use this function to start the Quick Setup menu for commissioning.  <b>Options:</b> YES NO  <b>Factory setting:</b> NO










Note!  
The display returns to the QUICK SETUP COMMISSION cell if you press the ESC key combination during interrogation.




a0005413-en



## 5 Group OPERATION


Function description OPERATION	
<b>LANGUAGE</b>	<p>Use this function to select the language for all texts, parameters and messages shown on the local display.</p> <p> <b>Note!</b> The displayed options depend on the available language group shown in the LANGUAGE GROUP function.</p> <p><b>Options:</b> Language group WEST EU / USA: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS PORTUGUESE</p> <p>Language group EAST EU / SCAND: ENGLISH NORSK SVENSKA SUOMI POLISH RUSSIAN CZECH</p> <p>Language group ASIA: ENGLISH BAHASA INDONESIA JAPANESE (Silbenschrift)</p> <p><b>Factory setting:</b> Country-dependent (see Page 58 ff.)</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ If you press the  keys simultaneously at startup, the language defaults to "ENGLISH".</li> <li>■ You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.</li> </ul>

<b>Function description OPERATION</b>	
<b>ACCESS CODE</b>	<p>All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the   keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).</p> <p>You can enable programming by entering your personal code, <b>(factory setting = 50, see function PRIVATE CODE on Page 12)</b></p> <p><b>User input:</b> max. 4-digit number: 0...9999</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position.</li> <li>■ You can also disable programming in this function by entering any number (other than the defined private code).</li> <li>■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.</li> </ul>
<b>PRIVATE CODE</b>	<p>Use this function to enter a personal code number for enabling programming.</p> <p><b>User input:</b> 0...9999 (max. 4-digit number)</p> <p><b>Factory setting:</b> 50</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Programming is always enabled with the code "0".</li> <li>■ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.</li> </ul>
<b>STATUS ACCESS</b>	<p>Use this function to check the access status for the function matrix.</p> <p><b>User interface:</b> ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)</p>
<b>ACCESS CODE COUNTER</b>	<p>Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix.</p> <p><b>Display:</b> max. 7-digit number: 0...9999999</p> <p><b>Factory setting:</b> 0</p>



## 6 Group USER INTERFACE

<b>Function description USER INTERFACE</b>	
<b>ASSIGN LINE 1</b>	<p>Use this function to define which display value is assigned to the main line (top line of the local display) for display during normal measuring operation.</p> <p><b>Options:</b>            OFF            VOLUME FLOW            VOLUME FLOW IN %            TOTALIZER 1            TOTALIZER 2</p> <p><b>Factory setting:</b>            VOLUME FLOW</p>
<b>ASSIGN LINE 2</b>	<p>Use this function to define which display value is assigned to the additional line (bottom line of the local display) for display during normal measuring operation.</p> <p><b>Options:</b>            OFF            VOLUME FLOW            VOLUME FLOW IN %            VOLUME FLOW BARGRAPH IN %            TOTALIZER 1            TAG NAME            OPERATING/SYSTEM CONDITION            FLOW DIRECTION            TOTALIZER 2</p> <p><b>Factory setting:</b>            TOTALIZER 1</p>
<b>100% VALUE</b>	<p> <b>Note!</b>            This function is only available if VOLUME FLOW IN % or VOLUME FLOW BARGRAPH IN % was selected in the function ASSIGN LINE 1 or ASSIGN LINE 2.</p> <p>Use this function to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>            5-digit floating-point number</p> <p><b>Factory setting:</b>            Depends on nominal diameter and country (see Page 58 ff.).</p>


<b>Function description USER INTERFACE</b>	
<b>FORMAT</b>	<p>Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → 1/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>DISPLAY DAMPING</b>	<p>Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p><b>User input:</b> 0...100 seconds</p> <p><b>Factory setting:</b> 3 s</p> <p> Note! Setting the time constant to zero seconds switches off damping.</p>
<b>CONTRAST LCD</b>	<p>Use this function to optimize display contrast to suit local operating conditions.</p> <p><b>User input:</b> 10...100%</p> <p><b>Factory setting:</b> 50%</p>

<b>Function description USER INTERFACE</b>	
<b>BACKLIGHT</b>	<p>Use this function to optimize the backlight to suit local operating conditions.</p> <p><b>User input:</b> 0...100%</p> <p> <b>Note!</b> Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.</p> <p><b>Factory setting:</b> 50%</p>
<b>DISPLAY TEST</b>	<p>Use this function to test the operability of the local display and its pixels.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p> <p>Test sequence:</p> <ol style="list-style-type: none"> <li>1. Start the test by selecting ON.</li> <li>2. All pixels of the main line and additional line are darkened for at least 0.75 seconds.</li> <li>3. The main line and additional line show an "8" in each field for at least 0.75 seconds.</li> <li>4. The main line and additional line show a "0" in each field for at least 0.75 seconds.</li> <li>5. The main line and additional line show nothing (blank display) for at least 0.75 seconds.</li> </ol> <p>When the test completes the local display returns to its initial state and the setting changes to OFF.</p>


## 7 Group TOTALIZER 1/2

Function description TOTALIZER 1/2	
<b>ASSIGN TOTALIZER</b>	<p>Use this function to assign a measured variable (volume flow) to the totalizer.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p> <p> <b>Note!</b> The totalizer is reset to "0" as soon as the selection is changed.</p>
<b>SUM</b>	<p>Use this function to view the total for the totalizer measured variable aggregated since measuring commenced. The value can be positive or negative.</p> <p><b>User interface:</b> max. 7-digit floating-point number, including sign and unit (e.g. 896,845.7 dm<sup>3</sup>)</p> <p> <b>Note!</b> The totalizer response to faults is defined in the FAILSAFE MODE function (see Page 18).</p>
<b>OVERFLOW</b>	<p>Use this function to view the overflow for the totalizer aggregated since measuring commenced.</p> <p>Total flow quantity is represented by a floating decimal point number consisting of max. 7 digits. You can use this function to view higher numerical values (&gt;9 999 999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function.</p> <p>Example: Reading for 2 overflows: 2 E7 kg (= 2 000 000 dm<sup>3</sup>) The value returned by the SUM function = 896,845.7 dm<sup>3</sup> Effective total quantity = 2,896,845.7 dm<sup>3</sup></p> <p><b>Display shows:</b> Integer with exponent, including sign and unit, e.g. 2 E7 dm<sup>3</sup></p>
<b>UNIT TOTALIZER</b>	<p>Use this function to define the unit for the totalizer.</p> <p><b>Options:</b> Metric → cm<sup>3</sup>; dm<sup>3</sup>; m<sup>3</sup>; ml; l; hl; Ml Mega US → cc; af; ft<sup>3</sup>; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p><b>Factory setting:</b> Depends on nominal diameter and country (see Page 58 ff.).</p>





Function description TOTALIZER 1/2	
<b>TOTALIZER MODE</b>	<p>Use this function to define how the flow components are to be totalised.</p> <p><b>Options:</b>                      BALANCE                      Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.</p> <p>FORWARD                      Positive flow components only</p> <p>REVERSE                      Negative flow components only</p> <p><b>Factory setting:</b>                      Totalizer 1 = BALANCE                      Totalizer 2 = FORWARD</p>
<b>RESET TOTALIZER</b>	<p>Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET).</p> <p><b>Options:</b>                      NO                      YES</p> <p><b>Factory setting:</b>                      NO</p> <p> <b>Note!</b>                      If the device is equipped with a status input and if it is appropriately configured, totalizer resetting can also be triggered by a pulse.</p>


## 8 Group HANDLING TOTALIZER





Function description HANDLING TOTALIZER	
<b>RESET ALL TOTALIZERS</b>	<p>Use this function to reset the totals (including all overflows) of the totalizers (1...2) to "zero".</p> <p><b>Options:</b> NO YES</p> <p><b>Factory setting:</b> NO</p> <p> <b>Note!</b> If the device has a status input and if it is appropriately configured, a reset for the totalizer (1...2) can also be triggered by a pulse (see the ASSIGN STATUS INPUT function on Page 31).</p>
<b>FAILSAFE MODE</b>	<p>Use this function to define the totalizer response in case of fault.</p> <p><b>Options:</b> STOP The totalizer is paused until the fault is rectified.</p> <p>ACTUAL VALUE The totalizer continues to count on the basis of the current flow measuring value. The fault is ignored.</p> <p>HOLD VALUE The totalizer continues to count the flow that is based on the last valid flow measuring value (before the fault occurred).</p> <p><b>Factory setting:</b> STOP</p>

## 9 Group CURRENT OUTPUT





Function description CURRENT OUTPUT	
<b>ASSIGN CURRENT OUTPUT</b>	<p>Use this function to assign a measured variable to the current output.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p> <p> <b>Note!</b> If you select OFF, the only function shown in this group is the function (ASSIGN CURRENT OUTPUT).</p>

<b>Function description CURRENT OUTPUT</b>																																													
<b>CURRENT SPAN</b>	<p>Use this function to define the current span. The selection specifies the operational range and the lower and upper signal on alarm. For the current output the option HART can be defined additionally.</p> <p><b>Options:</b>                      0–20 mA                      4–20 mA                      4–20 mA HART                      4–20 mA NAMUR                      4–20 mA HART NAMUR                      4–20 mA US                      4–20 mA HART US                      0–20 mA (25 mA)                      4–20 mA (25 mA)                      4–20 mA (25 mA) HART</p> <p><b>Factory setting:</b>                      4–20 mA HART NAMUR</p> <p><b>Current span, operational range and signal on alarm level</b></p>  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">a</th> <th style="text-align: center;">1</th> <th style="text-align: center;">2</th> <th style="text-align: center;">3</th> </tr> </thead> <tbody> <tr> <td>0-20 mA</td> <td>0 - 20.5 mA</td> <td>0</td> <td>22</td> </tr> <tr> <td>4-20 mA</td> <td>4 - 20.5 mA</td> <td>2</td> <td>22</td> </tr> <tr> <td>4-20 mA HART</td> <td>4 - 20.5 mA</td> <td>2</td> <td>22</td> </tr> <tr> <td>4-20 mA NAMUR</td> <td>3.8 - 20.5 mA</td> <td>3.5</td> <td>22.6</td> </tr> <tr> <td>4-20 mA HART NAMUR</td> <td>3.8 - 20.5 mA</td> <td>3.5</td> <td>22.6</td> </tr> <tr> <td>4-20 mA US</td> <td>3.9 - 20.8 mA</td> <td>3.75</td> <td>22.6</td> </tr> <tr> <td>4-20 mA HART US</td> <td>3.9 - 20.8 mA</td> <td>3.75</td> <td>22.6</td> </tr> <tr> <td>0-20 mA (25 mA)</td> <td>0 - 24 mA</td> <td>0</td> <td>25</td> </tr> <tr> <td>4-20 mA (25 mA)</td> <td>4 - 24 mA</td> <td>2</td> <td>25</td> </tr> <tr> <td>4-20 mA (25 mA) HART</td> <td>4 - 24 mA</td> <td>2</td> <td>25</td> </tr> </tbody> </table> <p style="text-align: right; font-size: small;">A0001222</p> <p><i>a = Current span</i>  <i>1 = Operational range (measuring information)</i>  <i>2 = Lower signal on alarm level</i>  <i>3 = Upper signal on alarm level</i></p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ When switching the hardware from an active (factory setting) to a passive output signal select a current span of 4–20 mA.</li> <li>■ If the measured value exceeds the measuring range a notice message is generated (#351...354, current span).</li> <li>■ In case of a fault the behaviour of the current output is according to the selected option in the function FAILSAFE MODE (see Page 21). Change the error category in the function ASSIGN SYSTEM ERROR (see Page 54) to generate a fault message instead of a notice message.</li> </ul>	a	1	2	3	0-20 mA	0 - 20.5 mA	0	22	4-20 mA	4 - 20.5 mA	2	22	4-20 mA HART	4 - 20.5 mA	2	22	4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA US	3.9 - 20.8 mA	3.75	22.6	4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6	0-20 mA (25 mA)	0 - 24 mA	0	25	4-20 mA (25 mA)	4 - 24 mA	2	25	4-20 mA (25 mA) HART	4 - 24 mA	2	25
a	1	2	3																																										
0-20 mA	0 - 20.5 mA	0	22																																										
4-20 mA	4 - 20.5 mA	2	22																																										
4-20 mA HART	4 - 20.5 mA	2	22																																										
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6																																										
4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6																																										
4-20 mA US	3.9 - 20.8 mA	3.75	22.6																																										
4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6																																										
0-20 mA (25 mA)	0 - 24 mA	0	25																																										
4-20 mA (25 mA)	4 - 24 mA	2	25																																										
4-20 mA (25 mA) HART	4 - 24 mA	2	25																																										

<b>Function description CURRENT OUTPUT</b>	
<b>VALUE 20 mA</b>	<p>Use this function to assign the 20 mA current a full scale value. Positive and negative values are permissible. The required measuring range is defined by defining the VALUE 20 mA.</p> <p>In the SYMMETRY measuring mode, (see Page 45), the value assigned applies to both flow directions; in the STANDARD measuring mode it applies only to the flow direction selected.</p> <p><b>User input:</b> 5-digit floating-point number, with sign</p> <p><b>Factory setting:</b> Depends on nominal diameter and country (see Page 58 ff.).</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).</li> <li>■ The value for 0 or 4 mA always corresponds to the zero flow (0 [unit]). This value is fixed and cannot be edited.</li> </ul>
<b>TIME CONSTANT</b>	<p>Use this function to enter a time constant defining how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p><b>User input:</b> fixed-point number 0.01...100.00 s</p> <p><b>Factory setting:</b> 3.00 s</p>
<b>FAILSAFE MODE</b>	<p>For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select here affects only the current output. The failsafe mode of other outputs and the totalizers is defined in the corresponding function groups.</p> <p><b>Options:</b></p> <p><b>MIN. CURRENT</b> The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN).</p> <p><b>MAX. CURRENT</b> The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN).</p> <p><b>HOLD VALUE (not recommended)</b> Measuring value output is based on the last measuring value saved before the error occurred .</p> <p><b>ACTUAL VALUE</b> Measured value output is based on the current flow measurement. The fault is ignored .</p> <p><b>Factory setting:</b> MIN. CURRENT</p>
<b>ACTUAL CURRENT</b>	<p>Use this function to view the computed actual value of the output current.</p> <p><b>User interface:</b> 0.00...25.00 mA</p>

<b>Function description CURRENT OUTPUT</b>	
<b>SIMULATION CURRENT</b>	<p>Use this function to activate simulation of the current output.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The "SIMULATION CURRENT OUTPUT" notice message indicates that simulation is active.</li> <li>■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs.</li> </ul> <p> Caution! The setting is not saved if the power supply fails.</p>
<b>VALUE SIMULATION CURRENT</b>	<p> Note!</p> <p>This function is not available unless the function SIMULATION CURRENT is active (= ON).</p> <p>Use this function to define a selectable value (e.g. 12 mA) to be output at the current output. This value is used to test downstream devices and the measuring device itself.</p> <p><b>User input:</b> Floating-point number: 0.00...25.00 mA</p> <p><b>Factory setting:</b> 0.00 mA</p> <p> Caution! The setting is not saved if the power supply fails.</p>

## 10 Group PULSE/FREQUENCY OUTPUT

Function description PULSE/FREQUENCY OUTPUT	
<p>This group is not available unless the measuring device is equipped with a pulse/frequency output.</p>	
<b>OPERATION MODE</b>	<p>Use this function to configure the output as a pulse output or frequency output. The functions available in this function group vary, depending on which option you select here.</p> <p><b>Options:</b> PULSE FREQUENCY</p> <p><b>Factory setting:</b> PULSE</p>
<b>ASSIGN FREQUENCY</b>	<p> <b>Note!</b> This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to assign a measured variable to the frequency output.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p> <p> <b>Note!</b> If you select OFF, the only functions shown in this function group are the functions ASSIGN FREQUENCY and OPERATION MODE.</p>
<b>END VALUE FREQ.</b>	<p> <b>Note!</b> This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to define a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE-f HIGH on Page 24.</p> <p><b>User input:</b> 4-digit fixed-point number 2...1250 Hz</p> <p><b>Factory setting:</b> 1000 Hz</p> <p>Example:</p> <ul style="list-style-type: none"> <li>■ VALUE-f HIGH = 1000 l/h, end frequency = 1000 Hz: i.e. at a flow of 1000 l/h, a frequency of 1000 Hz is output.</li> <li>■ VALUE-f HIGH = 3600 l/h, end frequency = 1000 Hz: i.e. at a flow of 3600 l/h, a frequency of 1000 Hz is output.</li> </ul> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 2 seconds, i.e. the on/off ratio is no longer symmetrical.</li> <li>■ The initial frequency is always 0 Hz. This value is fixed and cannot be edited.</li> </ul>

### Function description PULSE/FREQUENCY OUTPUT

#### VALUE-f HIGH



Note!

This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.

Use this function to assign a value to the end value frequency.


Positive and negative values are permissible. The required measuring range is defined by defining the VALUE-f HIGH. In the SYMMETRY measuring mode, (see Page 45), the value assigned applies to both flow directions; in the STANDARD measuring mode it applies only to the flow direction selected.

#### User input:

5-digit floating-point number

#### Factory setting:

Depends on nominal diameter and country, [value] / [dm<sup>3</sup>...m<sup>3</sup> or US-gal...US-Mgal] corresponds to the factory setting for the final value (see Page 58 ff.)



① = Value-f min.

② = Value-f high







A0001279



Note!

- The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).
- The value-f min. for the initial frequency always corresponds to the zero flow (0 [unit]). This value is fixed and cannot be edited.




Function description PULSE/FREQUENCY OUTPUT	
<b>OUTPUT SIGNAL</b>	<p> <b>Note!</b> Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.</p> <p>For selecting the output configuration of the frequency output.</p> <p><b>Options:</b> PASSIVE - POSITIVE PASSIVE - NEGATIVE</p> <p><b>Factory setting:</b> PASSIVE - POSITIVE</p> <p><b>Explanation</b></p> <ul style="list-style-type: none"> <li>■ PASSIVE = power is supplied to the frequency output by means of an external power supply.</li> </ul> <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the frequency output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> <li>■ If POSITIVE is selected, the internal transistor is activated with a <b>positive</b> signal level.</li> <li>■ If NEGATIVE is selected, the internal transistor is activated with a <b>negative</b> signal level (0 V).</li> </ul> <p> <b>Note!</b> With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (see examples).</p> <p><b>Example for passive output circuit (PASSIVE)</b> If PASSIVE is selected, the frequency output is configured as an open collector.</p>  <p style="text-align: right; font-size: small;">A0001225</p> <p>① = Open collector ② = External power supply</p> <p> <b>Note!</b> For continuous currents up to 25 mA (<math>I_{max} = 250 \text{ mA} / 20 \text{ ms}</math>).</p> <p><b>Example for output configuration PASSIVE-POSITIVE:</b> Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.</p>  <p style="text-align: right; font-size: small;">A0004687</p> <p>① = Open collector ② = Pull-up resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.</p>  <p style="text-align: right; font-size: small;">A0001975</p> <p>(continued on next page)</p>

## Function description PULSE/FREQUENCY OUTPUT

OUTPUT SIGNAL  
(continued)**Example for output configuration PASSIVE-POSITIVE:**

Output configuration with an external pull-down resistance.

In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.



A0004689


① = Open collector

② = Pull-down resistance

③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)

④ = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.




A0001981

**Example for output configuration PASSIVE-NEGATIVE:**

Output configuration with an external pull-up resistance.

In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.



A0004690


① = Open collector

② = Pull-up resistance





③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow)








④ = Output signal level in quiescent state (at zero flow)








In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.









A0001981








<b>Function description PULSE/FREQUENCY OUTPUT</b>	
<b>TIME CONSTANT</b>	<p> <b>Note!</b> This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to enter a time constant defining how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p><b>User input:</b> Floating-point number 0.00...100.00 s</p> <p><b>Factory setting:</b> 0.00 s</p>
<b>FAILSAFE MODE</b>	<p> <b>Note!</b> This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the frequency output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p><b>Options:</b>  <b>FALLBACK VALUE</b> Output is 0 Hz.  <b>FAILSAFE LEVEL</b> Output is the frequency specified in the FAILSAFE VALUE function.  <b>HOLD VALUE</b> Measuring value output is based on the last measuring value saved before the error occurred.  <b>ACTUAL VALUE</b> Measuring value output is based on the current flow measurement. The fault is ignored.</p> <p><b>Factory setting:</b> FALLBACK VALUE</p>
<b>FAILSAFE VALUE</b>	<p> <b>Note!</b> This function is not available unless FREQUENCY was selected in the OPERATION MODE function and FAILSAFE LEVEL was selected in the function FAILSAFE MODE.</p> <p>Use this function to define the frequency that the measuring device should output in the event of a fault.</p> <p><b>User input:</b> max. 4-digit number: 0...1250 Hz</p> <p><b>Factory setting:</b> 1250 Hz</p>
<b>ACTUAL FREQUENCY</b>	<p> <b>Note!</b> This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to view the computed value of the output frequency.</p> <p><b>User interface:</b> 0...1250 Hz</p>

<b>Function description PULSE/FREQUENCY OUTPUT</b>	
<b>SIMULATION FREQUENCY</b>	<p> <b>Note!</b> This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to activate simulation of the frequency output.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The "SIMULATION FREQUENCY OUTPUT" notice message indicates that simulation is active.</li> <li>■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs.</li> </ul> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>
<b>VALUE SIMULATION FREQUENCY</b>	<p> <b>Note!</b> This function is not available unless FREQUENCY was selected in the OPERATION MODE function and the function VALUE SIMULATION FREQUENCY is active (= ON).</p> <p>Use this function to define a selectable frequency value (e.g. 500 Hz) to be output at the frequency output. This value is used to test downstream devices and the measuring device itself.</p> <p><b>User input:</b> 0...1250 Hz</p> <p><b>Factory setting:</b> 0 Hz</p> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>
<b>ASSIGN PULSE</b>	<p> <b>Note!</b> This function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p>Use this function to assign a measured variable to the pulse output.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p> <p> <b>Note!</b> If you select OFF, the only functions shown in this function group are the functions ASSIGN PULSE and OPERATION MODE.</p>






<b>Function description PULSE/FREQUENCY OUTPUT</b>	
<b>PULSE VALUE</b>	<p> <b>Note!</b> This function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p>Use this function to define the flow at which a pulse is triggered. These pulses can be totalled by an external totalizer and in this way the total flow since measuring commenced can be registered.</p> <p><b>User input:</b> 5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b> Depends on nominal diameter and country (see Page 58 ff.).</p> <p> <b>Note!</b> The appropriate unit is taken from the group SYSTEM UNITS (see Page 8).</p>
<b>PULSE WIDTH</b>	<p> <b>Note!</b> This function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p>Use this function to enter the maximum pulse width of the output pulses.</p> <p><b>User input:</b> 0.5...2000 ms</p> <p><b>Factory setting:</b> 100 ms</p> <p>Pulse output is <b>always</b> with the pulse width (B) entered in this function. The intervals (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width (B = P).</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>transistor</p>  <p>conducting nonconducting</p> <p><math>B &lt; P</math></p> </div> <div style="text-align: center;"> <p>transistor</p>  <p>conducting nonconducting</p> <p><math>B = P</math></p> </div> </div> <p style="text-align: right; font-size: small;">A0001233-en</p> <p>B = Pulse width entered (the illustration applies to positive pulses) P = Intervals between the individual pulses</p> <p> <b>Note!</b> When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.).</p> <p> <b>Caution!</b> If the pulse number or frequency resulting from the pulse value entered, (see function PULSE VALUE on Page 27), and from the current flow is too large to maintain the pulse width selected (interval P is smaller than the pulse width B entered), a system error message (pulse memory) is generated after buffering/balancing time.</p>

Function description PULSE/FREQUENCY OUTPUT	
<b>OUTPUT SIGNAL</b>	<p> <b>Note!</b> Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p>For selecting the output configuration of the pulse output.</p> <p><b>Options:</b> PASSIVE - POSITIVE PASSIVE - NEGATIVE</p> <p><b>Factory setting:</b> PASSIVE - POSITIVE</p> <p><b>Explanation</b></p> <ul style="list-style-type: none"> <li>■ PASSIVE = power is supplied to the pulse output by means of an external power supply.</li> </ul> <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the pulse output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> <li>■ If POSITIVE is selected, the internal transistor is activated with a <b>positive</b> signal level.</li> <li>■ If NEGATIVE is selected, the internal transistor is activated with a <b>negative</b> signal level (0 V).</li> </ul> <p> <b>Note!</b> With the passive output configuration, the output signal levels of the pulse output depend on the external circuit (see examples).</p> <p><b>Example for passive output circuit (PASSIVE)</b> If PASSIVE is selected, the pulse output is configured as an open collector.</p>  <p style="text-align: right;">A0001225</p> <p>① = Open Collector ② = External power supply</p> <p> <b>Note!</b> For continuous currents up to 25 mA (<math>I_{max} = 250 \text{ mA} / 20 \text{ ms}</math>).</p> <p><b>Example for output configuration PASSIVE-POSITIVE:</b> Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.</p> <p style="text-align: center;">+ <math>U_{max} = 30 \text{ V DC}</math></p>  <p style="text-align: right;">A0004687</p> <p>① = Open Collector ② = Pull-Up-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.</p>  <p style="text-align: right;">A0001975</p> <p>(continued on next page)</p>




Function description PULSE/FREQUENCY OUTPUT	
<p><b>OUTPUT SIGNAL</b> (continued)</p>	<p><b>Example for output configuration PASSIVE-POSITIVE:</b> Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.</p> <div style="text-align: center;"> </div> <p>① = Open Collector                  ② = Pull-Down-Resistance                  ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)                  ④ = Output signal level in quiescent state (at zero flow)</p> <p>A0004689</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p>A0001981</p> <p><b>Example for output configuration PASSIVE-NEGATIVE:</b> Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p> <div style="text-align: center;"> </div> <p>① = Open Collector                  ② = Pull-Up-Resistance                  ③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow)                  ④ = Output signal level in quiescent state (at zero flow)</p> <p>A0004690</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p>A0001981</p>





<b>Function description PULSE/FREQUENCY OUTPUT</b>	
<b>FAILSAFE MODE</b>	<p> <b>Note!</b> This function is not available unless the PULSE setting was selected in the function OPERATION MODE.</p> <p>For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the pulse output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p><b>Options:</b> FALLBACK VALUE Output is 0 pulse.</p> <p>ACTUAL VALUE Measuring value output is based on the current flow measurement. The fault is ignored.</p> <p><b>Factory setting:</b> FALLBACK VALUE</p>
<b>SIMULATION PULSE</b>	<p> <b>Note!</b> This function is not available unless the PULSE option was selected in the OPERATION MODE function.</p> <p>Use this function to activate simulation of the pulse output.</p> <p><b>Options:</b> OFF</p> <p>COUNTDOWN The pulses specified in the VALUE SIMULATION PULSE function are output.</p> <p>CONTINUOUSLY Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the  key.</p> <p> <b>Note!</b> Simulation is started by confirming the CONTINUOUSLY option with the  key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The notice message #631 "SIM. PULSE" indicates that simulation is active.</li> <li>■ The on/off ratio is 1:1 for both types of simulation.</li> <li>■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.</li> </ul> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>





<b>Function description PULSE/FREQUENCY OUTPUT</b>	
<b>VALUE SIMULATION PULSE</b>	<p> <b>Note!</b> This function is not available unless the COUNTDOWN option was selected in the SIMULATION PULSE function.</p> <p>Use this function to specify the number of pulses (e.g. 50) which are output during the simulation. This value is used to test downstream devices and the measuring device itself. The pulses are output with the pulse width specified in the PULSE WIDTH function. The on/off ratio is 1:1.</p> <p>Simulation is started once the specified value is confirmed with the  key. The display remains at "0" if the specified pulses have been output.</p> <p><b>User input:</b> 0...10000</p> <p><b>Factory setting:</b> 0</p> <p> <b>Note!</b> Simulation is started by confirming the simulation value with the  key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>

## 11 Group STATUS OUTPUT

<b>Function description STATUS OUTPUT</b>	
This group is not available unless the measuring device is equipped with a status output.	
<b>ASSIGN STATUS OUTPUT</b>	<p>Use this function to assign a switching function to the status output.</p> <p><b>Options:</b>            OFF            ON (operation)            FAULT MESSAGE            NOTICE MESSAGE            FAULT MESSAGE or NOTICE MESSAGE            EPD or OED (Empty Pipe Detection / Open Electrode Detection, only if active)            FLOW DIRECTION            VOLUME FLOW LIMIT VALUE</p> <p><b>Factory setting:</b>            FAULT MESSAGE</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The behaviour of the status output is a normally closed behaviour, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress.</li> <li>■ It is very important to read and comply with the information on the switching characteristics of the status output, (see Page 34).</li> <li>■ If you select OFF, the only function shown in this function group is the function ASSIGN STATUS OUTPUT.</li> </ul>
<b>ON-VALUE</b>	<p> Note!</p> <p>This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the function ASSIGN STATUS OUTPUT.</p> <p>Use this function to assign a value to the switch-on point (status output pulls up). The value can be equal to, greater than or less than the switch-off point. Positive and negative values are permissible.</p> <p><b>User input:</b>            5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b>            0 [unit]</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).</li> <li>■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5 ), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.</li> </ul>

<b>Function description STATUS OUTPUT</b>	
<b>OFF-VALUE</b>	<p> <b>Note!</b> This function is not available unless LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT.</p> <p>Use this function to assign a value to the switch-off point (status output drops out). The value can be equal to, greater than or less than the switch-on point. Positive and negative values are permissible.</p> <p><b>User input:</b> 5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b> 0 [unit]</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).</li> <li>■ If SYMMETRY is selected in the function MEASURING MODE (Page 45) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.</li> </ul>
<b>TIME CONSTANT</b>	<p>Use this function to enter a time constant defining how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow.</p> <p><b>User input:</b> fixed-point number 0.00...100.00 s</p> <p><b>Factory setting:</b> 0.00 s</p>
<b>ACTUAL STATUS OUTPUT</b>	<p>Use this function to check the current status of the status output.</p> <p><b>User interface:</b> NOT CONDUCTIVE CONDUCTIVE</p>
<b>SIMULATION SWITCH POINT</b>	<p>Use this function to activate simulation of the status output.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The "SIMULATION STATUS OUTPUT" message indicates that simulation is active.</li> <li>■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs.</li> </ul> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>

Function description STATUS OUTPUT	
<b>VALUE SIMULATION SWITCH POINT</b>	<p> <b>Note!</b> This function is not available unless the function SIMULATION SWITCH POINT is active (= ON).</p> <p>Use this function to define the switching response of the status output during the simulation. This value is used to test downstream devices and the measuring device itself.</p> <p><b>Options:</b> NOT CONDUCTIVE CONDUCTIVE</p> <p><b>Factory setting:</b> NOT CONDUCTIVE</p> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>


## 11.1 Information on the response of the status output

### General

If you have configured the status output for "LIMIT VALUE" or "FLOW DIRECTION", you can configure the requisite switch points in the functions ON-VALUE and OFF-VALUE. When the measured variable in question reaches these predefined values, the status output switches as shown in the illustrations below.

### Status output configured for limit value


The status output switches as soon as the measured variable undershoots or overshoots a defined switch point. Application: Monitoring flow or process-related boundary conditions.



- A = Maximum safety → ① SWITCH-OFF POINT > ② SWITCH-ON POINT
- B = Maximum safety → ① SWITCH-OFF POINT < ② SWITCH-ON POINT
- C = Maximum safety → ① SWITCH-OFF POINT = ② SWITCH-ON POINT (this configuration is to avoid)
- ③ = Status output switched off (not conductive)





















### Status output configured for flow direction









The value entered in the function SWITCH-ON POINT defines the switch point for the positive and negative directions of flow. If, for example, the switch point entered is  $1 \text{ m}^3/\text{h}$ , the status output switches off at  $-1 \text{ m}^3/\text{h}$  (not conductive) and switches on again at  $+1 \text{ m}^3/\text{h}$  (conductive). Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value greater than or equal to the low flow rate.






- a = Status output conductive
- b = Status output not conductive

## 11.2 Switching response of the status output

Function	Status		Open collector response (transistor)
<b>ON (operation)</b>	System in measuring mode	 A0001052	conductive  A0001237
	System not in measuring mode (power supply failed)	 A0001291	not conductive  A0001238
<b>Fault message</b>	System OK	 A0001052	conductive  A0001237
	(System or process error) Fault → Error response of outputs/inputs and totalizer	 A0001291	not conductive  A0001238
<b>Notice message</b>	System OK	 A0001052	conductive  A0001237
	(System or process error) Fault → Continuation of measuring	 A0001291	not conductive  A0001238
<b>Fault message or notice message</b>	System OK	 A0001052	conductive  A0001237
	(System or process error) Fault → Response to error or Note → Continuation of measuring	 A0001291	not conductive  A0001238
<b>Empty pipe detection (EPD) / Open electrode detection (OED)</b>	Measuring tube full	 A0001292	conductive  A0001237
	Measuring tube partially filled / empty measuring tube	 A0001293	not conductive  A0001238

Function	Status	Open collector response (transistor)
<b>Flow direction</b>	Forward  A0001241	conductive  A0001237
	Reverse  A0001242	not conductive  A0001238
<b>Limit value</b> Volume flow	Limit value not overshoot or undershot  A0001243	conductive  A0001237
	Limit value overshoot or undershot  A0001244	not conductive  A0001238



## 12 Group STATUS INPUT

<b>Function description STATUS INPUT</b>	
This group is not available unless the measuring device is equipped with a status input.	
<b>ASSIGN STATUS INPUT</b>	<p>Use this function to assign a switching function to the status input.</p> <p><b>Options:</b>            OFF            RESET TOTALIZER 1            POSITIVE ZERO RETURN            RESET TOTALIZER 2            RESET ALL TOTALIZERS</p> <p><b>Factory setting:</b>            OFF</p> <p> <b>Note!</b>            Positive zero return is active as long as the active level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.</p>
<b>ACTIVE LEVEL</b>	<p>Use this function to define whether the assigned switch function, (see function ASSIGN STATUS INPUT) is released or sustained when the level is present (HIGH) or not present (LOW).</p> <p><b>Options:</b>            HIGH            LOW</p> <p><b>Factory setting:</b>            HIGH</p>
<b>MINIMUM PULSE WIDTH</b>	<p>Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function.</p> <p><b>User input:</b>            20...100 ms</p> <p><b>Factory setting:</b>            50 ms</p>
<b>SIMULATION STATUS INPUT</b>	<p>Use this function to activate simulation of the status input, i.e. to trigger the function assigned to the status input, (see function ASSIGN STATUS INPUT on Page 31).</p> <p><b>Options:</b>            OFF            ON</p> <p><b>Factory setting:</b>            OFF</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The "SIMULATION STATUS INPUT" notice message indicates that simulation is active.</li> <li>■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the outputs.</li> </ul> <p> <b>Caution!</b>            The setting is not saved if the power supply fails.</p>





Function description STATUS INPUT	
<b>VALUE SIMULATION STATUS INPUT</b>	<p> <b>Note!</b> This function is not available unless the function SIMULATION STATUS INPUT is active (= ON).</p> <p>Use this function to select the level to be simulated at the status input.</p> <p><b>Options:</b> HIGH LOW</p> <p><b>Factory setting:</b> LOW</p> <p> <b>Caution!</b> The setting is not saved if the power supply fails.</p>


## 13 Group COMMUNICATION


Function description COMMUNICATION	
<b>TAG NAME</b>	<p>Use this function to enter a tag name for the measuring device. You can edit and read this tag name at the local display or via the HART protocol.</p> <p><b>User input:</b> max. 8-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks</p> <p><b>Factory setting:</b> " _ _ _ _ _ _ _ _ " (no text)</p>
<b>TAG DESCRIPTION</b>	<p>Use this function to enter a tag description for the measuring device. You can edit and read this tag description at the local display or via the HART protocol.</p> <p><b>User input:</b> max. 16-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks</p> <p><b>Factory setting:</b> " _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ " (No text)</p>
<b>BUS ADDRESS</b>	<p>Use this function to define the address for the exchange of data with the HART protocol.</p> <p><b>User input:</b> 0...15</p> <p><b>Factory setting:</b> 0</p> <p> Note! Addresses 1...15: a constant 4 mA current is applied.</p>
<b>HART PROTOCOL</b>	<p>Use this function to display if the HART protocol is active.</p> <p><b>User interface:</b> OFF = HART protocol not active ON = HART protocol active</p> <p> Note! The HART protocol is activated by selecting 4–20 mA HART or 4–20 mA (25 mA) HART in the function CURRENT SPAN (see Page 20).</p>
<b>MANUFACTURER ID</b>	<p>Use this function to view the manufacturer.</p> <p><b>User interface:</b></p> <ul style="list-style-type: none"> <li>– Endress+Hauser</li> <li>– 17 (≙ 11 hex) for Endress+Hauser</li> </ul>
<b>DEVICE ID</b>	<p>Use this function to view the device ID in hexadecimal numerical format.</p> <p><b>User interface:</b> 41 (≙ 65 dez) for Promag 50</p>
<b>DEVICE REVISION</b>	<p>Use this function to view the device-specific revision of the HART command interface.</p> <p><b>User interface:</b> E.g.: 5</p>








# 14 Group PROCESS PARAMETER






Function description PROCESS PARAMETER	
<p><b>ASSIGN LOW FLOW CUT OFF</b></p>	<p>Use this function to assign the switch point for low flow cut off.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p>
<p><b>ON-VALUE LOW FLOW CUT OFF</b></p>	<p>Use this function to enter the switch-on point for low flow cut off.</p> <p>Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active.</p> <p><b>User input:</b> 5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b> Depends on nominal diameter and country (see Page 58 ff.).</p> <p> <b>Note!</b> The appropriate unit is taken from the group SYSTEM UNITS (see Page 8).</p>
<p><b>OFF-VALUE LOW FLOW CUT OFF</b></p>	<p>Use this function to enter the switch-off point for low flow cut off. Enter the switch-off point as a positive hysteresis value from the switch-on point.</p> <p><b>User input:</b> Integer 0...100%</p> <p><b>Factory setting:</b> 50%</p> <div data-bbox="778 1240 1086 1464" data-label="Figure"> </div> <p>① = switch-on point , ② = switch-off point</p> <p><math>a</math> = Low flow cut off is switched on  <math>b</math> = Low flow cut off is switched off (<math>a + a \cdot H</math>)  <math>H</math> = Hysteresis value: 0 to 100%   = Low flow cut off active  <math>Q</math> = Flow</p>




A0003882

<b>Function description PROCESS PARAMETER</b>	
<b>EMPTY PIPE DETECTION (EPD)</b>	<p>Flow cannot be measured correctly unless the measuring tube is full. This status can be monitored at all times with the Empty Pipe Detection function. Use this function to activate Empty Pipe Detection (EPD) or Open Electrode Detection (OED).</p> <ul style="list-style-type: none"> <li>■ EPD = Empty Pipe Detection (with the help of an EPD electrode)</li> <li>■ OED = Open Electrode Detection (empty pipe detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).</li> </ul> <p><b>Options:</b> OFF – ON SPECIAL – OED – ON STANDARD</p> <p>OFF (neither EPD nor OED are active)</p> <p>ON SPECIAL (only for DN &lt;400): Switching on the Empty Pipe Detection (EPD) for devices in remote version (transmitter and sensor are installed separately).</p> <p>OED: Switching on the Open Electrode Detection (OED).</p> <p>ON STANDARD: Switching on the Empty Pipe Detection (EPD) for:</p> <ul style="list-style-type: none"> <li>– Devices in compact version (transmitter and sensor form a single mechanical unit).</li> <li>– Applications where a facing and coating of the fluid on the measuring tube line and measuring electrode accrues.</li> </ul> <p><b>Factory setting:</b> OFF</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The options ON STANDARD and ON SPECIAL are not available unless the sensor is equipped with an EPD electrode.</li> <li>■ The default setting for the EPD/OED functions when the device is delivered is OFF. The functions must be activated as required.</li> <li>■ The devices are calibrated at the factory with water (approx. 500 µS/cm). If the conductivity of certain fluids deviates from this reference, empty pipe/full pipe adjustment must be performed again on site (see function EPD/OED ADJUSTMENT on page 46).</li> <li>■ The adjustment coefficients must be valid before you can switch on the EPD or OED. If these coefficients are not available, the function EPD/OED ADJUSTMENT is displayed (see Page 44).</li> <li>■ If there are problems with the adjustment, the following error messages appear on the screen: <ul style="list-style-type: none"> <li>– ADJUSTMENT FULL = EMPTY: The adjustment values for empty pipe and full pipe are identical. In such instances, empty pipe adjustment/full pipe adjustment <b>must</b> be carried out <b>again</b>.</li> <li>– ADJUSTMENT NOT OK: Adjustment is not possible as the fluid conductivity values are outside the permitted range.</li> </ul> </li> </ul> <p>(continued on next page)</p>

<b>Function description PROCESS PARAMETER</b>	
<p><b>EMPTY PIPE DETECTION (EPD)</b> (continued)</p>	<p><b>Notes on empty pipe detection (EPD and OED)</b></p> <ul style="list-style-type: none"> <li>■ Flow cannot be measured correctly unless the measuring pipe is completely full. This status can be monitored at all times by means of the EPD/OED.</li> <li>■ An empty or partially filled pipe is a process error. A default factory setting defines that a fault message is issued and that this process error has an effect on the outputs.</li> <li>■ The EPD/OED process error can be output via the configurable status output.</li> <li>■ Use the function ASSIGN PROCESS ERROR to define whether a notice or fault message should be triggered (see Page 54).</li> <li>■ A plausibility check of the adjustment values will only be executed by activating the empty pipe detection. If an empty or full pipe adjustment is performed during the empty pipe detection is active, the empty pipe detection has to be de- and again activated, after finishing the adjustment, to start the plausibility check.</li> </ul> <p><b>Response to partially filled pipes</b></p> <p>If the EPD/OED is switched on and responds to a partially filled or empty pipe, the fault message "EMPTY PIPE" appears on the display. If the pipe is partially empty and the EPD/OED is <b>not</b> switched on, the response can vary in identically configured systems:</p> <ul style="list-style-type: none"> <li>■ Flow reading fluctuates</li> <li>■ Zero flow</li> <li>■ Excessively high flow values</li> </ul> <p><b>Notes on Open Electrode Detection (OED)</b></p> <p>Open Electrode Detection (OED) functions like the Empty Pipe Detection (EPD). In contrast to the EPD where the measuring device must be equipped with a separate (optional) electrode, the OED detects partial filling by means of the two measuring electrodes which are present as standard (fluid no longer covers the measuring electrodes).</p> <p>Open electrode detection can also be used if:</p> <ul style="list-style-type: none"> <li>■ the sensor is not installed in the optimal position for using EPD (optimal = installed horizontally).</li> <li>■ the sensor is not equipped with an additional (optional) EPD electrode.</li> </ul> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ <b>Cable connection length:</b> When mounting a remote version, please observe the maximum permissible cable length of 15 metres in order to keep the OED function.</li> <li>■ <b>OED empty pipe adjustment:</b> To achieve the best results for the open electrode detection, it is important to have the electrodes surface as dry as possible (no liquid film) while the empty-pipe adjustment is being made. Even during normal operation, the OED function is only secured if there is no longer any liquid film present on the electrodes when the measuring pipe is empty.</li> </ul>





Function description PROCESS PARAMETER	
<b>EPD/OED ADJUSTMENT</b>	<p>Use this function to activate the EPD/OED adjustment for an empty or full measuring tube.</p> <p> <b>Note!</b> A detailed description and other helpful hints for the empty-pipe/full-pipe adjustment procedure can be found on Page 44.</p> <p><b>Options:</b> OFF FULL PIPE ADJUST EMPTY PIPE ADJUST OED FULL ADJUST OED EMPTY ADJUST</p> <p><b>Factory setting:</b> OFF</p> <p><b>Procedure for EPD or OED empty-pipe / full-pipe adjustment</b></p> <ol style="list-style-type: none"> <li>1. Empty the piping. In case of an EPD adjustment, the wall of the measuring tube should be wetted with fluid for the adjustment procedure but this is not the case with an OED adjustment!</li> <li>2. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press  to confirm.</li> <li>3. After empty-pipe adjustment, fill the piping with fluid.</li> <li>4. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press  to confirm.</li> <li>5. Having completed the adjustment, select the setting "OFF" and exit the function by pressing .</li> <li>6. Now select the "EMPTY PIPE DETECTION" function. Switch on Empty Pipe Detection by selecting the following settings: <ul style="list-style-type: none"> <li>– EPD → Select ON STANDARD or ON SPECIAL and press  to confirm.</li> <li>– OED → Select OED and confirm with .</li> </ul> </li> </ol> <p> <b>Caution!</b> The adjustment coefficients must be valid before you can activate the EPD/OED function. If adjustment is incorrect the following messages might appear on the display:</p> <ul style="list-style-type: none"> <li>– FULL = EMPTY The adjustment values for empty pipe and full pipe are identical. In cases of this nature you <b>must</b> repeat empty-pipe or full-pipe adjustment <b>again!</b></li> <li>– ADJUSTMENT NOT OK Adjustment is not possible because the fluid's conductivity is out of range.</li> </ul>




<b>Function description PROCESS PARAMETER</b>	
<b>EPD/OED RESPONSE TIME</b>	<p> <b>Note!</b> This function is not available unless ON STANDARD, ON SPECIAL or OED was selected in the EMPTY PIPE DETECTION function.</p> <p>Use this function to enter the time span for which the criteria for an "empty" pipe have to be satisfied without interruption before a notice message or fault message is generated. The setting defined here is used by the active empty pipe detection (EPD) or open electrode detection (OED).</p> <p><b>User input:</b> fixed-point number 1.0...100 s</p> <p><b>Factory setting:</b> 1.0 s</p> <p> <b>Note!</b> OED detection time: The recognition of open electrodes is, in contrast to the empty pipe detection (EPD), very slow reacting (delay at least 25 seconds) and is only activated after an additional delay from the programmed response time! We recommend in most applications to use the empty pipe detection (EPD) which is an optimal solution for detecting partly filled measuring tubes.</p>
<b>ECC</b>	<p> <b>Note!</b> This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).</p> <p>Use this function to activate cyclical electrode cleaning.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> ON (only if the optional electrode cleaning function ECC is available)</p> <p><b>Notes on electrode cleaning (ECC)</b> Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits accreting in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.</p> <p> <b>Caution!</b> If the ECC is switched off for a prolonged period in applications with conductive deposits, a layer forms inside the measuring tube and this can falsify measurement values. If the layer is allowed to accrete beyond a certain level, it might no longer be possible to remove it by switching on the ECC. If this happens the measuring tube must be cleaned and the layer removed.</p>
<b>ECC DURATION</b>	<p> <b>Note!</b> This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).</p> <p>Use this function to specify the electrode cleaning duration.</p> <p><b>User input:</b> fixed-point number 0.01...30.0 s</p> <p><b>Factory setting:</b> 2.0 s</p>




<b>Function description PROCESS PARAMETER</b>	
<b>ECC RECOVERY TIME</b>	<p> <b>Note!</b> This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).</p> <p>Use this function to specify the recovery time for which the last flow value measured prior to cleaning is retained. A recovery time is necessary as the signal outputs can fluctuate after electrode cleaning on account of electrochemical interference voltages.</p> <p><b>User input:</b> max. 3-digit number: 1 ... 600 s</p> <p><b>Factory setting:</b> 5 s</p> <p> <b>Caution!</b> The last value measured prior to cleaning is output for the duration of the recovery time (max. 600 s). This in turn means that the measuring system does not register changes in flow, e.g. stoppage, during this time span.</p>
<b>ECC CLEANING CYCLE</b>	<p> <b>Note!</b> This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).</p> <p>Use this function to specify the cleaning cycle for electrode cleaning.</p> <p><b>User input:</b> Integer: 30...10080 min</p> <p><b>Factory setting:</b> 40 min</p>








# 15 Group SYSTEM PARAMETERS



Function description SYSTEM PARAMETERS	
<b>INSTALLATION DIRECTION SENSOR</b>	<p>Use this function to reverse the sign of the flow quantity, if necessary.</p> <p><b>Options:</b>                      NORMAL (flow as indicated by the arrow)                      INVERSE (flow opposite to direction indicated by the arrow)</p> <p><b>Factory setting:</b>                      NORMAL</p> <p> <b>Note!</b>                      Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).</p>
<b>MEASURING MODE</b>	<p>Use this function to select the measuring mode for all outputs.</p> <p><b>Options:</b>                      STANDARD                      SYMMETRY</p> <p><b>Factory setting:</b>                      STANDARD</p> <p>The responses of the individual outputs in each of the measuring modes are described in detail on the following pages:</p> <p><b>Current output and frequency output</b>                      STANDARD</p> <p>Only the flow components for the selected flow direction are totalled, (positive or negative full scale value ② = flow direction). Flow components in the opposite direction are not taken into account (suppression).</p> <p>Example for current output:</p>  <p style="text-align: right; font-size: small;">A0001248</p> <p><b>SYMMETRY</b></p> <p>The output signals of the current and frequency outputs are independent of the direction of flow (absolute amount of the measured variable). The "VALUE 20 mA" or "VALUE-f HIGH" ③ (e.g. backflow) corresponds to the mirrored VALUE 20 mA or VALUE-f HIGH ② (e.g. flow). Positive and negative flow components are taken into account.</p> <p>Example for current output:</p>  <p style="text-align: right; font-size: small;">A0001249</p> <p> <b>Note!</b>                      The direction of flow can be output via the configurable status output.</p> <p>(continued on next page)</p>

<b>Function description SYSTEM PARAMETERS</b>	
<b>MEASURING MODE</b> (continued)	<p><b>Pulse output</b> STANDARD Only positive flow components are totalled. Negative components are not taken into account.</p> <p>SYMMETRY Positive and negative flow components are taken into account.</p> <p> Note! The direction of flow can be output via the configurable status output.</p> <p><b>Status output</b></p> <p> Note! The information is only applicable if LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT.</p> <p>STANDARD The status output signal switches at the defined switch points.</p> <p>SYMMETRY The status output signal switches at the defined switch points, irrespective of the sign. In other words, if you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (see illustration).</p> <p>Example for the SYMMETRY measuring mode: Switch-on point: Q = 4 Switch-off point: Q = 10</p> <p>① = Status output switched on (conductive) ② = Status output switched off (not conductive)</p>  <p style="text-align: right;">A0001247</p>
<b>POSITIVE ZERO RETURN</b>	<p>Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device.</p> <p><b>Options:</b> OFF ON → Signal output is set to the "ZERO FLOW" value.</p> <p><b>Factory setting:</b> OFF</p>








<b>Function description SYSTEM PARAMETERS</b>	
<b>SYSTEM DAMPING</b>	<p>Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The system reaction time decreases with an increasing filter setting.</p> <p><b>User input:</b> 0...15</p> <p><b>Factory setting:</b> 9</p> <p> <b>Note!</b> The system damping acts on all functions and outputs of the measuring device.</p>
<b>INTEGRATION TIME</b>	<p>Use this function to set the integration time. Under normal circumstances it is not necessary to change the factory settings.</p> <p><b>User input:</b> 3.3...65 ms</p> <p><b>Factory setting:</b> 20 ms at 50 Hz → mains frequency (e.g. Europe) 16.7 ms at 60 Hz → mains frequency (e.g. USA)</p> <p> <b>Caution!</b> The integration time must not be selected with a greater value than the measuring period (see Page 53).</p> <p> <b>Note!</b> The integration time defines the duration of internal totaling of the induced voltage in the fluid (measured by the measuring electrode), i.e. the time in which the measuring device records the true flow (afterwards the magnetic field for the next integration is created from the opposite pole).</p>





## 16 Group SENSOR DATA

<b>Function description SENSOR DATA</b>	
<p>All sensor data (calibration factors, zero point and nominal diameter etc.) are set at the factory and saved on the S-DAT sensor memory chip.</p> <p> <b>Caution!</b> Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code.</p> <p>Contact the Endress+Hauser service organization if you have any questions about these functions.</p>	
<b>CALIBRATION DATE</b>	<p>Use this function to view the current calibration date and time for the sensor.</p> <p><b>User interface:</b> Calibration date and time</p> <p><b>Factory setting:</b> Calibration date and time of the current calibration.</p> <p> <b>Note!</b> The calibration date and time format is defined in the FORMAT DATE TIME function, → Page 9.</p>
<b>K-FACTOR</b>	<p>Use this function to display the current calibration factor for the sensor. The calibration factor is determined and set at the factory.</p> <p><b>User interface:</b> 5-digit fixed-point number: 0.5000...2.0000</p> <p><b>Factory setting:</b> Depends on nominal diameter and calibration</p> <p> <b>Note!</b> This value is also provided on the sensor nameplate.</p>
<b>ZERO POINT</b>	<p>This function shows the current zero-point correction value for the sensor. Zero-point correction is determined and set at the factory.</p> <p><b>User interface:</b> max. 4-digit number: -1000...+1000</p> <p><b>Factory setting:</b> Depends on nominal diameter and calibration</p> <p> <b>Note!</b> This value is also provided on the sensor nameplate.</p>
<b>NOMINAL DIAMETER</b>	<p>This function shows the nominal diameter for the sensor. The nominal diameter depends on the size of the sensor and is set at the factory.</p> <p><b>User interface:</b> 2...2000 mm or 1/12...78"</p> <p><b>Factory setting:</b> Depends on the size of the sensor</p> <p> <b>Note!</b> This value is also provided on the sensor nameplate.</p>





<b>Function description SENSOR DATA</b>	
<b>MEASURING PERIOD</b>	<p>Use this function to set the time for a full measuring period. The duration of the measuring period is calculated from the rise time of the magnetic field, the brief recovery time, the integration time (which can be set) and the empty pipe detection time.</p> <p><b>User input:</b> 0.0...1000 ms</p> <p><b>Factory setting:</b> Depends on nominal diameter</p> <p> <b>Note!</b> The system checks the time entered and sets the measuring period which is actually used internally to a plausible value. If you enter 0 ms, the system automatically computes the shortest time.</p>
<b>OVERVOLTAGE TIME</b>	<p>Use this function to specify the time in which overvoltage is applied to the coil circuit in order to build up the magnetic field as fast as possible. The overvoltage time is adjusted automatically while measuring is in progress. The overvoltage time depends on the sensor type and the nominal diameter and is set at the factory.</p> <p><b>User interface:</b> 4-digit floating-point number: 0.0...100.0 ms</p> <p><b>Factory setting:</b> Depends on nominal diameter</p>
<b>EPD ELECTRODE</b>	<p>Use this function to check whether the sensor is equipped with an EPD electrode.</p> <p><b>User interface:</b> YES NO</p> <p><b>Factory setting:</b> YES → Electrode fitted as standard</p>
<b>POLARITY ECC</b>	<p>Use this function to display the actual current polarity for optional electrode cleaning (ECC). Electrode cleaning uses either a positive or negative current, depending on the electrode material. The measuring device automatically selects the correct polarity on the basis of the electrode-material data stored in the S-DAT.</p> <p><b>User interface:</b> POSITIVE → for electrodes made of: 1.4435, Hastelloy C, platinum, titanium NEGATIVE → for electrodes made of: tantalum</p> <p> <b>Caution!</b> If the incorrect current is applied to the electrodes, the electrode material is destroyed.</p>

## 17 Group SUPERVISION

Function description SUPERVISION	
<b>CURRENT SYSTEM CONDITION</b>	<p>Use this function to check the present system status.</p> <p><b>User interface:</b> "SYSTEM OK" or the fault / notice message with the highest priority.</p>
<b>PREVIOUS SYSTEM CONDITIONS</b>	<p>Use this function to view the fifteen most recent fault and notice messages since measuring last started.</p> <p><b>User interface:</b> The last 15 fault/notice messages appear on the display</p>
<b>ASSIGN SYSTEM ERROR</b>	<p>Use this function to view all system errors and the associated error categories (fault message or notice message). By selecting a certain system error, its error category can be changed in the subsequent function ERROR CATEGORY.</p> <p><b>Options:</b> CANCEL List of system errors</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ You can exit this function as follows: select "CANCEL" and confirm with .</li> <li>■ A list of possible system errors is provided in the Operating Instructions Promag 50, BA 046D/06/en</li> </ul>
<b>ERROR CATEGORY</b>	<p> Note!</p> <p>This function is only available if a system error has been selected in the function ASSIGN SYSTEM ERROR.</p> <p>Use this function to define whether a system error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance with their defined error response patterns.</p> <p><b>Options:</b> NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)</p> <p> Note!</p> <p>Press the  key twice to call up the ASSIGN SYSTEM ERROR function.</p>
<b>ASSIGN PROCESS ERROR</b>	<p>Use this function to view all process errors and the associated error categories (fault message or notice message). By selecting an individual process error, its error category can be changed in the subsequent function ERROR CATEGORY.</p> <p><b>Options:</b> CANCEL List of process errors</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ You can exit this function as follows: select "CANCEL" and confirm with .</li> <li>■ A list of possible process errors is provided in the Operating Instructions Promag 50, BA 046D/06/en</li> </ul>

<b>Function description SUPERVISION</b>	
<b>ERROR CATEGORY</b>	<p> <b>Note!</b> This function is only available if a process error has been selected in the function ASSIGN PROCESS ERROR.</p> <p>Use this function to define whether a process error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance with their defined error response patterns.</p> <p><b>Options:</b> NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)</p> <p> <b>Note!</b> Press the  key twice to call up the ASSIGN PROCESS ERROR function.</p>
<b>ALARM DELAY</b>	<p>Use this function to define a time span in which the criteria for an error have to be satisfied without interruption before an error or notice message is generated.</p> <p>Depending on the setting and the type of error, this suppression acts on:</p> <ul style="list-style-type: none"> <li>■ Display</li> <li>■ Status output</li> <li>■ Current output</li> <li>■ Frequency output</li> </ul> <p><b>User input:</b> 0...100 s (in steps of one second)</p> <p><b>Factory setting:</b> 0 s</p> <p> <b>Caution!</b> If this function is activated error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.</p>
<b>SYSTEM RESET</b>	<p>Use this function to perform a reset of the measuring system.</p> <p><b>Options:</b> NO RESTART SYSTEM (restart without interrupting power supply)</p> <p><b>Factory setting:</b> NO</p>
<b>OPERATION HOURS</b>	<p>The hours of operation of the device appear on the display.</p> <p><b>Display:</b> Depends on the number of hours of operation elapsed: Hours of operation &lt; 10 hours → display format = 0:00:00 (hr:min:sec) Hours of operation 10...10,000 hours → display format = 0000:00 (hr:min) Hours of operation &gt; 10,000 hours → display format = 000000 (hr)</p>
<b>PERMANENT STORAGE</b>	<p>This function indicates whether permanent storage of all parameters in the EEPROM has been switched on or off.</p> <p><b>Display:</b> 0 = OFF 1 = ON</p> <p><b>Factory setting:</b> ON</p>

## 18 Group SIMULATION SYSTEM


Function description SIMULATION SYSTEM	
<b>SIMULATION FAILSAFE MODE</b>	<p>Use this function to set all inputs, outputs and the totalizer to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display.</p> <p><b>Options:</b> ON OFF</p> <p><b>Factory setting:</b> OFF</p>
<b>SIMULATION MEASURED VARIABLE</b>	<p>Use this function to set all inputs, outputs and the totalizer to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> OFF</p> <p> Caution!</p> <ul style="list-style-type: none"> <li>■ The measuring device cannot be used for measuring while this simulation is in progress.</li> <li>■ The setting is not saved if the power supply fails.</li> </ul>
<b>VALUE SIMULATION MEASURED VARIABLE</b>	<p> Note! This function is not available unless the SIMULATION MEASURED VARIABLE function is active (= VOLUME FLOW).</p> <p>Use this function to specify a selectable value (e.g. 12 m<sup>3</sup>/s). This value is used to test downstream devices and the measuring device itself.</p> <p><b>User input:</b> 5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b> 0 [unit]</p> <p> Caution! The setting is not saved if the power supply fails.</p> <p> Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8)</p>



## 19 Group SENSOR VERSION

Function description SENSOR VERSION	
<b>SERIAL NUMBER</b>	Use this function to view the serial number of the sensor.
<b>SENSOR TYPE</b>	Use this function to view the sensor type.
<b>HARDWARE REVISION NUMBER SENSOR</b>	Use this function to view the hardware revision number of the sensor.
<b>SOFTWARE REVISION NUMBER S-DAT</b>	Use this function to view the software revision number of the software used to create the content of the S-DAT

## 20 Group AMPLIFIER VERSION

Function description AMPLIFIER VERSION	
<b>DEVICE SOFTWARE</b>	Displays the current device software version.
<b>SOFTWARE REVISION NUMBER AMPLIFIER</b>	Use this function to view the software revision number of the amplifier.
<b>LANGUAGE GROUP</b>	<p>Use this function to view the language group.</p> <p>The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA.</p> <p><b>Display:</b> available language group</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The language options of the available language group are displayed in the LANGUAGE function.</li> <li>■ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.</li> </ul>
<b>I/O MODULE TYPE</b>	Use this function to view the configuration of the I/O module complete with terminal numbers.
<b>SOFTWARE REVISION NUMBER I/O MODULE</b>	Use this function to view the software revision number of the I/O module.

## 21 Factory settings

### 21.1 SI units (not for USA and Canada)

#### Low flow, full scale value, pulse value, totalizer

Nominal diameter		Low flow		Full scale value		Pulse value		Totalizer
[mm]	[inch]	(approx. v = 0.04 m/s)		(approx. v = 2.5 m/s)		(approx. 2 pulses/s at v = 2.5 m/s)		
2	1/12"	0.01	dm <sup>3</sup> /min	0.5	dm <sup>3</sup> /min	0.005	dm <sup>3</sup>	dm <sup>3</sup>
4	5/32"	0.05	dm <sup>3</sup> /min	2	dm <sup>3</sup> /min	0.025	dm <sup>3</sup>	dm <sup>3</sup>
8	5/16"	0.1	dm <sup>3</sup> /min	8	dm <sup>3</sup> /min	0.10	dm <sup>3</sup>	dm <sup>3</sup>
15	1/2"	0.5	dm <sup>3</sup> /min	25	dm <sup>3</sup> /min	0.20	dm <sup>3</sup>	dm <sup>3</sup>
25	1"	1	dm <sup>3</sup> /min	75	dm <sup>3</sup> /min	0.50	dm <sup>3</sup>	dm <sup>3</sup>
32	1 1/4"	2	dm <sup>3</sup> /min	125	dm <sup>3</sup> /min	1.00	dm <sup>3</sup>	dm <sup>3</sup>
40	1 1/2"	3	dm <sup>3</sup> /min	200	dm <sup>3</sup> /min	1.50	dm <sup>3</sup>	dm <sup>3</sup>
50	2"	5	dm <sup>3</sup> /min	300	dm <sup>3</sup> /min	2.50	dm <sup>3</sup>	dm <sup>3</sup>
65	2 1/2"	8	dm <sup>3</sup> /min	500	dm <sup>3</sup> /min	5.00	dm <sup>3</sup>	dm <sup>3</sup>
80	3"	12	dm <sup>3</sup> /min	750	dm <sup>3</sup> /min	5.00	dm <sup>3</sup>	dm <sup>3</sup>
100	4"	20	dm <sup>3</sup> /min	1200	dm <sup>3</sup> /min	10.00	dm <sup>3</sup>	dm <sup>3</sup>
125	5"	30	dm <sup>3</sup> /min	1850	dm <sup>3</sup> /min	15.00	dm <sup>3</sup>	dm <sup>3</sup>
150	6"	2.5	m <sup>3</sup> /h	150	m <sup>3</sup> /h	0.025	m <sup>3</sup>	m <sup>3</sup>
200	8"	5.0	m <sup>3</sup> /h	300	m <sup>3</sup> /h	0.05	m <sup>3</sup>	m <sup>3</sup>
250	10"	7.5	m <sup>3</sup> /h	500	m <sup>3</sup> /h	0.05	m <sup>3</sup>	m <sup>3</sup>
300	12"	10	m <sup>3</sup> /h	750	m <sup>3</sup> /h	0.10	m <sup>3</sup>	m <sup>3</sup>
350	14"	15	m <sup>3</sup> /h	1000	m <sup>3</sup> /h	0.10	m <sup>3</sup>	m <sup>3</sup>
400	16"	20	m <sup>3</sup> /h	1200	m <sup>3</sup> /h	0.15	m <sup>3</sup>	m <sup>3</sup>
450	18"	25	m <sup>3</sup> /h	1500	m <sup>3</sup> /h	0.25	m <sup>3</sup>	m <sup>3</sup>
500	20"	30	m <sup>3</sup> /h	2000	m <sup>3</sup> /h	0.25	m <sup>3</sup>	m <sup>3</sup>
600	24"	40	m <sup>3</sup> /h	2500	m <sup>3</sup> /h	0.30	m <sup>3</sup>	m <sup>3</sup>
700	28"	50	m <sup>3</sup> /h	3500	m <sup>3</sup> /h	0.50	m <sup>3</sup>	m <sup>3</sup>
–	30"	60	m <sup>3</sup> /h	4000	m <sup>3</sup> /h	0.50	m <sup>3</sup>	m <sup>3</sup>
800	32"	75	m <sup>3</sup> /h	4500	m <sup>3</sup> /h	0.75	m <sup>3</sup>	m <sup>3</sup>
900	36"	100	m <sup>3</sup> /h	6000	m <sup>3</sup> /h	0.75	m <sup>3</sup>	m <sup>3</sup>
1000	40"	125	m <sup>3</sup> /h	7000	m <sup>3</sup> /h	1.00	m <sup>3</sup>	m <sup>3</sup>
–	42"	125	m <sup>3</sup> /h	8000	m <sup>3</sup> /h	1.00	m <sup>3</sup>	m <sup>3</sup>
1200	48"	150	m <sup>3</sup> /h	10000	m <sup>3</sup> /h	1.50	m <sup>3</sup>	m <sup>3</sup>
–	54"	200	m <sup>3</sup> /h	13000	m <sup>3</sup> /h	1.50	m <sup>3</sup>	m <sup>3</sup>
1400	–	225	m <sup>3</sup> /h	14000	m <sup>3</sup> /h	2.00	m <sup>3</sup>	m <sup>3</sup>
–	60"	250	m <sup>3</sup> /h	16000	m <sup>3</sup> /h	2.00	m <sup>3</sup>	m <sup>3</sup>
1600	–	300	m <sup>3</sup> /h	18000	m <sup>3</sup> /h	2.50	m <sup>3</sup>	m <sup>3</sup>
–	66"	325	m <sup>3</sup> /h	20500	m <sup>3</sup> /h	2.50	m <sup>3</sup>	m <sup>3</sup>
1800	72"	350	m <sup>3</sup> /h	23000	m <sup>3</sup> /h	3.00	m <sup>3</sup>	m <sup>3</sup>
–	78"	450	m <sup>3</sup> /h	28500	m <sup>3</sup> /h	3.50	m <sup>3</sup>	m <sup>3</sup>
2000	–	450	m <sup>3</sup> /h	28500	m <sup>3</sup> /h	3.50	m <sup>3</sup>	m <sup>3</sup>

**Language**

<b>Country</b>	<b>Language</b>
Australia	English
Austria	Deutsch
Belgium	English
Czech Republic	Czech
Denmark	English
England	English
Finland	Suomi
France	Francais
Germany	Deutsch
Hong Kong	English
Hungary	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Netherlands	Nederlands
Norway	Norsk
Poland	Polish
Portugal	Portuguese
Russia	Russian
Singapore	English
South Africa	English
Spain	Espanol
Sweden	Svenska
Switzerland	Deutsch
Thailand	English

**Length**

	<b>Unit</b>
Length	mm

## 21.2 US units (only for USA and Canada)

### Low flow, full scale value, pulse value, totalizer

Nominal diameter		Low flow		Full scale value		Pulse value		Totalizer
[inch]	[mm]	(approx. v = 0.04 m/s)		(approx. v = 2.5 m/s)		(approx. 2 pulses/s at v = 2.5 m/s)		
1/12"	2	0.002	gal/min	0.1	gal/min	0.001	gal	gal
5/32"	4	0.008	gal/min	0.5	gal/min	0.005	gal	gal
5/16"	8	0.025	gal/min	2	gal/min	0.02	gal	gal
1/2"	15	0.10	gal/min	6	gal/min	0.05	gal	gal
1"	25	0.25	gal/min	18	gal/min	0.20	gal	gal
1 1/4"	32	0.50	gal/min	30	gal/min	0.20	gal	gal
1 1/2"	40	0.75	gal/min	50	gal/min	0.50	gal	gal
2"	50	1.25	gal/min	75	gal/min	0.50	gal	gal
2 1/2"	65	2.0	gal/min	130	gal/min	1	gal	gal
3"	80	2.5	gal/min	200	gal/min	2	gal	gal
4"	100	4.0	gal/min	300	gal/min	2	gal	gal
5"	125	7.0	gal/min	450	gal/min	5	gal	gal
6"	150	12	gal/min	600	gal/min	5	gal	gal
8"	200	15	gal/min	1200	gal/min	10	gal	gal
10"	250	30	gal/min	1500	gal/min	15	gal	gal
12"	300	45	gal/min	2400	gal/min	25	gal	gal
14"	350	60	gal/min	3600	gal/min	30	gal	gal
16"	400	60	gal/min	4800	gal/min	50	gal	gal
18"	450	90	gal/min	6000	gal/min	50	gal	gal
20"	500	120	gal/min	7500	gal/min	75	gal	gal
24"	600	180	gal/min	10500	gal/min	100	gal	gal
28"	700	210	gal/min	13500	gal/min	125	gal	gal
30"	–	270	gal/min	16500	gal/min	150	gal	gal
32"	800	300	gal/min	19500	gal/min	200	gal	gal
36"	900	360	gal/min	24000	gal/min	225	gal	gal
40"	1000	480	gal/min	30000	gal/min	250	gal	gal
42"	–	600	gal/min	33000	gal/min	250	gal	gal
48"	1200	600	gal/min	42000	gal/min	400	gal	gal
54"	–	1.3	Mgal/d	75	Mgal/d	0.0005	Mgal	Mgal
–	1400	1.3	Mgal/d	85	Mgal/d	0.0005	Mgal	Mgal
60"	–	1.3	Mgal/d	95	Mgal/d	0.0005	Mgal	Mgal
–	1600	1.7	Mgal/d	110	Mgal/d	0.0008	Mgal	Mgal
66"	–	2.2	Mgal/d	120	Mgal/d	0.0008	Mgal	Mgal
72"	1800	2.6	Mgal/d	140	Mgal/d	0.0008	Mgal	Mgal
78"	–	3.0	Mgal/d	175	Mgal/d	0.001	Mgal	Mgal
–	2000	3.0	Mgal/d	175	Mgal/d	0.001	Mgal	Mgal

### Language, length

	Unit
Language	English
Length	inch

## 22 Index of key words

### Numerics

100% Value ..... 13

### A

Access code ..... 12

Active level (status input) ..... 40

Actual

    Current ..... 21

    Frequency ..... 27

    Status output ..... 35

Alarm delay (notice or fault messages) ..... 55

Assign

    Current output ..... 19

    Display line 1 ..... 13

    Display line 2 ..... 13

    Frequency ..... 23

    Low flow cut off ..... 43

    Process error ..... 54

    Pulse ..... 28

    Status input ..... 40

    Status output ..... 34

    System error ..... 54

    Totalizer ..... 16

### B

Bus address ..... 42

### C

Code

    Access code ..... 12

    Counter (Unlocking) ..... 12

    Private code ..... 12

Commissioning Quick Setup ..... 10

Contrast LCD ..... 14

Current span ..... 20

### D

Device ID ..... 42

Device Revision ..... 42

Device software ..... 57

Display

    Backlight ..... 15

    Contrast LCD ..... 14

    Damping ..... 14

    Format ..... 14

    Test ..... 15

### E

ECC (electrode cleaning) ..... 47

    Cleaning cycle ..... 48

    Duration ..... 47

    Polarity ..... 53

    Recovery time ..... 48

Empty Pipe Detection (EPD/OED)

    EPD electrode ..... 53

    EPD/OED adjustment ..... 46

    General information ..... 44

    Response time ..... 47

    Switching on/off EPD/OED ..... 44

End value frequency ..... 23

Error category

    Process error ..... 55

    System error ..... 54

### F

Factory settings ..... 58

Failsafe mode

    Current output ..... 21

    Frequency output ..... 27

    Pulse output ..... 32

    Totalizer ..... 18

Flow damping (system damping) ..... 51

Format (display) ..... 14

Frequency (High value) ..... 24

Function matrix

    Layout and use ..... 5

    Overview ..... 6

### G

Group

    Amplifier version ..... 57

    Communication ..... 42

    Current output ..... 19

    Handling totalizer ..... 18

    Measuring values ..... 7

    Operation ..... 11

    Process parameter ..... 43

    Pulse/frequency output ..... 23

    Quick Setup ..... 10

    Sensor data ..... 52

    Sensor version ..... 57

    Simulation system ..... 56

    Status input ..... 40

    Status output ..... 34

    Supervision ..... 54

    System parameters ..... 49

    System units ..... 8

    Totalizer ..... 16

    User interface ..... 13

### H

Hardware revision number (sensor) ..... 57

HART Protocol ..... 42

### I

I/O module type (input/output type) ..... 57

Installation direction sensor ..... 49

Integration time ..... 51

### K

K-Factor ..... 52

### L

Language

    Factory settings ..... 59, 60

    Language group (display) ..... 57

    Selection ..... 11

Low flow cut off	
Off value	43
On value	43

**M**

Manufacturer ID	42
Measuring mode	49
Measuring period	53
Minimum pulse width	40

**N**

Nominal diameter	52
------------------	----

**O**

OED (Open electrode detection)	
see Empty Pipe Detection	44
Off value	
Low flow cut off	43
Status output	35
On value	
Low flow cut off	43
Status output	34
Operation hours	55
Operation mode (pulse/frequency output)	23
Output signal	
Frequency output	25, 26
Pulse	30, 31
Overflow (totalizer)	16
Overvoltage time	53

**P**

Permanent storage	55
Polarity ECC	53
Positive zero return	50
Previous system conditions	54
Pulse value	29
Pulse width	29

**Q**

Quick Setup commissioning	10
---------------------------	----

**R**

Reset	
All totalizers	18
System	55
Totalizer	17

**S**

Sensor	
Installation direction	49
K-Factor	52
Measuring period	53
Overvoltage time	53
Sensor type	57
Serial number	57
Zero point	52
Simulation	
Current	22
Failsafe mode	56
Frequency	28

Measured variable	56
Pulses	32
Status input	40
Switch point	35
Software revision number	
Amplifier	57
Device Software	57
I/O Module	57
S-DAT	57
Status access	12
Status output	
Flow direction	37
General	37
Limit value	37
Switching response	38
Storage	
permanent	55
Sum (totalizer)	16
System	
Current conditions	54
Damping (flow damping)	51
Operation hours	55
Previous conditions	54
Reset	55

**T**

Tag	
Description	42
Name	42
Test display	15
Time constant	
Current output	21
Frequency output	27
Status output	35
Totalizer	16
Assign	16
Failsafe mode	18
Mode	17
Overflow	16
Reset	17
Reset all totalizers	18
Unit selection	16

**U**

Unit	
Length	9
Totalizer	16
Volume	8
Volume flow	8

**V**

Value	
20 mA	21
f high	24
Failsafe level	27
Value simulation	
Current	22
Frequency	28
Measured variable	56
Pulse	33

Status input .....	41
Switch point .....	36
Volume flow (display) .....	7
<b>Z</b>	
Zero point .....	52











[www.endress.com/worldwide](http://www.endress.com/worldwide)

---

**Endress+Hauser**   
People for Process Automation

---