


| Force | Pressure | Temperature | Switch | Service

Operating manual/Programmer`s manual



EZE30


Digital load cell amplifier with analogue output and setpoints

CONTENTS

Wiring Diagram and Key Functions	Page 3
Quick Setup and Calibration using Weights	Page 4
Quick Setup and Calibration using the load cell mV/V Sensitivities	Page 6
1. Enable Zero Button / Calibrate Zero point	Page 8
2. Setup and calibrate the Span Function / Display Input Signal in mV/V	Page 10
3. Setup the Display (Over/Under Range Limits, steps size & decimal point, Logic I/O Status)	Page 12
4. Filter Setting and No Motion	Page 14
Filter Setting Tables & Update Rates (Number of Readings Averaged)	Page 15
5. Analogue Output (4-20mA) Settings	Page 16
6. Logic Inputs 1, 2 & 3	Page 17
7. Logic Outputs 1, 2 & 3	Page 19
8. Data Communication Settings	Page 20
Error Codes / Return to Factory Settings	Page 21
Communication Protocol	Page 22
Examples	
Calibration Procedure using weights	Page 23
Calibration Procedure from known load cell mV/V sensitivities - Multiple active load cells	Page 24
Single active load cell plus pivot	Page 25
Programmers manual	Annex A

Recessed Enable Switch

(Enables changes to be made to important parameters. Must be pressed AFTER entering 'Set up' mode but before attempting to change parameters 1.1 to 1.3, 2.1 to 2.3 and 3.1 to 3.3)



'Set-up' menu structure

*Please note that if you have a 4 wire cable from your junction box or load cell to the EZE30, you MUST put in additional links between the Exc+ and Sen+ terminals and between the Exc- and Sen- terminals. Otherwise the display will show Err 5 (faulty load cell connection)

Load cell connections*

QUICK SET UP AND CALIBRATION USING WEIGHTS

(Also see calibration examples on page 22)

Enter the Setup menu



Press the UP or DOWN key for more than 3 seconds to enter the Set-up Menu

Please note that if you wish to change any values in these sections, you have to first press the recessed enable switch (top left corner of unit)

Set the Display Upper Limit



SET THE DISPLAY OVER RANGE LIMIT. (MAXIMUM VALUE +99,999)

Use this menu point to define the display maximum value. If the displayed weight exceeds this maximum, the display will then show over range (dashes at the top of the display). This can be useful to indicate when a weight value is outside a normal range. Use the UP/DOWN & MOVE RIGHT keys to set the maximum display value and store by pressing the enter key. Factory default value 10,000. Please note that the zero button is limited to $\pm 2\%$ of the display maximum value. See section 1.1 Zero Button Enable for more details

Set the Display Lower Limit



SET THE DISPLAY UNDER RANGE LIMIT. (MINIMUM VALUE -99,999)

Use this menu point to define the display minimum value. If the displayed weight drops below this minimum, the display will then show under range (dashes at the bottom of the display) This can be useful to indicate when a weight value is outside a normal range. Use the UP/DOWN & MOVE RIGHT keys to set the minimum display value and store by pressing the enter key. Factory default value -9,999.

Set the Display Step Size




SELECT THE DISPLAY STEP SIZE. (1, 2, 5, 10, 20, 50, 100, 200 or 500)

Use this menu point to select the display step size. The minimum display step size is 1 [Factory default] up to a maximum step size of 500. If for example you select a display step size of 50, the display will show 000, 050, 100, 150 etc as the weight value increases. Using higher step sizes will give a more stable weight display but with a lower resolution. Use the UP or DOWN key to select the required display step size. Press the enter key to store.

QUICK SET UP AND CALIBRATION USING WEIGHTS (Continues on the next page)

QUICK SET UP AND CALIBRATION USING WEIGHTS (Continued)



QUICK SET UP AND CALIBRATION USING THE LOAD CELL mV/V SENSITIVITY

(Also see calibration examples on page 23)

Enter the Setup menu



Press the UP or DOWN key for more than 3 seconds to enter the Set-up Menu

Please note that if you wish to change any values in these sections, you have to first press the recessed enable switch (top left corner of unit)

Set the Display Upper Limit



SET THE DISPLAY OVER RANGE LIMIT. (MAXIMUM VALUE +99,999)

Use this menu point to define the display maximum value. If the displayed weight exceeds this maximum, the display will then show over range (dashes at the top of the display). This can be useful to indicate when a weight value is outside a normal range. Use the UP/DOWN & MOVE RIGHT keys to set the maximum display value and store by pressing the enter key. Factory default value 10,000. Please note that the zero button is limited to $\pm 2\%$ of the display maximum value. See section 1.1 Zero Button Enable for more details

Set the Display Lower Limit



SET THE DISPLAY UNDER RANGE LIMIT. (MINIMUM VALUE -99,999)

Use this menu point to define the display minimum value. If the displayed weight drops below this minimum, the display will then show under range (dashes at the bottom of the display) This can be useful to indicate when a weight value is outside a normal range. Use the UP/DOWN & MOVE RIGHT keys to set the minimum display value and store by pressing the enter key. Factory default value -9,999.

Set the Display Step Size




SELECT THE DISPLAY STEP SIZE. (1, 2, 5, 10, 20, 50, 100, 200 or 500)


Use this menu point to select the display step size. The minimum display step size is 1 [Factory default] up to a maximum step size of 500. If for example you select a display step size of 50, the display will show 000, 050, 100, 150 etc as the weight value increases. Using higher step sizes will give a more stable weight display but with a lower resolution. Use the UP or DOWN key to select the required display step size. Press the enter key to store.

QUICK SET UP AND CALIBRATION USING LOAD CELL mV/V (Continues on the next page)

QUICK SET UP AND CALIBRATION USING LOAD CELL mV/V (Continued)




ENTERING THE SETUP MENU




Press the UP or DOWN key for more than 3 seconds to enter the Set-up Menu

If you wish to change any values in these sections, you have to first press the recessed enable switch (top left corner of unit)

ENABLE ZERO BUTTON / SET ZERO TRACK RANGE / CALIBRATE ZERO POINT




ENABLE ZERO BUTTON / CALIBRATE ZERO POINT (Continued)



2. SET UP AND CALIBRATE SPAN FUNCTION / DISPLAY INPUT SIGNAL IN mV/V - See Next Page


If you wish to change any values in these sections, you have to first press the recessed enable switch (top left corner of unit)

2. SET UP AND CALIBRATE SPAN / DISPLAY INPUT SIGNAL IN mV/V




SET UP AND CALIBRATE SPAN / DISPLAY INPUT SIGNAL IN mV/V (Continues on next page)

SET UP AND CALIBRATE SPAN /DISPLAY INPUT SIGNAL IN mV/V (Continued)




If you wish to change any values in these sections, you have to first press the recessed enable switch (top left corner of unit)

3 SET UP THE DISPLAY (OVER/UNDER RANGE LIMITS, STEP SIZE & DECIMAL POINT, LOGIC I/O STATUS)




SET UP THE DISPLAY (Continues on next page)

SET UP THE DISPLAY (Continued)



4. FILTER SETTINGS & NO MOTION



5. ANALOGUE OUTPUT SETTINGS - See Page 16

FILTER SETTINGS TABLES & UPDATE RATES (NUMBER OF READINGS AVERAGED)

MENU 4.1-4.2 FILTER TYPE IIR (MODE 0) SECOND ORDER GAUSSIAN LOW

Filter Setting	3dB Cut-off Frequency in Hz	Update Rate in Samples/sec.	Settling time to 0.1% in ms.	Damping in dB At 300Hz
1	18	600	55	57
2	8	600	122	78
3	4	600	242	96
4	3	600	322	104
5	2	600	482	114
6	1	600	963	132
7	0.5	600	1923	149
8	0.25	600	3847	164

This section refers to Menu points 4.1 - 4.3. Setting the filter level to 0 will disable the filters in either modes (0 or 1). The Gaussian filter type IIR (mode 0) filter level 4 is the factory default. This provides a slower response with a high level of damping. The FIR filter type provides better response where high speed is required. Both types of filter can be enhanced further by using the UR parameter Menu 4.3 to average between 1 (UR=0) and 128 (UR=7) measurements.


MENU 4.1- 4.2 FILTER TYPE FIR (MODE 1) COMBINATION LOW PASS

Filter Setting	3dB Cut-off Frequency in Hz	Update Rate in Samples/sec.	Settling time to 0.1% in ms.	20dB Damping @ frequency Hz	40dB Damping @ frequency Hz	Stopband in Hz	Damping in dB in Stopband
1	19.7	600	47	48	64	>80	>90
2	9.8	300	93	24	32	>40	>90
3	6.5	200	140	16	21	>26	>90
4	4.9	150	187	12	16	>20	>90
5	3.9	120	233	10	13	>16	>90
6	3.2	100	280	8	11	>13	>90
7	2.8	85.7	327	7	9	>11	>90
8	2.5	75	373	6	8	>10	>90

MENU 4.3 UPDATE RATE - DEFINES HOW MANY MEASUREMENTS ARE USED TO CALCULATE AN AVERAGE


Update Rates	0	1	2	3	4	5	6	7
No. of Samples	1	2	4	8	16	32	64	128

5. ANALOGUE OUTPUT (4-20 mA) SETTINGS




6. LOGIC INPUTS - See Next Page


LOGIC INPUTS



LOGIC INPUTS (Continued)



7 LOGIC OUTPUTS




7.2 AS PER SECTIONS 7.1 BUT FOR LOGIC OUTPUT 2

7.3 AS PER SECTIONS 7.1 BUT FOR LOGIC OUTPUT 3

8 DATACOMS - See Next Page

8. DATA COMMUNICATION SETTINGS



9. SET UP AND CALIBRATE ZERO FUNCTION

ERROR CODES

Err 1

The zero key is not enabled (See menu 1.1)

Err 2

Set final zero out of range. (You are trying to set a zero which is greater than $\pm 20\%$ of the Upper Display Limit menu 3.1o)

Err 3

Excessive sensitivity requested. (The input signal is being divided into too many divisions i.e the size of each division is less than 0.5uV)

Err 4

The input signal is in excess of ± 3.2 mV/V

Err 5

Faulty load cell connection (Open circuit / Short Circuit / Wire disconnected / Sense wires not connected or shorted to Exc terminals)

Err 6

You are trying to enter a value which is not valid (Outside the acceptable parameter range)

Display overload (Display value exceeds the upper limit set in Menu 3.1o)

Display underload (Display value is more negative than the lower limit set in Menu 3.1U)

If when trying to set a new zero or tare, you see a series of dashes through the middle of the display, this indicates that the weight value is changing too much over a short period of time. In other words the 'No motion' parameters as set in Menu 4.4 have been exceeded. To correct this you can increase the 'no-motion' range (Menu 4.4.1) or decrease the 'Stabilisation time' (Menu 4.4.2). You can also increase the filter strength (Menu 4.1) to make the weight readings more stable. Please note that instability may be indicative of another problem which should be resolved as opposed to masked by adjusting the no-motion or filter parameters.

If you need to return the EZE30 to the factory settings simply press and hold the recessed enable switch whilst powering up the unit. All parameters will then revert to the factory settings

COMMUNICATION PROTOCOL AND COMMANDS

ASCII protocol format:

Baudrate 9600/19200/38400/115200
Data bits 8-bits
Stop bits 1-bit
Parity NONE

ASCII protocol commands:


Single shot commands

Command	Response strings	Operation
OP <XXX><CR> CL<CR>	OK<CR>/ERR<CR>	Open connection to channel XXX Close channel connection
IV<CR> ID<CR> IS<CR>	V:XXXX<CR> D:DAS<CR> S:XXXXXX<CR>	Returns Software Version Number (XXXX) Returns Device Identity (DAS) Returns Device Status (XXXXXX)
SZ<CR> RZ<CR>	OK<CR>/ERR<CR> OK<CR>/ERR<CR>	Set a new Zero value Revert to original calibration Zero
ST<CR> RT<CR>	OK<CR>/ERR<CR> OK<CR>/ERR<CR>	Set a new Tare value Revert to Gross mode
GG<CR> GN<CR> SG<CR> SN<CR>	G 00000<CR> N 00000<CR> G 00000<CR> N 00000<CR>	Get the Gross value Get the Net value Send the Gross value continuously Send the Net value continuously
IM<CR> IN<CR> OM<CR> IO<CR> LI<CR>	IM:XXXX<CR> IN:XXXX<CR> OM:XXXX<CR> IO:XXXX<CR>	Input Mask - Disable push button functions Read Inputs Status Output Mask - Disable Setpoint outputs Read / Modify Output Status Lists all menu values

CALIBRATION PROCEDURE USING WEIGHTS

Example:

3 leg tank or silo fitted with 3 off 1000Kg 2mV/V load cells
Dead load 500Kg, Live range 2000Kg in 1 Kg steps



It is assumed that the load cell system is connected to the EZE30 and the power is on. The maximum and minimum display values, display increment size and decimal point position should be defined prior to carrying out the calibration (See Menu 3). For this example the display maximum is define as 2009, the display minimum is -200, the display step size is 1 and there is no decimal point.

Remember that all parameters under sections 1.1 - 1.3, 2.1 - 2.3 and 3.1 - 3.3 can only be accessed or changed after the Recessed Enable Switch has been pressed.

- a) Go to Menu 1.2 and using the UP/DOWN and RIGHT keys set the display to read 0000. Make sure that the weighing system is empty or at the point where you want the display to read zero. Press the 0 [Enter] key. This defines the actual zero calibration point.
- b) Go to Menu 2.1 and using the UP/DOWN and RIGHT keys set the display to read the value of the calibration weight(s) which will be applied. For this example if the calibration load applied which will be applied is 2000 kg, set the display to read 2000. Press the 0 [Enter] key. This defines the calibration weight.
- c) Go to Menu 2.2. Apply the calibration weight(s) to the weighing system. Press the 0 [Enter] key. The display will show the actual input signal in mV/V. Press the 0 [Enter] key. This defines the actual span calibration point. The display will now show 2.2. Press the right arrow key twice and the DAS will be back in weighing mode.
- d) If required the zero can be re-calibrated without affecting the span. To do this make sure that the weighing system is empty or at the point where you want the display to read zero. Goto Menu 1.2. Press the 0 [Enter] key. The display shows the actual input signal in mV/V. Press the 0 [Enter] key. Press the right arrow key twice and the DAS will be back in weighing mode.


Calibration is now complete

CALIBRATION PROCEDURE USING KNOWN LOAD CELL MV/V SENSITIVITY

MULTIPLE ACTIVE LOAD CELLS

Example:

3 leg tank or silo fitted with 3 off 1000Kg 2mV/V load cells
Dead load 500Kg, Live range 2000Kg in 1 Kg steps



It is assumed that the load cell system is connected to the EZE30 and the power is on. The maximum and minimum display values, display increment size and decimal point position should be defined prior to carrying out the calibration (See Menu 3). For this example the display maximum is define as 2009, the display minimum is -200, the display step size is 1 and there is no decimal point.

Remember that all parameters under sections 1.1 - 1.3, 2.1 - 2.3 and 3.1 - 3.3 can only be accessed or changed after the Recessed Enable Switch has been pressed.

- a) Go to Menu 1.2. Press the 0 [Enter] key. The display will read the input signal in mV/V. Make sure that the weighing system is empty or at the point where you want the display to read zero. Press the 0 [Enter] key. This defines the actual zero calibration point.
- b) Go to Menu 2.1 and using the UP/DOWN and RIGHT keys set the display to read the capacity of the load cell system or the weight value at which the sensitivity is known. For this example the load cell capacity is $3 \times 1000\text{Kg} = 3000\text{Kg} @ 2\text{mV/V}$. Set the display to read 3000. Press the 0 [Enter] key. This defines the theoretical calibration weight (equivalent to 2mV/V in this example).
- c) Go to Menu 2.3. Press the 0 [Enter] key. Use the UP/DOWN and RIGHT keys set the display to read the mV/V sensitivity of the load cell system you are using. For this example the load cell sensitivity or Output at Rated Load is 2.000mV/V. In multiple load cell installations (load cells wired in parallel) the sensitivity is the average of all the load cells connected. Press the 0 [Enter] key. This defines the theoretical span calibration point.
- d) If required the zero can be re-calibrated without affecting the span. To do this make sure that the weighing system is empty or at the point where you want the display to read zero. Goto Menu 1.2. Press the 0 [Enter] key. The display shows the actual input signal in mV/V. Press the 0 [Enter] key. Press the right arrow key twice and the DAS will be back in weighing mode.

Calibration is now complete


CALIBRATION PROCEDURE USING KNOWN LOAD CELL MV/V SENSITIVITY

SINGLE ACTIVE LOAD CELL PLUS HINGE PIVOT

Example:

A rectangular tank fitted with 1 off 2000Kg 2mV/V load cell central on the left hand side and a pivot (hinge) along the complete opposite face .

Dead load 500Kg, Live range 2000Kg in 1 Kg steps



It is assumed that the load cell system is connected to the EZE30 and the power is on. The maximum and minimum display values, display increment size and decimal point position should be defined prior to carrying out the calibration (See Menu 3). For this example the display maximum is define as 2009, the display minimum is -200, the display step size is 1 and there is no decimal point.

Remember that all parameters under sections 1.1 - 1.3, 2.1 - 2.3 and 3.1 - 3.3 can only be accessed or changed after the Recessed Enable Switch has been pressed.

- Go to Menu 1.2. Press the 0 [Enter] key. The display will read the input signal in mV/V. Make sure that the weighing system is empty or at the point where you want the display to read zero. Press the 0 [Enter] key. This defines the actual zero calibration point.
- Go to Menu 2.1 and using the UP/DOWN and RIGHT keys set the display to read the capacity of the load cell system or the weight value at which the sensitivity is known. For this example the load cell capacity is 2000Kg @ 2mV/V. But the hinge pivot on the opposite side of the tank carries half the load (if the centre of gravity is in the middle of the tank). Therefore when there is 4000Kg in

the tank equally split between the load cell and the hinge the output from the load cell will be 2 mV/V. The system is therefore 4000Kg @2mV/V. Set the display to read 4000. Press the 0 [Enter] key. This defines the theoretical calibration weight (equivalent to 2mV/V in this example).

- Go to Menu 2.3 and using the UP/DOWN and RIGHT keys set the display to read the mV/V sensitivity of the load cell system you are using. For this example the load cell sensitivity or Output at Rated Load is 2.000mV/V. In multiple load cell installations (load cells wired in parallel) the sensitivity is the average of all the load cells connected. Press the 0 [Enter] key. This defines the theoretical span calibration point.
- If required the zero can be re-calibrated without affecting the span. To do this make sure that the weighing system is empty or at the point where you want the display to read zero. Goto Menu 1.2. Press the 0 [Enter] key. The display shows the actual input signal in mV/V. Press the 0 [Enter] key. Press the right arrow key twice and the DAS will be back in weighing mode.

PLEASE NOTE THAT IF THE LOAD IS NOT EQUALLY SHARED BY THE LOAD CELL AND PIVOT THE CALIBRATION WILL BE INACCURATE.

Content

1. INTRODUCTION	Page 2
2. COMMUNICATIONS & GETTING STARTED	Page 2
3. COMMAND PROTOCOL - LONG DESCRIPTIONS	Page 6
4. COMMAND PROTOCOL - SHORT DESCRIPTIONS	Page 23

1. INTRODUCTION

The EZE30 digital amplifier is a high performance device that can form weighing systems intended for industrial applications. The device feature full multi-drop communications capability and can be controlled via a straightforward ASCII command set.

2. COMMUNICATIONS & GETTING STARTED

Communicating with the EZE30 digital amplifier is performed via the RS422/RS485 port. The data format is the familiar 8/N/1 structure (8 data bits, no parity, 1 stop bit)

Available data rates are:

9600
19200
38400
57600
115200

Point-to-point or multi-drop connections are supported.

Protocol Summary

The EZE30 digital amplifier are intended for use with standard PC or PLC systems, and require no special interfacing hardware and no special software adapters.

The command set is based on a simple ASCII format, as per the example below:

Master (PC or PLC) sends:	OP 1	(Open the device # 1)
Slave (EZE30) sends:	OK	(acknowledging device #1 active)
Master sends:	GG	(Get the gross weight result)
Slave sends:	G+123.45	(the gross weight with sign and decimal point information)

Note: The complete list of available commands is printed on the page 19 of this manual.

This protocol is standard across the whole range of the instrumentation, so it is possible to mix different types of devices on the same bus.

Multi-Drop Support

A connection to the required device is opened by sending the OP xxx command, where xxx is the address of the relevant slave device, in decimal notation. The relevant device responds by acknowledging that it is active, and will then respond to any other command sent along the bus, until another OP xxx with a different address value is detected, or until a “Close Connection” command (CL) is detected.

Baudrate Settings

In configuration mode it is possible from the front panel to set the baudrate. The default factory setting is 9600.

RS422/485 Setting

In configuration mode it is possible from the front panel to switch between RS422 and RS485 mode. In RS485 mode the instrument will turn its transmitter off after sending data allowing other devices to use the bus. In RS422 mode, the transmitter will remain on. The default factory setting is RS422.

Address Settings

In configuration mode it is possible from the front panel to set the network address of the instrument to any address between 0 and 255. Setting the address to 0 will set continuously active mode, where the instrument becomes permanently active, and will listen and respond to any command on the bus, without the need for an OP xxx command. The default factory setting is 0.

Auto transmit Settings

In configuration mode it is possible from the front panel to enable auto transmission after power on without sending any commands. The default factory setting is off.

Getting Started

You will require having available:

- PC or PLC with either a RS422 or RS485 communication port;
- RS232 to RS422/485 converter - necessary if it is intended to use communication driven from the master which has only a RS232 port available;
- Interconnecting cabling - confirm that all of the relevant pins are in use - check against the wiring diagram that follows this section;
- A load cell with test weights, OR a load cell simulator;
- A DC power supply capable of delivering 12-24 VDC. Current capacity dependent on the number of device and the number of load cells to be connected. (One device plus one load cell requires less than 250 mA);
- One or more EZE30;
- A suitable ASCII communication software (HyperTerminal etc)

3. COMMAND PROTOCOL – LONG DESCRIPTIONS

For ease of interpretation, the commands have been grouped together and will be described in the following sequence:

- 3.1 System Diagnostics Commands
- 3.2 Weigh Control Commands
- 3.3 Output Commands
- 3.4 Auto-Transmit Commands
- 3.5 Remote I/O Commands
- 3.6 Calibration Commands
- 3.7 Motion Detection Commands
- 3.8 Filter Setting Commands
- 3.9 Set-point Commands
- 3.10 Communication Set-up Commands
- 3.11 Analogue Output Commands
- 3.12 Save Set-up Commands

3.1 SYSTEM DIAGNOSTICS COMMANDS – ID, IV, IS, SR, LI

The following five commands provide a means of interrogating the device to confirm the type of device present, the software version of that device and the status.

The commands require no parameters and are used as follows:

ID Determine the device ID code - this is a code, which identifies the type of device, which is currently open for communications. Issuing the ID command, which has no parameters, will return the code **D:7210** This code is useful when mixed devices may be present on the bus.

IV Determines the device software version - this identifies the release of software that is installed in the device. This is useful when determining the availability of special commands or features that may have been requested for special applications. Issuing the IV command, which has no parameters, will return the software identification code in the format **V:0201**

IS Determine the device status - Issuing the ID command, which has no parameters, will return a result in the format **S:000000**. This result comprises two 3-digit decimal values, which can be decoded according to the table below:

Leftmost 3-digit value:

Rightmost 3-digit value:

1	Signal stable	1	not used
2	Zero action performed	2	not used
4	Tare active	4	not used
8	Not used	8	not used
16	Not used	16	not used
32	Output 1 on	32	not used
64	Output 2 on	64	not used
128	Output 3 on	128	not used

Therefore, the example result **S:001000** decodes as signal stable (no-motion) no zero action, no tare and all outputs off. The unsupported bits are reserved for use on other members of our instrument family and in the case of the EZE30 are always set at zero.

SR Software Reset – this command will respond with ‘OK’ and after maximum 400ms perform a complete reset of the EZE30.

LI List settings - dump the complete EZE30 setup formatted as lines of ASCII characters to the serial channel. The output refers to the front panel schematic columns 1 to 8.

3.2 WEIGHER CONTROL COMMANDS – SZ, RZ, ST, RT

The following commands provide the means to control the setting and resetting of the zero and tare points. The availability of net weighing depends on these functions.

The zero point which is set at calibration time, remains the “true” zero, but the “current” zero will be the basis for the output result. Remember that the “current” zero can be influenced by the “zero tracking” function, and this should be taken into account when designing the application. A basic system control is the disabling of the “set zero „and “set tare”functions whenever the weighing signal is not stable, as defined by the “no-motion” function. Furthermore, the zero point cannot be reset if it has moved more than 20% away from the original calibration zero point, with respect to the maximum allowable display value.

SZ Set the system zero - this command will create a “current” zero point which will become the basis for all weighed operation, until further updated by the zero tracking function, or another SZ command or the “reset zero” command (RZ). As previously stated, any attempt to zero a drift of more than +/- 20% of the maximum allowable display value will result in the SZ command being rejected (**ERR**). The SZ command is also rejected if the weighing signal is fluctuating, as defined by the “zero no-motion” function. The “zero signal stable” bit in the responses to the “info status” (IS) command must therefore be active before a SZ command can be accepted. Issuing the SZ command, which has no parameters, will return the **OK** or **ERR** response. If **OK** is returned, then the “zero action performed” bit in the response to the “info status” (IS) command will be activated.

RZ Reset the zero point to the “calibration” zero - this command will return the zero point to that which was stored during the calibration procedure. Issuing the RZ command, which has no parameters, will return the **OK** or **ERR** response. If **OK** is returned, then the “zero action performed” bit in the response to the “info status” (IS) command will be de-activated.

ST Set the tare point - this command will activate the net weighing function, by storing the current weighing signal output value as a tare value. The ST command is rejected if the weighing signal is fluctuating, as defined by the “tare no-motion” function. The “tare signal stable” bit in the “info status” return must therefore be active before a ST command can be accepted. Issuing the ST command, which has no parameters, will return the **OK** or **ERR** response. If **OK** is returned, then the “tare active” bit in the response to the “info status” (IS) command will be activated.

RT Reset the tare - this command cancels the net weighing mode, and restores the current zero. The weighing signal output returns to the gross mode. Issuing the RT command, which has no parameters, will return the **OK** or **ERR** response. If **OK** is returned, then the “tare active” bit in the response to the “info status” (IS) command will be activated.

3.3 OUTPUT COMMANDS – GG, GN, GT, GS, GW

The following commands provide the means of obtaining an output results from the device.


GG Get the gross value - returns the current gross weight value. Issuing the GG command, which has no parameters, will return the gross weight value in the format **G+01.100** .

GN Get the net value - returns the current net weight value. Issuing the GN command, which has no parameters, will return the net weight value in the format **N+01.100** .

GT Get the tare value - returns the current tare weight value. Issuing the GT command, which has no parameters, will return the tare weight value in the format **T+01.100** .

GS Get the A/D sample value – returns the current output result of the A/D converter (ADC). This facility is useful when developing the application, or when calibrating the system, as it allows a check to be made of the operating range of the ADC. Issuing the GS command, which has no parameters, will return the ADC output value in the format **S+100000**.

GW Get the "long" weight values - returns the current net, gross and status values. Issuing the GW command, which has no parameters, will return the net weight, the gross weight, the status and the checksum values, all combined into one single string in the format **W+00100+01100010F**. The first two sections of the return string comprise the net weight and gross weight results, followed by two hexadecimal characters, which represent two bitmapped status indicators. The last two hexadecimal characters represent the checksum, which is the inverse of the sum of all the ASCII values of the string, not including the checksum characters. (see following)



The bitmapped characters are:

First Bit value description	Second Bit value description
1 Not used. 2 Output 1 active. 4 Output 2 active. 8 Output 3 active.	1 No motion. 2 Zero action performed. 4 Tare active. 8 Not used.

The checksum is derived as follows:

- a. Add the ASCII values (in hex) of all the 15 characters in the string
- b. Invert the hexadecimal value
- c. Add one to the value
- d. Use only the last two digits
- e. Convert the hexadecimal value to characters

3.4 AUTO-TRANSMIT COMMANDS – SG, SN, SW

The following command provide the means to output the weight results in a continuous stream, which starts upon the issue of the relevant command, and ends upon the issue of any other command.

SG Auto-transmit the gross weight value - continually returns the current gross weight value. Issuing the SG command, which has no parameters, will continually return the gross weight value in the format **G+01.100** , until interrupted by any other command.

SN Auto-transmit the "long" weight value - continually returns the current net weight value. Issuing the SN command, which has no parameters, will continually return the net weight value in the format **N+01.100** , until interrupted by any other command.

SW Auto-transmit the net weight value - continually returns the current net weight, the gross and status values. Issuing the SW command, which has no parameters, will continually return the net weight, the gross weight, the status and the checksum values, all combined into one single string in the format: **W+00100+01100010F** until interrupted by any other command. The decode of the string is exactly as per the "long" weight command GW, listed in section 3.3, "OUTPUT COMMANDS". Note that decimal point information is not transmitted.

3.5 REMOTE I/O COMMANDS – IN, IO, OM

The EZE30 includes 3 independent logic input channels and 3 solid-state relay outputs. The inputs can be read directly by the host application, allowing for such uses as machine status indication or can be used as remote control inputs for the zero and tare pushbuttons.

The relay outputs can be used with the set-points or can be remote controlled by the host.

The following group of commands provides control of the logic I/O.

IN Read the status of the three input channels - returns the status in the form of a bitmapped four-digit value where 0 corresponds to "false" and 1 corresponds to "true" (inputs are active "high"). Issuing the IN command, which has no parameters, returns the input status in the form **IN:0001**, where Input 1 status is given by the Least Significant Digit (in this example 1) and so on.

OM Output mask - disable the set-point function of the relay outputs when used as host controlled logic outputs. A logic 1 will disable the corresponding set-point function. Issuing the command without any parameters returns the current OM value in the form **OM:0010**. Value after reset / power on: **0000**.

IO Read/Modify the status of the three output channels - returns the status in the form of a bitmapped four-digit value where 0 corresponds to “false” and 1 corresponds to “true” and modifies that status if enabled by the OM command. Issuing the command without any parameters returns the output status in the form **IO:0010**, where Output 1 status is given by the Least Significant Digit and so on. Value after reset / power on: **0000**.

3.6 CALIBRATION COMMANDS – CE, CM, CI, DS, DP, CZ, AZ, CG, AG, ZT, FD, CS

CE Set the calibration functions to the enabled state. This command must be issued PRIOR to any attempt to set the calibration parameters CM, CI, DS, DP, CZ, AZ, CG, AG, ZT, FD or CS. Issuing the command without any parameters results in the response **E+XXXXX** where **XXXXX** is the Traceable Access Code (TAC). This is an internal code that is used to record any changes in the calibration settings of the device.

CM Set the maximum allowable output value. Lower limit 1, upper limit 99999. Issuing the command without any parameters returns the current CM value. This value will determine the point at which the output will change to **000000**, signifying over-range. To set a new value for CM, the command must be preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. The new CM value required is then input as a parameter of CM, in the format **CM 4010**. Factory default setting: 10000.

CI Set the minimum allowable output value. Lower limit -99999, upper limit 0. Issuing the command without any parameters returns the current CI value. This value will determine the point at which the output will change to **uuuuuuu**, signifying under-range. To set a new value for CI, the command must be preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. The new CI value required is then input as a parameter of CI, in the format **CI 4010**. Factory default setting: -9000.

DS Set the display step size - this allows the output to step up or down by a unit other than 1. Permitted values are 1, 2, 5, 10, 20, 50, 100, 200 or 500. To set a new value for DS, the command must be preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. The new DS value required is then input as a parameter of DS, in the format **DS 100**. Factory default setting: 1.

DP Set the decimal point position - this allows the decimal point to be positioned anywhere between leftmost and rightmost digits of the 5-digit output result. Permitted values are 0 for the rightmost position, and 5 for the leftmost position. To set a new value for DP, the command must be preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. The new DP value required is then input as a parameter of DP, in the format **DP 2**. Factory default setting: 0.

CZ Set the calibration zero point - this is the reference point for all weight calculations, and is subject to TAC control. The command returns **ERR** and has no action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. Confirmation of action is provided by the return **OK**. Factory default setting: 0mV/V input.

AZ Absolute zero point calibration - this is the reference point for all weight calculations, and is subject to TAC control. The command returns **ERR** and has no action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. The zero value required (in mV/V, without decimal point) is input as a parameter of AZ, in the format **AZ 500**. Factory default setting: 0mV/V input.

CG Set the calibration gain (span) value - this is the reference point for the calibration under load, and is subject to TAC control. The lower limit for CG is 1, the upper limit is 99999. The weight signal used for calibration should be as close as possible to the maximum allowable display value (CM) so as to ensure optimum calibration accuracy. A feature provided is the ability to recall the value of the calibration weight used for the current calibration by the issue of a CG command without any parameters. This is useful information for future calibration purposes or for diagnostics. When calibrating the span, the actual value of the calibration weight must be entered as a parameter of the CG command, for example if the output 25000 is required for the weight placed on the load cell, then the calibration command becomes **CG 25000**. The command return "**ERR**" and has no updating action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. **If the load applied to calibrate the span is less than 1% of full scale (2mV/V), the gain calibration will fail and 'ERR' will be returned.** Factory default setting: 10000 at 2mV/V input.

AG Absolute gain calibration. The command returns **ERR** and has no action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. The gain value (in mV/V, without decimal point) is input as a parameter of AG followed by the required number of increments as a second parameter, in the format **AG 20000 10000**. Factory default setting: 10000 at 2mV/V input.

ZT Zero tracking - this command enables or disables the zero tracking. Parameter = 0 disables the zero tracking and parameter = 1 enables the zero tracking. Issuing the command without any parameters returns the current ZT value. The command returns **ERR** and has no updating action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC. Zero tracking will be performed only on results less than +/-0.5d at a rate of 0.4 d/sec where d = display step size (see DS command). The zero can only be tracked to +/- 20% of max (see CM command). Factory default setting: 0.

FD Factory default settings – this command put the EZE30 back to a known state. The data will be written to the EEPROM and the TAC will be incremented by 1.

NOTE: All calibration and set-up information will be lost by issuing this command.

The command returns **ERR** and has no updating action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC.

CS Save the calibration values - this command results in the calibration values being saved to EEPROM, and causes the TAC to be incremented by 1. The CS command saves all of the calibration group values, as set by CZ, AZ, CG, AG, CM, CI, DS, DP and ZT. The command returns **ERR** and has no updating action unless it is preceded by the **CE XXXXX** command, where **XXXXX** is the current TAC.

3.7 MOTION DETECTION COMMANDS – NR, NT

The Motion Detection facility provides a means of disabling certain functions whenever a condition of instability, or “motion”, is detected. The “no-motion”, or “stable” condition is achieved whenever the signal is steady for the period of time set by NT, during which it cannot fluctuate by more than NR increments. The stable condition activates the relevant bit of responses to “Info Status” (IS - see section 3.1, “SYSTEM DIAGNOSTICS COMMANDS”).

The functions which are disabled whenever motion is detected are “Calibrate Zero” (CZ) “Calibrate Gain” (CG) “Set zero” (SZ) and “Set tare” (ST).

NR Set the “no-motion” range - this is the range within which the weighing signal is allowed to fluctuate and still be considered as “stable”. Issuing the NR command without any parameter will return the current value. Set a new value by issuing the NR command followed by the desired value, in the format **NR 5**. Permitted values are between the lower limit of 0 and the upper limit of 65535. Factory default setting: 1.

NT Set the stabilisation time for the “in motion” band. This is the time parameter that defines the period during which the output must not fluctuate more than NR increments in order to be considered “stable”. Set a new value by issuing the NT command followed by the desired value in milliseconds, in the format **NT 1000**. Permitted values are between the lower limit of 0 and the upper limit of 65535. Factory default setting: 1000.

3.8 FILTER SETTING COMMANDS – FL, FM, UR

The facility exists for the setting of a digital filter via the command parameters FL, FM, and UR. This filter can be adjusted to eliminate most unwanted disturbances. Note that this filter is positioned immediately after the A/D Converter, and will therefore have an effect on all aspects of weighing operation.

FL Set the filter cut off frequency - permitted values are between 0 and 8, see tables below. A setting of 0 will disable the filter in both mode 0 and 1. Issuing the FL command without any parameters will return the current filter value. Set a new value by issuing the FL command followed by the desired value, in the format **FL 4**. Factory default setting: 3.

NOTE: Remember to store the setting using the **WP** command before turning off the power.

FM Set the filter mode - permitted values are between 0 and 1, see tables below. Mode 0 uses a 2.order low pass Gaussian IIR filter and mode 1 uses a combination of FIR filters. Issuing the FM command without any parameters will return the current filter mode. Set a new value by issuing the FM command followed by the desired value, in the format **FM 1**. Factory default setting: 0.

NOTE: Remember to store the setting using the **WP** command before turning off the power.

Mode 0 characteristics:

FL	Settling time to 0.1% in ms.	3dB Cut-off frequency in Hz.	Damping in dB at 300Hz.	Update-rate in samples/sec.
1	55	18	57	600
2	122	8	78	600
3	242	4	96	600
4	322	3	104	600
5	482	2	114	600
6	963	1	132	600
7	1923	0.5	149	600
8	3847	0.25	164	600

Mode 1 characteristics:

FL	Settling time to 0.1% in ms.	3dB Cut-off frequency in Hz.	20dB damping at frequency in Hz.	40dB damping at frequency in Hz.	Damping in dB in the stopband	Stopband in Hz.	Update-rate in samples/sec.
1	47	19.7	48	64	>90	>80	600
2	93	9.8	24	32	>90	>40	300
3	140	6.5	16	21	>90	>26	200
4	187	4.9	12	16	>90	>20	150
5	233	3.9	10	13	>90	>16	120
6	280	3.2	8	11	>90	>13	100
7	327	2.8	7	9	>90	>11	85.7
8	373	2.5	6	8	>90	>10	75

UR Set the update-rate. This command will define over how many measurements, from the preceding IIR or FIR filter, an average will be calculated. Permitted values are between 0 and 7, see table below. Issuing the UR command without any parameters will return the current update rate. Set a new value by issuing the UR command followed by the desired value, in the format **UR 2**. Factory default setting: 0.

NOTE: Remember to store the setting using the **WP** command before turning off the power.

Update rates:

UR	0	1	2	3	4	5	6	7
Number of samples	1	2	4	8	16	32	64	128

3.9 SETPOINT COMMANDS – Sn, Hn, An

S1 (S2, S3) Set the setpoint value for channel 1 (2, 3) – sets the value which will trigger the required action of the output channel transistor, in conjunction with the settings of the other controls H1 (H2, H3) and A1 (A2, A3). Issuing the S1 (S2, S3) command without any parameters will return the current value in the form **S1:+00200.**, signifying that setpoint number 1 is set to trigger at value +200, and in so doing will set output 1 “ON”. The source to be monitored for the purpose of setpoint action is determined by the setpoint ACTION command A1 (A2, A3). After the setpoint has been reached, the action of the setpoint, and the status of the relevant output channel, is dependent on the setting of the HYSTERESIS command H1 (H2, H3).

H1 (H2, H3) Set the hysteresis value for channel 1 (2, 3) – sets the value and polarity by which the output value must change in order to release the setpoint. Issuing the H1 (H2, H3) command without any parameters will return the current value in the form **H1:+00100.** , signifying that setpoint 1 must hold it's “ON” status until the source value drops by 100. If H1 returns a negative value, then this signifies that the source value must increase beyond 100, after which point the setpoint will release, and the relevant output channel will change to the “OFF” condition. This command therefore allows the setpoint to be inverted.

A1 (A2, A3) Set the action for channel 1 (2, 3) – sets the source for the value which will trigger the required action of the output channel relay, according to the settings of the other controls S1 (S2, S3) and H1 (H2, H3). Issuing the A1 (A2, A3) command without any parameters returns the current value in the form **A1:+00001**.

An = 0	Gross weight as setpoint source
An = 1	Net weight as setpoint source

NOTE: Remember to store the settings using the **SS** command before turning off the power.

3.10 COMMUNICATION SET-UP COMMANDS – AD, BR, DX

AD Set the address of the EZE30 for networking (0-255). Setting the device address to 0 will set the continuously active mode, where the device becomes permanently active, and will listen and respond to any command on the bus, without the need for an **OP** xxx command. Issuing the AD command without any parameters will return the current address. Factory default setting: 0.

NOTE: this setting will take effect after power on reset (remember to store the setting using the **WP** command before turning off the power).

BR Set the EZE30 baud rate. Issuing the **BR** command without any parameters will return the current baud rate. Set a new value by issuing the **BR** command followed by the desired value, in the format **BR 115200**. Factory default setting: 9600.

NOTE: this setting will take effect after power on reset (remember to store the setting using the **WP** command before turning off the power).

DX Half or full duplex – this command select half or full duplex communication.
Parameter = 0 select half duplex communication and parameter = 1 select full duplex
Communication - use half duplex setting when using two wire RS485.

3.11 ANALOGUE OUTPUT SET-UP COMMANDS – AL, AH, AA

AL Set the analogue low level. This command defines the weight value for 4mA analogue output. Issuing the AL command without any parameters will return the current low level value in the form **L+00000**. Factory default setting: 0.

AH Set the analogue high level. This command defines the weight value for 20mA analogue output. Issuing the AH command without any parameters will return the current high level value in the form **H+10000**. Factory default setting: 10000.

AA Sets the source which will be used by the analogue output. Issuing the AA command without any parameters returns the current value in the form **A+00001**.
Factory default setting: 1.

An = 0	Gross weight as analogue output source
An = 1	Net weight as analogue output source

NOTE: Remember to store the settings using the **AS** command before turning off the power.

3.12 SAVE SET-UP PARAMETERS COMMAND – WP, SS, AS

The configuration parameters can be considered as four distinct groups, namely:

- Calibration Parameters (CZ, AZ, CG, AG, CM, CI, DS, DP, ZT);
- Indicator Parameters (FL, FM, UR, NR, NT, BR, AD, DX);
- Set-point Parameters (S1, S2, S3, H1, H2, H3, A1, A2, A3);
- Analog Parameters (AL, AH, AA);

The alteration and amendment of the calibration parameters is subject to the control procedure that is described in section 3.6. This procedure includes the use of the “Calibration Save” (CS) command. All other settings can be saved using the save commands WP, SS and AS.

WP Save the “indicator” set-up parameters - saves the settings of the “Filter” (FL, FM, UR), the “No-Motion” settings (NR, NT) and the communication settings (AD, BR, DX) in the EEPROM.

SS Save the “setpoint” set-up parameters - saves the settings of the setpoints (S1, S2 and S3), the “Setpoint Hysteresis” settings (H1, H2 and H3) and the “Setpoint Action” settings (A1, A2 and A3). Issuing the SS command, which has no parameters, will return OK or ERR response. The OK response signifies the “setpoint” parameters group settings have been saved to EEPROM

AS Save the “analogue” set-up parameters - saves the settings of the analogue output (AL, AH, AA) in the EEPROM

4. COMMAND PROTOCOL – SHORT DESCRIPTIONS

Command	Short Description	Usage	Parameter Values	Typical Response
OP	Open connection	Open device XXXX	0 to 255	0:002/OK
CL	Close all connections	Close all devices (OP XXXX implies CL)	none	none
ID	Inform device ID	Information - device identification	none	D:7210
IV	Inform version number	Information - software version number	none	V:0204
IS	Inform on device status	Information - motion, zero and tare status	none	S:000000
SR	Software reset	Restart the DAS	none	OK
LI	List settings	Information - list settings as ASCII lines	none	List of lines
SZ	Set system zero	Set system zero point	none	OK/ERR
RZ	Reset system zero	Restores the calibration zero point	none	OK/ERR
ST	Set tare	Set tare point	none	OK/ERR
RT	Reset tare	Restores current zero point	none	OK/ERR
GG	Get gross value	Get gross value	none	G+01100
GN	Get net value	Get net value	none	N+00000
GT	Get tare value	Get tare value	none	T+00000
GS	Get sample	Get data from A/D Converter	none	S+000000
GW	Get long weight information	Get long weight information	none	W+00100+01100010F
SG	Start auto-transmit gross	Start auto-transmitting gross weight result	none	G+01100
SN	Start auto-transmit net	Start auto-transmitting net weight result	none	N+00000
SW	Start auto-transmit weight	Start auto-transmitting long weight result	none	W+00100+011005109
IN	Read input status	Read input status	none	I:0011
OM	Output mask	Disable setpoint outputs	0000 through 0111	OM:0010
IO	Read/Modify output status	Read/Modify output status	0000 through 0111	O:0011
CE	Calibrate enable	Open legal parameters (CE 'TAC')	0 through 65535	E+00001/OK/ERR
CM	Calibrate max (TAC protected)	Read/modify max	0 through 99999	M+30000/OK/ERR
CI	Calibrate min (TAC protected)	Read/modify min	0 through -99999	-09000/OK/ERR
DS	Display step size (TAC protect)	Read/modify the display step size	1,2,5,10,20,50,100,200,500	S+00001/OK/ERR
DP	Decimal point (TAC protected)	Read/modify decimal point position	0 through 5	P+00005/OK/ERR
CZ	Calibrate zero (TAC protected)	Calibrate zero - no load on platform	none	OK/ERR
AZ	Absolute zero calibrate (TAC protected)	Calibrate zero using absolute zero in m/VV (without decimal point)	-32000 through 32000	OK/ERR
CG	Calibrate gain (TAC protected)	Calibrate gain at some load >> zero	0 through 99999	G+20000/OK/ERR
AG	Absolute gain calibrate (TAC protected)	Calibrate gain using absolute sensitivity in m/VV (without dp)	+/-32000; 0 through 99999	G+2.0000/OK/ERR
ZT	Zerotrack (TAC protected)	Zerotrack off (0) or zerotrack on (1)	0 through 1	Z:001/OK/ERR

FD	Factory default (TAC protected)	Load factory defaults into EEPROM	none	OK/ERR
CS	Calibrate save (TAC protected)	Save CM,CZ,AZ,CG,AG,DS,DP,ZT to EEPROM	none	OK/ERR
NR	No-motion range	No-motion range	0 through 65535	R+00010/OK/ERR
NT	No-motion time	No-motion time in milliseconds	0 through 65535	T+00500/OK/ERR
FL	Filter setting	Read/modify filter setting	0 through 8	F+00008/OK/ERR
FM	Filter mode	Read/modify filter mode setting	0 through 1	M+00001/OK/ERR
UR	Update rate	Read/modify update rate setting	0 through 7	U+00000/OK/ERR
Sn	Get/set setpoint n	Setpoint 1, 2 or 3	-99999 through 99999	Sn:+00000/OK/ERR
Hn	Get/set setpoint n hysteresis	Setpoint hysteresis 1, 2 or 3	-99999 through 99999	Hn:+00000/OK/ERR
An	Get/set setpoint n action	Setpoint action 1, 2 or 3	0 through 1	An:+00000/OK/ERR
AD	Network address	Read/modify network address	0 through 255	A:014/OK/ERR
BR	Baudrate	Read/modify baudrate setting	9600 through 115200	B 9600
DX	Duplex	Select half (0) or full (1) duplex	0 through 1	X:001/OK/ERR
AL	Get/set analog low	Analog low calibration point	-99999 through 99999	L+00000/OK/ERR
AH	Get/set analog high	Analog high calibration point	-99999 through 99999	H+10000/OK/ERR
AA	Get/set analog action	Analog action	0 through 1	A+00000/OK/ERR
WP	Save set-up parameters	Save FL, FM, UR, NR, NT, AD, BR, DX to EEPROM	none	OK/ERR
SS	Save setpoint parameters	Save S1, S2, S3, H1, H2, H3, A1, A2, A3 to EEPROM	none	OK/ERR
AS	Save analog output parameters	Save AL, AH, AA to EEPROM	none	OK/ERR

tecsis GmbH

Carl-Legien-Straße 40
D-63073 Offenbach am Main
Telefon: +49 69 5806-0
Telefax: +49 69 5806-170
E-Mail: force@tecsis.de
Internet: www.tecsis.de

