



Spring Cable Reel BEF150 – BEF500


Contents

1	General Notes	5
1.1	About this document	5
1.2	Limitation of liability	5
1.3	Copyright	5
1.4	Spare parts	6
1.5	Warranty and guarantee	6
1.6	Customer service	6
2	Safety Rules	7
2.1	Requirements on the personnel	8
2.1.1	Qualifications	8
2.1.2	Unauthorized personnel	8
2.1.3	Instruction	9
2.2	Personal protective equipment	9
2.3	Intended use	10
2.4	Improper use	10
2.5	Protective measures to be taken by the operator / user	10
3	Terminology	11
4	Technical Specifications	12
4.1	Type plate	12
4.2	Technical specifications	12
4.3	Operating conditions	13
4.4	Type designation code:	13
4.5	Dimensional drawings	13
5	Functional Description	14
5.1	Function	14
5.2	Construction	14
5.3	Danger zone	15
6	Transport and storage	16
6.1	Shipment	16

Spring Cable Reel

BEF150 – BEF500

6.1.1	Safety instructions for transport.....	16
6.1.2	Transport inspection	16
6.2	Packing.....	17
6.3	Storage of packed parts	17
7	Commissioning	18
7.1	Mechanical attachment.....	18
7.2	Electrical installation	23
7.2.1	Connecting the feed cable.....	28
7.3	Pretensioning	30
7.3.1	Adjustment	30
8	Operation	31
8.1	Safety	31
8.2	Function.....	31
8.3	Winding behaviour.....	31
9	Service.....	34
9.1	Safety	34
9.2	Service intervals and maintenance work	34
9.2.1	Reel.....	34
9.3	Replacing springs.....	37
9.3.1	Prerequisites	38
9.3.2	Series connection.....	38
9.3.3	Parallel connection	42
9.4	Changing the direction of rotation.....	44
9.4.1	Series connection.....	44
9.4.2	Parallel connection	47
10	Troubleshooting	49
11	Dismantling and disposal	50
11.1	Safety	50
11.2	Dismantling.....	50
11.3	Disposal.....	51



Spring Cable Reel
BEF150 – BEF500

12	Additional Documents	52
13	Indices	53
13.1	Figures	53
13.2	Keywords.....	54

1 General Notes

1.1 About this document

This document makes it possible for you to work safely and efficiently with a spring cable reel.

This document is a part of the spring cable reel, and must be kept accessible to personnel at all times in its immediate vicinity. Personnel must read this document carefully and understand it before starting any work. A basic condition for workplace safety is the observance of all safety and handling instructions appearing below.

Local accident protection regulations and general safety regulations apply for the area of use of the spring cable reel.

The figures in this document are to be used for basic understanding, and may deviate from the actual design under some circumstances.

In addition to this manual, the instructions located in the appendices for the individual assembled components also apply.

1.2 Limitation of liability

All information and instructions in this Installation and Operating Manual have been compiled with due regard to the standards and regulations in force, best engineering practice, and the findings and experience we have accumulated over many years.

The manufacturer is in no way liable for damages resulting from:

- Non-observance of the operating instructions
- Improper use
- Use by untrained personnel
- Unauthorized modifications
- Technical changes
- Use of unauthorized replacement parts and accessories

The actual scope of delivery may differ from the explanations and illustrations described here for special variants, if additional order options are utilized, or due to the latest technical changes.

The obligations agreed upon in the delivery agreement and our General Terms of Business apply, as do the delivery conditions of the manufacturer and all regulations applicable at the time the contract was concluded.

All products are subject to technical modifications in the context of improvement of function and further development.

1.3 Copyright

This document is subject to copyright, and is exclusively intended for internal use by the customer.

Provision of the installation and operating instructions to third parties, duplications in any form – even in part – as well as the reuse and/or disclosure of their content are not permitted without the written approval of the manufacturer, except for internal use by the customer.

Violations will be subject to damages. This will not exclude additional claims.

Spring Cable Reel BEF150 – BEF500

1.4 Spare parts



WARNING!

Safety risk due to wrong spare parts!

Wrong or faulty spare parts can result in damages, malfunctions or complete failure as well as impair safety.

- Use only original spare parts of the manufacturer!
- Order replacement parts from your contracted dealer or directly from the manufacturer.

Contact data:

Conductix-Wampfler GmbH
Rheinstrasse 27 + 33
79576 Weil am Rhein - Markt
Germany

Tel.: +49 (0) 7621 662-0
Fax: +49 (0) 7621 662-144
info.de@conductix.com
www.conductix.com

Replacement parts list:

Separate document delivered with the order. If necessary, request from Conductix-Wampfler.
Please specify the order number in your request.

1.5 Warranty and guarantee

The terms of warranty and guarantee can be found in the General Terms of Business of the manufacturer (see www.conductix.de).

1.6 Customer service

Our customer service is available for technical questions (see contact data).

Our employees are always interested in new information and experience from the field that can be valuable for the improvement of our products.

2 Safety Rules

Safety and hazard information is identified in this manual by the use symbols. Signal words are used to indicate the degree of hazard in these safety instructions. Always observe safety and hazard information and work carefully to avoid accidents, bodily harm or property damage!



DANGER!

... indicates an immediately hazardous situation, which if not avoided, may result in death or serious injury.



DANGER!

... indicates an immediately hazardous situation due to electricity, which if not avoided, may result in death or serious injury.



WARNING!

... indicates a possibly hazardous situation, which if not avoided, may result in death or serious injury.



WARNING!

... indicates a possibly hazardous situation due to electricity, which if not avoided, may result in death or serious injury.



CAUTION!

... indicates a possibly hazardous situation, which if not avoided, may result in moderate or minor injury.



Tips and recommendations:

... refers to useful tips and recommendations as well as information for efficient and trouble-free operation.



CAUTION!

... indicates measures that help avoid property damage.

Spring Cable Reel BEF150 – BEF500

2.1 Requirements on the personnel

2.1.1 Qualifications



WARNING!

Injury due to insufficient qualifications!

Improper use can result in serious injury to person and property.

→ All activities may only be performed by qualified personnel.

The following qualifications have been mentioned in this manual for different areas of operation:

- **Trained personnel/operators**

have been instructed by the operator about the tasks assigned to him/her and the possible hazards resulting from improper use.

- **Qualified specialists**

due to their specialized training, knowledge, and experience, as well as knowledge of applicable regulations, are capable of carrying out work assigned to them, while independently recognizing and avoiding possible risk. Personnel are considered qualified if they have successfully concluded training, for example, as electricians, master electricians, electrical engineers, or electrical technicians. Personnel are also considered qualified who have been employed correspondingly for several years, have been educated in theory and practice during that time, and have whose knowledge and skills in the trade required have been tested. The operator of the machine or system must document that the corresponding certification or other documentation of qualification are present or have been demonstrated.

- Only those persons are authorized as personnel who can be expected to perform their work reliably. People whose capacity for reaction is influenced e.g. by drugs, alcohol, or medications are not authorized.
- When selecting personnel, follow all age- and occupation-specific guidelines applicable at the location of use.

2.1.2 Unauthorized personnel



WARNING!

Danger due to unauthorized personnel!

Unauthorized personnel who do not meet the requirements described here do not understand the danger in the working area.

- Keep unauthorized personnel away from the working area
- In case of doubt, address the person and direct them away from the working area
- Stop work as long as unauthorized personnel is in the working area

Spring Cable Reel BEF150 – BEF500

2.1.3 Instruction

Before commissioning the equipment, personnel must be instructed by the operator. For better transparency, the performance of this instruction must be logged.

Example of instruction log:

Date	Name:	Type of instruction	Instruction given by	Signature
5 November 2010	John Doe	First safety training for personnel	Horst Müller	

2.2 Personal protective equipment

Always wear:

For all work:



Protective headgear

For protection from falling and flying parts and materials.



Protective gloves

For the protection of hands from friction, scrapes, stabbing, or deep wounds, as well as from contact with hot surfaces.



Work safety clothing

Primarily as protection against entrapment by moving machine parts. Working clothes must fit tightly with low resistance to tearing, close-fitting sleeves and no protruding parts.



Protective footwear

Used to protect from falling heavy parts and slipping on slippery floors.

For special tasks, wear:

When carrying out particular tasks, special safety gear is required. The individual sections specify this gear in detail.



Safety goggles

To protect the eye from harmful influences such as strong light, chemicals, dust, splinters, or weather.



Respirator (FFP-3 – according to country-specific requirements)

For protection against materials, particles or organisms.

Here, protection from dust resulting from the wear of the carbon brushes.

Spring Cable Reel BEF150 – BEF500

2.3 Intended use

The spring cable reel is used for the transmission of power and data to mobile consumers with automatic winding using a coil spring. Unwinding is not carried out manually, but rather by the mobile consumer.

Both the reel and the cable are permanently installed.

Flexible reel-capable energy or control cables are used.

The spring cable reel must always be mounted with its axis horizontal.

2.4 Improper use

Improper use is any use other than those listed in 2.3.

Use for any purpose other than or in addition to the intended use is permitted only after discussion with the manufacturer.

2.5 Protective measures to be taken by the operator / user

The spring cable reel is used in commercial/industrial areas. The operator of the spring cable reel is therefore subject to legal regulations concerning workplace safety. In addition to the safety instructions in this manual, all valid safety, accident protection and environmental protection regulations applicable for the place of operation of the spring cable reel apply.

This particularly includes:

- The operator must be informed of applicable workplace safety regulations and carry out a risk assessment to detect additional dangers resulting from the specific working conditions in the place of operation of the spring cable reel. This must be implemented in the form of operating instructions for the operation of the spring cable reel.
- For the entire period of use of the spring cable reel, the operator must check whether the operating instructions prepared correspond to the current state of regulations, and update the operating instructions as needed.
- The operator must clearly regulate and determine responsibilities for installation, operation, troubleshooting, and maintenance.
- The operator must ensure that all employees involved with the spring cable reel have read and understood this manual. The operator must furthermore train personnel at regular intervals and inform them of hazards.
- The operator must provide personnel with all required safety gear.

The operator is furthermore responsible for ensuring that the spring cable reel is always in a technically trouble-free condition. The following thus applies:

- The operator must ensure that the service intervals described in this manual are observed.
- The operator must regularly have all safety systems inspected for functionality and completeness (once yearly if possible, but at least as often as required by applicable national regulations).
- If the device or system has been modified, the safety systems must be inspected again and adapted to the changed conditions in such a way that the device or system is safe again.

Spring Cable Reel

BEF150 – BEF500

3 Terminology




Fig. 1 Main assemblies of the spring cable reel

Item	Description
1	End flange, both sides
2	Slip ring body, housing with type plate
3	Reel-capable cable (optional)
4	Coil spring with protective guard
5	Fastening flange

Power spring

Coil spring without coiling gap, with large energy storage capacity.

Spring nominal values

n_v : pre-loading rotations

n_a : work rotations

n_R : reserve rotations

n_{BI} : rotations until block = $n_v + n_a + n_R$



Winding direction: left by default (as seen from slip ring body housing: counter-clockwise)

Protective guard

Sheet metal housing in which the drive springs are installed to protect service personnel from injury.

Protection class

Protection against contact and against penetration of foreign bodies and water (see EN 60529; DIN VDE 0470-1).

Spring Cable Reel BEF150 – BEF500

4 Technical Specifications

4.1 Type plate

The type plate is located on the top part of the slip ring body housing (see Fig. 2).

The technical specifications can be read off the type plate (depending on the model and variant).



Fig. 2 Type plate

4.2 Technical specifications

Example:

Data	Value
Model	BEF 325524 – 1824/04ML – 2MB (T)H/L
Spring rotations	depending on the cable take-off
Max. total	44
Pretension n_v	20
Reserve n_r	4
Year of construction	2010
Slip ring body	1824 21+PE+2xS/04ML
Electrical current	21x25A+PE+4x20mA
Voltage	690 V/10 V
Protection class	IP65
Winding length	24 m
Order number	123456xxx

Spring Cable Reel BEF150 – BEF500

4.3 Operating conditions

Requirements for the working environment:

Designation	Value	Notes
Winding behaviour	0.3 m/s ²	Max. acceleration
Temperature range	-20 to 40 °C	
Operation in air	-	Maritime climate possible for short periods, mild chemical atmosphere, not in radioactive environment




Other values may be possible upon request.

4.4 Type designation code:

The type designation code includes the specification and the design features of the spring cable reel.

BEF 32 55 24 - 1824/04ML - 2 MB(T) H/L



4.5 Dimensional drawings

See separate documentation for dimensional drawings and dimensional tables.

Spring Cable Reel BEF150 – BEF500

5 Functional Description

5.1 Function

The spring cable reel is designed for the automatic coiling cables for mobile consumers. The cable is wound using pretensioned coil springs that are installed inside the body of the reel.

The reel is equipped with a fastening flange that is connected to the fixed axis by two threaded pins.

Unwinding is automatic and is implemented on site.

5.2 Construction

The reel is ball bearing mounted.

The reel body consists of a solid screwed plate structure (galvanised plate). Inside the reel body there is the spring chamber with the spring set.

The drive springs and ball bearings are lubricated with a special grease for the temperature range from -55 °C to +100 °C.

Against the flange side is the chamber in which the slip ring body is housed. This area is covered by a two-part plastic or steel hub (protection classes: IP54 steel, IP65 plastic).

The metric entry for the reel-capable cable (cable collar) is located in the lower part of the hub.

The slip ring of the slip ring body is screwed onto the fixed axis.

The current collector part is connected to the rotating reel body.




Fig. 3 Reel mount

Spring Cable Reel BEF150 – BEF500

5.3 Danger zone

When using spring cable reels, there are two main danger zones to take into consideration:

Rotating reel

During operation, the reel cable is unrolled and/or rolled back in under spring tension. The reel body turns during these actions.



WARNING!

Danger zone: rotating parts!

Danger of injury from rotating machine parts!

→ During operation, keep a safe distance from the rotating reel body!

Reel cable

During operation, the reel cable is unrolled and/or rolled back in under spring tension. The cable represents an obstacle. Increased alertness is required in this area.



DANGER!

Danger zone: reel cable!

Danger of stumbling resulting in injury due to moving exposed cables!

→ During operation, keep a safe distance from the reel cable!



DANGER!

Danger zone: reel cable!

While the reel cable is being wound by spring tension, there is a danger of entanglement/crushing.

→ Increased alertness is required in the winding area!



DANGER!

Danger zone: reel cable!

Danger of crushing and entanglement resulting in injury due to cables being reeled in!

→ During winding, keep a safe distance from the rotating reel body!

6 Transport and storage

6.1 Shipment

6.1.1 Safety instructions for transport



WARNING!

Danger of death due to hanging loads!

Falling parts or those swinging out of control can lead to severe injury or even death.

- Never step under hanging loads
- Only use the attachment points provided; do not fasten lifting accessories to projecting machine parts or components built onto eyes.
- Be sure the connection elements are firmly seated
- Use only authorized lifting accessories and connection elements with sufficient load capacity
- Do not use torn or worn ropes or straps, but rather replace them with new ones
- Do not attach ropes or straps to sharp corners and edges, and do not knot or twist them
- Move loads only under supervision
- Set down the load when leaving the workplace



WARNING!

Possible damage from improper transport!

Improper transport can result in substantial property damage.

- Act with care when unloading packaged parts upon delivery as well as during internal transport, and observe the symbols and the hazard information on the packaging
- Use only the attachment points provided
- Wait to remove packaging material until just before installation

6.1.2 Transport inspection

Check the delivery for completeness and transport damage immediately upon receipt.

Procedure in case of externally detectable transport damage:

- Do not accept delivery, or accept it only with reservations
- Note the scope of damage on the transport documents or on the transporter's delivery note
- File a complaint



CAUTION!

Damage compensation claims may only be made within the applicable claim periods.

- Claim every defect as soon as the defect is detected.

Spring Cable Reel BEF150 – BEF500

6.2 Packing

The individual packaged parts must be packed according to the transport conditions to be expected. Only environmentally friendly materials have been used for packaging.

The packaging must protect the individual components from transport damages, corrosion, and other damage until installation.



Do not destroy the packaging and remove it only just before installation.

Handling packaging materials:

Dispose of packaging material according to valid legal regulations and local guidelines.



CAUTION!

Environmental damage due to improper disposal!

Packaging material is a valuable resource and can be reused, processed or recycled in many cases.

- Dispose of packaging materials in an environmentally appropriate manner
- Comply with locally applicable disposal guidelines; if necessary, engage a specialist with disposal

6.3 Storage of packed parts

Store packed parts under the following conditions:

- Do not store outdoors
- Store in a dry, dust-free place
- Do not expose to aggressive media
- Protect from direct sunlight
- Avoid mechanical vibrations
- Storage temperature: 15-35 °C
- Relative humidity: max. 60 %
- When storing for more than 3 months, check the general condition of all parts and the packaging at regular intervals. If necessary, add or replace the preservative



CAUTION!

Under some circumstances, there may be instructions for storage on the packed parts which go beyond the requirements listed here.

- Follow them appropriately

Spring Cable Reel BEF150 – BEF500

7 Commissioning



CAUTION!

Installation

→ During electrical installation of the reel, note whether it was delivered with or without the wound cable.



CAUTION!

Commissioning may only be carried out by an electrician.

7.1 Mechanical attachment

The unit must be mechanically attached to a stable connection point with adequate load capacity. Beams, massive masonry or fastening blocks (accessories) may be used as connection points.

Use the three drilling templates depending on the flange size:

Flange size	Drilling templates
61-F001-0039	BEF150
61-F001-0055	BEF185 – 325
61-F001-0056	BEF400 + 500



The three drilling templates for cutting out are on the following pages.



CAUTION!

Check the drilling templates!

If you use the drilling templates shown below, then please note the following:

- Do not scale the document while creating and printing the PDF! In the print menu, select the function "No scaling"
- Before cutting the templates out, check their dimensions!

Spring Cable Reel
BEF150 – BEF500




Fig. 4 Drilling template BEF150/61-F001-0039

Spring Cable Reel

BEF150 – BEF500




Fig. 5 Drilling template BEF185 – 325/61-F001-0055

Spring Cable Reel

BEF150 – BEF500




Fig. 6 Drilling template BEF400 – 500/61-F001-0056

Spring Cable Reel BEF150 – BEF500

During installation, please note:

- The axis of the spring cable reel must always be positioned horizontally.
- The screw attachment surface must be flat.




Fig. 7 Fastening flange and reel axis



Reel attachment

The threaded pin for attaching the flange (detail A, Fig. 7) must engage in the depression in the axis. The threaded pin is secured at the factory against loosening.

- Do not loosen the threaded pin, secure it again when it is screwed back in
- Be sure the reel is mounted at right angles to the cable take-off!

Use the following screw sizes to match the drilling template:

Dimension/drilling template	Screw size	Tightening torque, match to screwing surface
BEF150/61-F001-0039	M8 (4x)	25 Nm
BEF185-135/61-F001-0055	M12 (4x)	85 Nm
BEF400-500/61-F001-0056	M16 (4x)	210 Nm

Leave the following dimensions for the cable entry depending on the conductor cross-section/dimensions:

Size	Connection hole	Max. cable diameter
BEF150	M20x1.5	10 mm
BEF185-225	M25x1.5	20 mm
BEF265-325	M32x1.5	25 mm
BEF400-500	M40x1.5	35 mm

Spring Cable Reel BEF150 – BEF500

7.2 Electrical installation

Connecting the reel cable



CAUTION!

Attach tension relief!

→ To avoid damage to the cables, always provide sufficient tension relief



WARNING!

Note before turning on!

→ Before the device or system is started, test the insulation resistance according to locally applicable technical standards, directives, and law

→ Carry out all locally required electrical testing according to applicable regulations



WARNING!

Danger of death by electrocution!

Contact with components carrying electrical power can lead to death or severe injury by electrocution. Danger of injury due to shock reactions, falling, or being thrown away due to electrical shock.

→ Before starting electrical connection work, **disconnect all relevant cables from power and secure the device or system against being turned back on**

→ Follow the five safety rules!

→ **Earth the device on the earthing connection (PE) of the slip ring body**



Carry out electrical installation after mechanical attachment is complete.



The connections for earth, electrical feed and the reel cable are in the slip ring body.

Spring Cable Reel BEF150 – BEF500




Fig. 8 Cable connections on the slip ring body

Connecting the reel cable:

- Remove slip ring body hub.
- Guide the mobile cable (= reel cable) through the slot in the outer round plate and into the collar in the lower part of the hub in the slip ring body.
- Connect the reel cable to the current collectors of the slip ring body.
- The cable may not contact the slip ring body within the slip ring body housing!
- Tighten the cable collars to relieve tension.

Overview of current collector variants:

Current collectors	Connection material to be used
Type 45	Blade receptacle 6 3x0.5 (see Fig. 9)
Type 13	M5 cable shoe (see Fig. 10)
Type 15	M6 cable shoe (see Fig. 10)
Type 16	M8 cable shoe (see Fig. 11)
Type 18	M4 cable shoe (see Fig. 12) or insulated blade receptacle 6 3x0.5
Type 19	M8 cable shoe (see Fig. 11)



CAUTION!

Terminal diagram

- Follow the attached terminal diagram for connection work.

Spring Cable Reel BEF150 – BEF500

The current collector variants:




Fig. 9 Type 45 current collector connection




Fig. 10 Types 13, 15 current collector connection

Spring Cable Reel

BEF150 – BEF500




Fig. 11 Types 16, 19 current collector connection




Fig. 12 Type 18 current collector connection

Spring Cable Reel BEF150 – BEF500




Fig. 13 Types 18 current collector connection with blade receptacle

- Wind the reel cable by hand without twisting it, and tie the cable end onto the reel.
- Pretension the reel with n_v turns (see section 4.1) in the take-off direction and secure against rewinding.
- Release the end of the cable and unwind as much cable by hand (without turning the reel) as needed to reach the attachment point that is the shortest distance away.
- Connect the cable end.
- Remove the protection against unwinding and release the spring tension carefully.
- Check whether unwinding works (check the unwinding function).



DANGER!

Danger of injury if cable breaks!

If the spring set is tightened until it blocks, the cable can tear off (cable break) because excessive forces are exerted on the cable. This can lead to extreme property damage and injury or even death!

- During installation, please be sure that **at least two reserve windings** are left when the mobile attachment point is at its maximum distance (complete cable unwinding)
- Never wind the spring set to its blocking point

Spring Cable Reel BEF150 – BEF500

7.2.1 Connecting the feed cable



Danger of death by electrocution!

Contact with components carrying electrical power can lead to death or severe injury by electrocution. Danger of injury due to shock reactions, falling, or being thrown away due to electrical shock.

- Before starting electrical connection work, **disconnect all relevant cables from power and secure the device or system against being turned back on**
- Follow the five safety rules!
- **Earth the device on the earthing connection (PE) of the slip ring body**

- Unscrew and remove the cap of the slip ring body.
- Guide the feed cable and earthing cable through the cable entry (masonry, beams, etc.), the reel flange and the reel axis to the slip ring body.



CAUTION!

Terminal diagram

- Follow the attached terminal diagram for connection work.

- Connect the cables.
- Check all connections for secure, firm seating.
- Replace the slip ring body cap and screw it back into place.
- Wind the reel cable by hand without twisting and tie the cable end down.

The connections to the slip ring variants are shown in the illustrations below:

Slip ring	Connection material to be used
Type 45	None needed, since the only terminal board variant possible has mantle terminals
Type 13	M6 cable shoe
Type 15	M8 cable shoe
Type 16	M8 cable shoe
Type 18	None for terminal board variants with mantle terminals; M5 cable shoe for direct wiring
Type 19	M8 cable shoe

Spring Cable Reel BEF150 – BEF500




Fig. 14 Type 13, connection plate with terminals




Fig. 15 Type 18, connection plate with terminals




Fig. 16 Type 45, terminal board with terminals

Spring Cable Reel BEF150 – BEF500

7.3 Pretensioning

7.3.1 Adjustment

Connecting the reel



DANGER!

Danger of injury from pretensioned drive springs!

If the spring tension is released suddenly, the reel can turn at high speed in an uncontrolled manner. This can cause impacts, crushing, shearing and other severe injuries.

- Secure the cable against unwinding while pretensioning
- Always avoid sudden release of the spring tension

- Tie the free end of the cable to the reel.
- Move the mobile attachment point to its closest distance.
- Pretension the reel with n_v turns (see the type plate) in the take-off direction, and hold it fast.
- Release the end of the mobile cable and manually unwind enough cable to reach the attachment point.



Do not turn the reel, but rather unwind the cable from the reel!

- Connect the cable end to the attachment point and release the reel.

Test run:

- Remove any obstacles that could lead to collisions with the reel or the cable.
- At low speed and with visual contact, carry out a test run to check that the cable can unwind without problems.



WARNING!

Danger of injury if the cable breaks!

An emergency stop must be possible at any time throughout the unwinding process!

- Count the working turns of the reel and compare them with the specifications on the type plate.
- If the specified number of working turns (see type plate) has been exceeded, immediately stop the unwinding process and contact Conductix-Wampfler.
- Check the orientation of the cable on the reel: The cable must overlap itself in an orderly manner when wound.

8 Operation

8.1 Safety



WARNING

Danger of injury due to improper operation!

Improper operation can result in serious injury to person and property.

- Carry out all operating steps according to the specifications of these instructions.
- Before starting work, be sure that all covers and safety systems are installed and working properly.
- Never disable the safety systems during operation.
- Maintain order and cleanliness in the working area! Loosely stacked or scattered components and tools are a source of accidents.



WARNING

Danger for unauthorized personnel!

Personnel who do not meet the requirements described here do not understand the danger in the working area.

- Keep unauthorized personnel away from the working area
- In case of doubt, address the person and direct them away from the working area
- Stop work as long as unauthorized personnel is in the working area

Personnel:

- Only instructed personnel may operate the device or system.

Personal protective clothing (must be worn for all work):

- Work safety clothing
- Protective footwear

8.2 Function

After proper mechanical and electrical installation, the spring cable reel can be used.

Depending on the specific application, cable supports or rollers may need to be designed and installed. For short take-off lengths, free cable-take-off is possible.

In the case of vertical take-off either upwards or downwards, additional weight (due to the cable's own weight or for example control panels or the like) or opposing weights (from above) must also be taken into consideration.

The wound cable is unwound against the pretensioned coil springs, in either the horizontal or the vertical direction.

Be sure that the cable is always wound and unwound at a 90° angle to the reel axis.

8.3 Winding behaviour

While setting up the spring cable reel, be sure that the fixed point is located within the winding width (dimension "b" in Fig. 17) in order to achieve optimum winding behaviour. The deflection angle of the cable may never be > 3°-5° in any position, since otherwise there will be irregularities during winding and excessive axial force will result.

Spring Cable Reel BEF150 – BEF500



The cable can only be properly wound if the maximum permissible angle is observed!




Fig. 17 Optimum winding behaviour

Spring Cable Reel BEF150 – BEF500




Fig. 18 Deflection



CAUTION!

Do not twist cable during operation!

The cable must not be installed in such a way that it can twist around its lengthwise axis. This will destroy the cable.

- Check the winding behaviour of the reel at regular, short intervals
- Replace defective cables and set up the application in such a way that cables only wind straight

Spring Cable Reel BEF150 – BEF500

9 Service

9.1 Safety



WARNING!

Danger of death by electrocution!

Contact with components carrying electrical power can lead to death or severe injury by electrocution. Danger of injury due to shock reactions, falling, or being thrown away due to electrical shock.

- Before starting electrical connection work, **disconnect all relevant cables from power and secure the device or system against being turned back on**
- Follow the five safety rules!
- **Earth the device on the earthing connection (PE) of the slip ring body**

9.2 Service intervals and maintenance work

Have an electrician carry out an inspection after no more than one year. If the strain is unusually high, the electrician must be called earlier.

9.2.1 Reel

- Check all bolts and nuts for firm seating, since all reels are assembled from individual parts.
- Check all rubber seals and cable collars for tightness and/or damage.
- If necessary, replace rubber seals or cable collars.

Flange

- Check the connection between the flange and axis for firm seating.

Clean the slip ring body

Protective equipment needed:



CAUTION!

Danger of sensitization, mucous membrane irritation and respiratory disease due to dust!

Abrasion residue from the carbon brushes collects in the slip ring body. This dust is very fine and is a health hazard.

- During cleaning, wear personal protective equipment:
 - Safety goggles
 - Dust mask, class FFP3
- **Do not blow out dust with compressed air** but rather vacuum it away. The vacuum cleaner must be equipped with a class H fine filter
- Do not eat, drink or smoke during work!

Spring Cable Reel BEF150 – BEF500



CAUTION!

Do not clean the ring surface with chemical agents. The ring surface can be destroyed by chemical agents.

- Clean dust deposits and abrasion residue from the slip ring body.
- Check the ring surface; grind it smooth if necessary.
- Check all wires for firm connections and damage to insulation.

Replace current collector:



Conductix-Wampfler uses different types of current collectors!

- Disconnect all cables from power and secure against being turned back on.
- Unscrew and remove the housing of the slip ring body.
- Unscrew the cables and wires from the rings and current collectors.
- Unscrew the wires from the current collectors that will be replaced.
- Insert and bolt down the new current collector.
- Reconnect all wires and check for firm seating.
- Replace the housing of the slip ring body and screw it in place.

Overview of current collector variants with rings:




Fig. 19 Type 13, current collector with slip ring




Fig. 20 Type 15, current collector with slip ring

Spring Cable Reel BEF150 – BEF500




Fig. 21 Type 16, current collector with slip ring




Fig. 22 Type 18 current collector, assembly/disassembly and slip ring




Fig. 23 Type 19, current collector with slip ring

Spring Cable Reel

BEF150 – BEF500




Fig. 24 Type 45/1 + 45/3: Current collector with slip ring and wire




Fig. 25 Type 45/2, current collector with slip ring and wire

Cables:

- Check that cables are installed without twisting. If necessary, loosen the cable and install it so that it is not twisted.
- Check state. Replace damaged cables.
- Check cable collars.
- The cables in the slip ring body housing must be laid in such a way that the current collectors can move freely.

9.3 Replacing springs

Replacement parts for reels and slip ring bodies can be found in the replacement parts list you received with your reel (see section 1.4).

Spring Cable Reel BEF150 – BEF500



DANGER!

Danger of fatal injury from pretensioned drive springs!

The drive springs are installed in protective metal housings for protection from injury. If the protective housings are opened, then the drive springs (coils of spring steel) can be released from the protective housing in an uncontrolled manner. This can cause severe cuts and impact injuries that could even be fatal.

- Do not open the protective housing!
- Replace springs only as a complete unit with the protective housings!



DANGER!

Danger of death due to hanging loads!

When lifting loads, there is a danger of death from falling parts or those swinging out of control.

- Never step under hanging loads
- Follow the specifications for the attachment points provided

9.3.1 Prerequisites

- Disconnect all cables from power and secure against being turned back on.
- Disconnect the mobile cable from the feed point (= attachment point) and wind it onto the reel body. Release the springs slowly and completely during this process.
- Remove the mobile cable from the reel.
- Unscrew and remove the housing of the slip ring body.
- Disconnect the fixed feed cable from the slip ring body and pull it out through the central axis.
- The complete cable must be removed.
- Remove the complete reel from the device.

9.3.2 Series connection

Spring designation, e.g.: 2DH (T) H or 2UA (T)H [H for series connection]

9.3.2.1 Dismantling

- Loosen the threaded pin [1] of the fastening flange.
- Pull off the flange [2], V-ring [3] and spacer [4].

Spring Cable Reel BEF150 – BEF500

"Left" take-off:




Fig. 26 Changing springs, series connection with left take-off

BEF185 – BEF500

- On the flange side, loosen the hex nuts [10] of the protective housing bolts and the hex nuts [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange and the reel body, then carefully pull off the end flange with its bearing flange [6].
- Loosen the threaded pin of the spacer [7] and pull it off the axis.
- Carefully lift out the protective housing [9, 11].

BEF150

- On the flange side, loosen the cylinder screws [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange [6] and the reel body [0], then carefully pull off the end flange with its bearing flange.
- Loosen the threaded pin of the spacer [10] and pull it off the axis.
- Carefully lift out the protective housing [7, 8].



CAUTION!

The towing part protective housing is suspended in the guide groove of the reel body and the first spring [7] on the flange side.

Spring Cable Reel BEF150 – BEF500

"Right" take-off:




Fig. 27 Changing springs, series connection with right take-off

BEF185 – BEF500

- On the flange side, loosen the hex screws [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange and the reel body, then carefully pull off the end flange with its bearing flange [6].
- Loosen the threaded pin of the spacer [7] and pull it off the axis.
- Loosen the threaded pin of the fixed spring nut [8] and take it out.
- Lift the protective housing(s) [9] out with the spring nut.
- Loosen the hex nuts [10] of the fixed protective housing [11] on the outside of the end flange on the slip ring body side.
- Carefully lift out the protective housing [11].

BEF150

- On the flange side, loosen the cylinder screws [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange [6] and the reel body [13], then carefully pull off the end flange with its bearing flange.
- Loosen the threaded pin [11] of the slip ring body and carefully pull the axis out until the threaded pins [9] of the spring nut [12] are accessible.
- Loosen the threaded pins of the spacer [10] and the spring nut, and take them out.
- Carefully lift out the protective housing [7, 8].



CAUTION!

The towing part protective housing [8] is suspended in the guide groove of the reel body and is held in place by a plastic profile.

- Take out the plastic profile and then the protective housing [8].

Spring Cable Reel BEF150 – BEF500

9.3.2.2 Installation

Even the unbroken springs should be replaced, since they can soon be expected to suffer from fatigue.

→ Before reassembly, coat the spring nuts and their holes generously with acid-free, elastic grease.



Recommended grease: Klüber CENTOPLEX 2 DL

- Clean all parts that will be reused.
- Assembly proceeds in the reverse sequence.
- Secure the threaded pin [1] against loosening.
- Follow the starting instructions (see Chapter 7).



WARNING!

Danger of death by electrocution!

→ Earth the device on the earthing connection (PE) of the slip ring body!

Spring Cable Reel BEF150 – BEF500

9.3.3 Parallel connection

Spring designation, e.g.: 2DH (T) or 2UA (T)




Fig. 28 Changing springs, parallel connection

9.3.3.1 Dismantling

- Loosen the threaded pin [1] of the fastening flange.
- Pull off the flange [2], V-ring [3] and spacer [4].

BEF185 – BEF500

- On the flange side, loosen the hex nuts [5] of the parallel bolts and the hex nuts [6] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange and the reel body, then carefully pull off the end flange with its bearing flange [7].
- Pull the spacers [8] off the parallel bolts.
- Carefully lift out the protective housing(s) [9].

BEF150

- On the flange side, loosen the cylinder screws [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange [6] and the reel body [8].
- Carefully pull off the end flange with its bearing flange.
- Carefully lift out the protective housing and springs [7].



CAUTION!

All protective housings are towing part housings and are guided by a guide bar inside the reel body!

Spring Cable Reel

BEF150 – BEF500

9.3.3.2 Installation

Even the unbroken springs should be replaced, since they can soon be expected to suffer from fatigue.

→ Before reassembly, coat the spring nuts and their holes generously with acid-free, elastic grease.



Recommended grease: Klüber CENTOPLEX 2 DL

→ Clean all parts that will be reused.

→ Assembly proceeds in the reverse sequence.

→ Follow the starting instructions (see Chapter 7).



WARNING!

Danger of death by electrocution!

→ Earth the device on the earthing connection (PE) of the slip ring body!

Spring Cable Reel BEF150 – BEF500

9.4 Changing the direction of rotation

9.4.1 Series connection

Spring designation, e.g.: 2DH (T) H or 2UA (T)H [H for series connection]

BEF185 – BEF500




Fig. 29 BEF185 – BEF500 change of rotation direction, series connection with left/right take-off

- Section 9.3 describes the steps needed for preparation.
- Loosen the threaded pin [1] of the fastening flange, then pull off the flange [2], V-ring [3] and spacer [4].
- On the flange side, loosen the hex nuts [10] of the protective housing bolts and the hex nuts [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange and the reel body, then carefully pull off the end flange with its bearing flange [6].
- Loosen the threaded pin of the spacer [7] and pull it off the axis.
- Carefully lift out the protective housing [9, 11].
- Loosen the threaded pin of the fixed spring nut [8] still on the axis and take it out.
- Remove the hex nuts [13] of the "dummy" collar from the end flange on the slip ring body side, and use it to seal the open holes for the protective housing bolts on the end flange on the flange side.
- Turn the first protective housing by 180° on its spacer bolts, insert it into the freed-up holes in the end flange on the slip ring body side and tighten it with the hex nuts [10].
- Turn the other protective housings by 180° with the spring nut screwed in place, then insert them one after the other into the first protective housing and then each successive one.
- Turn the final single spring nut [12] by 180° and fasten it to the axis in such a way that the protective housings are one above the other and have at least 4 to 5 mm of play.
- Fasten the spacer [7] onto the axis.
- Insert the end flange [6] onto the axis (with the spacer as stop) and use the hex bolts [5] to fasten it to the reel body.
- Insert and fasten the spacer [5], V-ring [3] and flange [2].

Spring Cable Reel BEF150 – BEF500

- Secure the threaded pin [1] against loosening.
- Seal the cuts on the reel with silicone.
- Connect the reel (see Chapter 7).



WARNING!

Danger of death by electrocution!

- Earth the device on the earthing connection (PE) of the slip ring body!

BEF150




Fig. 30 BEF185 Change of rotation direction, series connection with left/right take-off

- Section 9.3 describes the steps needed for preparation.
- Loosen the threaded pin [1] of the fastening flange, then pull off the flange [2], V-ring [3] and spacer [4].
- On the flange side, loosen the cylinder screws [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange [6] and the reel body.
- Carefully pull off the end flange with its bearing flange.
- Carefully lift out the protective housing and springs [7.8].



CAUTION!

The towing part protective housing is guided by a guide bar inside the reel body and is on the side where the flange is located.

- Loosen the threaded pins of the fixed spring nut [9] still on the axis and take them out
- Turn the towing part protective housing by 180°, insert the guide and push to the empty side of the slip ring body.
- Turn the other protective housings the fixed spring nut by 180°, then insert them one after the other into the first protective housing and then each successive one.

Spring Cable Reel

BEF150 – BEF500

- Turn the final single spring nut [9] by 180° and fasten it to the axis. Carefully pull out the axis until the fastening bolts are accessible.
- Insert the end flange with its bearing flange [6] onto the axis (with the spacer as stop) and use the cylinder screws [5] to fasten it to the reel body.
- Insert and fasten the spacer [5], V-ring [3] and flange [2].
- Secure the threaded pin [1] against loosening.
- Seal the cuts on the reel with silicone.
- Connect the reel (see Chapter 7).



WARNING!

Danger of death by electrocution!

- Earth the device on the earthing connection (PE) of the slip ring body!

Spring Cable Reel BEF150 – BEF500

9.4.2 Parallel connection

Spring designation, e.g.: 2D H (T) or 2UA (T)

BEF185 – BEF500




Fig. 31 BEF185 – FEB500 Change of rotation direction, parallel connection

- Section 9.3 describes the steps needed for preparation.
- Loosen the threaded pin [1] of the fastening flange, then pull off the flange [2], V-ring [3] and spacer [4].
- On the flange side, loosen the hex nuts [5] of the parallel bolts and the hex nuts [6] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange and the reel body.
- Carefully pull off the end flange with its bearing flange [7].
- Pull the spacers [8] off the parallel bolts.
- Carefully lift out the protective housing(s) [9].
- Turn the protective housing(s) by 180° and place them onto the axis one after the other.
- Insert spacers onto the parallel bolts.
- Insert the end flange [7] onto the axis (with the spacer/spring nut as stop) and use the hex bolts to fasten it to the reel body.
- Insert and fasten the spacer [5], V-ring [3] and flange [2].
- Secure the threaded pin [1] against loosening.
- Seal the cuts on the reel with silicone.
- Connect the reel (see Chapter 7).



WARNING!

Danger of death by electrocution!

- Earth the device on the earthing connection (PE) of the slip ring body!

Spring Cable Reel BEF150 – BEF500

BEF150




Fig. 32 BEF150 Change of rotation direction, parallel connection

- Section 9.3 describes the steps needed for preparation.
- Loosen the threaded pin [1] of the fastening flange, then pull off the flange [2], V-ring [3] and spacer [4].
- On the flange side, loosen the cylinder screws [5] of the connection between the end flange and the reel body.
- Remove the silicone joint between the end flange [6] and the reel body.
- Carefully pull off the end flange with its bearing flange.
- Carefully lift out the protective housings.
- Loosen the threaded pin on the spring nut [9] still on the axis, pull out the spring nut, turn it by 180° and fasten it onto the axis.
- Turn the towing part protective housings by 180°, insert them into the guide and insert them one after the other.
- Insert the end flange with its bearing flange [6] onto the axis (with the spacer as stop) and use the cylinder screws [5] to fasten it to the reel body.
- Insert and fasten the spacer [5], V-ring [3] and flange [2].
- Secure the threaded pin [1] against loosening.
- Seal the cuts on the reel with silicone.
- Connect the reel (see Chapter 7).



WARNING!

Danger of death by electrocution!

- Earth the device on the earthing connection (PE) of the slip ring body!

Spring Cable Reel BEF150 – BEF500

10 Troubleshooting



WARNING!

Danger of injury due to improper troubleshooting!

Improper troubleshooting can result in serious injury to person and property.

→ Contact the manufacturer in case of malfunction

→ Have troubleshooting carried out only by personnel from or authorized by the manufacturer

Fault in	Fault description	Cause or correction
Winding behaviour	Cable rises during winding or cable does not wind to full width.	Check the alignment of the reel (horizontal alignment and axis position). Check deflection angle of the cable.
Reel	Cable is not wound by the springs. Noise while unwinding cable.	Direction of rotation wrong? Check direction of rotation.
	Pull too weak while winding.	Check pretensioning
	Blocking position of the springs reached.	Check the cable length and pretensioning. Check the number of working turns on the reel.
Slip ring body	No continuity	Check connection.
	Errors in data transmission	Wear in current collector/ring. Contamination. Cable connections loose; cable defective.
	Earth fault	Contamination due to abrasion residue in the slip ring body.

11 Dismantling and disposal

11.1 Safety



WARNING!

Danger of injury due to improper disassembly!

Stored energy, sharp components, points, and edges on and in the device or the tools needed can cause injury.

- Before starting work, ensure sufficient space
- Handle open, sharp-edges components carefully
- Maintain order and cleanliness in the work area!
- Loosely stacked or scattered components and tools are a source of accidents
- Dismount components properly.
- Note the high weight of some components. If necessary, use lifting gear
- Secure components so that they cannot fall or fall over
- Involve the manufacturer in case of any unclear points

11.2 Dismantling

After the system is no longer in use, the spring cable reel must be disassembled and environmentally friendly disposal carried out.



WARNING!

Environmental damage due to improper disposal!

Packaging material is a valuable resource and can be reused, processed or recycled in many cases.

- Dispose of packaging materials in an environmentally appropriate manner
- Comply with locally applicable disposal guidelines; if necessary, engage a specialist with disposal



WARNING!

Danger of death by electrocution!

- Earth the device on the earthing connection (PE) of the slip ring body!



WARNING!

Be careful of hazards!

Danger due to hazardous dust, sharp edges and moving parts

Spring Cable Reel BEF150 – BEF500



WARNING!

Danger of death due to hanging loads!

Falling parts or those swinging out of control can lead to severe injury or even death.

- Never step under hanging loads
- Only use the attachment points provided; do not fasten lifting accessories to projecting machine parts or components built onto eyes.
- Be sure the connection elements are firmly seated
- Use only authorized lifting accessories and connection elements with sufficient load capacity
- Do not use torn or worn ropes or straps, but rather replace them with new ones
- Do not attach ropes or straps to sharp corners and edges, and do not knot or twist them
- Move loads only under supervision
- Set down the load when leaving the workplace

Personnel:

- May only be carried out by trained technicians
- At least two people

11.3 Disposal

Properly disassembled components are to be recycled if no return or disposal agreement has been made.

- Scrap metals
- Take plastic elements for recycling
- The other components are to be disposed of according to their material composition



CAUTION!

Environmental damage due to improper disposal!

Electrical waste, electronic components, lubricants, and other auxiliary materials are subject to hazardous waste disposal regulations and may only be disposed of by authorized specialists.

Local community officials or special disposal companies can provide information about environmentally appropriate disposal.

12 Additional Documents

Additional Documents:

- Declaration of incorporation
- Dimensional drawings
- Spare parts list

Applicable documents:

- BAL6100-0001-Drive springs
- TI5100-0007-Slip ring body wear limits

Spring Cable Reel BEF150 – BEF500

13 Indices

13.1 Figures

Fig. 1 Main assemblies of the spring cable reel.....	11
Fig. 2 Type plate	12
Fig. 3 Reel mount.....	14
Fig. 4 Drilling template BEF150/61-F001-0039.....	19
Fig. 5 Drilling template BEF185 – 325/61-F001-0055.....	20
Fig. 6 Drilling template BEF400 – 500/61-F001-0056.....	21
Fig. 7 Fastening flange and reel axis	22
Fig. 8 Cable connections on the slip ring body	24
Fig. 9 Type 45 current collector connection	25
Fig. 10 Types 13, 15 current collector connection	25
Fig. 11 Types 16, 19 current collector connection	26
Fig. 12 Type 18 current collector connection	26
Fig. 13 Types 18 current collector connection with blade receptacle	27
Fig. 14 Type 13, connection plate with terminals	29
Fig. 15 Type 18, connection plate with terminals	29
Fig. 16 Type 45, terminal board with terminals	29
Fig. 17 Optimum winding behaviour	32
Fig. 18 Deflection	33
Fig. 19 Type 13, current collector with slip ring.....	35
Fig. 20 Type 15, current collector with slip ring.....	35
Fig. 21 Type 16, current collector with slip ring.....	36
Fig. 22 Type 18 current collector, assembly/disassembly and slip ring	36
Fig. 23 Type 19, current collector with slip ring.....	36
Fig. 24 Type 45/1 + 45/3: Current collector with slip ring and wire	37
Fig. 25 Type 45/2, current collector with slip ring and wire	37
Fig. 26 Changing springs, series connection with left take-off.....	39
Fig. 27 Changing springs, series connection with right take-off.....	40
Fig. 28 Changing springs, parallel connection	42
Fig. 29 BEF185 – BEF500 change of rotation direction, series connection with left/right take-off	44
Fig. 30 BEF185 Change of rotation direction, series connection with left/right take-off.....	45
Fig. 31 BEF185 – FEB500 Change of rotation direction, parallel connection.....	47
Fig. 32 BEF150 Change of rotation direction, parallel connection.....	48

Spring Cable Reel

BEF150 – BEF500

13.2 Keywords

Changing the direction of rotation	44	Protection class.....	11
Construction	14	Protective equipment	9
Copyright	5	Protective guard	11
Customer service	6	Protective measures	10
Danger zone.....	15	Safety instructions.....	7
Dimensional drawings	13	Spare parts	6
Dismantling.....	50	Specification.....	13
Function.....	14	Spring nominal values.....	11
Instruction.....	9	Technical specifications	12
Intended use.....	10	Terminology	11
Limitation of liability	5	Troubleshooting	49
Operating conditions	13	Type designation code:.....	13
Operator	10	Type plate	12
Personnel	8	Unauthorized personnel.....	8
Power spring	11	Warranty and guarantee	6

Conductix-Wampfler GmbH
Rheinstrasse 27 + 33
79576 Weil am Rhein - Markt
Germany

Tel.: +49 (0) 7621 662-0
Fax: +49 (0) 7621 662-144
info.de@conductix.com
www.conductix.com