


# Operating Instructions SupplyCare Hosting

Operating program for the coordination of material and information flow along the supply chain



# Table of Contents

<b>1</b>	<b>Document information</b> . . . . .	<b>4</b>	<b>7</b>	<b>Viewing personalized tank view - "My tank view" workplace</b> . . . . .	<b>52</b>
1.1	Target audience for this manual . . . . .	4	7.1	Viewing secondaries . . . . .	55
1.2	Version history . . . . .	4	<b>8</b>	<b>Editing events - "Event" workplace</b> . . . . .	<b>56</b>
1.3	Document function . . . . .	5	8.1	Event management - Status and weighting of events . . . . .	56
1.4	Documentation . . . . .	6	8.2	Viewing event messages . . . . .	57
<b>2</b>	<b>Basic safety instructions</b> . . . . .	<b>7</b>	8.3	Processing messages . . . . .	60
2.1	Requirements for the personnel . . . . .	7	8.4	Setting the resubmission date . . . . .	61
2.2	IT security . . . . .	7	<b>9</b>	<b>Planning delivery and disposal - "Scheduling" workplace</b> . . . . .	<b>62</b>
2.3	Designated use . . . . .	7	9.1	Status management - delivery and disposal . . . . .	62
2.4	Technical improvement . . . . .	7	9.2	Status display and notification of planned deliveries and disposals . . . . .	62
2.5	This document . . . . .	8	9.3	Planning delivery and disposal - "Scheduling" workplace . . . . .	65
<b>3</b>	<b>Identification</b> . . . . .	<b>9</b>	9.4	Copying a delivery or disposal . . . . .	70
3.1	Product identification . . . . .	9	<b>10</b>	<b>Totaling and managing templates - "Totaling" workplace</b> . . . . .	<b>72</b>
3.2	Order code and software type . . . . .	9	10.1	Totaling . . . . .	72
3.3	System requirements . . . . .	9	10.2	Saving a selection as a template . . . . .	73
3.4	Registered trademarks . . . . .	9	10.3	Selecting or deleting templates . . . . .	75
<b>4</b>	<b>System description</b> . . . . .	<b>10</b>	<b>11</b>	<b>Viewing analysis data - "Analysis" workplace</b> . . . . .	<b>76</b>
4.1	Inventory Control with SupplyCare . . . . .	10	11.1	"Analysis" overview table . . . . .	77
4.2	SupplyCare Hosting . . . . .	10	11.2	KPIs (key performance indicators) . . . . .	77
4.3	Indication of inventory data . . . . .	10	11.3	Outflow/Inflow . . . . .	78
4.4	Management of master data . . . . .	10	11.4	Chart hourly . . . . .	80
4.5	Reports and connection to ERP-systems . . . . .	10	11.5	Chart daily . . . . .	81
4.6	Event management . . . . .	10	<b>12</b>	<b>Viewing tank locations on the map - "Map" workplace</b> . . . . .	<b>82</b>
4.7	Alarm messages . . . . .	10	12.1	Viewing a map and associated information . . . . .	82
4.8	Retrieval of measured values . . . . .	10	12.2	Tank details . . . . .	83
<b>5</b>	<b>User interface</b> . . . . .	<b>13</b>	12.3	Planning a disposal or delivery . . . . .	84
5.1	Starting the program . . . . .	13	<b>13</b>	<b>Managing master data</b> . . . . .	<b>85</b>
5.2	Page structure . . . . .	16	13.1	Managing companies . . . . .	85
5.3	Elements . . . . .	20	13.2	Managing users . . . . .	87
5.4	Icons . . . . .	20	13.3	Managing tanks . . . . .	91
5.5	Descriptions . . . . .	25	13.4	Managing aggregated tanks . . . . .	104
5.6	General processing functions . . . . .	26	13.5	Managing locations . . . . .	108
5.7	Receiving messages (messaging) . . . . .	34	13.6	Managing products . . . . .	112
<b>6</b>	<b>Monitoring tanks - "Tank" workplace</b> . . . . .	<b>35</b>			
6.1	Viewing tanks and associated information . . . . .	35			
6.2	Editing tank service status . . . . .	43			
6.3	Download history . . . . .	44			
6.4	Viewing secondaries . . . . .	46			
6.5	Viewing historical values and forecast values in the inventory chart . . . . .	48			
6.6	Zoom functions in the inventory chart . . . . .	49			
6.7	Planning delivery and disposal via the inventory chart . . . . .	50			

- 13.7 Managing tank groups ..... 115
- 13.8 Managing units ..... 118
- 13.9 Managing a report  
    (using CIDX and CSV reports) ..... 119
- 13.10 Setting up messaging ..... 126
- 13.11 Maintaining a user profile ..... 128
- 13.12 Selecting and changing user preferences ..... 129
  
- 14 User roles and authorization .....132**
  
- Index. ....134**

# 1 Document information

## 1.1 Target audience for this manual

This manual should support during the configuration and operation of SupplyCare Hosting. Beside basic PC operating knowledge no special training is needed to perform the Supply Chain software management operations. Nevertheless it is recommended receiving a training on the system by Endress+Hauser.





## 1.2 Version history

Document version	Valid for SW version	Changes to the previous version
BA050S/04/en/12.07	1.00.xx	Original
BA050S/04/en/03.10	2.01.xx	System and hardware environment changed. DA Scheduler replaced by Connection Manager.
BA050S/04/en/06.10	2.02.xx	Additional functions: Alarm hysteresis, Recycling tank, Export and download to Excel, Management of decimal places per type of unit.
BA00050S/04/EN/01.11	2.03.xx	The following menus are implemented: Scheduling and Analysis. The following tabs are implemented: Notes and files, Tank notes, Location notes and Secondaries. Additional illustration of secondary values implemented in the "Tank" overview table and the inventory chart. "Analysis user" implemented.
BA00050S/04/EN/02.11	2.04.xx	"Unit" and "Time zone" filters implemented in diverse overviews. The following items are implemented in the "Workplace" menu: My tank view and Map. The following menus have been changed: Report and Linearization. The following user role is implemented: Report user. "Copy data record" function is implemented. PDL and PDE check boxes are implemented.
BA00050S/04/EN/03.12	2.05.xx	Secondary values increased from three to eight. The following items are implemented: filter "Default home page" in the "User preferences" menu item, three additional tank shapes, display of thousand separators in the "Workplace" menu, colors showing the tank status forecast value in the calendar, "Totalling" menu item, info window containing long text, check box "Assign", new time zone format
BA00050S/04/EN/13.12	2.06.xx	User roles modified. Implemented: tank setup wizard, optional deactivation of tank limits, choice between templates "Tank" and "Object", modules, processing of negative values, deactivation of forecast, scaling in the inventory chart, hiding of tabs without information
BA00050S/00/EN/15.13	2.08.xx	Implementation of Freeze Events, filters in Workplace Event
BA00050S/00/EN/16.14	2.09.xx	Implementation of new user role Product-Tank-Assignment; Additional shape for tanks/objects; Auto refresh feature; New picklist for listing of groups in "My tank view"; Receiving data from redundant sources; Manual data insertion





## 1.3 Document function

### 1.3.1 Used symbols



#### Safety symbols

Symbol	Meaning
 A0011189-EN	<b>DANGER!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
 A0011190-EN	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 A0011191-EN	<b>CAUTION!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
 A0011192-EN	<b>NOTICE!</b> This symbol contains information on procedures and other facts which do not result in personal injury.

#### Symbols for certain types of information

Symbol	Meaning
 A0011193	<b>Tip</b> Indicates additional information.
 A0011195	<b>Reference to page</b> Refers to the corresponding page number.
	Series of steps
 A0018373	Result of a sequence of actions

#### Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
1., 2., 3. ...	Series of steps
A, B, C ...	Views
 A0011187	<b>Hazardous area</b> Indicates a hazardous area.
 A0011188	<b>Indicates a non-hazardous location</b> Safe area (non-hazardous area)

### 1.3.2 Conventions used in this manual

Typographical emphasis and particular symbols have been used to provide a clear structure for this manual and highlight important information.

### Emphasizing text

The following table provides you with a brief overview of conventions used to highlight and emphasize text in this manual.

Text emphasis	Meaning	Example
<b>Bold</b>	Keyboard entry, button, tab, menu, instruction, directory path, commands	Select the <b>Event Details</b> tab. Click the <b>Event</b> menu items.

## 1.4 Documentation

### 1.4.1 Operating instructions

Document number	Product	Type of Document
SH00001S/00/EN/15.14	SupplyCare Hosting	Service Manual

## 2 Basic safety instructions

### 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists: must have a relevant qualification for this specific function and task
- Are authorized by the plant owner/operator
- Are familiar with federal/national regulations
- Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- Being instructed and authorized according to the requirements of the task by the facility's owner operator
- Following the instructions in these Operating Instructions

### 2.2 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

### 2.3 Designated use

SupplyCare Hosting is a web-based operating program for coordinating the flow of material and information along the supply chain.

SupplyCare Hosting gives you complete transparency over inventory levels in tanks and silos, anytime, anywhere and even at remote locations.

Based on the measuring and transmission technology installed on site, the current inventories are recorded and transmitted to SupplyCare.

With SupplyCare, you have a constant overview of all the current inventories. Critical levels are clearly indicated and you can also receive active information on these levels if required. Calculated prognosis gives additional security for replenishment planning.

### 2.4 Technical improvement

Endress+Hauser reserves the right to make technical improvements to the hardware and software without prior notice. Such improvements are not documented if they do not affect the operating functions of the software. A new version of the Operating Instructions is always created if the improvement affects operation. See the change history in this manual.

## 2.5 This document



The screen views illustrated in this manual are sample views and can deviate from the views you see on your screen. The screen views depend on personal settings and on the application.



## 3 Identification

### 3.1 Product identification

The following options are available for identification of the software:

- Order code with breakdown of the software features on the delivery note
- Enter serial number in W@M Device Viewer  
([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)): All information about the software is displayed.

### 3.2 Order code and software type



To find out the version of your software, enter your software's order code in the search screen at the following address: [www.products.endress.com/order-ident](http://www.products.endress.com/order-ident)

### 3.3 System requirements

#### Internet browser:

- Microsoft® Internet Explorer 7, 8 and 9
- Mozilla Firefox > 3.5

#### Compatible browser:

- Opera 17.0
- Safari® 5.1 (for Windows)
- Google® Chrome 30.0

#### Mobile devices:

- Apple® iPhone® with Safari® on iOS 6 or later
- Apple iPad® with Safari® on iOS 6 or later

- Active Scripting enabled
- JavaScript enabled
- Allow cookies
- Enhanced Security Configuration disabled

### 3.4 Registered trademarks

Microsoft® and the Microsoft logo are registered trademarks of the Microsoft Corporation.

Google Maps is a service of Google Incorporated. © 2012 Google Inc. All rights reserved.  
Chrome is a trademark of Google Inc.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Safari®, iPhone® and iPad® are trademarks of Apple® Inc., registered in the U.S. and other countries.

Opera and O logo are trademarks of Opera Software ASA.

All other brand and product names are trademarks or registered trademarks of the companies and organizations in question.

## 4 System description

### 4.1 Inventory Control with SupplyCare

SupplyCare Hosting comprises software components and information within the field of Inventory Control.

SupplyCare can collect and visualize inventory, availability, consumption and needs of the tanks and silos online. This allows the rationalization of business and logistic processes and the reduction of inventory and stockout. From onsite measurement and global remote data transmission and visualization to integration in ERP systems, SupplyCare offers a universal, standards-based solution. SupplyCare is modular in design.

### 4.2 SupplyCare Hosting

SupplyCare Hosting is a web-based operating program for the indication and monitoring of levels of e.g. tanks and silos spread all over the world.

### 4.3 Indication of inventory data

The tank and silo inventories are regularly collected by SupplyCare. The current and previous inventory data can be indicated at any time (→ [§ 35](#) and → [§ 82](#)).

### 4.4 Management of master data

With SupplyCare you can create and manage master data of locations, companies, tanks, products and users (→ [§ 85](#) and → [§ 119](#)).

### 4.5 Reports and connection to ERP-systems

With SupplyCare you can create Excel reports about the measured value history or provide current level and master data via CIDX-Report to an ERP-System such as SAP (→ [§ 119](#))

### 4.6 Event management

An event management system is integrated into SupplyCare. It shows events like the fall below safety stocks or plan points. Additionally, notification e-mails can be sent to predetermined users (→ [§ 56](#) and → [§ 126](#)).

### 4.7 Alarm messages

Whenever there is a technical problem e.g. connection problems, alarm messages are generated and alarm e-mails are sent to the System Administrator.

### 4.8 Retrieval of measured values


The inventory of the tanks and silos are retrieved by level measuring devices site. SupplyCare offers the following possibilities to retrieve measured values.

#### 4.8.1 Via HTTP-Modem or GSM

The point of time and interval are adjusted via a **Scheduler**, which enables SupplyCare to actively retrieve the measured values.


### Gateways (Fieldgates)

Endress+Hauser-measuring devices are retrieved by gateways (so-called Fieldgates).




### 4.8.2 About incoming e-mails from the gateways (Fieldgates)

Another possibility is to receive the measured values from the incoming e-mails from the gateways. There, the measured values are embedded in the gateway e-mails and sent to a separate e-mail-server. SupplyCare collects these e-mails from the e-mail server and processes the included measured values.



### 4.8.3 Via redundant data sources


It is also possible to receive the measured values from two redundant data sources (Gateways/Fieldgates). In case of failure of the primary data source, the system switches automatically to the secondary data source.



## 5 User interface


### 5.1 Starting the program

1. Start your Web browser. Internet Explorer and Firefox are supported.
2. Enter the URL or IP address for SupplyCare.
3. The following screen appears:



PS0000736aen

4. Enter your User ID and password.
5. Click Log on to confirm your entries.
6. The first time you log in, you are asked to change your password.




PS0000737aen

7. Enter your current password in the **Old password** field. Enter your new password in the **New password** and **Confirm password** fields.
8. Click the **Change** button to confirm the new password.
9. Select the **SupplyCare** menu.



PS0000738aen


10. The portal window is displayed within the browser window. The view depends on the user role you have been assigned.



S1\_EN\_BA000505\_0211


### 5.1.1 Login failure

1. If the user ID or password are not correct, the message **User authentication failed** appears. The following screen is displayed:




PS0000739aen

2. Enter the correct login data or click on the **Log on** button.
3. The following screen is displayed:



PS0000740aen


4. Select one of the following options:
  - Password reset: You have forgotten your user ID and/or password.
  - Other logon problems
5. Click the **Submit** button.
6. If you select the **Password reset** option, the following screen is displayed:



Having trouble logging in?  
Please provide your user ID and E-mail and fill the form below.  
You will be sent a new password.


User ID \*

E-Mail \*



PS0000741aen

7. Enter your **User ID** and your **E-mail address**.
8. Click **Submit**. If the user ID and e-mail address do not match up, a corresponding message will appear.
9. If you select the **Other logon problems** option, the following screen appears:



Having trouble logging in?  
Provide your E-Mail and message in the notes area for the administrator.

E-Mail \*

Message to Administrator:



PS0000742aen


10. Enter your **E-mail address** and a **Message to administrator**.
11. Click **Submit**.



## 5.2 Page structure

### 5.2.1 Portal window

You can see the arrangement of the individual objects in the portal window in the graphic below.



- 1 Portal window
- 2 Header
- 3 Menues
- 4 Menue items
- 5 Navigation window
- 6 Application window



The menu and the appropriate menu items vary depending on the user role and thus also changes the Portal Window (→ 18).




SupplyCare is modular in design. The menu items differ for this reason. Furthermore, the contents of the application window can also differ as well as the contents of the dialog windows.



### 5.2.2 Header

#### Logging out

You can find the link to log off in the right-hand side of the header.  
Clicking **Log off** takes you back to the **Login** screen:



### 5.2.3 Navigation window

#### Menus

Depending on the user role, the menus Workplace, Configuration, and Profile appear.



Multiple user roles can be assigned to a user at the same time. The menu tree is then made up of the menus for the user roles in question.

#### Navigation window

Clicking a menu expands or collapses this menu. The active menu is highlighted in blue.

#### Menu items

The menu is made up of various menu items depending on the user role in question. The following table lists the menu items depending on the user role selected:



The menu items in the **Workplace**, **Configuration** and **Profile** menus differ as a result of SupplyCare's modular design

	Menus		
User Role	Workplace	Configuration	Profile
Read only	<ul style="list-style-type: none"> <li>■ Tank <sup>1)</sup></li> <li>■ My tank view</li> <li>■ Event <sup>2)</sup></li> <li>■ Totaling</li> <li>■ Map</li> </ul>	–	<ul style="list-style-type: none"> <li>■ User Profile</li> <li>■ User Preferences</li> </ul>
Operator	<ul style="list-style-type: none"> <li>■ Tank <sup>1)</sup></li> <li>■ My tank view</li> <li>■ Event <sup>2)</sup></li> <li>■ Totaling</li> <li>■ Analysis</li> <li>■ Map</li> </ul>	–	<ul style="list-style-type: none"> <li>■ User Profile</li> <li>■ User Preferences</li> </ul>
Scheduler	<ul style="list-style-type: none"> <li>■ Tank <sup>1)</sup></li> <li>■ My tank view</li> <li>■ Event <sup>2)</sup></li> <li>■ Scheduling</li> <li>■ Totaling</li> <li>■ Analysis</li> <li>■ Map</li> </ul>	–	<ul style="list-style-type: none"> <li>■ User Profile</li> <li>■ User Preferences</li> </ul>
Product-Tank-Assignment	–	<ul style="list-style-type: none"> <li>■ Product <sup>3)</sup></li> </ul>	<ul style="list-style-type: none"> <li>■ User Profile</li> </ul>
Master data	–	<ul style="list-style-type: none"> <li>■ User</li> <li>■ Tank</li> <li>■ Aggregated tank</li> <li>■ Location</li> <li>■ Company</li> <li>■ Product</li> <li>■ Unit</li> <li>■ Tank Group</li> <li>■ Report</li> </ul>	<ul style="list-style-type: none"> <li>■ User Profile</li> </ul>
<p>1) Only users with the <b>Operator</b> user role can change the tank service status.  2) Only users with the <b>Scheduler</b> or <b>Operator</b> user role can change the status of an event.  3) Users with the <b>Product-Tank-Assignment</b> user role are only able to assign existing products to existing tanks.</p>			

#### 5.2.4 Application window


The content of the Application window varies depending on the menu item selected. The active menu item is highlighted in blue.



As a result of SupplyCare's modular design, the contents of "Overview" and of "Detailed view" can differ as can the contents of the dialog windows.

Most of the Application windows contain the following view:

- Overview
- Detailed view



1 Overview  
2 Detailed view

Overview

The users or data are listed in tabular form in the overview.

Detailed view

Detailed information on the line selected in the table is displayed in the lower section. Left-clicking another line in the **Overview** opens up the detailed view of the information. Where necessary, the information in the detailed view is split even further into tabs.

Tabs

Using the tabs, you can create, change and delete new objects. Forms or tables are displayed in the tab.



Tank\_Tank\_details\_BA00050SEN

## 5.3 Elements

















The following elements are available in the individual views:

Button	Function
Input fields	One-line input fields to enter a value (text or digits). Multiline input fields to enter a long text.
Output fields	One-line output fields to display a value (text or digits). Multiline output fields to display a long text.
Tables	Multicolumn tables in which individual rows can be selected.
Picklists	These allow the user to select from specified values.
Check boxes	These allow the user activate and deactivate certain functions.

## 5.4 Icons







### 5.4.1 Standard buttons

The following standard buttons are used to edit and process individual objects:

Button	Function
	<b>New</b> – creates a new object that can be saved with Save  .
	<b>Edit</b> – allows the user change the displayed contents of an object (depends on role).
	<b>Delete</b> – deletes the content of an object. A dialog box appears for the user to confirm the deletion.
	<b>Save</b> – saves altered contents and newly created objects.
	<b>Cancel</b> – undo
	<b>Copy</b> – copies the data for the user, tank, aggregated tank, location, company, product, tank group, report, a disposal or a delivery.
	<b>Select tank picture</b> – select a tank picture for tanks and aggregated tanks in the <b>Tank details</b> tab.
	<b>Update view</b> – updates contents.
	<b>Configure my tank view</b> – opens a popup window to configure the <b>My tank view / My object view</b> screen.
	<b>Calendar</b> – Button for selecting a period of time (e.g. resubmission date, start and end date for a history).
	<b>Excel-Export</b> – Button for downloading data such as measured values to an Excel spreadsheet.
	<b>PDF-Export</b> – Button for downloading data such as the system settings as a PDF file.
	<b>Print</b> – button for printing charts.
	<b>Show</b> – shows contents.
	<b>Cancel</b> – undo.





### 5.4.2 Buttons in tables

You can navigate through the table via the following buttons at the bottom of the table:





Button	Function
	Goes to the start of the table.
	Scrolls back one page.
	Moves the table up one line. The element selected remains unchanged.
	Moves the table down one line. The element selected remains unchanged.
	Scrolls forward one page.
	Goes to the end of the table.

### 5.4.3 Symbols for events

#### Status display

Button	Meaning
	<b>Open</b> - the event was triggered.
	<b>Acknowledged</b> - the event was acknowledged but no action has yet been taken.
	<b>In process</b> - measures have been initiated to replenish material.
	<b>Done</b> - recorded by measurement. Replenishment process completed successfully.

#### Priority (weight)

Button	Meaning
	<b>Plan point</b> (GREEN)
	<b>Ship point</b> (YELLOW)
	<b>Safety stock</b> (RED)
	<b>Freeze event</b> (Eye-symbol with tooltip "Check")

















### 5.4.4 Icons for tanks

SupplyCare allows users to select between the template types "Tank" and "Object". These two template types have the exact same functionality. However, depending on your selection, the descriptions in the menu, in **Overview** and in **Detailed view** change as well as the symbols and tool tips that appear when you move the cursor over a symbol.



The symbols for tanks and objects are shown in the following tables. The descriptions that are different are listed after this (→ 25). Please note that the template type "Tank" is used in all remaining sections of these Operating Instructions.

## Status display

Button		Meaning
Tank	Object	
		<b>OK (GREEN)</b> Standard tank/Standard object: the current (last measured) inventory level of the tank/object in question is above the plan point/observance limit. Recycling tank/Recycling object: the current (last measured) inventory level of the tank/object in question is below the plan point/observance limit.
		<b>OK (GREEN)</b> Aggregated standard tanks/Aggregated standard objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is above the plan point/observance limit. Aggregated recycling tanks/Aggregated recycling objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is below the plan point/observance limit.
		<b>Plan point/Observance limit reached (YELLOW)</b> Standard tank/Standard object: the current (last measured) inventory level of the tank/object in question is below the plan point/observance limit. Recycling tank/Recycling object: the current (last measured) inventory level of the tank/object in question is above the plan point/observance limit.
		<b>Plan point/Observance limit reached (YELLOW)</b> Aggregated standard tanks/Aggregated standard objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is below the plan point/observance limit. Aggregated recycling tanks/Aggregated recycling objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is above the plan point/observance limit.
		<b>Ship point/Point of action reached (ORANGE)</b> Standard tank/Standard object: the current (last measured) inventory level of the tank/object in question is below the ship point/point of action.
		<b>Ship point/Point of action reached (ORANGE)</b> Aggregated standard tanks/Aggregated standard objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is below the ship point/point of action.
		<b>Safety stock/Critical limit (RED)</b> Standard tank/Standard object: the current (last measured) inventory level of the tank/object in question is below the safety stock/critical limit. Recycling tank/Recycling object: the current (last measured) inventory level of the tank/object in question is above the safety stock/critical limit.
		<b>Safety stock/Critical limit (RED)</b> Aggregated standard tanks/Aggregated standard objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is below the safety stock/critical limit. Aggregated recycling tanks/Aggregated recycling objects: the current (last measured) inventory level of the aggregated tank/aggregated object in question is above the safety stock/critical limit.

Button		Meaning
Tank	Object	
		<b>Bad measured data</b> - communication error. No measured data are available for the tank/object in question. The state is also shown for displayed secondary data if the tank/object is not out of order.
		<b>Bad measured data</b> - communication error. No measured data are available for the aggregated tank/aggregated object in question.
		<b>Out of service</b> - the tank/object is not available (e.g. due to overhaul). The time when the tank/object is out of order is marked in gray in the inventory chart.
		<b>Out of service</b> - the aggregated tank/aggregated object is not available (e.g. due to overhaul). The time when an associated tank/object is out of order is marked in gray in the inventory chart.

### 5.4.5 Icons for tanks ("Map workplace")

Button		Meaning
Tank	Object	
		<b>OK (GREEN)</b> - no delivery/disposal planned.
		<b>OK (GREEN)</b> - planned delivery/disposal.
		<b>OK (GREEN)</b> - aggregated tank/aggregated object: no delivery/disposal planned.
		<b>OK (GREEN)</b> - aggregated tank/aggregated object: planned delivery/disposal.
		<b>OK (GREEN)</b> - several tanks/objects available at the location. All the tanks/objects have the OK status. The tanks/objects can have different scheduling statuses (delivery/disposal planned or not planned).
		<b>Plan point/Observe limit reached (YELLOW)</b> - no delivery/disposal planned.
		<b>Plan point/Observe limit reached (YELLOW)</b> - planned delivery/disposal.
		<b>Plan point/Observe limit reached (YELLOW)</b> - aggregated tank/aggregated object: no delivery/disposal planned.
		<b>Plan point/Observe limit reached (YELLOW)</b> - aggregated tank/aggregated object: planned delivery/disposal.
		<b>Ship point/Point of action reached (ORANGE)</b> - no delivery/disposal planned.
		<b>Ship point/Point of action reached (ORANGE)</b> - planned delivery/disposal.
		<b>Ship point/Point of action reached (ORANGE)</b> - aggregated tank/aggregated object: no delivery/disposal planned.
		<b>Ship point/Point of action reached (ORANGE)</b> - aggregated tank/aggregated object: planned delivery/disposal.
		<b>Safety stock/Critical limit reached (RED)</b> - no delivery/disposal planned.
		<b>Safety stock/Critical limit reached (RED)</b> - planned delivery/disposal.
		<b>Safety stock/Critical limit reached (RED)</b> - aggregated tank/aggregated object: no delivery/disposal planned.
		<b>Safety stock/Critical limit reached (RED)</b> - aggregated tank/aggregated object: planned delivery/disposal.
		<b>Bad measurement data</b> - no delivery/disposal planned.
		<b>Bad measurement data</b> - planned delivery/disposal.
		<b>Bad measurement data</b> - aggregated tank/aggregated object: no delivery/disposal planned.
		<b>Bad measurement data</b> - aggregated tank/aggregated object: planned delivery/disposal.
		<b>Out of order</b> - no delivery/disposal planned.
		<b>Out of order</b> - planned delivery/disposal.

Button		Meaning
Tank	Object	
		<b>Out of order</b> - aggregated tank/aggregated object: no delivery/disposal planned.
		<b>Out of order</b> - aggregated tank/aggregated object: planned delivery/disposal.
		<b>Diverse</b> - several tanks/objects with different statuses displayed are available at the location. The tanks/objects can have different scheduling statuses (delivery/disposal planned or not planned).

#### 5.4.6 Icons for scheduling









Button		Meaning
Tank	Object	
		<b>Planned delivery/Planned disposal</b> - a planned delivery or disposal is indicated in the inventory chart and the calendar by a delivery van icon.
		<b>Standard tank/Standard object</b> - how a standard tank/standard object is indicated in the <b>Scheduling</b> menu item.
		<b>Aggregated standard tanks/Aggregated standard objects</b> - how aggregated standard tanks/aggregated standard objects are indicated in the <b>Scheduling</b> menu item.
		<b>Recycling tank/Recycling object</b> - how a recycling tank/recycling object is indicated in the <b>Scheduling</b> menu item.
		<b>Aggregated recycling tanks/Aggregated recycling objects</b> - how aggregated recycling tanks/aggregated recycling objects are indicated in the <b>Scheduling</b> menu item.

#### 5.4.7 Icons for disposal and delivery status

Button	Meaning
	<b>Detected</b> - the <b>Detected</b> status is displayed in the following situations: <ul style="list-style-type: none"> <li>▪ The system has detected a delivery or disposal which has been scheduled too early or too late. You can process this delivery or disposal in the <b>Details</b> tab using the <b>Confirm</b> button.</li> <li>▪ The system has detected a missing delivery or disposal. You can process this delivery or disposal in the <b>Details</b> tab using the <b>Mark as fulfilled</b> button.</li> <li>▪ The system has detected that measured data are missing. You can process this delivery or disposal in the <b>Details</b> tab using the <b>Mark as fulfilled</b> button.</li> </ul>
	<b>Confirmed</b> - the <b>Confirmed</b> status is displayed in the following situations: <ul style="list-style-type: none"> <li>▪ A delivery or disposal which has been scheduled too early or too late was confirmed when the delivery/disposal was created.</li> <li>▪ A delivery or disposal which has been scheduled too early or too late has been confirmed in the <b>Details</b> tab.</li> </ul>
	<b>Deleted</b> - a planned delivery or disposal has been deleted.
	<b>New</b> - a new delivery or disposal has been planned.
	<b>Fulfilled</b> - a new delivery or disposal has been fulfilled. If a delivery and disposal is made, this is flagged by SupplyCare as <b>Delivery made (detected)/Disposal made (detected)</b> . If the system has detected a missing delivery/disposal or missing measured data, you can process this delivery/disposal in the <b>Details</b> tab using the <b>Mark as fulfilled</b> button. The delivery/disposal is displayed as <b>Delivery fulfilled (confirmed)/Disposal fulfilled (confirmed)</b> .



### 5.4.8 Icons for analysis

Button		Meaning
Tank	Object	
		<b>Standard tank/Standard object</b> - how a standard tank/standard object is indicated in the <b>Analysis</b> menu item.
		<b>Aggregated standard tanks/Aggregated standard objects</b> - how aggregated standard tanks/aggregated standard objects are indicated in the <b>"Analysis"</b> menu item.
		<b>Recycling tank/Recycling object</b> - how a recycling tank/recycling object is indicated in the <b>Analysis</b> menu item.
		<b>Aggregated recycling tanks/Aggregated recycling objects</b> - how aggregated recycling tanks/aggregated recycling objects are indicated in the <b>Analysis</b> menu item.

## 5.5 Descriptions

Depending on whether "Tank" or "Object" was selected as the template type, the descriptions in the menu, in "Overview" and in "Detailed view" change as well as the symbols and tool tips that appear when you move the cursor over a symbol.


The following are the differences in the descriptions that involve more than simply replacing the word "Tank" with "Object".

Standard template type "Tank"	Standard template type "Object"
Tank name	Object
Tank details	Details
Tank partners	Partners
Tank service status	Service status
PP (Plan point)	OL (Observance limit)
SP (Ship point)	POA (Point of action)
SST (Safety stock)	CL (Critical limit)
DSST (Day(s) until reaching the safety stock)	DCL (Day(s) until reaching critical limit)
Capacity	Maximum
Free capacity	Free space
Inventory chart	Chart
Inventory	Received value
Outflow	Decrease
Inflow	Increase
DO (Daily outflow)	DD (Daily decrease)
ADO (Average daily outflow)	ADD (Average daily decrease)
DI (Daily inflow)	DI (Daily increase)
ADI (Average daily inflow)	ADI (Average daily increase)
Average inventory level	Average level

## 5.6 General processing functions

### 5.6.1 Using filter functions in tables (searching)

You can use the filter function to reduce the number of data sets displayed for a table. You enter the filter functions in the top line of the table.



1. In the top table line, enter a complete designation or just the first few letters in the desired field.
2. Press **Enter**.
3. Only the matching table entries are now displayed.  
In order to display the entire table contents again, delete your entries and then press **Enter**.

You can always use the following filter functions for the individual fields:

Description		Example	
Group	Function	User entry	Result (data displayed)
Character string	* (wildcard)	Tank0*	All entries that start with "Tank0", e.g. "Tank01", "Tank02-special" etc.
		*Tank0*	All entries that contain "Tank0", e.g. Frankfurt_Tank0-mp1 etc.
Integers	Integer	8	All rows with the value 8
	=integer	=8	
	>integer	>8	All rows with values greater than 8
	>=integer	>=8	All rows with values greater than or equal to 8
	<integer	<8	All rows with values less than 8
	<=integer	<=8	All rows with values less than or equal to 8
	Integer-integer	8-100	All rows with values between 8 and 100
	<>integer	<>8	All rows with values not equal to 8
	!integer	!8	
	Integer*	8*	All rows with values that start with "8"


Description		Example	
Group	Function	User entry	Result (data displayed)
Floating point numbers	>floating point number	>8.0	All rows with values greater than 8
	<floating point number	<8.0	All rows with values less than 8
	Floating point number-floating point number	8.0-100.50	All rows with values between 8.0 and 100.50
	Floating point number* (wildcard)	8*	All rows with values that start with "8"

Date columns are converted for display purposes so they can be filtered link a string column.

5.6.2 Filtering the data records displayed (picklist)


You can use picklists to filter the data records displayed, such as for **Unit**, **Time zone**, **Tank group**, **Product**, **Supplier** or **Location**.


If you have selected a value from the picklist, the data records that match the filter criteria are automatically displayed. The content of the picklists is reset to the default values when you leave the overview.



S21\_EN\_BA00050S\_0211

5.6.3 Changing the column display (fields) in the overview table


Pressing the button  in the table header in the overview opens a context menu. Via this context menu, you can show and hide columns or change the column order.



PS0000953en



5.6.4 Viewing numerical values (master data)

Numerical values above 1000 are displayed with a thousand separator. This is **only** the case within the **Workplace** menu, however.  
In contrast to **Measured values**, **Manual values** are displayed in blue color followed by the text **MAN**. The column **Data source** provides information on where the data comes from: measured or manually entered (for more details see Service Manual).



The character the system uses as the thousand separator depends on the language setting selected in the browser, e.g.:

German (Germany) de-DE	1.234,78
German (Switzerland) de-CH	1'234.78
English (US) en-US	1,234.78

-  No thousand separator is used for numerical values that appear in views, histories or reports that are downloaded, sent or printed out.
-  The number of places after the decimal point is defined in the **Configuration** menu, **Unit** menu item. Only people whose user role is configured as **Master Data** can change the number of places after the decimal point for the units.

5.6.5 Changing master data

Depending on your particular user role, you can change data records in the "Company", "User", "Tank", Aggregated tank", "Location", "Product" and "Tank groups" master data.  
The data for a tank are changed in the following example. Proceed in the same way for other master data.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. The following detail view is displayed in the Application window:

Configuration >> Tank

Product: All Buyer: All Supplier: All

Tank name	Location	Capacity	Product	Notes	Unit
IC 01000	US Operations North	20000	Product IC 010		l
IC 02000	US Operations West	100	Product IC 020	Tank soll regelmäßig alle 3...	%
IC 03000	HQ	355000	Product IC 030		l
IC 04000	CA Operations	320000	Product IC 040		gal
IC Waste	EU Operations UK	400000	Waste IC 011	Material Safety Instruction...	l


1 of 9

Tank details Secondary Tank freeze Tank groups Tank notes

Tank setup wizard

Tank name: IC 01000  
 Location: US Operations North  
 Buyer: Buyer AG  
 Supplier: Supplier AG  
 SDT: 2 Days  
 Product: Product IC 010  
 Tank type: Standard tank  
 ADI/ADO based on: 14 Days  
 Activate forecast: ☒

Capacity: 20000  
 Optimum: 15500  
 Plan point: 12000  
 Ship point: 10000  
 Safety stock: 5000  
 Hysteresis: 100  
 Unit: l



Configuration\_tank\_tank\_details\_BA00050EN


4. In the table, click the tank for which you want to make changes.
5. Select the **Tank details** tab.
6. The related tab is displayed in the lower section of the Application window:

Tank details Secondary Tank freeze Tank groups Tank notes


Tank setup wizard


Tank name: IC 02000  
 Location: US Operations West  
 Buyer: Buyer AG  
 Supplier: Supplier AG  
 SDT: 2 Days  
 Product: Product IC 020  
 Tank type: Standard tank  
 ADI/ADO based on: 14 Days  
 Activate forecast: ☒



Capacity: 100  
 Optimum:   
 Plan point: 50  
 Ship point:   
 Safety stock: 35  
 Hysteresis: 2  
 Unit: %



Configuration\_tank\_tank\_details\_2\_BA00050EN


7. Click the  button.
8. The tab is displayed in the edit mode.



- 9. Make your changes.
- 10. Click  to save your changes. Click  to abort the process.
- 11. If you want to make changes to the **Tank groups** tab, proceed as described for the **Tank details** tab.

5.6.6     **Displaying modified master data in full**


If a text that has been entered in an input box is too long to be displayed in full in a table column, it is truncated. However, if you hover the cursor over the text, the text is displayed in full in a separate info box.





5.6.7     **Selecting all the rows in a table**

By activating the **Assign** check box you can select all the rows in a table.

- 1. Click the button .
- 2. The specific tab is displayed in the edit mode:







3. Activate the **Assign** check box.
4. Click  to save your selection. Click  to abort the process.


### 5.6.8 Deleting master data

Depending on your particular user role, you can delete data records in the "Company", "User", "Tank", Aggregated tank", "Location", "Product" and "Tank groups" master data.

-  A data record can only be deleted if the  symbol is displayed in the tab. If the symbol is not displayed, the record is linked to other information. These links must be disabled before the data record can be deleted.

The data for a tank are deleted in the following example. Proceed in the same way for other master data.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. The following detail view is displayed in the Application window:



**Configuration >> Tank**

Product: All | Buyer: All | Supplier: All

Tank name	Location	Capacity	Product	Notes	Unit
IC 01000	US Operations North	20000	Product IC 010		l
IC 02000	US Operations West	100	Product IC 020	Tank soll regelmäßig alle 3...	%
IC 03000	HQ	355000	Product IC 030		l
IC 04000	CA Operations	320000	Product IC 040		gal
IC VVaste	EU Operations UK	400000	VVaste IC 011	Material Safety Instruction...	l

1 of 9

**Tank details** | Secondaries | Tank freeze | Tank groups | Tank notes

Tank setup wizard

**Tank name \*** IC 01000

**Location** US Operations North

**Buyer** Buyer AG

**Supplier** Supplier AG

**SDT** 2 Days

**Product** Product IC 010

☐ Use product unit

**Tank type**

☒ Standard tank

☐ Recycling tank

**ADI/ADO based on** 14 Days

☐ Include negative values

**Activate forecast** ☒

**Capacity \*** 20000

**Optimum** 15500

**Plan point** 12000

**Ship point** 10000

**Safety stock** 5000


**Hysteresis** 100

**Unit** l

Configuration\_tank\_tank\_details\_4\_BA00050EN

4. In the overview table, click the tank you want to delete.
5. The related tab is displayed in the lower section of the Application window:

Configuration\_tank\_tank\_details\_6\_BA00050EN

6. Click  to delete the tank.
7. The prompt "Do you really want to delete?" is displayed.
8. Click **OK** to delete the tank. Click **Cancel** to abort the process.

### 5.6.9 Copying and changing a data record

Depending on your user role, you can copy a data record in the following menu items: User, Tank, Aggregated tank, Location, Company, Product, Tank group and Report.


Data (fields) that belong specifically to the data record are not copied. These fields remain empty in the copied data record.

If the function is available, the following button  is displayed.

The data record of a tank is copied in the following example. The same procedure applies if you want to copy other data records.


1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the overview table, click the tank you want to copy.
4. The following detail view is displayed in the Application window:






Configuration\_tank\_tank\_details\_7\_BA00050EN

5. Click the  button. The data record is displayed in the editing mode.




Configuration\_tank\_tank\_details\_8\_BA00050EN


### 5.7 Receiving messages (messaging)

 Everyone can receive a notification message.

A message from the system administrator is displayed the next time the user logs on.









The following options are available:


Button/field	Meaning
	Save message as PDF file.
Previous message	This button is displayed if several messages are available. Click the <b>Previous message</b> button to view and process previous messages.
Next message	This button is displayed if several messages are available. Click the <b>Next message</b> button to view and process subsequent messages.
OK	This button is displayed for the last message. Click <b>OK</b> to exit the dialog.
Mark as read	Mark the message as read using the <b>Mark as read</b> field.



## 6 Monitoring tanks - "Tank" workplace

### 6.1 Viewing tanks and associated information

-  The **Tank** menu item is available to people with **Read only**, **Scheduler** or **Operator** configured as their user role.
-  The **Notes and Files**, **Tank Partners**, **Location Details**, **Event Details** and **Freeze Event Details** tabs are displayed only if they contain at least one piece of information.
-  The time zone configured for the location is used for the **Tank** menu item (→  108). "UTC+00:00" is the default value.
-  Depending on your configuration, **Objects** are displayed instead of **Tanks**. For more information refer to the appropriate chapter in the Service Manual for System administration.
-  **Manual values** are displayed in blue color followed by the text **MAN**. The column **Data source** provides information on where the data comes from: measured or manually entered.


1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item. A list of the tanks assigned to you is displayed.



State	Location	Tank name	Level	Value	Unit	Data source	Product	Free
	Maulburg	Tank_02 Monthly ramp	66%	210,000.0	MAN I	Manual	50% Caustic Soda	110,000.0
		Temperature		-8.4	°C	Measured		
		Pressure		181.9	bar	Measured		
	Grenzach-Whylen	Tank_01 Monthly ramp	68%	101,205.0	kg	Measured		218,795.0
		Temperature (inside)		10.1	°C	Measured		

Workplace\_tank\_2\_BA00050SEN


3. In the table, click the tank you want to view in greater detail.
4. The details of the selected tank are displayed in the application window:



Workplace\_tank\_3\_BA00050SEN

5. If you click on another line, the details of the newly selected tank are displayed. Click the **Hide details** button when you want to hide the details again.
  6. You can choose the following tabs in the lower part of the application window: Inventory chart, Tank details, Notes and files, Tank partners, Location details, Tank service status, Event details and Download history.
- i** SupplyCare distinguishes between standard tanks and recycling tanks. From a standard tank, the product is withdrawn. For a recycling tank, the tank is filled with the product (→ 95).
- In the "Workplace – Tank" view, the current level/available capacity are displayed in graphic form in the **Level** column. For standard tanks, the colored bar drifts from left to right with increasing level. The percentage specified corresponds to the current level. For recycling tanks, the colored bar drifts from right to left with increasing level. The percentage specified corresponds to the currently available capacity.

### 6.1.1 "Tank" overview table

Pressing the button  in the table header in the overview opens a context menu. Via this context menu, you can show, hide and move table columns.

The following columns are available for the overview table:

Columns	Description
Status	The symbol for the current tank status is shown on the display. See also the "Icons for tanks" chapter, "Status display" section.
Location	Indicates the tank location. The location is the name of the location. The name is selected in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Location</b> . The location is specified in the <b>Location</b> menu item.
Tank name	Indicates the tank name. The field can also be displayed for existing secondary values. <ul style="list-style-type: none"> <li>Primary value: The tank name for the primary value is entered in the <b>Tank name</b> field. Path: Configuration → Tank → Tank details → Tank name</li> <li>Secondary value: The tank names for the secondary values are entered in the <b>Configuration</b> menu, <b>Tank</b> menu item, <b>Secondaries</b> tab, <b>Name</b> field.</li> </ul>
Level	The current level is indicated as a symbol and a percentage.
Value	Displays the last valid primary value. The field can also be displayed for existing secondary values. <ul style="list-style-type: none"> <li>The Value field indicates the last valid measured value.</li> <li>For aggregated tanks, the sum of the valid measured values for the associated tanks is displayed. Tanks with status "Out of service" are not included. If all associated tanks are "Out of service", "0" is displayed as the value.</li> <li>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</li> <li><b>Manual values</b> are displayed in blue color followed by the text <b>MAN</b>, even if a manual value is used for a tank which is part of an aggregated tank.</li> </ul>
Unit	Indicates the unit. The field can also be displayed for existing secondary values. <ul style="list-style-type: none"> <li>The unit for the primary value is selected via the Unit field in the <b>Tank details</b> tab. The units for the other measured values (secondary) are selected in the <b>Profile</b> menu in the <b>User preferences</b> tab.</li> <li>In the case of mass units, the selection for the field <b>Unit mass</b> in the <b>User preferences</b> menu item has priority over the setting in the <b>Tank</b> menu item.</li> <li>In the case of volume units, the selection for the field <b>Unit volume</b> in the <b>User preferences</b> menu item has priority over the setting in the <b>Tank</b> menu item.</li> </ul>
Data Source	Provides information on the data and displays whether the data comes from a measured source or manually entered.
Free	The free capacity of the tank is calculated.
Product	The product name is selected in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Product</b> . The product is specified in the <b>Product</b> menu item.
Notes	Indicates whether tank and/or location notes are available.
Optimum	The optimum capacity of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Optimum</b> . The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.
Capacity	The capacity of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Capacity</b> . The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.
PP (plan point)	Tank plan point. The field can also be displayed for existing secondary values. The plan point of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Plan point</b> . The value entered in the <b>Secondaries</b> tab is used here for secondary values. The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.
SP (Ship point)	The ship point of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Ship point</b> . If the <b>Recycling</b> check box is enabled, the ship point is not displayed. The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.
SST (Safety stock)	Tank safety stock. The field can also be displayed for existing secondary values. The safety stock of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Safety stock</b> . The value entered in the <b>Secondaries</b> tab is used here for secondary values. The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.
Hysteresis	The hysteresis serves to prevent constant event messages, e.g. due to a fluctuating level. The field can also be displayed for existing secondary values. The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.


Columns	Description
Out of service	The field is activated if the tank is currently "Out of service".
From date	Indicates the date as of which a tank was, is or will be "Out of service".
To date	Indicates the date until which a tank was, is or will be "Out of service".
Supplier	Indicates the responsible supplier. The supplier is created as a company.
Buyer	Indicates the buyer. The buyer is created as a company.
Buyer ID	Is equivalent to the <b>ID</b> field in the <b>Company detail</b> stab in the <b>Company</b> menu item.
SDT (standard delivery time/standard disposal time)	Standard tanks: The standard delivery time for the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Standard delivery time</b> . Recycling tank: The standard disposal time for the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Standard disposal time</b> .
Time unit	Time unit used for the <b>SDT</b> field (standard delivery/disposal time).
Time stamp	Time stamp for the last measured value. The field can also be displayed for existing secondary values. <ul style="list-style-type: none"> <li>The time stamp of the time zone for the last valid measured value is used. Also see <b>Time zone</b> field.</li> <li>In the case of aggregated tanks, the time stamp from the associated tank which supplied the most recent measured value is used.</li> </ul>
Time zone	Time zone of time stamp. The field can also be displayed for existing secondary values. The time zone of the location is used.
DSST (days until safety stock is reached)	Indicates the estimated number of days remaining until the safety stock is reached. The value is calculated with the average quantity per day. The calculated average quantity is based on the "Forecast based on" value.
PD (planned delivery/planned disposal)	The date and time for the next planned delivery are displayed for standard tanks. The date and time for the next disposal are displayed for recycling tanks. The field is empty if no delivery or disposal has been planned. The time zone of the location is used.
PD amount (amount for planned delivery/amount for planned disposal)	Amount for the planned delivery and disposal. The unit corresponds to the unit in the <b>Unit</b> column.

## 6.1.2 Inventory chart

The historical and expected pattern for the inventory is displayed in the diagram for the period selected. The distribution is 2/3 for the history (measured values) and 1/3 for extrapolation (calculated values).

If the tank is out of service, only the historic pattern of the inventory is displayed. The expected pattern for the inventory is not displayed.

**Manual values** are displayed in blue color followed by the text **MAN**.









Workplace\_tank\_4\_BA00050SEN



Via the **Scaling** field, choose between the minimum/maximum scaling and automatic scaling. If "Min/Max" is chosen, the inventory is displayed between "0" and "Capacity". "Auto" displays the inventory between the smallest and largest displayable value - including forecast values.

Select the period of time for the inventory chart via the **Period selection** field.

The current **limit values** are specified as horizontal lines in various colors

Color	Standard tanks	Recycling tanks
 green	Range between the Optimum and Plan point limit values	Range between Empty (value 0) and the Plan point limit value
 yellow	Range between the Plan point and Ship point limit values	Range between the Plan point and Safety stock limit values
 orange	Range between the Ship point and Safety stock limit values	not present
 red	Range between the Safety stock limit value and Empty (value 0)	Range between the Safety stock and Capacity limit values

 Click the  button to print the inventory chart.

 If you want to zoom into a specific period (→  49).

### 6.1.3 Tank details

The tab displays information on the tank and limit values.



The screenshot shows the 'Tank details' tab with the following data:

Organization		Limits	
Tank name	IC 02000	Capacity	100.0
Value	80.6	Optimum	50.0
Unit	%	Plan point	50.0
Time stamp	9/11/12 3:10 AM	Ship point	35.0
Product	Product IC 020	Safety stock	2.0
Location	US Operations West	Hysteresis	19.4
Time zone	UTC-05:00	Free capacity	19.4
SDT	2	Tank type	Standard tank

Workplace\_tank\_5\_BA00050SEN



## Description of fields

Field	Description
Tank name	The tank name is selected in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Tank name</b> .
Value	<p>Last primary value</p> <ul style="list-style-type: none"> <li>The Value field indicates the last valid measured value.</li> <li>For aggregated tanks, the sum of the valid measured values for the associated tanks is displayed. Tanks with status "Out of service" are not included. If all associated tanks are "Out of service", "0" is displayed as the value.</li> <li>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</li> </ul>
Unit	<p>Last unit of primary value</p> <ul style="list-style-type: none"> <li>The unit is specified in the <b>Tank</b> menu item.</li> <li>In the case of mass units, the selection for the field <b>Unit mass</b> in the <b>User preferences</b> menu item has priority over the setting in the <b>Tank</b> menu item.</li> <li>In the case of volume units, the selection for the field <b>Unit volume</b> in the <b>User preferences</b> menu item has priority over the setting in the <b>Tank</b> menu item.</li> </ul>
Time stamp	<p>Time stamp of last primary value</p> <ul style="list-style-type: none"> <li>The time stamp of the time zone for the last valid measured value is used. Also see <b>Time zone</b> field.</li> <li>In the case of aggregated tanks, the time stamp from the associated tank which supplied the most recent measured value is used.</li> </ul>
Product	The product name is selected in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Product</b> . The product is specified in the <b>Product</b> menu item.
Location	The location is selected in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Location</b> . The location is specified in the <b>Location</b> menu item.
Time zone	<p>Time zone of time stamp.</p> <p>The time zone of the location is used.</p>
SDT (Standard delivery time in days or hours)	The standard delivery time for the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Standard delivery time</b> .
Capacity	<p>The capacity of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b>, field <b>Capacity</b>.</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Optimum	<p>The optimum capacity of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b>, field <b>Optimum</b>.</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Plan point	<p>The plan point of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b>, field <b>Plan point</b>.</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Ship point	<p>The ship point of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b>, field <b>Ship point</b>.</p> <p>If the <b>Recycling</b> check box is enabled, the ship point is not displayed.</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Safety stock	<p>The safety stock of the tank is specified in the <b>Configuration</b> menu in menu item <b>Tank</b>, field <b>Safety stock</b>.</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Hysteresis	<p>The hysteresis serves to prevent constant event messages, e.g. due to a fluctuating level (→ 96).</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Free capacity	The free capacity of the tank is calculated.
Tank type	The tank type is displayed: "Standard tank" or "Recycling tank"
Constituent tanks	<p>This field is displayed for aggregated tanks only.</p> <p>All corresponding tanks are displayed in this list.</p>
Value (aggregated tanks)	<p>This field is displayed for aggregated tanks only.</p> <p>The <b>Value</b> field shows the last valid measured value for the tank selected in the "Constituent tanks" list.</p> <p>The number of places after the decimal point is defined in the <b>Configuration</b> menu, <b>Unit</b> menu item.</p>
Out of service	<p>This field is displayed for aggregated tanks only.</p> <p>The field is activated if the tank selected in the "Constituent tanks" list is out of service.</p>
Bad measurement(s)	<p>This field is displayed for aggregated tanks only.</p> <p>The field is activated if the tank selected in the "Constituent tanks" list returns bad measurement data.</p>



### 6.1.4 Notes and files

Notes, data and files pertaining to the tank and location are displayed in this tab.

S33\_EN\_BA00050S\_0211

Via the **Record selection** field, choose whether the **Notes** or **Data** should be displayed.

Via the **Files** table, you can open the files and save them locally as follows:

1. Click the **File name** (hyperlink) in the **Name** column in the table.
2. A dialog box opens. Here you can choose whether you want to open the file or save it.
3. Click **OK** to open or save the file. Click **Cancel** to abort the process.

### 6.1.5 Tank partners

Information on the buyer and supplier is displayed in this tab. If no buyer/supplier is currently assigned to the selected tank, this tab is not visible.

S33-2\_EN\_BA00050S\_0211



The tank partner, buyer and supplier are assigned to the tank via the **Configuration** menu in the **Tank** menu item, **Tank details** tab (→ 91).

6.1.6 Location details

Information on the tank location is displayed in this tab.

Inventory chart

Tank details

Notes and files

Tank partners

Location details

Tank service status

Event details

Download history

Location

Manager

Company

Mustermann AG

Street

City

California

Zip code

State

CA

Country

USA

Name

US Operations West

Name

First name

E-mail

Fax

Mobile

Phone

S34-1\_EN\_BA00050S\_0211

6.1.7 Tank service status

Information on the tank service is displayed in this tab.

Inventory chart

Tank details

Notes and files

Tank partners

Location details

Tank service status

Event details

Download history

From date

To date

Comment

S34-2\_EN\_BA00050S\_0211

6.1.8 Event details

The event details for the currently applicable event, e.g. "Safety stock reached", for the selected tank are shown in this tab. If no event is currently applicable for the selected tank, this tab is not visible. For a description of the **Event details** tab (→ 58).

Inventory chart

Tank details

Notes and files

Tank partners

Location details

Tank service status

Event details

Download history

Message

Ship point reached, detected by measurement.

Comment

Status

Acknowledge

In process

Planned delivery

Amount

64.9

Unit

%

Time stamp

11/19/11 7:00 AM

Time zone

US/East-Indiana

Comment

PO 1234

S34-3\_EN\_BA00050S\_0211

### 6.1.9 Freeze event details

The event details for the currently applicable freeze event for the selected tank, are shown in this tab. If no freeze event is currently applicable for the selected tank, this tab is not visible.

For a description of the **Freeze event details** tab → 58.

## 6.2 Editing tank service status



Only users with the **Operator** user role can specify or change the service status of a tank. All other user roles can only read this tab.

If a tank is out of order for a service, this is shown in the tank overview table by the symbol for individual tanks and the symbol for aggregated tanks. Measured values are no longer updated. Notifications of tank events are no longer produced.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item. A list of the tanks assigned to you is displayed.
3. In the overview table, select the tank whose service status you want to edit.
4. In the lower section of the application window, select the **Tank service status** tab.



5. Click the button.

6. The tab is displayed in the edit mode.

7. Select a time in the future when you want to put the tank out of service. You can either enter the date directly in the **Start date** and **End date** fields or use the button. When entering the date directly use the dd.mm.yy format.

8. If necessary, enter a comment in the **Comment** field.

9. Click to save your changes. Click to abort the process.




## 6.3 Download history

The following options are available via the **Download history** tab:

- Save measured value history for all tanks shown in the overview or for one tank selected in the overview in CSV format.
- Display measured value history for one tank selected in the overview in a diagram.

The CSV file contains the following data: Tank name, Time stamp, Value, Unit, Optimum, Plan point, Ship point, Safety stock and Measuring point (→ 44). If a value is manually configured it is marked with the suffix **MAN**.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item. A list of the tanks assigned to you is displayed.
3. In the overview table, select the tank whose history you want to view as a chart or save as a CSV file.
4. In the lower section of the application window, select the **Download history** tab.

5. Select a time in the past for which you want to download data. You can either enter the date directly in the **Start date** and **End date** fields or use the  button. When entering the date directly use the dd.mm.yy format. The "UTC+00:00" time zone is used for the start and end date.
6. If you want to download the measured value history as a file, MS Excel (CSV) is available as the **Format**.
7. Activate the check box **Export selected tank only**, if you only want to download the data from the selected tank. Deactivate the check box if you want to download the data from all of the tanks shown in the table.
8. Activate the check box **Include secondary values**, if you also want to download the secondary values. This information is only relevant when downloading the data as an Excel file.
9. Activate the check box **Include scaled values**, if you also want to download the scaled values.
10. Via the field **Readings (max.)**, specify the maximum number of primary values per tank.
11. Click the  buttons to display the measured value history in a diagram. If the selected tank is out of service, only the historic pattern of the inventory is displayed. The expected pattern for the inventory is not displayed.
12. Click the  button to download the measured values as an Excel spreadsheet

**The CSV file has the following structure:**

Tank name	Time stamp	Value	Unit	Optimum	Plan point	Ship point	Safety stock	R (Recycling tank)	Recycling tank Plan point	Recycling tank Safety stock	Measuring point
TANK_01	1/13/10 6:40 AM	1.76	l	0	0	0	0	1	7.0	3.0	1
TANK_01	1/13/10 6:49 AM	5	A	0	0	0	0	1	7.0	3.0	2
TANK_01	1/13/10 6:58 AM	1	V	0	0	0	0	1	7.0	3.0	3
TANK_01	1/13/10 7:07 AM	28	°C	0	0	0	0	1	7.0	3.0	4
TANK_01	1/14/10 6:43 AM	1.757	l	0	0	0	0	1	7.0	3.0	1
TANK_01	1/14/10 6:52 AM	6	A	0	0	0	0	1	7.0	3.0	2
TANK_01	1/14/10 7:01 AM	2	V	0	0	0	0	1	7.0	3.0	3
TANK_01	1/14/10 7:10 AM	29	°C	0	0	0	0	1	7.0	3.0	4
TANK_01	1/15/10 6:46 AM	1.754	l	0	0	0	0	1	7.0	3.0	1
TANK_01	1/15/10 6:55 AM	7	A	0	0	0	0	1	7.0	3.0	2
TANK_01	1/15/10 7:04 AM	3	V	0	0	0	0	1	7.0	3.0	3
TANK_01	1/15/10 7:13 AM	30	°C	0	0	0	0	1	7.0	3.0	4
TANK_02	1/13/10 6:40 AM	2.76	l	10.0	8.0	7.0	3.0	0	0	0	1
TANK_02	1/13/10 6:49 AM	2.5	A	10.0	8.0	7.0	3.0	0	0	0	2
TANK_02	1/13/10 6:58 AM	31	V	10.0	8.0	7.0	3.0	0	0	0	3
TANK_02	1/13/10 7:07 AM	2.8	°C	10.0	8.0	7.0	3.0	0	0	0	4
TANK_02	1/14/10 6:43 AM	2.757	l	10.0	8.0	7.0	3.0	0	0	0	1
TANK_02	1/14/10 6:52 AM	2.6	A	10.0	7.0	7.0	3.0	0	0	0	2
TANK_02	1/14/10 7:01 AM	32	V	10.0	7.0	7.0	3.0	0	0	0	3
TANK_02	1/14/10 7:10 AM	2.9	°C	10.0	7.0	7.0	3.0	0	0	0	4
TANK_02	1/15/10 6:46 AM	2.754	l	10.0	8.0	7.0	3.0	0	0	0	1
TANK_02	1/15/10 6:55 AM	2.7	A	10.0	8.0	7.0	3.0	0	0	0	2
TANK_02	1/15/10 7:04 AM	33	V	10.0	8.0	7.0	3.0	0	0	0	3
TANK_02	1/15/10 7:13 AM	3.0	°C	10.0	8.0	7.0	3.0	0	0	0	4



The language of the header of the CSV file depends on the language setting in the browser.



The table is sorted first by tank name, then by time stamp. The "UTC+00:00" time zone is always used for the time stamp.



The column **R** provides information about the tank type. "0" stands for standard tank. "1" stands for recycling tank.



The date and time are displayed as follows in the standard factory setting: yyyy-MM-dd, HH:mm:ss





Manual values are marked with the suffix **MAN**.

## 6.4 Viewing secondaries


A range of measuring devices allows additional measured variables (secondary) to be recorded in addition to the primary variable.

If secondary values have also been assigned to a tank, you can view these values in the "Workplace – Tank" view in the overview table, in the **Inventory chart** tab and in the **Tank details** tab. A maximum of one primary value and eight secondary values can be assigned to a tank.


 The unit for the primary value is specified via the **Unit** field in the **Tank details** tab. In the case of mass units and volume units, priority is given to your settings for the **Mass unit** or **Volume unit** fields in the **User preferences** menu item.

 The units for the secondary values are specified in the **Measuring point details** tab in the **Engineering unit (for application)** field.

### 6.4.1 Viewing secondaries in the overview table in the "Tank" menu item

 The secondary values are hidden or displayed as standard depending on the system settings for your contract. The secondary values are hidden in the default standard setting.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item.
3. The following detail view is displayed in the Application window:




State	Tank name	Location	Product	Level	Value	Free	Capacity	Unit	Time stamp	Time zone
	IC Waste	EU Operations UK	Waste IC 011	90%	3000.0	27000.0	30000.0	l	11/18/11 12:00 PM	Europe/Berlin
	IC Waste II	EU Operations PL	Waste IC 011	90%	3000.0	27000.0	30000.0	l	11/18/11 12:00 PM	Europe/Berlin
	IC Waste III	EU Operations ES	Waste IC 011	90%	3000.0	27000.0	30000.0	l	11/18/11 12:00 PM	Europe/Berlin
	LNG 01000	APAC Operations SG	Product LNG 010	2%	1000.0	49000.0	50000.0	l	11/18/11 10:10 PM	Singapore
	LNG Waste	APAC Operations TH	Waste LNG 011	24%	19085.4	5914.6	25000.0	l	11/18/11 4:30 PM	Singapore


S38\_EN\_BA00050S\_0211

4. Click the **Show secondary data** button.
5. All the associated secondary data are shown underneath the specific tanks. Of the secondary data, the following data are shown if available: Tank name, Value, Unit, Hysteresis, Limit 1 and Limit 2. The tank name corresponds to the **Name** field in the **Secondaries** tab in the **Tank** menu item.
6. Click the **Hide secondary data** button to hide the secondary data.

### 6.4.2 Viewing secondaries in the inventory chart

 Users with the **Master Data** user role can specify a name via the **Secondaries** tab in the **Tank** menu item. This name is used in the overview table for the button and the graph. If no name has been entered, the secondary values are given the default names Secondary[1], Secondary[2], Secondary[3], Secondary[4], Secondary[5], Secondary[6], Secondary[7] and Secondary[8].



1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the table, click the tank whose secondary data you want to display in the **Inventory chart** tab.
4. The following detail view is displayed in the Application window:




S39\_EN\_BA000505\_0211


The inventory chart displays the graph for the primary value.

5. Click the **Show [Name]** button beneath the chart.  
Depending on the number of secondary values that have been assigned to the tank, the appropriate number of **Show [Name]** buttons are displayed beneath the inventory chart.
6. Click the **Hide [Name]** button to hide the specific graph.

 Click the  button to print the inventory chart.

 If you move the cursor over the graph, the specific value and time stamp are displayed for the individual point in the graph.

### 6.4.3 Viewing secondary data via the "Tank details" tab

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the table, click the tank for which you want to display secondary data.
4. Select the **Tank details** tab.
5. Click the button  beside the Value field.
6. The following screen appears:

Details			
	Value	Unit	Time stamp
Primary	865.00	l	3/5/12 3:35 PM
Secondary[1]	51,535.00	l	3/5/12 3:35 PM
Secondary[2]			
Secondary[3]			
Secondary[4]			
Secondary[5]			
Secondary[6]			
Secondary[7]			
Secondary[8]			

Tank\_details\_details\_BA00050SEN

The magnifying glass cannot be selected in the following cases:

- No secondary values are assigned to the selected tank.
- The tank supplies a bad measured value.
- The tank is out of service.
- The tank is assigned to an aggregated tank.

### 6.5 Viewing historical values and forecast values in the inventory chart

The inventory chart displays the values measured up to the present date with a continuous line and the values calculated from the present date with a broken line. No forecast values are available for secondary values.


In the case of standard tanks, the forecast values are calculated from the "Average daily outflow" value. In the case of recycling tanks, the forecast values are calculated from the "Average daily inflow" value.

The inventory chart offers the following additional functionalities:

#### Mouseover function

Additional information is displayed if you move the cursor over a graph in the inventory chart. If the point in the graph is in the past, the "Inventory" window appears with information on the measured value and the time stamp. If the point in the graph is in the future, the "Forecast" window appears with information on the calculated value and the time stamp.





Workplace\_tank\_inventory\_chart\_BA00050SEN

### Clicking on a point in the graph

A dialog box appears if you click on a point in the graph with the cursor. The **Historical value** dialog box appears for the values measured in the past. The **Forecast value** dialog box appears for the calculated values in the future. The **Current value** dialog box appears for the last measured value received.



Workplace\_tank\_inventory\_chart\_2\_BA00050SEN

### Navigating via the dialog box

The **Value** field in the dialog box displays the measured value for the past and the calculated value for the future. The **Time stamp** field displays the associated date and time. Click the button to view the older measuring points. Click the button to view the more recent measuring points. If you want to view points that are further back in time, change the number of displayed days in the **Period selection** field.

## 6.6 Zoom functions in the inventory chart

You can use the zoom function to enlarge a maximum section of 12 hours in the inventory chart to get a closer look at the data.

1. Set the start of the zoom-in zone.

Proceed as follows:

- Using the left mouse button, click the desired starting point.
- While holding the left mouse button, drag the mouse to the left or right.
- The selected zone is marked with a dark background. You can move the zone to the left or right by dragging the mouse.


2. Click the left mouse button to select the end of the zoom-in zone.


3. The inventory chart with the selected zone is loaded.
4. Click **Reset zoom** to zoom out again.






## 6.7 Planning delivery and disposal via the inventory chart

**i** Only users with the **Scheduler** user role can plan deliveries for standard tanks and disposals for recycling tanks.


1. Click the **Workplace** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the overview table, select the tank for which you want to plan a delivery or disposal.
4. In the lower section of the application window, select the **Inventory chart** tab.
5. Click the graph in the inventory chart for the date you are planning a delivery or disposal. The planned date must be in the future.
6. The **Forecast value** dialog box is displayed.
7. Click the **Plan delivery** (standard tanks) or **Plan disposal** (recycling tanks) button.
8. The **Plan delivery** dialog box appears for standard tanks. The **Plan disposal** dialog box appears for recycling tanks.
9. Click the  button.
10. The dialog box appears in the editing mode.
11. You can view and enter the following data here:

- **Value:** Displays the project level
- **Delivery date and time:** The day selected in the calendar is used for the date. The time is predefined.
- **Amount:** Enter the planned amount.
- **Range:** This field shows the number of days before the safety stock is reached for the amount entered. In the case of standard tanks, the number of days is calculated from the "Average daily outflow" value. In the case of recycling tanks, the number of days is calculated from the "Average daily inflow" value.
- **Refresh range:** Via the  button, the **Range** field is updated for the amount entered.
- **Comment:** Enter a comment or note.


12. Click  to save your changes. Click  to abort the process.
13. A delivery van icon  indicates the delivery and disposal in the inventory chart. If you move the cursor over the delivery van field, information on the planned delivery or disposal is displayed along with the delivery date and time.

## 7 Viewing personalized tank view - "My tank view" workplace


The personalized tank view shows you the tanks that you selected in your user profile in the **My tank view** tab (→ 128).

 The **My tank view** menu item is available to people with **Read only**, **Scheduler** or **Operator** configured as their user role.


1. Click the **Workplace** menu in the Navigation window.
2. Click the **My tank view** menu item.
3. You are shown a list of all the tanks which you selected in the user profile.

 **Manual values** are displayed in blue color followed by the text **MAN**. The column **Data source** provides information on where the data comes from: measured or manually entered.

 You can filter the tanks via the picklist **Tank group**. Whenever a selection is done, only the tanks within that group are displayed on the screen.



4. Where available, the following primary data are displayed for every tank: Tank name, Company name, Location, Product, Value with unit, Time stamp with time zone.

 The last primary value is displayed. For aggregated tanks, the sum of all the last measured values for the associated tanks is displayed.

Click the  button to export the content displayed to an Excel file.


To update the view and call up new measured data, you can either click the  button.

In addition it is possible to automatically refresh the view. Therefore, select your favored time period for reloading from the picklist **"Auto refresh"**.




The Auto refresh function only works if this feature is predefined in your system properties (see respective chapter in the Service Manual).

Click the button to configure your Tank view. The **My tank view** configuration window is displayed.



Configuration\_My tank view\_BA0050SEN

Click the button to display the legend. You can move the legend to another location by pointing the cursor at the blue title bar and pressing and holding the left mouse button.



Workplace\_tank\_view\_BA0050SEN

5. Click the picture of the tank if you would like to see more tank details (→ 39).





Workplace\_My\_tank\_view\_3\_BA00050SEN

## 7.1 Viewing secondaries




The  button is also displayed if secondary data are available for the tank.




1. Click the  button to display the secondary data.

2. A submenu opens. The first menu item displays the tank name of the primary value. This can be followed by up to eight secondary names.



Select\_secondary\_value\_BA00050SEN

3. Select the appropriate secondary name.

4. The following secondary data are displayed: Tank name, Secondary name, Value with unit, Time stamp with time zone.  
Click the  button again to return to the primary data. Select the tank name of the primary value in the submenu.

## 8 Editing events - "Event" workplace

### 8.1 Event management - Status and weighting of events


An event is triggered if a limit value is undershot (Plan point, Ship point, Safety stock). The status of the event is then set to **Open**. The weighting (severity) is derived from the limit value, i.e. reaching the plan point is categorized as not critical (low) while reaching the safety stock level is regarded as very critical (high).

Once an event has been generated, the user can change the status to **Acknowledged** or **In process**. To making it easier to track events later, the change is stored with a time stamp and user name.

If a critical limit is reached, determined by another measurement, the status of the event is set to **Open**. If an inventory that is above the plan point is detected for standard tanks, and if an inventory that is below the plan point is detected for recycling tanks, the event assumes the status **Done** and no other activities are required.



A point must be noted with the **In process** status. If the tank is not refilled by the set resubmission date, the event status returns to **Open**.

The following diagram shows the status for an event in SupplyCare Hosting:






## 8.2 Viewing event messages

-  The **Event** menu item is available to people with **Read only**, **Scheduler** or **Operator** configured as their user role.
-  The time zone configured in the **User preferences** menu item is used for the **Event details/Freeze event details** and **Event history** tabs (→ [129](#)). "UTC+00:00" is the default value. The time zone configured for the location is used for the **Inventory chart** and **Tank details** tabs (→ [108](#)). "UTC+00:00" is the default value.

The **Event** menu item provides effective support in a replenishment process which is controlled by means of order limits. For standard tanks, the events are triggered if limit values in the individual tanks are undershot; for recycling tanks, they are triggered if the limit values in the individual tanks are exceeded. A **Freeze Event** is triggered if the actual measurement exceeds the configured freeze event delta. In addition to screen display, people can also be notified of the events by e-mail.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Event** menu item.
3. The following is displayed in the portal window with an overview of all the events, sorted in order of priority:




The screenshot shows the 'Workplace >> Event' interface. At the top, there are filters for 'View' (All), 'Status' (All (except for done)), and 'Severity' (All). Below this is a table of events with columns: Severity, Status, Tank, Location, Supplier, and Time stamp. The table contains three rows of data. Below the table, there are tabs for 'Freeze event details', 'Event history', 'Inventory chart', and 'Tank details'. The 'Freeze event details' tab is selected, showing a 'Mark as done' button and a 'Message' field. The message is 'Freeze event, detected by measurement.' Below the message, there are fields for 'Value' (90,050.0), 'Unit' (kg), 'Time stamp' (11/9/13 1:50 AM), and 'Time zone' (UTC+01:00). At the bottom, there is a 'Limit' section with fields for 'Value' (82,355.0), 'Unit' (kg), 'Time stamp' (11/9/13 12:55 AM), 'Time zone' (UTC+01:00), and 'Freeze event delta' (0.1).

S48\_EN\_BA000505\_0211


4. To filter the displayed events, select the filter criteria:
  - **View:** Select between **All**, **Only limit events** or **Only freeze events**.
  - **Status:** Select between **All (except for done)**, **Only open**, **Only acknowledged**, **Only in process** or **Only done**.  
The filters **Only acknowledged** and **Only in process** exclusively have an effect on limit events. Any other filter will effect both types of events.
  - **Severity:** Select between **All**, **Only low**, **Only medium** or **Only high**.  
The filters **Only low** and **Only medium** and **Only high** exclusively have an effect on limit events. Any other filter will effect both types of events.

If the set filters do not overlap each other, i.e. resulting in no events, the previous filter settings are restored. The following error message is displayed:



- 5. In the overview table, click on an event which you would like to view or for which you require further information.
- 6. You can select the following tabs in the lower area of the application window:  
**Event details/Freeze event details, Event history, Inventory chart or Tank details.**


8.2.1 Event details



A form with the following fields is shown on this tab:  
Message, Comment, Acknowledge and In process.

In addition, the display also shows the **Amount, Time stamp, Unit, Time zone** and **Comments** fields for standard tanks for planned deliveries, and for recycling tanks for planned disposals.

8.2.2 Freeze event details



A form with the following fields is shown on this tab:

**Message**, **Value** of the received measurement, **Unit** of the tank, **Time stamp** of the measurement in the respective time zone, **Time zone** of the measurement.

In addition, the display shows in the lower section information on the Limit:

**Value** ("Frozen measurement" in respective Unit), **Unit** of the tank, **Time stamp** of the frozen measurement in the respective time zone, **Time zone** of the frozen measurement, **Freeze event delta**, **Unit** of the tank.

1. Click the **Mark as done** button to acknowledge the event. The following message appears:



2. Click **OK**.

**i** A Freeze event will only be generated once during a check period. The status of the event is **Open** until it is marked as done. If a new Freeze event occurs in the next check period, the previously created event is taken over to the Event history.

### 8.2.3 Event history

Time stamp	Severity	Status	Message	Comment	User
11/18/11 5:07 AM	!		Ship point reached, detected by measurement.		

S49-2\_EN\_BA00050S\_0211

This tab displays the history of an event selected in the overview table. The screen includes **Time stamp**, **Severity**, **Status**, **Message**, **Comment** and **User**.


### 8.2.4 Inventory chart

The inventory chart of the associated tank is shown here for the event currently selected. For a description of the **Inventory chart** tab, → 38.


### 8.2.5 Tank details

The tank details of the associated tank are shown here for the event currently selected. For a description of the **Tank details** tab, → 39.

## 8.3 Processing messages

 Only users with the **Scheduler** or **Operator** user role can comment on events and assign a status.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Event** menu item.
3. In the overview table, select the event that you want to process.
4. In the lower section of the application window, select the **Event details** tab.



Event details | Event history | Inventory chart | Tank details

**Message** Ship point reached, detected by measurement.

**Comment**

**Status** ☐ Acknowledge  
☐ In process


**Planned delivery**


**Amount** 64.9 **Unit** %

**Time stamp** 11/19/11 7:00 AM **Time zone** UTC-05:00

**Comment** PO 1234

S50\_EN\_BA00050S\_0211

5. Click the  button.
6. The tab is displayed in the edit mode.



Event details | Event history | Inventory chart | Tank details

**Message** Ship point reached, detected by measurement.

**Comment**

**Status** ☐ Acknowledge  
☐ In process

**Planned delivery**


**Amount** 64.9 **Unit** %

**Time stamp** 11/19/11 7:00 AM **Time zone** UTC-05:00

**Comment** PO 1234


S50-2\_EN\_BA00050S\_0211

7. If you have acknowledged this event, activate the **Acknowledge** check box.  
If replenishment measures have already been initiated, activate the **In process** check box and change the resubmission date if necessary.  
You can enter comments on this event in the **Comment** section.


 If the status of the event was set to **In process**, the system monitors whether the tank is replenished by the **Resubmission date**. If this is not the case, the status of the event is reset to **Open** and the appropriate notification messages are triggered. As standard, the **Resubmission date** is calculated from the standard delivery time. This can also be set individually for every event however.


8. Click  to save your changes. Click  to abort the process.

## 8.4 Setting the resubmission date




 Only people whose user role is configured as **Scheduler** or **Operator** can set a resubmission date for events.


 You can only set a resubmission date for the **In process** option.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Event** menu item.
3. In the overview table, select the event that you want to process.
4. In the lower section of the application window, select the **Event details** tab.
5. Click the  button.
6. Activate the **In process** check box.
7. The tab is displayed in the edit mode.



SS1\_EN\_BA00050S\_0211

8. Either enter the date directly in the **Resubmission date** field or use the  button.
9. If necessary, specify a time (in hours and minutes) for the **Resubmission time** fields.
10. Click  to save your changes. Click  to abort the process.

 If a standard tank is refilled and the inventory is again above the plan point, the status of the event automatically changes to **Done**. If a recycling tank is drained and the inventory is once again below the plan point, the status of the event automatically changes to **Done**.

 The "Standard delivery time" is displayed for standard tanks, and the "Standard disposal time" for recycling tanks.


## 9 Planning delivery and disposal – "Scheduling" workplace

### 9.1 Status management – delivery and disposal

When a new delivery/disposal is created, the system checks whether the delivery/disposal is planned too early or too late. The forecast data determined by SupplyCare are used to check the information. The user can either reschedule the delivery/disposal which is too late/early or confirm this as an early or late delivery/disposal.



SupplyCare monitors the deliveries and disposals daily. If it detects an early or late delivery/disposal, this delivery/disposal can be confirmed. If it detects a missing delivery/disposal, this delivery/disposal can be mark as fulfilled.

The following diagram shows the status management for disposals and deliveries in SupplyCare Hosting:




SCH Req 29-35\_Flowchart EN

### 9.2 Status display and notification of planned deliveries and disposals

-  Only users with the **Scheduler** user role receive notification of planned deliveries and disposals and can process such notification messages.
-  For a user to receive notification, the PDL and/or PDE check boxes must be enabled in the Tank group tab in the Tank group menu.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. Click the **Overview** tab.

4. The following is displayed in the portal window with an overview of all the statuses for all the disposals and deliveries:



The screenshot shows a software interface with a table titled 'Workplace >> Scheduling >> Overview'. The table has columns for State, Message, PD, PD Amount, Unit, Tank name, Time zone, State changed at, Buyer, and Supplier. Below the table are tabs for 'Details' and 'History', and a section for 'Planned delivery' with fields for Amount, Unit, Time stamp, and Comment.

State	Message	PD	PD Amount	Unit	Tank name	Time zone	State changed at	Buyer	Supplier
	New planned delivery	4/4/12 6:00 AM	4,500.0 I	I	IC 01000	UTC-05:00	3/26/12 10:37 AM	Buyer AG	Supplier AG
	Early disposal (conf...)	3/30/12 12:00 PM	3,000.0 I	I	IC Waste II	UTC+01:00	3/26/12 4:36 PM	Buyer AG	Mustermann AG
	New planned delivery	3/31/12 6:00 AM	90.0 %	%	IC 02000	UTC-05:00	3/26/12 10:36 AM	Buyer AG	Supplier AG
	Deleted delivery	3/31/12 12:00 PM	0.0 %	%	IC 02000	UTC-05:00	3/26/12 10:36 AM	Buyer AG	Supplier AG
	Missed delivery (det...)	2/14/12 1:00 PM	12,000.0 I	I	IC 03000	UTC+01:00	2/15/12 3:52 AM	Buyer AG	Supplier AG

1 of 7

**Details** History

**Message** New planned delivery

**Planned delivery**

**Amount** 4,500.0 **Unit** I

**Time stamp** 4/4/12 6:00 AM **Time zone** UTC-05:00






**Comment**

S53\_EN\_BA000505\_0211


5. In the overview table, click a status to change it or to view the history.
6. You can select the following tabs in the lower area of the Application window:  
**Details** or **History**.

### 9.2.1 Processing status

The following status information can be displayed:

Button	Meaning
	<b>Detected</b> - the <b>Detected</b> status is displayed in the following situations: <ul style="list-style-type: none"> <li>The system has detected a delivery or disposal which has been scheduled too early or too late. You can process this delivery or disposal in the <b>Details</b> tab using the <b>Confirm</b> button.</li> <li>The system has detected a missing delivery or disposal. You can process this delivery or disposal in the <b>Details</b> tab using the <b>Mark as fulfilled</b> button.</li> <li>The system has detected that measured data are missing. You can process this delivery or disposal in the <b>Details</b> tab using the <b>Mark as fulfilled</b> button.</li> </ul>
	<b>Confirmed</b> - the <b>Confirmed</b> status is displayed in the following situations: <ul style="list-style-type: none"> <li>A delivery or disposal which has been scheduled too early or too late was confirmed when the delivery/disposal was created.</li> <li>A delivery or disposal which has been scheduled too early or too late has been confirmed in the <b>Details</b> tab.</li> </ul>
	<b>Deleted</b> - a planned delivery or disposal has been deleted.
	<b>New</b> - a new delivery or disposal has been planned.
	<b>Fulfilled</b> - a new delivery or disposal has been fulfilled. If a delivery and disposal is made, this is flagged by SupplyCare as <b>Delivery made (detected)/Disposal made (detected)</b> . If the system has detected a missing delivery/disposal or missing measured data, you can process this delivery/disposal in the <b>Details</b> tab using the <b>Mark as fulfilled</b> button. The delivery/disposal is displayed as <b>Delivery fulfilled (confirmed)/Disposal fulfilled (confirmed)</b> .

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. In the overview table, select a status that you want to process.
4. In the lower section of the Application window, select the **Details** tab. The following tab appears:



SS4\_EN\_BA000505\_0211

You can process the following statuses with the **Mark as fulfilled** button:

- Missed delivery/disposal (detected)
- Missed delivery/disposal (no measurement)

You can process the following statuses with the **Confirm** button:

- Early delivery/disposal (detected)
- Late delivery/disposal (detected)





### 9.2.2 Viewing status history

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. In the overview table, select a status that you want to process.
4. In the lower section of the Application window, select the **History** tab. The following tab appears:

Time stamp	State	Message	User
11/18/11 10:42 AM	★	New planned delivery	I2468701


S55\_EN\_BA00050S\_0211

## 9.3 Planning delivery and disposal – "Scheduling" workplace

-  Only users with the **Scheduler** user role can plan deliveries for standard tanks and disposals for recycling tanks.
-  **Manual values** are displayed in blue color followed by the text **MAN**. The column **Data source** provides information on where the data comes from: measured or manually entered.

You can plan several deliveries for each standard tank but you can only plan a maximum of one delivery per day. You can plan several disposals for each recycling tank but you can only plan a maximum of one disposal per day.

The time zone of the location of the tank is used as the time zone. The unit of the tank is used as the unit. In the case of mass units and volume units, priority is given to your settings for the **Mass unit** or **Volume unit** fields in the **User preferences** menu item.

If a tank is out of service, this is indicated in the calendar with a bar and the  symbol. No deliveries or disposals can be planned for this period.

Planned deliveries and disposals are indicated by a delivery van  in the calendar and in the **Inventory chart** tab.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. Click on the **Planning** tab. The following view is displayed in the Application window:

OverviewPlanning

Workplace >> Scheduling >> Planning

Auto refreshUnitTime zoneLocation

Tank groupAllProductAllSupplierAllLocationAll

State	Location	Tank name	Level	Value	Unit	Data source	Product	Free
	Grenzach-Whylen	Tank_01 Monthly ramp	62%	120,805.0	kg	Measured		199,195.0
	Maulburg	Tank_02 Monthly ramp	56%	180,000.0	MAN I	Manual	50% Caustic Soda	140,000.0
	Grenzach-Whylen	Tank_03 Monthly ramp	0%	0.0	l	Measured	50% Caustic Soda	0.0
	Reinach	Tank_10 Monthly ramp	0%	0.0	l	Measured		150,000.0

Plan\_delivery\_disposal\_1\_BA00050SEN

4. In the overview table, click the tank for which you want to plan a disposal or delivery.
5. The following detail view is displayed in the Application window:

Plan delivery / disposalPlanned delivery / disposal

Time zoneUTC+01:00Unitl


Last MonthMarch 2012Next Month

Sun	Mon	Tue	Wed	Thu	Fri	Sat
			1	2	3	4
5	6	7	8	9	10	11
12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30	31	
241,054.76						

Plan\_delivery\_disposal\_1\_BA00050SEN

The current date is displayed with a grey background in the calendar. Every date in the future has a color background. The color indicates the forecast value for the tank status for that particular date.

Color	Standard tanks	Recycling tanks
Grey	Current date	Current date
Green	"OK": The forecast value is larger than the plan point	"OK": The forecast value is between 0 and the plan point
Yellow	"Plan point": The forecast value is between the plan point and the ship point	"Plan point": The forecast value is between the plan point and the safety stock
Orange	"Ship point": The forecast value is between the ship point and the safety stock	Not applicable
Red	"Safety stock": The forecast value is below the safety stock	"Safety stock": The forecast value is above the safety stock
White	The date is in the past or the tank/ aggregated tank is out of service	The date is in the past or the tank/ aggregated tank is out of service


Click the  button to display the legend. You can move the legend to another location by pointing the cursor at the blue title bar and pressing and holding the left mouse button.



00:00 (midnight) is the time that is used to determine the color or the tank status for the particular date. For example, if the "Ship point" is reached at 4 a.m. (04:00) on May 15, and the "Safety stock" at 8:30 p.m. (20:30), May 15 is given the background color "red" for "Safety stock".


### 9.3.1 Planning a delivery or disposal

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. Click on the **Planning** tab.
4. In the overview table, click the tank for which you want to plan a delivery or disposal.
5. The following detail view is displayed in the Application window:








6. Click the **Plan delivery/Plan disposal** tab.
7. In the calendar, where necessary use the **Next month** button to select the month for which you are planning a delivery or disposal.
8. Click the preferred **day**. Before clicking the **day**, a green "x" beside the day indicates whether a delivery or disposal is possible on that day.
9. The **Plan delivery** dialog box appears for standard tanks. The **Plan disposal** dialog box appears for recycling tanks.

PS000099ten



10. Click the  button.
11. The dialog box appears in the editing mode.
12. You can view and enter the following data here:

– **Value:** Displays the projected level

- **Delivery date and time:** The day selected in the calendar is used for the date. The time is predefined.
- **Amount:** Enter the planned amount.
- **Range:** This field shows the number of days before the safety stock is reached for the amount entered. In the case of standard tanks, the number of days is calculated from the "Average daily outflow" value. In the case of recycling tanks, the number of days is calculated from the "Average daily inflow" value.
- **Refresh range:** Via the  button, the **Range** field is updated for the amount entered.
- **Comment:** Enter a comment or note.

13. Click  to save your changes. Click  to abort the process.  
The system performs a plausibility check when a planned disposal or planned delivery is saved. If the values entered are implausible, a dialog box is displayed, →  69.
14. Deliveries and disposals are entered in the calendar with a delivery van icon  and the planned amount. The delivery date and time are displayed when you move the cursor over this field.

### 9.3.2 Plausibility check

-  The plausibility check only checks the latest planned delivery/disposal.
-  A plausibility check is only performed if a safety stock (SST) and plan point (PP) have been saved for the tank.


The system performs a plausibility check on which a planned delivery or a planned disposal is saved. The planned date and the planned time are checked with the calculated values for the safety stock (SST) and plan point (PP). If the planned date is before the calculated date when the plan point will be reached, a dialog box is displayed with the message "In consideration of the forecast value(s) the planned delivery/disposal date might be too early". If the planned date is after the date on which the safety stock will be reached, the dialog box "In consideration of the forecast value(s) the planned delivery/disposal date might be too late" is displayed.



S58\_EN\_BA000505\_0211

Click the **Confirm** button to confirm the date entered for the delivery/disposal.

Click the **Reschedule** button to correct your entries.


- The **Plan delivery** dialog box appears for standard tanks. The **Plan disposal** dialog box appears for recycling tanks.
- Correct your entries.
- Click  to save your changes.

### 9.3.3 Deleting a delivery or disposal

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. Click on the **Planning** tab.
4. In the table, click the tank for which you want to delete a delivery or disposal.
5. Click the **Plan delivery/Plan disposal** tab.
6. In the calendar, click the entry that you want to delete.
7. The **Delivery details** dialog box appears for standard tanks. The **Disposal details** dialog box appears for recycling tanks.



PS0000965en



8. Click the  button to delete the delivery or disposal.
9. The prompt "Do you really want to delete?" is displayed.
10. Click **OK** to delete the entry. Click **Cancel** to abort the process.




### 9.4 Copying a delivery or disposal

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. Click on the **Planning** tab.
4. In the overview table, click the tank for which you want to copy a delivery or disposal.
5. Click the **Plan delivery/Plan disposal** tab.
6. In the calendar, click the entry that you want to copy.
7. The **Delivery status** dialog box appears for standard tanks. The **Disposal status** dialog box appears for recycling tanks.




PS0000965en

8. Click  to copy the entry.
9. The **Copy delivery** dialog box appears for standard tanks. The **Copy disposal** dialog box appears for recycling tanks.
10. Click the  button.
11. The dialog box appears in the editing mode.
12. Enter the desired amount in the **Amount** field.
13. For the **Delivery date and time** field, select a new date and time.

14. Enter a comment or a note for the **Comment** field.
15. Click  to save your changes. Click  to abort the process.
16. Deliveries and disposals are entered in the calendar with a delivery van icon  and the planned amount. The delivery date and time are displayed when you move the cursor over this field.


### 9.4.1 Viewing a planned delivery or disposal and saving as an Excel spreadsheet

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Scheduling** menu item.
3. Click on the **Planning** tab.
4. In the overview table, click the tank for which you want to display the deliveries or disposals.
5. Click the **Planned delivery/Planned disposal** tab.
6. The following detail view is displayed in the Application window:



PD	PD Amount	Comment
30/03/11 12:00	10433.8	

PS0000967en

7. All the deliveries or disposals for the selected tank are listed in the table, with information on the date (**PD** column), amount (**PD amount** column) and a comment.
8. Click the  button to download the table as an Excel spreadsheet

# 10 Totaling and managing templates – "Totaling" workplace

- i*


The **Totaling** menu item is available to people with **Read only**, **Scheduler** or **Operator** configured as their user role.
- i*

**Manual values** are displayed in blue color followed by the text **MAN**. The column **Data source** provides information on where the data comes from: measured or manually entered.

## 10.1 Totaling

In the **Totaling** menu item, it is possible to add up the values of the **Value**, **Capacity**, **Free** and **PD amount** fields. The totalized **Level** is represented graphically. The values of standard tanks can be totaled in the **Standard tanks** tab and the values of recycling tanks in the **Recycling tanks** tab. Tanks and aggregated tanks can be included in a calculation.

- Click the **Workplace** menu in the Navigation window.
- Click the **Totaling** menu item.
- The following view is displayed in the Application window:



- In the **Select** table column, enable the check boxes of the tanks that should be totaled.
- i*

At least one tank must be selected for the calculation.
- i*

Only tanks with the same unit can be totalized.
- i*

Activating the check box in the **Select** column header selects all the tanks in the table, while deactivating the check box disables all the tanks.



Select	State	Location	Tank name	Level	Value	Unit	Free	Product	Time zone
<input checked="" type="checkbox"/>		HQ	IC 03-mix	5%	6,000.0 I			34,000.0 Product IC 030	UTC+01:00
<input checked="" type="checkbox"/>		HQ	IC 03000	5%	3,000.0 I			17,000.0 Product IC 030	UTC+01:00
<input checked="" type="checkbox"/>		APAC Operations SG	LNG 01000	2%	1,000.0 I			49,000.0 Product LNG 010	UTC+01:00

Workplace\_totaling\_2\_BA00050SEN

5. Select the unit of the selected tanks in the **Unit** field.
6. Click the **Calculate** button.
7. The following detail view is displayed in the Application window:

Level	5%
Value	10,000.0 I
Capacity	110,000.0 I
Free	100,000.0 I
PD Amount	0.0 I

Workplace\_totaling\_3\_BA00050SEN

- You must press the **Calculate** button a second time to incorporate any changes to the selection which are made after the calculation has been performed. If you do not, the following message is displayed beside the **Calculate** button: "You have changed the selection. Please recalculate."
- Clicking the button deactivates any activated check boxes and deletes the calculated values in the detail view. However, anything selected via the picklists of the various fields in the table header is retained.

## 10.2 Saving a selection as a template

The choice of tanks or aggregated tanks can be saved as a template.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Totaling** menu item.
3. In the **Select** table column, select the check boxes of the tanks that should be totaled.
4. Select the unit of the selected tanks in the **Unit** field.
5. Click the **Calculate** button.
6. The **Save** button appears in the header of the table.
7. Click the **Save** button.
8. The **Save selection as template** dialog box appears on the display:



Workplace\_totaling\_4\_BA00050SEN

The and buttons do not appear in the dialog box when you create the first template.

9. Click the button.

10. The dialog box appears in the editing mode.



Workplace\_totaling\_5\_BA00050SEN

You have two options: you can either create a new template or overwrite an existing template.

### 10.2.1 Creating a new template


1. Perform all the steps specified in Chapter "Saving a selection as a template", → 73.
2. In the **Save selection as template** dialog box, click the button.

The button does not appear in the dialog box when you create the first template.

3. Enter a template name. The template name can have a maximum of 64 characters.
4. Click to save your changes. Click to abort the process.

### 10.2.2 Overwriting an existing template

1. Perform all the steps specified in Chapter "Saving a selection as a template", → 73.
2. Click the button.
3. The **Overwrite existing template** dialog box is displayed:








Workplace\_totaling\_6\_BA00050SEN

4. In the overview table, click the template you wish to overwrite.
5. The template is displayed in the **Save selection as template** window.




Workplace\_totaling\_7\_BA00050SEN

6. If you want to undo your selection, click the  button, then click the  button and select another template.
7. Click the  button if you want to save the selection. Click the  button if you want to abort the process.


-  A tank is deleted from a template automatically if the tank is deleted or if the tank is no longer part of the tank group that was assigned to a user.

### 10.3 Selecting or deleting templates


1. Click the  **Open** button in the overview.
2. The **Template overview** window is displayed:



Workplace\_totaling\_8\_BA00050SEN

3. If you want to accept a template, click the corresponding row in the table. If you want to delete a template, click the  button in the corresponding row and then click **OK** in the **Confirm deletion** window.

## 11 Viewing analysis data – "Analysis" workplace

 The **Tank** menu item is available to people with **Scheduler** or **Operator** configured as their user role.

This menu item allows you to view important indicators for the inflow and outflow of the individual tanks as data and charts. You can use these data and charts to analyze past cycle patterns and use them as the basis for future planning. You can export all the information to an Excel spreadsheet. In addition, it is also possible to print out the charts.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Analysis** menu item. A list of the tanks assigned to you is displayed.

Workplace >> Analysis

Tank group: US OperationsProduct: All

Tank name	Location	Time zone	Unit	DO	ADO	DI	ADI	Product
IC 01000	US Operations North	UTC-05:00	I	80.8	221.1	96.9		Product IC 010
IC 02000	US Operations West	UTC-05:00	%	3.9	4.6	0.1		Product IC 020

1 of 2

KPIsOutflow/InflowChart hourlyChart daily

Daily outflow3/25/201280.8I

Average daily outflow221.1I

Daily inflow3/25/201296.9I

Day(s) until reaching safety stock> 30d


Next planned delivery4/4/2012UTC-05:004,500.0I

From dateTo dateShow available period

PS0000968en

3. In the table, click the tank whose analysis data you want to view.
4. You can choose the following tabs in the lower part of the application window:  
KPIs, Outflow/Inflow, Chart hourly and Chart daily.

## 11.1 "Analysis" overview table


Pressing the button  in the table header in the overview opens a context menu. Via this context menu, you can show, hide and move table columns.

The following columns are available for the overview table

Columns	Description
Location	Indicates the tank location. The location is the name of the location. The name is selected in the <b>Configuration</b> menu in menu item <b>Tank</b> , field <b>Location</b> . The location is specified in the <b>Location</b> menu item.
Tank name	Indicates the tank name. The tank name is entered in the <b>Tank name</b> field (path: Configuration → Tank → Tank details → Tank name).
Unit	Indicates the unit. The unit for the primary value is specified via the <b>Unit</b> field in the <b>Tank details</b> tab. In the case of mass units and volume units, priority is given to your settings for the <b>Mass unit</b> or <b>Volume unit</b> fields in the <b>User preferences</b> menu item.
Time zone	Time zone of time stamp. The time zone of the location is used.
DO (daily outflow)	Displays the daily outflow last calculated
ADO (average daily outflow)	Displays the value for "Average daily outflow". The value is calculated with the average quantity per day. The calculated average quantity is based on the configured "Forecast based on" value. This field is empty for recycling tanks.
DI (daily inflow)	Displays the daily inflow last calculated
ADI (average daily inflow)	Displays the value for "Average daily inflow". The value is calculated with the average quantity per day. The calculated average quantity is based on the configured "Forecast based on" value. This field is empty for standard tanks.
Product	Indicates the product in the tank.

## 11.2 KPIs (key performance indicators)

The tab displays important indicators for the inflow and outflow of the selected tank.



The screenshot shows the KPIs tab with the following data:

Metric	Value	Unit
Daily outflow	1.6	%
Average daily outflow	3.9	%
Daily inflow	0.3	%
Day(s) until reaching safety stock	14d 8h	
Next planned delivery		
Total outflow	446.0	%
Total inflow	449.7	%
Number of deliveries	9	
Frequency of deliveries	9.66	day(s)

Additional information displayed:

- From date: 12/31/2010
- To date: 3/27/2011
- Show available period: ☒
- Actual period between first and last outflow: from 12/31/2010 to 3/27/2011

The **Daily outflow** and **Daily inflow** fields display the values last calculated.

Additional information is displayed if you enter a period for the **From date** and **To date** fields or enable the **Show available period** check box.

### Description of fields

Field	Description
Daily outflow	Displays the calculated daily outflow for the date entered.
Average daily outflow/ average daily inflow	<ul style="list-style-type: none"> <li>Standard tanks: Average daily outflow</li> <li>Recycling tanks: Average daily inflow</li> </ul> <p>The values are calculated with the average quantity per day. The calculated average quantity is based on the configured "Forecast based on" value.</p>
Daily inflow	Displays the daily inflow for the date entered.
Days until the safety stock is reached	<p>Indicates the estimated number of days remaining until the safety stock is reached.</p> <p>The value is calculated with the average quantity per day.</p> <ul style="list-style-type: none"> <li>If "Safety stock" has been disabled or if the value is "0", the <b>Days until the safety stock is reached</b> field is empty.</li> </ul>
Next planned delivery/ Next planned disposal	<ul style="list-style-type: none"> <li>Standard tanks: Displays the next planned delivery</li> <li>Recycling tanks: Displays the next planned disposal</li> </ul>
Total outflow	Displays the total outflow for the period entered.
Total inflow	Displays the total inflow for the period entered.
Number of deliveries/ Number of disposals	<ul style="list-style-type: none"> <li>Standard tanks: Displays the number of deliveries made for the period entered.</li> <li>Recycling tanks: Displays the number of disposals made for the period entered.</li> </ul>
Frequency of deliveries/ Frequency of disposals	<ul style="list-style-type: none"> <li>Standard tanks: Average interval between two deliveries for the period entered.</li> <li>Recycling tanks: Average interval between two disposals for the period entered.</li> </ul>

## 11.3 Outflow/Inflow

The tab displays important indicators for the inflow and outflow of the selected tank.

KPIs Outflow/Inflow Chart hourly Chart daily

From date 12/30/2010 To date 3/30/2011 ☒ Show available period

Actual period between first and last measurement: from 12/30/2010 to 3/30/2011

Average inventory level	51.2	%
Average delivery quantity	50.6	%
Turnover rate	9	
Average rate of usage	73	%
Maximum value	84.6	%
Minimum value	7.6	%
Safety stock reached	2	
Average safety stock reached	3.3	%

PS0000971en

Using the **From date** and **To date** fields, you can enter a period for which you want to analyze the values. If you enable the **Show available period** check box all the saved values will be analyzed.

### Description of fields

Field	Description
Average inventory level	Displays the average amount for the period entered.
Average delivery quantity/ Average disposal quantity	<ul style="list-style-type: none"> <li>Standard tanks: Displays the average delivery quantity for the period entered.</li> <li>Recycling tanks: Displays the average disposal quantity for the period entered.</li> </ul> <p>To ensure that fluctuating changes in the level do not falsify the result, the value entered for the <b>Hysteresis</b> field is factored into the calculation.</p>
Turnover rate	<p>Displays the turnover rate for the period entered.</p> <ul style="list-style-type: none"> <li>Calculation for standard tanks: Total outflow/Average inventory level</li> <li>Calculation for recycling tanks: Total inflow/Average inventory level</li> </ul>
Average rate of usage	<p>Displays the average rate of usage for the period entered.</p> <ul style="list-style-type: none"> <li>Calculation for standard tanks: <math>(\text{Average inventory level} / \text{Optimum}) * 100</math> If "Optimum" has been disabled or if the value is "0", the system calculates with the capacity entered.</li> <li>Calculation for recycling tanks: <math>(\text{Average inventory level} / \text{Safety stock}) * 100</math> If "Safety stock" has been disabled, the system calculates with the capacity entered.</li> </ul>
Maximum value	Maximum value for the period entered.
Minimum value	Minimum value for the period entered.
Safety stock reached	<p>Number of times the safety stock has been undershot in the case of standard tanks and exceeded in the case of recycling tanks for the period entered.</p> <ul style="list-style-type: none"> <li>Valuation for standard tanks: Measured value &lt; value entered for safety stock</li> <li>Calculation for recycling tanks: Measured value &gt; value entered for safety stock</li> <li>All measured values within the set hysteresis are not counted (→ 96).</li> <li>If "Safety stock" has been disabled, the <b>Safety stock reached</b> field is empty.</li> <li>If the value for "Safety stock" is "0", the <b>Safety stock reached</b> field is "0".</li> </ul>
Average safety stock reached	<p>Standard tanks: Average value by which the safety stock was undershot for the period entered.</p> <p>Recycling tanks: Average value by which the safety stock was exceeded for the period entered.</p> <p>If "Safety stock" has been disabled, the <b>Average safety stock reached</b> field is empty.</p> <p>If the value for "Safety stock" is "0", the <b>Average safety stock reached</b> field is "0".</p>

## 11.4 Chart hourly

This chart shows the outflow, inflow or the difference between the inflow and outflow for the period selected, depending on the option selected.



PS0000972en

Select the period of time for **Chart hourly** via the **Period selection** field. You can select a period of 1, 2, 3 or 4 days.


Select the type of chart via the **Column** or **Line** buttons.

If you move the cursor over a graph in the chart, a window appears with the name of the graph, the specific measured value and the time stamp.



## 11.5 Chart daily

This chart shows the outflow, inflow or the difference between the inflow and outflow for the period entered, depending on the option selected.





Using the **From date** and **To date** fields, specify a period for **Chart daily**.

Select the type of chart via the **Column** or **Line** buttons.

If you move the cursor over a graph in the chart, a window appears with the name of the graph, the specific measured value and the time stamp.


## 12 Viewing tank locations on the map – "Map" workplace


 The **Map** menu item is available to people with **Read only**, **Scheduler** or **Operator** configured as their user role.

 **Manual values** are displayed in blue color followed by the text **MAN**.


You can use this menu item to get an overview of the locations of the individual tanks on Google Maps. The tanks can be filtered by tank group, product, supplier and location. You can call up detailed information on every tank, such as value, plan delivery or disposal.

### 12.1 Viewing a map and associated information

 The following conditions must be met to display a tank or an aggregated tank on the map:

- The tank or aggregated tank must be assigned to a specific location. The user must have the geographical coordinates (degree latitude and longitude) of the location.  
→  108.
- The tank or aggregated tank must be assigned to a tank group.

1. Click the **Workplace** menu in the Navigation window.
2. Click the **Map** menu item. A map with an overview of the tank locations is displayed.




S67\_EN\_BA00050S\_0211

- The map view is automatically adapted to the filter criteria so that you see all the tanks for the locations in question.
- If no tanks are found for the filter criteria, the message "No tanks found!" is displayed. The filter criteria are reset to the values previously used.

## 12.2 Tank details


1. If you click a tank on the map, this opens up a window containing more detailed information.
2. The following data are displayed for the tank:





- Scroll icons if there are several tanks in one location.
  - Tank name along with the number and total quantity of tanks if there are several tanks in one location.
  - Location
  - Value and unit
  - Time stamp and time zone
  - Product
  - Status of the tank with the symbol for the event.
  - Amount and unit, deliverable (for standard tanks) or recyclable (for recycling tanks) if a disposal or delivery is not planned.  
PD amount and unit as well as PD (date and time of delivery/disposal) if a delivery or disposal is planned.
  - **Plan delivery** or **Plan disposal** button.
3. To close the window, click the **Close** icon on the top right.

## 12.3 Planning a disposal or delivery

1. Click the **Plan delivery** or **Plan disposal** button in the window with the tank details.
2. The **Plan delivery** or **Plan disposal** dialog box appears:




S68-2\_EN\_BA000505\_0211

3. Click the  button.
4. Select the **Date** for the planned delivery/disposal in the calendar, or enter the date manually.
5. The **Value**, **Amount** and **Range** fields are computed automatically. These fields are recomputed if you change the date.
6. You can update the range, enter a comment and save or reject the changes for the amount entered, →  68.


## 13 Managing master data

### 13.1 Managing companies

 Only people whose user role is configured as **Master data** can create, change and delete companies.

#### 13.1.1 Creating a company

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Company** menu item.
3. The following detail view is displayed in the Application window:



The screenshot shows the 'Configuration >> Company' window. It contains a table with three columns: Name, City, and Description. The table lists three companies: Buyer AG (Zürich, Buyer Chemicals), Mustermann AG (Basel, Compounds & Mixes), and Supplier AG (St. Gallen, Supplier Chemicals). Below the table is a 'Company details' tab. The 'Company details' tab is currently in view and shows the details for 'Buyer AG'. The details include: Name (Buyer AG), Street (Nebenstrasse 55), City (Zürich), Description (Buyer Chemicals), Contact (empty), Identifier (empty), Zip code (8001), Identifier agency (AssignedByBuyer), State (empty), and Country (CH).

Name	City	Description
Buyer AG	Zürich	Buyer Chemicals
Mustermann AG	Basel	Compounds & Mixes
Supplier AG	St. Gallen	Supplier Chemicals

Company details


Name \* Buyer AG Street Nebenstrasse 55 Description Buyer Chemicals


Contact City Zürich

Identifier Zip code 8001

Identifier agency \* AssignedByBuyer State Country CH

S69\_EN\_BA000505\_0211

4. Click the  button on the **Company details** tab.
5. The tab is displayed in the edit mode.



The screenshot shows the 'Company details' tab in edit mode. The details include: Name (empty), Street (empty), City (empty), Description (empty), Contact (empty), Identifier (empty), Zip code (empty), Identifier agency (Other), State (empty), and Country (empty).

Company details

Name \* Street Description

Contact City



Identifier Zip code

Identifier agency \* Other State Country

PS0000845aen

6. Here, you can enter company data such as:

- **Name** (obligatory): Name of the company
- **Contact**: Select a contact person from the picklist.  
The contact person has to have been added beforehand using the **User** menu item and assigned to the **Company**.
- **Identifier**: Company ID to be used in the CIDX reports
- **Identifier agency**: Selection of organization responsible for managing the identifier for the companies. The selection complies with the CIDX standard. The identifier agency is required to create CIDX reports.
- **Street**
- **City**
- **Zipcode**
- **State**
- **Country**
- **Description**: You can enter a multiline description here.



7. Click  to save your entries. Click  to abort the process.

### 13.1.2 Changing a company

For details →  27

### 13.1.3 Deleting a company

For details →  31

 A company can only be deleted if no more users are assigned to this company. If you still want to delete the company, you first have to delete the users assigned to this company. The  button is only displayed for a company which can be deleted.

### 13.1.4 Copying a company

For details →  32

## 13.2 Managing users



Only people whose user role is configured as **Master data** can create, change and delete users.

### 13.2.1 Creating a user

1. Click the **Configuration** menu in the Navigation window.
2. Click the **User** menu item.
3. The following detailed view appears in the Application window:

The screenshot shows the 'Configuration >> User' window. At the top, there's a 'Company' dropdown set to 'All'. Below is a table with columns: Login name, Name, First name, and Company. The table lists five users, all from 'Mustermann AG'. Below the table is a 'User details' tab, which is active. It contains a 'Make me a SupplyCare user' button and a form with fields for Title, Salutation, First name, Name, Language, E-mail, Phone, Fax, Mobile, Street, City, Zip code, State, and Country. The 'Login allowed' checkbox is checked. The 'Login name' field is filled with 'e03000053'.

User\_details\_BA00050SEN

4. Select the **User details** tab.
5. Click the button.
6. The tab is displayed in the edit mode.





The screenshot shows the 'User details' tab in edit mode. The form fields are now empty, except for 'Language' (set to 'EN'), 'Company' (set to 'Mustermann AG'), 'Street' (set to 'Hauptstrasse 144'), 'City' (set to 'Basel'), 'Zip code' (set to '4416'), and 'Country' (set to 'CH'). The 'Login allowed' checkbox is now unchecked.

S71-2\_EN\_BA00050S\_0211



7. Here, you can enter data on the user such as:


- Title
- Salutation
- First name (obligatory)


- **Surname** (obligatory): Surname of user
- **Login allowed**: If the **Login allowed** check box is activated, the **Confirmed** check box and the **Login name** field are displayed.  
Once the user has been created and the **Login allowed** check box has been activated, Endress+Hauser checks whether the user is authorized for SupplyCare Hosting. If the user is authorized, the user receives his or her Login name from Endress+Hauser via the e-mail address specified here.  
If the **Login allowed** field is deactivated, the **Confirmed** check box and **Login name** field are no longer displayed.
- **Confirmed** (read only): This check box only appears once the Login allowed check box has been activated. The check box is activated by Endress+Hauser.
- **Login name** (read only): This field only appears once the Login allowed check box has been activated. The **Login name** is displayed once the user has been confirmed for SupplyCare Hosting by Endress+Hauser.
- **Language**
- **E-Mail** (obligatory)
- **Phone**
- **Fax**
- **Mobile**
- **Company** (obligatory): The company is automatically pre-populated.
- **Street**
- **City**
- **Zipcode**
- **State**
- **Country**

8. Click  to save your entries. Click  to abort the process.
9. Select the **User roles** tab to assign a role to the user (→  88).
10. Select the **Tank groups** tab to assign a tank group to the user (→  89).

### 13.2.2 Assigning user roles



One or more user roles can be assigned to a user in the **User roles** tab. The user receives different authorizations depending on the user role (→  18 and →  132). On this tab you can also specify whether the user should receive alarms via e-mail.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **User** menu item.
3. Select the **User roles** tab.
4. Click the  button.
5. The tab is displayed in the edit mode.




Configuration\_user\_roles\_BA00050EN






6. Activate the appropriate **check box** to assign the user a user role. You can assign multiple user roles to a user at the same time.
7. Click  to save your entries. Click  to abort the process.

### 13.2.3 Changing a user

For details →  27

### 13.2.4 Deleting a user

For details →  31

-  A user can only be deleted if he or she is not assigned to any tank group or any company as a contact person. The user must not be logged in. The tank group assignment can be canceled in the **Tank groups** tab. The company assignment can be canceled in the **Company** menu item. The  symbol is only displayed for a user who can be deleted.


### 13.2.5 Copying a user

For details →  32

### 13.2.6 Assigning tank groups to a user and setting up notifications for tank events


You can assign one or more tank groups to the user using the **Tank groups** tab. On this tab you can also specify the tank events which the user should be informed about.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **User** menu item.
3. In the table, click the user whose assignment you want to edit.
4. Select the **Tank groups** tab.



Assign	Tank group	Description	By e-mail	PP	SP	SST	TF	PDL	PDE
<input checked="" type="checkbox"/>	Recycling tanks		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	Standard tanks		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>



ST4\_EN\_BA00050S\_0211

5. Click the  button.
6. The tab is displayed in the edit mode.



Assign	Tank group	Description	By e-mail	PP	SP	SST	TF	PDL	PDE
<input checked="" type="checkbox"/>	Recycling tanks		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	Standard tanks		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

of 2

S74-2\_EN\_BA000505\_0211

7. Activating the **check box** in the **Assign** column assigns a tank group to the user. Deactivate the **check box** to undo the assignment. The assigned tank groups are listed in the "Workplace - Tank" view.
8. Activate the **By E-Mail** check box if you want the user to also be informed about tank events by e-mail.
9. Enable the check boxes corresponding to the events for which the user should receive notification.
  - **PP** (plan point)
  - **SP** (ship point)
  - **SST** (safety stock)
  - **TF/OF** (Tank freeze/object freeze): comprises all the information regarding tank freeze/object freeze events
  - **PDL** (planned delivery/disposal loop): comprises all the new deliveries/disposals which have been planned or deleted
  - **PDE** (planned delivery/disposal events): comprises all the early, late, missed and completed deliveries/disposals
10. Click  to save your entries. Click  to abort the process.




## 13.3 Managing tanks

-  Only people whose user role is configured as **Master Data** can create, change and delete tanks.
-  Depending on your configuration, **Objects** are displayed instead of **Tanks**. For more information refer to the appropriate chapter in the Service Manual for System administration.

### 13.3.1 Creating a tank


There are several ways to create a tank in SupplyCare: you can use the Tank setup wizard or the tabs in the **Configuration** menu, **Tank** menu item.

By using the Tank setup wizard you can easily select the tank settings for a new tank: the basic settings **Tank name**, **Capacity**, **Tank type** and **Tank group** and other optional tank settings. The settings can be changed subsequently via the tabs mentioned above.


-  A tank always has to be assigned to a tank group since you can only assign tank groups to a user.
-  The **"Location"**, **"Buyer"**, **"Supplier"** and **"Product"** first have to be created before you can select elements for these fields. The **Buyer** and **Supplier** are created as a Company (→  85).

#### a) Creating a tank using the Tank setup wizard


1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. The detail view is displayed in the Application window.
4. Click the **Tank setup wizard** button.


-  The Tank wizard **cannot** be used to create aggregated tanks.

5. The dialog window **Step 1 out of 2: Basic tank settings** is displayed:



Configuration\_tank\_wizard\_BA00050EN



6. Enter the following data:  
**Tank name** (mandatory), **Capacity** (mandatory), **Tank type** (→  95)


7. By activating the **check box** in the **Assign** column, assign the tank to a tank group that already exists or create a new tank group if applicable.
8. Click the  button to create a new tank group.
9. The **Create new tank group** dialog window appears:



The dialog window titled "Create new tank group" contains two input fields: "Name \*" and "Description". The "Name \*" field is a single-line text box, and the "Description" field is a multi-line text box. There are also icons for saving (floppy disk) and canceling (X) at the top left.




Configuration\_tank\_wizard\_2\_BA00050EN

10. Enter the following data:  
**Name** (mandatory), **Description**
11. Click  to save your entries. Click  to abort the process.
12. Click **Next** to enter more optional tank settings, click **Cancel** to cancel the process or click **Finish** to finish creating the tank.
13. When you click **Next** the **Step 2 out of 2: Optional tank settings** dialog window appears:





The dialog window titled "Step 2 out of 2: Optional tank settings" contains various configuration options for a tank. On the left, there are fields for "Tank name \*" (filled with "Product IC 500"), "Location", "Buyer", "Supplier", "SDT" (with a "Days" dropdown), and "Product". Below these are checkboxes for "Use product unit", "Tank type" (Standard tank selected, Recycling tank), "ADI/ADO based on" (14 Days), "Include negative values", and "Activate forecast" (checked). On the right, there are fields for "Capacity \*" (20000), "Optimum", "Plan point", "Ship point", "Safety stock", "Hysteresis", and "Unit". In the center, there is a warning icon and the text "No tank picture selected". At the bottom, there are buttons for "Back", "Next", "Cancel", and "Finish".

Configuration\_tank\_wizard\_3\_BA00050EN

14. Enter the data as described below →  93.
15. Click the appropriate  button to create a new location, buyer, supplier and product.
16. Select a graphic depicting the appropriate tank shape (→  96).
17. Click **Back** to go back to the **Step 1 out of 2: Basic tank settings** dialog window, click **Cancel** to cancel the process or **Finish** to finish creating the tank.

### b) Creating a tank using the tabs in the Configuration menu, Tank menu item

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. The detail view is displayed in the Application window. In the lower section, select the **Tank details** tab.
4. Click the  button.
5. The tab is displayed in the edit mode.







Configuration\_tank\_tank\_details\_9\_BA00050EN


6. Here, you can enter data on the tank such as:

- **Tank name** (obligatory)
- **Location**: Select the location from the picklist.
- **Buyer**: Select a buyer (company) from the picklist.
- **Supplier**: Select a supplier (company) from the picklist.
- **SDT** (Standard delivery/disposal time)
- **Product**: Select a product from the picklist.
- **Use product unit**: If this option is activated, the unit of the selected product is automatically used in the **Unit** field. The values in the fields **Capacity**, **Optimum**, **Plan point**, **Ship point**, **Safety stock** and **Hysteresis** are converted based on the density entered for the product.
- **Tank type**: By activating the **Standard tank** check box, you specify that the tank is a standard type of tank, and by activating the **Recycling tank** check box you specify that the tank is a recycling tank. The event messages and the way the inventory chart and levels are displayed are adapted to this tank type (→ 95).
- **ADI(/ADO based on**: 14 days is the standard value specified here. This period is used for extrapolating in the inventory chart (→ 38).
- **Include negative values**: If this option is enabled, negative measuring values are included in the ADI/ADO calculations.
- **Activate forecast**: If this option is enabled, a forecast of the inventory is displayed in the **Inventory Chart** tab.  
The enabled forecast is displayed with a green button; the disabled forecast is displayed with a red button. This option can be changed in edit mode by clicking the green or red button.
- **Capacity** (obligatory)
- **Optimum** (for standard tanks only)
- **Plan point**
- **Ship point**(for standard tanks only)
- **Safety stock**

– **Hysteresis:** The hysteresis serves to prevent constant event messages, e.g. due to a fluctuating level (→  96).

– **Unit**



7. In the case of a standard tank it is possible to deactivate the **Optimum**, **Plan point**, **Ship point** and **Safety stock** input fields individually, and the **Safety stock** and **Plan point** fields in the case of a recycling tank. For this purpose, click the button to the right of the specific input field. This field then becomes gray just like the button. It is no longer possible to enter information. These input fields can be activated by clicking the gray button in question.
8. Select a graphic depicting the appropriate tank shape (→  96).
9. Click  to save your entries. Click  to abort the process.
10. Select the **Tank groups** tab.
11. Click the  button.
12. The tab is displayed in the edit mode.



Assign	Name	Description
<input checked="" type="checkbox"/>	All Tanks	
<input checked="" type="checkbox"/>	US Operations	
<input type="checkbox"/>	APAC Operations	
<input type="checkbox"/>	EU Operations	


of 4

S77\_EN\_BA00050S\_0211

13. Activating the **check box** in the **Assign** column assigns the tank to a tank group.
14. Click  to save your entries. Click  to abort the process.



### Standard tank and recycling tank

SupplyCare distinguishes between standard tanks and recycling tanks. From a standard tank, the product is withdrawn. For a recycling tank, the tank is filled with the product. Activating the **Recycling** check box turns the standard tank into a recycling tank. The display logic in the inventory chart and the notification logic are changed according to the following illustration.



Hysteresis




The hysteresis pertains solely to event notifications. The hysteresis prevents multiple triggering of an event notification, e.g. due to fluctuating levels. The hysteresis applies to the following events: Plan point, Ship point and Safety stock

Standard tank	Recycling tank
<div><p>PS0000902en</p></div>	<div><p>PS0000903en</p></div>
<div><p>a. The level falls below the limit value for the Plan point. The "Plan point reached" event is triggered. The status of the event is set to <b>Open</b>.</p><p>b. The level climbs back above the limit value for the Plan point. The status for event a) remains <b>Open</b>. The tank status switches to "OK" (green).</p><p>c. The level falls back below the limit value for the Plan point. No new event is triggered. The status for event a) remains <b>Open</b>. The tank status switches to "Plan point reached" (yellow). No new event is triggered, as the level has not first climbed above the limit value for the Plan point plus the hysteresis.</p><p>d. The level rises above the limit value for the Plan point plus the hysteresis. Event a) now assumes the status <b>Done</b>.</p><p>e. The level falls back below the limit value for the Plan point. A new "Plan point reached" event is triggered. The status of the event is set to <b>Open</b>.</p></div>	<div><p>a. The level climbs above the limit value for the Plan point. The "Plan point reached" event is triggered. The status of the event is set to <b>Open</b>.</p><p>b. The level falls below the limit value for the Plan point. The status for event a) remains <b>Open</b>. The tank status switches to "OK" (green).</p><p>c. The level climbs back above the limit value for the Plan point. No new event is triggered. The status for event a) remains <b>Open</b>. The tank status switches to "Plan point reached" (yellow). No new event is triggered, as the level has not first fallen below the limit value for the Plan point minus the hysteresis.</p><p>d. The level falls below the limit value for the Plan point minus the hysteresis. Event a) now assumes the status <b>Done</b>.</p><p>e. The level climbs back above the limit value for the Plan point. A new "Plan point reached" event is triggered. The status of the event is set to <b>Open</b>.</p></div>

13.3.2 Selecting and deleting a depicted tank shape

Selecting a depicted tank shape

In the **Tank details** tab, you can select a graphic depicting the appropriate tank shape for a tank created. The selected graphic is also displayed in the "Workplace – Tank" view in the **Tank details** tab.

 The "Vertical bar"  and "Horizontal bar"  tank pictures can be used if you prefer general symbols.










The "Digital display" tank picture  can be used if you prefer the value to be displayed in digital format.





Please note that the digital display can show a maximum of 17 digits, including commas and thousand separators. If the value is longer than 17 digits, some or all of the decimal places are not displayed. If the value can still not be displayed with 17 digits even when the decimal places are omitted, the following appears on the display: #####




The speedometer or gauge  can also be used to display non-tank asset use, e.g. pressure.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. Select the **Tank details** tab.
4. Click the  button.
5. The tab is displayed in the edit mode.
6. Click the  button.
7. The **Select tank picture** dialog box is displayed.
8. Click the picture of the tank shape that applies for the tank you created.
9. The selected graphic is added to the **Tank details** tab.
10. Click  to save your selection. Click  to abort the process.


### Deleting a depicted tank shape

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. Select the **Tank details** tab.
4. Click the  button.
5. The tab is displayed in the edit mode.
6. Click the  button in the **Tank shape** graphic.
7. The prompt "Do you really want to delete?" is displayed.
8. Click **OK** to delete the graphic. The "No tank picture selected" graphic is displayed. Click **Cancel** to abort the process.
9. Click  to save your changes. Click  to abort the process.





The picture is only deleted if you save your changes with  button.

### 13.3.3 Changing tank-tank group assignment


1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the table, click the tank whose assignment you want to change.
4. Select the **Tank groups** tab.
5. Click the  button.
6. The tab is displayed in the edit mode.




- 7. Activating the check box in the **Assign** column assigns the tank to a tank group. Deactivate the check box to undo the assignment.
- 8. Click  to save your entries. Click  to abort the process.

13.3.4 Configuring secondaries

If secondary values have been assigned to the tank via the "Gateway configuration" menu item in the "Assign measuring point to tank" tab, these secondary values are displayed in the "Secondaries" tab.

- 1. Click the **Configuration** menu in the Navigation window.
- 2. Click the **Tank** menu item.
- 3. In the lower section of the application window, select the **Secondaries** tab.
- 4. Click the  button.
- 5. The tab is displayed in the edit mode.



- 6. You can enter additional information on the secondary values here, such as:


- **Name:** The name is displayed in the "Workplace – Tank" view in the **Tank name** column and in the **Inventory chart** tab.
- **Limit 1:** See the following section: Display for "Descending limits" and "Ascending limits".
- **Limit 2:** See the following section: Display for "Descending limits" and "Ascending limits".

- **Hysteresis**
- **Unit** (read only)
- **Upswing**: Switch between descending and ascending limits.

### Display for "Descending limits" and "Ascending limits"

Using the **Upswing** check box, choose between the "Descending limits" and "Ascending limits" display.


"Upswing" check box	Description	Column in the "Workplace – Tank" view
Descending limits: "Upswing" check box disabled	Limit 1	PP (plan point)
	Limit 2	SST (safety stock)
Ascending limits: "Upswing " check box enabled	Limit 2	PP (plan point)
	Limit 1	SST (safety stock)



PS0000993en

### 13.3.5 Configuring tank freeze events

Tank freeze events are generated using an internal limit based on the latest measurement received for the tank within a defined time span, e.g. to recognize material theft, leakage or defects.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the lower section of the application window, select the **Tank freeze** tab.
4. Click the  button.
5. The tab is displayed in the edit mode.

6. Here you can enter data to configure tank freeze events, such as:

- **Activate:** If this option is enabled, tank freeze events are enabled.  
The enabled tank freeze events are displayed with a green button; the disabled tank freeze events are displayed with a red button. This option can be changed in edit mode by clicking the green or red button. The default setting for this option is "disabled".
- **Delta calculation:** Select **absolute** to specify the **Freeze event delta** as a fixed value in the unit of the tank. Select **percentaged** to specify the **Freeze event delta** as a percentage of the configured tank capacity. The default setting for this option is **absolute**.
- **Freeze event delta:** (obligatory) Enter a positive numeric value.  
At the beginning of the monitoring time the last measured tank value (e.g. the tank level) is saved ("frozen"). This "frozen" measurement is compared with the current measurements during the monitoring time. If the difference between the frozen measurement and the current measurement exceeds the **Freeze event delta** (positive or negative), a tank freeze event is generated.
- **Unit:** Displays the unit configured for the tank capacity if **Delta calculation** is set to absolute. Displays "%" otherwise.
- **Time zone:** Select the time zone to be used for the monitoring times configured under **Repetition rule**.
- **Repetition rule:** (obligatory) Select a rule for the repetition of the monitoring time.  
**Daily:** Select a **From time** (start time) and a **To time** (end time) for the daily monitoring for tank freeze events.  
The **From time** must represent an earlier time point than the **To time**. For a daily monitoring time from a time point before midnight and after midnight, configure a **Weekly on every...** repetition rule.  
**Weekly on every...:** Configure monitoring times for tank freeze events for each weekday individually.  
For more details on the configuration of the **Weekly on every...** repetition rule, refer to the following chapter "Configuring the Weekly on every... repetition rule" (→ 100).

7. Click to save your configuration. Click to abort the process.

Use the **Copy to other tanks** button to copy the **Tank freeze** configuration to other tanks. For more details, refer to the chapter "Copying the Tank freeze configuration to other tanks" (→ 101).

### Configuring the Weekly on every ... repetition rule

Configure monitoring times for tank freeze events for each weekday individually.

- Select the weekdays for which to configure the monitoring times.
- Select a **From time** (start time) and a **To time** (end time) for the monitoring for tank freeze events of the selected day. If the **To time** is smaller than the **From time**, the monitoring time extends into the next weekday. E.g. if for a selected Monday a **From time** of 18:00 and a **To time** of 6:00 is configured, the monitoring time runs from 18:00 on Monday to 6:00 on Tuesday even if the Tuesday is not selected.
- Select **until end of day** for a selected weekday to set the end of the monitoring time to 23:59, i.e. substituting **To time** with 23:59.  
If **until end of day** is selected, **To time** is disabled and hidden.
- Select **all day** for a selected weekday to set the monitoring time from 0:00 to 23:59, i.e. substituting **From time** with 0:00 and **To time** with 23:59.  
If **all day** is selected, **From time** and **To time** are disabled and hidden.


### Copying the Tank freeze configuration to other tanks

1. Click the **Copy to other tanks** button in the **Tank freeze** tab.
2. The dialog window **Step 1 out of 2: Copy 'Tank freeze' configuration to other tanks** is displayed:

3. The window displays the last saved Tank freeze configuration.

Change the configuration if desired.

- Click **Next** to proceed to the next step, click **Cancel** to cancel the process.
- When you click **Next**, the dialog window **Step 2 out of 2: Copy 'Tank freeze' configuration to other tanks** is displayed:



6. Select the tanks to which you want to copy the Tank freeze configuration by activating the check boxes before the tanks.  
You can filter the displayed tanks by **Tank group**, **Location**, **Product** or **Supplier**.
7. Click **Back** to return to the previous step, click **Cancel** to cancel the process or **Finish** to copy the Tank freeze configuration to the selected tanks.


### 13.3.6 Adding, opening and deleting files and other information for a tank


Using the **Tank notes** tab, you can add additional information for a tank and a maximum of five files. The information entered here and the attached files are also displayed in the "Workplace – Tank" view, **Notes and files** tab.

The files must meet the following requirements:


- File formats supported: doc, xls, pdf, ppt, jpg, gif, png, bmp or txt.
- Maximum file size: 5 MB

## Adding a file

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. In the table, click the tank for which you want to add a file.
4. Select the **Tank notes** tab.
5. Click the  button.







SB2\_EN\_BA00050S\_0211



6. The **Tank notes** tab is displayed in the edit mode.
7. Enter a description for the **Notes**, **Data 1**, **Data 2** and **Data 3** fields.
8. Click the  button in the table.
9. The **Upload new file** dialog box is displayed.
10. Click the **Search** button.
11. Select the **File** in your directory. The file name is displayed in the **Name** column in the table.
12. Click the **Upload new file** button.
13. The file is listed in the table with information on the file format, file name, file size and the date the file was last changed.



### Opening or saving a file

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. Select the **Tank notes** tab.
4. Click the **File name** (hyperlink) in the **Name** column in the table.
5. A dialog box opens. Here you can choose whether you want to open the file or save it.
6. Click **OK** to open or save the file. Click **Cancel** to abort the process.


### Deleting a file

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank** menu item.
3. Select the **Tank notes** tab.
4. Click the  button.
5. The **Tank notes** tab is displayed in the edit mode.
6. In the table, enable the check box for the file that you want to delete.
7. Click the  button.
8. The prompt "Do you really want to delete?" is displayed.
9. Click **OK** to delete the file. Click **Cancel** to abort the process.
10. Click  to save your changes. Click  to abort the process.


 The file is only deleted if you save your changes by pressing the  button.

 You can change or delete descriptions in the **Notes**, **Data 1**, **Data 2** and **Data 3** fields in the editing mode. Click  to save the changes.

### 13.3.7 Changing a tank

For details →  27


### 13.3.8 Deleting a tank


For details →  31

### 13.3.9 Copying a tank

For details →  32

## 13.4 Managing aggregated tanks


 Only people whose user role is configured as **Master Data** can create, change and delete aggregated tanks.


 Depending on your configuration, **Aggregated Objects** are displayed instead of **Aggregated Tanks**. For more information refer to the appropriate chapter in the Service Manual for System administration.


### 13.4.1 Creating an aggregated tank

 The **Location**, **Buyer**, **Supplier** and **Product** first have to be created before you can select elements for these fields. The **Buyer** and **Supplier** are created as a Company →  85).

 If you have assigned a tank to an aggregated tank, this tank is removed from the **Tank assignment** tabs under the **Tank**, **Tank group** and **Report** menu items.

 If you would like to make changes to a tank that is assigned to an aggregated tank, you first have to remove the tank from the tank list.

 If you want to assign a tank, which is already assigned to a tank group, to an aggregated tank, this tank must be removed from the tank group.

 An aggregated tank always has to be assigned to a tank group since you can only assign tank groups to a user.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Aggregated tank** menu item.
3. The following detail view is displayed in the Application window:



Configuration >> Aggregated tank

Product: All Buyer: All Supplier: All

Tank name	Notes	Location
IC 03-mix		HQ


1 of 1

Tank details | Tank list | Tank freeze | Tank groups | Tank notes

Tank name: IC 03-mix  
 Location: HQ  
 Buyer: Buyer AG  
 Supplier: Supplier AG  
 SDT: 5 Days  
 Product: Product IC 030  
 Use product unit: ☒  
 Tank type: ☒ Standard tank ☐ Recycling tank  
 ADI/ADO based on: 14 Days  
 Include negative values: ☐  
 Activate forecast: ☒

Capacity: 750000  
 Optimum: 38000  
 Plan point: 20000  
 Ship point: 15000  
 Safety stock: 8500  
 Hysteresis: 0  
 Unit: l

Configuration\_aggregated\_tank\_BA00050EN

4. In the lower section of the application window, select the **Tank details** tab.
5. Click the  button.
6. The tab is displayed in the edit mode.

Tank details | Tank list | Tank groups | Tank notes

Tank name:   
 Location:   
 Buyer:   
 Supplier:   
 SDT:  Days  
 Product:   
 Use product unit: ☐  
 Tank type: ☒ Standard tank ☐ Recycling tank  
 ADI/ADO based on: 14 Days  
 Include negative values: ☐  
 Activate forecast: ☒




No tank picture selected




Capacity: 0  
 Optimum: 0  
 Plan point: 0  
 Ship point: 0  
 Safety stock: 0  
 Hysteresis: 0  
 Unit:


Configuration\_aggregated\_tank\_2\_BA00050EN

7. Here, you can enter data on the aggregated tank such as:

- **Tank name** (obligatory)
- **Location**: Select the location from the picklist.
- **Buyer**: Select a buyer (company) from the picklist.
- **Supplier**: Select a supplier (company) from the picklist.
- **SDT** (Standard delivery/disposal time)
- **Product**: Select a product from the picklist.
- **Use product unit**: If this option is activated, the unit of the selected product is automatically used in the **Unit** field.




- **Tank type:** By activating the **Standard tank** check box, you specify that the aggregated tank is a standard type of tank, and by activating the **Recycling tank** check box you specify that the tank is a recycling tank. The event messages and the way the inventory chart and levels are displayed are adapted to this tank type (→  95).
- **ADI(/ADO based on:** 14 days is the standard value specified here. This period is used for extrapolating in the inventory chart (→  38).
- **Include negative values:** If this option is enabled, negative measuring values are included in the ADI/ADO calculations.
- **Activate forecast:** If this option is enabled, a forecast of the inventory is displayed in the **Inventory Chart** tab.  
The enabled forecast is displayed with a green button; the disabled forecast is displayed with a red button. This option can be changed in edit mode by clicking the green or red button.
- **Capacity** (read only)
- **Optimum**
- **Plan point**
- **Ship point**
- **Safety stock**
- **Hysteresis:** (→  96)
- **Unit** (obligatory)


8. In the case of a standard tank it is possible to deactivate the **Optimum**, **Plan point**, **Ship point** and **Safety stock** input fields individually, and the **Safety stock** and **Plan point** fields in the case of a recycling tank. For this purpose, click the button to the right of the specific input field. This field then becomes grey just like the button. It is no longer possible to enter information. These input fields can be activated by clicking the grey button in question.
9. Click  to save your entries. Click  to abort the process.
10. Select the **Tank list** tab.
11. Click the  button.
12. The tab is displayed in edit mode in the lower part of the Application window.




Assign	Tank name	Notes	Location
<input checked="" type="checkbox"/>	IC 03002		HQ
<input checked="" type="checkbox"/>	IC 03003		HQ
<input type="checkbox"/>	LNG 01000		APAC Operations SG
<input type="checkbox"/>	IC 01000		US Operations North
<input type="checkbox"/>	IC 03000		HQ



SB5-2\_EN\_BA000505\_0211

13. Activating the appropriate check box in the **Assign** column assigns the tanks to the aggregated tank.  
 Only the same type of tanks - i.e. standard tanks or recycling tanks - are displayed in the tank list. In the **Measuring point details** tab, these tanks must be assigned a measuring point and the same "Engineering unit (for application)" as has been assigned to the aggregated tank. Only these tanks can be added to the aggregated tank.
14. Click  to save your entries. Click  to abort the process.
15. Select the **Tank groups** tab.

16. Click the  button.
17. The tab is displayed in the edit mode.



S87\_EN\_BA00050S\_0211


18. Activating the **check box** in the **Assign** column assigns the tank to a tank group.
19. Click  to save your entries. Click  to abort the process.

### 13.4.2 Selecting and deleting a depicted tank shape


For details →  96


### 13.4.3 Adding, opening and deleting files and other information for an aggregated tank

Using the **Tank notes** tab, you can add additional information for an aggregated tank and a maximum of five files. The information entered here and the attached files are also displayed in the "Workplace – Tank" view, **Notes and files** tab.



For information on adding, opening, saving or deleting a file, →  102.

### 13.4.4 Changing aggregated tank-tank group assignment

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Aggregated tank** menu item.
3. In the overview table, click the aggregated tank whose assignment you want to change.
4. Select the **Tank groups** tab.
5. Click the  button.
6. The tab is displayed in the edit mode.



S87\_EN\_BA00050S\_0211

7. Activating the **check box** in the **Assign** column assigns the aggregated tank to a tank group. Deactivate the **check box** to undo the assignment.
8. Click  to save your entries. Click  to abort the process.

### 13.4.5 Configuring aggregated tank freeze events

For details →  99

### 13.4.6 Changing an aggregated tank

For details →  27


### 13.4.7 Deleting an aggregated tank

For details →  31


### 13.4.8 Copying an aggregated tank

For details →  32

## 13.5 Managing locations

 Only people whose user role is configured as **Master Data** can create, change and delete locations.

### 13.5.1 Creating a location


 A tank must be created before you can assign this tank to a location.

However, you can first create the location and then assign the tanks to a location at a later date.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Location** menu item.
3. The following detail view is displayed in the Application window:

The screenshot shows the 'Configuration >> Location' window. At the top, there is a 'Company' dropdown menu set to 'All'. Below it is a table with columns: Company, City, Country, and Time zone. The table contains five entries for 'Mustermann AG' with locations: Birsfelden (Switzerland, UTC+01:00), Madrid (Spain, UTC+01:00), Leeds (GB, UTC+01:00), California (USA, UTC-05:00), and Bangkok (Thailand, UTC+08:00). Below the table is a 'Location details' tab, which is currently selected. The 'Location details' tab shows a form with fields for Name, Company, Manager, Time zone, Street, City, Zip code, State, Country, Latitude, and Longitude. The 'Name' field is filled with 'HQ', 'Company' with 'Mustermann AG', 'Time zone' with '(UTC+01:00) Amsterdam, Berl', 'City' with 'Birsfelden', and 'Country' with 'Switzerland'. The 'Latitude' field is filled with '47.55377190' and 'Longitude' with '7.62790409999999'. A 'Calculate based on address' button is at the bottom right.


S88\_EN\_BA000505\_0211

4. In the lower section of the application window, select the **Location details** tab.
5. Click the  button.
6. The tab is displayed in the edit mode.




The screenshot shows the 'Location details' tab in edit mode. The form fields are empty except for the 'Time zone' field, which is set to 'GMT'. The 'Calculate based on address' button is at the bottom right.


S88-2\_EN\_BA000505\_0211

7. Here, you can enter data for the location such as:



- **Name** (obligatory): Unique identifier of the location
- **Company**: Select the company from the picklist.
- **Manager**
- **Time zone**: Select the time zone for the location from the picklist.  
All time data, particularly time stamps for measurements for tanks at this locations are displayed in this time zone. There is also the preferred time zone for users that is used for time information for events.
- **Street**
- **City**
- **Zipcode**
- **State**
- **Country**
- **Longitude** and **Latitude**: You can save the geographical coordinates for this location here (→  110).

- These coordinates are used to display the location on the overview map (→ 82).
- **Calculate based on address:** The longitude and latitude are calculated automatically. (→ 111).
- These coordinates are used to display the location on the overview map (→ 82).

8. Click  to save your changes. Click  to abort the process.
9. Select the **Tanks at location** tab.
10. Click the  button.
11. The tab is displayed in the edit mode.



S89\_EN\_BA000505\_0211

12. Activating the **check box** in the **Assign** column assigns the tank to the location.  
The table shows the tanks which are already assigned to the location or which are not yet assigned to a location.
13. Click  to save your changes. Click  to abort the process.

### 13.5.2 Adding, opening and deleting files and other information for a location


Using the **Location notes** tab, you can add additional information for a location and a maximum of five files. The information entered here and the attached files are also displayed in the "Workplace – Tank" view, **Notes and files** tab.

For information on adding, opening, saving or deleting a file → 102.



### 13.5.3 Changing location-tank assignment

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Location menu** item.
3. In the overview table, click the location whose assignment you want to change.
4. Select the **Tanks at location** tab.


S90\_EN\_BA000505\_0211

5. Click the  button.
6. The tab is displayed in the edit mode.

S90-2\_EN\_BA000505\_0211

7. Activating the appropriate **check box** in the **Assign** column assigns the tanks to the selected location. Deactivate the **check box** to undo the assignment.
8. Click  to save your entries. Click  to abort the process.

### 13.5.4 Computing the location automatically or entering it manually

 If you change the address data, you must also update the longitude and latitude information.

You can either have the system compute the longitude and latitude automatically based on the address entered, or you can enter this information manually.

#### Computing the location automatically

1. Click the **Based on address** button.
2. The longitude and latitude automatically computed are displayed in a window.

S91\_EN\_BA000505\_0211

3. Click **OK** to confirm the longitude and latitude.

If the longitude and latitude cannot be computed because not enough address information is available, for example, the "Unknown or bad address. Please enter manually" message appears on the screen.

### Entering the location manually


Enter the longitude and latitude in the corresponding fields.

The latitude must be between -85 and 85, and the longitude must be between -180 and 180. You can enter a number with up to 16 decimal places.

## 13.5.5 Displaying the location on the map

For details →  82

## 13.5.6 Changing a location

For details →  27

## 13.5.7 Deleting a location

For details →  31



You can only delete a location if no tanks are assigned to the location.

## 13.5.8 Copying a location

For details →  32

## 13.6 Managing products



Only people whose user role is configured as **Master Data** can create, change and delete products.



People whose user role is configured as **Product-Tank-Assignment** only can change product-tank assignments.

### 13.6.1 Creating a product



A tank must be created before you can assign a product to a tank.



However, you can first create the product and then assign the tanks to a product at a later date.




The **Product name** and the combination of the fields **Identifier** and **Identifier agency** may only be used once in the system.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Product menu** item.
3. The following detail view is displayed in the Application window:






S92\_EN\_BA00050S\_0211


4. In the lower section of the application window, select the **Product details** tab.
5. Click the  button.
6. The tab is displayed in the edit mode.



S92-2\_EN\_BA00050S\_0211

7. Here, you can enter data on the product such as:


- **Product name** (obligatory): Unique identifier of a product
- **Identifier**: Unique product ID to be used in the CIDX reports
- **Identifier agency** (obligatory): Selection of organization responsible for managing the identifier for the companies. The selection complies with the CIDX standard. The identifier agency is required to create CIDX reports.
- **Units** (obligatory)
- **Consistency**
- **Density** (obligatory): The unit can be selected
- **Formula**: Chemical formula of the product
- **Alias**: Another name for the product, e.g. tradename etc.
- **Description**: You can enter a multiline description here.


- 8. Click  to save your entries. Click  to abort the process.
- 9. Select the **Used in tanks** tab.
- 10. Click the  button.
- 11. The tab is displayed in the edit mode.





- 12. Activating the **check box** in the **Assign** column assigns the product to the tank. The table shows the tanks which are already assigned to the product or which are not yet assigned to a product.
- 13. Click  to save your entries. Click  to abort the process.

13.6.2 Changing product-tank assignment

- 1. Click the **Configuration** menu in the Navigation window.
- 2. Click the **Product** menu item.
- 3. In the table, click the product for which you want to change the assignment.
- 4. Select the **Used in tanks** tab.
- 5. Click the  button.
- 6. The tab is displayed in edit mode in the lower section of the Application window:



- 7. Activating the **check box** in the **Assign** column assigns the selected product to a tank. Deactivate the **check box** to undo the assignment. The table shows the tanks which are already assigned to the product or which are not yet assigned to a product.
- 8. Click  to save your entries. Click  to abort the process.


### 13.6.3 Changing a product

For details →  27

### 13.6.4 Deleting a product

For details →  31



You can only delete a product if the product is not assigned to a tank. The  symbol is only displayed for a product which can be deleted.

### 13.6.5 Copying a product

For details →  32

## 13.7 Managing tank groups



Only people whose user role is configured as **Master Data** can create, change and delete tank groups.



Depending on your configuration, **Object groups** are displayed instead of **Tank groups**. For more information refer to the appropriate chapter in the Service Manual for System administration.

Tank groups are used to organize tanks and to assign authorized users to the tanks. In the **Tank assignment** tab, you create tank groups and assign tanks to the groups. You can assign one or more users to the tank group using the **User assignment** tab. In the **User assignment** tab, you also specify the tank events for which the user should receive notification.

### 13.7.1 Creating tank groups

1.

Click the **Configuration** menu in the Navigation window.

2.

Click the **Tank group** menu item.

3.

The following detail view is displayed in the Application window:

Configuration >> Tank group

Name: All Tanks


Description:

Product: All

Tank name	Notes	Location
<input checked="" type="checkbox"/> IC Waste	Material Safety Instructions must be signed off for every waste disposal!	EU Operations UK
<input checked="" type="checkbox"/> IC 02000		US Operations West
<input checked="" type="checkbox"/> LNG Waste	Material Safety Instructions must be signed off for every waste disposal!	APAC Operations TH
<input checked="" type="checkbox"/> LNG 01000		APAC Operations SG
<input checked="" type="checkbox"/> IC 01000		US Operations North

1 of 4

S95\_EN\_BA00050S\_0211

4. In the lower section of the Application window, select the **Tank assignment** tab.
5. Click the  button.
6. The tab is displayed in the edit mode.

Tank assignment

Name:




Description:

Product: All


Tank name	Notes	Location
<input type="checkbox"/> IC Waste	Material Safety Instructions must be signed off for every waste disposal!	EU Operations UK
<input type="checkbox"/> IC 02000		US Operations West
<input type="checkbox"/> LNG Waste	Material Safety Instructions must be signed off for every waste disposal!	APAC Operations TH
<input type="checkbox"/> LNG 01000		APAC Operations SG
<input type="checkbox"/> IC 01000		US Operations North


1 of 5

S96\_EN\_BA00050S\_0211

7. Here, you can enter data on the tank group such as:
  - **Name** (obligatory): Unique identifier of the tank group
  - **Description**: You can enter a multiline description here.
  - **Assignment**: By means of the table, you can activate the **check boxes** to assign the corresponding tanks to this tank group.
8. Click  to save your entries. Click  to abort the process.
9. Select the **User assignment** tab to assign the tank groups to a user (→  117).

### 13.7.2 Assigning users to a tank group and setting up notifications for tank events



1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank group** menu item.
3. Select the **User assignment** tab.
4. Click the  button.
5. The tab is displayed in the edit mode.



Assign	First name	Name	By e-mail	PP	SP	SST	TF	PDL	PDE
<input checked="" type="checkbox"/>	Claude	Fischer	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	Customer Support	E+H	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	Martina	Meister	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

S96-2\_EN\_BA000505\_0211

You can assign one or more users to the tank group using the "User assignment" tab. On this tab you can also specify the tank events which the user should be informed about.

6. Activating the **check box** in the **Assign** column assigns a user to the tank group. Deactivate the **check box** to undo the assignment. The assigned tank groups are listed in the Workplace Tank view.
7. Activate the **By E-Mail check box** if you want the user to also be informed about tank events by e-mail.
8. Enable the **check boxes** corresponding to the events for which the user should receive notification:
  - **PP** (plan point)
  - **SP** (ship point)
  - **SST** (safety stock)
  - **TF/OF** (Tank freeze/object freeze): Comprises all the information regarding tank freeze/object freeze events
  - **PDL** (planned delivery/disposal loop): Comprises all the new deliveries/disposals which have been planned or deleted
  - **PDL** (planned delivery/disposal events): Comprises all the early, late, missed and completed deliveries/disposals
9. Click  to save your entries. Click  to abort the process.

### 13.7.3 Changing tank group

For details →  27


### 13.7.4 Deleting tank groups

For details →  31


### 13.7.5 Copying tank groups


For details →  32

### 13.8 Managing units


 Only people whose user role is configured as **Master Data** can change the number of places after the decimal point for the units.

In the **Unit** menu item, you specify the number of places after the decimal point for the various units.

 The **Unit** menu item lists all the units along with their description, number of decimal places and unit type. "Customer-specific" types of units cannot be converted to another unit. Customer-specific units are for display purposes only.




The  button in the table header opens a context menu. Via this context menu, you can show and hide the **Unit type** column in the overview table.

- 1. Click the **Configuration** menu in the Navigation window.
- 2. Click the **Unit** menu item.
- 3. The following detail view appears in the application window:








S99\_EN\_BA000505\_0211

The table displays all units along with their description and number of places after the decimal point.

- 4. Select the unit in the table for which you want to change the number of places after the decimal point.
- 5. Click the  button.
- 6. The tab is displayed in edit mode in the lower part of the window.
- 7. Enter the desired number in the **Decimal places** field.
- 8. Click  to save your entries. Click  to abort the process.

## 13.9 Managing a report (using CIDX and CSV reports)

-  Only people whose user role is configured as **Master Data** can set up reports.
  -  To use automatic data exchange in CIDX format, a server to receive the files must be set up on the receiver side. The URL, user name and password of the receiver side must be known.
  -  You can schedule up to five reports.
  -  **Manual values** are always marked with the text **MAN**.
1. Click the **Configuration** menu in the Navigation window.
  2. Click the **Report** menu item.
  3. The following detail view is displayed in the Application window:



S100\_EN\_BA00050S\_0211

### Format CIDX and CSV

The generated CIDX and CSV files have the following format:

<contractNr><report.name>\_<timestamp "yyyyMMdd\_HH:mm:ss">.<suffix>

Example: contract1\_report1\_20100505\_1634031.xml

CIDX: The CIDX format used is "InventoryActualUsage, Version 4".

The CSV files have the following structure:

Tank name	Time stamp	Value	Unit	Optimum	Plan point	Ship point	Safety stock
Tank 1	12.06.2009 17:20	920.0	l	1000	100	80	50

## Validate CIDX

Once you have assigned the tanks to the report group, validation is performed to check whether the configuration complies with CIDX specifications. The following checks are performed:

- Is a supplier assigned to the tank?
- Is a buyer assigned to the tank?
- Is a location assigned to the tank?
- Is a product assigned to the tank?
- Is a company assigned to the location?
- Is an identifier and identifier agency set for the buyer?
- Is an identifier and identifier agency set for the supplier?
- Is an identifier and identifier agency set for the product?
- Is an identifier and identifier agency set for the company of the location?
- Is a measuring point assigned to the tank?

### 13.9.1 Creating a report


Using the Report Wizard, you can create a report in six simple steps. You can use different report templates.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Report** menu item.
3. In the lower section of the Application window, select the **General report information** tab.
4. Click the **Create new report** button. The **General report information** dialog box appears:

S101\_EN\_BA000505\_0211

5. Here, you can enter general data on the report such as:
  - **Name** (obligatory): Unique identifier
  - **Description**: You can enter a multiline description here.
  - **Select a template**: Select the template for the report here.
6. Click the **Next** button. The **Column selection** dialog box is displayed:





S102\_EN\_BA00050S\_0211

7. Here you can select the information (columns) which should be analyzed in the report.

**i** If **Manual values** shall also be displayed in the report the column **Value (with manual marker)** has to be selected additionally.

- **Available columns:** This lists all the columns that can be analyzed in the report. If you want to add a column, enable the **check box** for the corresponding column and click the **>>** button. If you want to select all the columns, enable the uppermost **check box** beside the columns.
- **Assigned columns:** This lists all the columns that are analyzed in the report. If you want to remove a column, enable the **check box** for the corresponding column and click the **<<** button. If you want to select all the columns, enable the uppermost **check box** beside the columns.  
If you want to change the order of the columns, select the corresponding column and click the **▲** or **▼** button.
- **Include secondary values:** The secondary values are also displayed.
- **Add column names as headers:** The column names are used as headers.
- **Header language:** Choice of language for the column names in the header of the report. The language from your user preferences is used as the default language. If no language is selected in the user preferences, the column names are in English.

8. Click the **Next** button. The **Tank assignment** dialog box is displayed:

Step 3 out of 6 : Tank assignment

Select the tanks

Assignment type: Tank

Tank group: All Location: All Product: All Supplier: All

<input type="checkbox"/>	Tank name	Notes	Location
<input type="checkbox"/>	IC Waste	Material Safety Instructions must be signed off for every...	EU Operations UK
<input type="checkbox"/>	IC 02000		US Operations West
<input type="checkbox"/>	LNG Waste	Material Safety Instructions must be signed off for every...	APAC Operations TH
<input type="checkbox"/>	LNG 01000		APAC Operations SG
<input type="checkbox"/>	IC 01000		US Operations North
<input type="checkbox"/>	IC 03000		HQ
<input type="checkbox"/>	IC 03-mix		HQ
<input type="checkbox"/>	IC Waste II	Material Safety Instructions must be signed off for every...	EU Operations PL

of 9

Back Next Cancel Finish

S102-2\_EN\_BA000505\_0211

9. By means of the table, you can activate the **check boxes** to assign the corresponding tanks to this report.
10. Click the **Next** button. For CIDX and CSV reports, validation is performed to check whether the configuration complies with the specifications. The **Format selection** dialog box is displayed:

Step 4 out of 6 : Format selection

Select the output format

☐ XLS  
☐ TXT  
☐ PDF  
☐ CSV  
☐ XML

Back Next Cancel Finish


S103\_EN\_BA000505\_0211

11. You can select how the report is output here:

- **XLS**: Excel file
- **TXT**: text file
- **PDF**: PDF file
- **CSV**: CSV file
- **XML**: XML file

12. Click the **Finish** button to finish the report.

13. Click the **Next** button to go to the channel configuration. The **Channel configuration** dialog box is displayed:



Step 5 out of 6 : Channel configuration

Select and configure the delivery channel

Channel


Back Next Cancel Finish

S103-2\_EN\_BA00050S\_0211

14. Select the distribution channel for the **Channel** field.
15. Depending on the distribution channel selected, additional fields are displayed in the tab.

**a) Distributed by e-mail**

- Click the  button to select a user. Click the  button to remove a user who has been selected.



Step 5 out of 6 : Channel configuration

Select and configure the delivery channel

Channel E-mail

E-mail

Back Next Cancel Finish

S104\_EN\_BA00050S\_0211

b) Distributed by FTP

Step 5 out of 6 : Channel configuration

Select and configure the delivery channel

Channel

FTP

URL

User

Password

Back


Next

Cancel

Finish

S104-2\_EN\_BA00050S\_0211

- Enter the following data here:
- **URL** (obligatory): Website of the selected channel
  - **User name**
  - **Password**
  - **Use proxy**

 You can also use the FTP channel for transmission via secure FTP (FTPS).

16. Click the **Finish** button to finish the report. Click the **Next** button to go to scheduling. The **Scheduling** dialog box is displayed:

Step 6 out of 6 : Scheduling

Define the scheduling rules

Enable scheduling

☐

Time zone

(UTC+00:00) Coordinated Uni

Repetition rule

Please select a repetition rule

Overview of affected dates

<

November 2011

>

Sun	Mon	Tue	Wed	Thu	Fri	Sat
		1	2	3	4	5
6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30			

Back

Next

Cancel

Finish

S105\_EN\_BA00050S\_0211

17. Here, you can enter data on the scheduling such as:

- **Enable scheduling:** The scheduling rule is enabled immediately as soon as the report has been completed.
- **Time zone**
- **Repetition rule:** You can select a rule here.
  - Daily:** Possible to schedule by time or frequency.
  - Weekly on every...:** Possible to select the specific days and schedule by time or frequency.
  - Monthly on specified date:** Possible to schedule the start date and time for creating the report every month.
  - Monthly on last day of month:** Performed on the last day of the month. Possible to schedule the time for creating the report every month.


The days on which a scheduling rule is executed are highlighted in color in the calendar. You can scroll through the calendar on a month-by-month basis.

S105-2\_EN\_BA000505\_0211

18. Click the **Finish** button to finish the report.


### 13.9.2 Downloading the report as a PDF file


You can download a report as a PDF file and save it in your file system.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Report** menu.
3. Select the report in the upper section of the Application window.
4. In the lower section of the Application window, select the **General report information** tab.
5. Click the  button.
6. As soon as the report is finished, the **File download** dialog box is displayed.
7. Click the **Open** button to view the report immediately. Click the **Save** button to save the report in your file system. Click **Cancel** to abort the process.

### 13.9.3 Creating reports and sending them immediately

Irrespective of the scheduling rules, you can create a report any time and send the report to the recipients as defined in the channel configuration. The scheduling rules remain unchanged.

 Only measured values with the status 0 are taken into consideration in **CDIX** and **CSV**-type reports.

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Report** menu.
3. Select the report in the upper section of the Application window.
4. In the lower section of the Application window, select the **General report** tab.
5. Click the  button.
6. The report is created in the background and sent to the recipients. You receive a notification message to this effect.
7. Click **Ok** to confirm the notification message.

### 13.9.4 Changing a report

For details →  27

### 13.9.5 Deleting a report


For details →  31


### 13.9.6 Copying a report

For details →  32

## 13.10 Setting up messaging

SupplyCare Hosting can actively inform users of events by e-mail. Depending on the event weighting, different people can be informed.

 Only people whose user role is configured as **Master data** can set up message notification.

 Message-based notification can only be set up for people with **Read only**, **Scheduler** or **Operator** configured as their user role.

 The e-mail connection must be set up for SupplyCare before the user can be notified by e-mail.

### 13.10.1 Setting up messaging

1. Click the **Configuration** menu in the Navigation window.
2. Click the **Tank group** menu.
3. The following detail view is displayed in the Application window:

Configuration >> Tank group

Name Description

All Tanks

APAC Operations

EU Operations

US Operations

1 of 4

Tank assignment User assignment

Name \* All Tanks


Description

Product All

all	Tank name	Notes	Location
<input checked="" type="checkbox"/>	IC Waste	Material Safety Instructions must be signed off for every waste disposal!	EU Operations UK
<input checked="" type="checkbox"/>	IC 02000		US Operations West
<input checked="" type="checkbox"/>	LNG Waste	Material Safety Instructions must be signed off for every waste disposal!	APAC Operations TH
<input checked="" type="checkbox"/>	LNG 01000		APAC Operations SG
<input checked="" type="checkbox"/>	IC 01000		US Operations North

of 9

S107\_EN\_BA000505\_0211

4. In the overview table, select the tank group to which you want to assign a user.
5. In the lower section of the application window, select the **User assignment** tab.
6. Click the  button.
7. The tab appears in the edit mode:

Tank assignment User assignment



Assign First name Name By e-mail PP SP SST TF PDL PDE

<input checked="" type="checkbox"/>	Claude	Fischer	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	Customer Support	E+H	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	Martina	Meister	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

of 3

S108\_EN\_BA000505\_0211


Anyone with **Read only**, **Scheduler** and **Operator** user roles is listed in the table. You can only assign these people to a tank group, and thus to a tank.

8. You can assign one or more tank groups to the user using the **Assign** column. These tank groups are listed in the "Workplace - Tank" view.  
You can also specify what events the user should be notified of, and whether this notification should be sent by e-mail.
9. Click  to save your entries. Click  to abort the process.




### 13.11 Maintaining a user profile


 Each person has the possibility to change his/her user profile.

- 1. Click the **Profile menu** in the Navigation window.
- 2. Click the **User profile** menu item.
- 3. Select the **User profile** tab.
- 4. The following is an example of what is displayed in the Application window:




S109\_EN\_BA00050S\_0211

- 5. Click the  button.
- 6. The tab is displayed in the edit mode.
- 7. Make your changes. You can change the fields with a white background, e.g. **Name** and **E-mail address**.
- 8. Click  to save your changes. Click  to abort the process.
- 9. The **Tank group assignment** tab shows you what tank groups you are assigned to.



S109-2\_EN\_BA00050S\_0211

-  The tank group assignment can only be changed by people with **Master data** user role in the **Tank groups** menu item.
- 10. The **My tank view** tab shows you all the tanks and aggregated tanks which you can access via the assigned tank groups.



Tank name	Notes	
IC 01000		<input checked="" type="checkbox"/>
IC 02000		<input checked="" type="checkbox"/>
IC 03-mix		<input checked="" type="checkbox"/>
IC 03000		<input checked="" type="checkbox"/>
IC Waste	Material Safety Instructions must be signed off for every waste disposal!	<input checked="" type="checkbox"/>
LNG 01000		<input checked="" type="checkbox"/>
LNG V Waste	Material Safety Instructions must be signed off for every waste disposal!	<input checked="" type="checkbox"/>
IC Waste II	Material Safety Instructions must be signed off for every waste disposal!	<input type="checkbox"/>
IC V Waste III	Material Safety Instructions must be signed off for every waste disposal!	<input type="checkbox"/>

S110\_EN\_BA000506\_0211

11. Click the button.
12. The tab is displayed in the edit mode.
13. Enable the **check boxes** of the tanks that should be shown in the **My tank view** workplace.
14. Click to save your changes. Click to abort the process.

## 13.12 Selecting and changing user preferences

Only people with **Read only**, **Scheduler** or **Operator** configured as their user role can change the user preferences.

1. Click the **Profile** menu in the Navigation window.
2. Click the **User preferences** menu item.

User\_preferences\_BA000506EN

3. Click the button.
4. The tab is displayed in the edit mode.
5. Here, you can select or change an option for the **Tank group filter**, **Time zone**, **Default time zone filter**, **Unit mass**, **Unit volume**, **Language** and **Default home page** fields.
6. Click to save your changes. Click to abort the process.

### 13.12.1 Description of the filters (fields)

#### "Time zone" filter

The **Time zone** selected here is used in the following areas of the program:

Menu	Description
Workplace – Tank	<ul style="list-style-type: none"> <li>■ <b>Notes and files</b> tab</li> <li>■ <b>Event details</b> tab</li> </ul>
Workplace – My tank view	<ul style="list-style-type: none"> <li>■ Tank overview</li> </ul>
Workplace – Event	<ul style="list-style-type: none"> <li>■ Event table</li> <li>■ <b>Event details</b> tab</li> <li>■ <b>Event history</b> tab</li> </ul>
Configuration – Tank	<ul style="list-style-type: none"> <li>■ <b>Tank notes</b> tab</li> </ul>
Configuration – Aggregated tank	<ul style="list-style-type: none"> <li>■ <b>Tank notes</b> tab</li> </ul>
Configuration – Location	<ul style="list-style-type: none"> <li>■ <b>Location notes</b> tab</li> </ul>

#### "Default time zone filter"

The **Time zone** filter selected here is displayed in the **Time zone** picklist in the "Tank", "My tank view", "Event" and "Scheduling" workplaces. You can select the following values:

- **Empty:** The "Location" value is displayed in the "Tank", "My tank view" and "Scheduling" workplaces. "User preference" is displayed in the "Event" workplace.
- **Location:** The "Location" value is displayed.
- **User preference:** The selected time zone is displayed. The value "UTC+00:00" is displayed if the time zone is empty.
- **UTC:** The value "UTC+00:00" is displayed. "UTC" is short for "Universal Time Coordinated".

#### "Mass unit" and "Volume unit" filters

If you selected "Mass" for the tank unit, the mass unit selected here is used in the following areas of the program. If you selected "Volume" for the tank unit, the volume unit selected here is used in the following areas of the program.

Menu	Description
Workplace – Tank	<ul style="list-style-type: none"> <li>■ "Tank" table</li> <li>■ <b>Inventory chart</b> tab</li> <li>■ <b>Tank details</b> tab</li> <li>■ <b>Event details</b> tab</li> <li>■ <b>Download history</b> tab</li> </ul>
Workplace – My tank view	<ul style="list-style-type: none"> <li>■ Tank overview</li> <li>■ <b>Inventory chart</b> tab</li> <li>■ <b>Tank details</b> tab</li> <li>■ <b>Event details</b> tab</li> <li>■ <b>Download history</b> tab</li> </ul>
Workplace – Event	<ul style="list-style-type: none"> <li>■ <b>Event details</b> tab</li> <li>■ <b>Inventory chart</b> tab</li> <li>■ <b>Tank details</b> tab, <b>Unit</b> field</li> </ul>
Workplace – Scheduling	<ul style="list-style-type: none"> <li>■ Planning table</li> <li>■ <b>Plan delivery/disposal</b> tab</li> <li>■ <b>Planned delivery/disposal</b> tab</li> <li>■ <b>Overview</b> tab</li> </ul>
Workplace – Analysis	<ul style="list-style-type: none"> <li>■ Analysis table</li> <li>■ <b>KPIs</b> tab</li> <li>■ <b>Outflow/Inflow</b> tab</li> <li>■ <b>Chart hourly</b> tab</li> <li>■ <b>Chart daily</b> tab</li> </ul>

**"Language" filter**

The **Language** selected here is used as the language for event and limit notifications, as well as for the names of the columns in the header of a report.

**"Default home page" filter**

The **Default home page** selected here is displayed in the application window following successful login. If a splash screen image is used in the application window, the default home page is displayed once the user clicks **Next**.

## 14 User roles and authorization



Multiple user roles can be assigned to one person at the same time.

### Master data

Person with **Master data** configured as their user role are authorized to perform the following:

- Create, change and delete users
- Assign a user role to a user
- Assign a tank group to a user
- Assign notifications to a user
- Change their own user profile
- Create, change and delete a tank
- Assign a tank to a tank group
- Create, change and delete an aggregated tank
- Assign an aggregated tank to a tank group
- Create, change and delete a location
- Assign a tank to a location
- Create, change and delete a company
- Create, change and delete a product
- Create, change and delete a tank group
- Assign a product to a tank
- Create, change and delete reports
- Change the number of decimal places for a unit type

### Read only

Person with **Read only** configured as their user role are authorized to perform the following:

- View tanks (measured values)
- View personalized tank view
- View tanks on a map (Google Maps)
- View and save measured value history
- View tank details
- View location details
- View tank service status
- View events
- Perform totaling
- Change their own user profile
- Make user preferences

### Operator

The **Operator** is authorized to perform the following:

- View tanks (measured values)
- View personalized tank view
- View tanks on a map (Google Maps)
- View and save measured value history
- Analyze the history of existing measured values
- View tank details
- View location details
- Change tank service status
- View and edit events
- View event history
- Perform totaling
- Change their own user profile
- Make user preferences

**Scheduler**

The **Scheduler** is authorized to perform the following:

- View tanks (measured values)
- View personalized tank view
- View tanks on a map (Google Maps)
- View and save measured value history
- View notifications and status displays on planned disposals and deliveries
- View tank details
- View location details
- View tank service status
- View and edit events
- Set the resubmission date
- View event history
- Plan deliveries and disposals
- Perform totaling
- Change their own user profile
- Make user preferences

**Product-Tank-Assignment**

Person with **Product-Tank-Assignment** configured as their user role are authorized to perform the following:

- Change their own user profile
- Assign an existing product to an existing tank

# Index

## A

ADI (average daily inflow) .....	77
ADO (average daily outflow) .....	77
Amount for planned delivery .....	38
Amount for planned disposal .....	38
Analysis .....	76
Application window .....	18
Assigning tank groups to a user .....	89
Average daily inflow .....	77–78
Average daily outflow .....	77–78
Average delivery quantity .....	79
Average disposal quantity .....	79
Average inventory level .....	79
Average rate of usage .....	79
Average safety stock reached .....	79

## B

Bad measurement(s) .....	40
Buttons .....	20–21
Buyer .....	38
Buyer ID .....	38

## C

Capacity .....	37, 40
Changing	
Aggregated tank-tank group assignment .....	107
Location-tank assignment .....	110
Master data .....	28
Product-tank assignment .....	114
Tank-tank group assignment .....	97
CIDX reports .....	119
Company .....	85
Company details .....	85
Configuring freeze events .....	99
Configuring secondaries .....	98
Constituent tanks .....	40
Copy	
Delivery .....	70
Disposal .....	70
Creating a report group .....	120
CSV reports .....	119

## D

Daily basis .....	81
Daily inflow .....	77–78
Daily outflow .....	77–78
Data source .....	37
Days until safety stock is reached .....	38
Days until the safety stock is reached .....	78
Deleting	
Master data .....	31
Tank .....	104
Delivery	
Details .....	70
Status management .....	62
Designated use .....	7
Detailed view .....	19

Device version .....	9
DI (daily inflow) .....	77
Disposal	
Details .....	70
Status management .....	62
DO (daily outflow) .....	77
Download history .....	44
DSST (days until safety stock is reached) .....	38

## E

Elements .....	20
Event .....	56–57, 60
Event details .....	42, 58, 60
Event history .....	59
Event symbols .....	21

## F

Fieldgates .....	11
Filter functions .....	26
Forecast values .....	48
Free .....	37
Free capacity .....	40
Freeze event details .....	43, 58
Frequency of deliveries .....	78
Frequency of disposals .....	78
From date .....	38

## G

Gateways .....	11
----------------	----

## H

Historical values .....	48
Hourly basis .....	80
Hysteresis .....	37, 40, 96

## I

Icons .....	5, 20–21, 23–25
Inflow .....	78
Inventory chart .....	38, 59
Inventory control .....	10

## K

Key performance indicators .....	77
KPIs .....	77

## L

Language .....	131
Level .....	37
Location .....	37, 40, 77, 108
Location details .....	42, 109
Logging out .....	17
Login .....	14

## M

Mass unit .....	130
Master data .....	18, 132
Maximum value .....	79

Menu		Setting up a report group	120
Configuration	18	Setting up e-mail notification	117
Profile	18	Setting up messaging	126
Workplace	18	Setting up notifications for tank events	89
Menu items	17	Ship point	40
Messaging	34	SP (Ship point)	37
Minimum value	79	SST (Safety stock)	37
Monitoring tanks	35	Standard delivery time	38
My tank view	52	Standard disposal time	38
<b>N</b>		Standard tanks	39, 66
Navigation window	17	Starting the program	13
Next planned delivery	78	Status	37
Next planned disposal	78	Status display	22
Notes	37	Supplier	38
Notes and files	41	Symbols	5
Notification	34	System description	10
Number of deliveries	78	<b>T</b>	
Number of disposals	78	Tabs	19
<b>O</b>		Tank	91
Operator	18, 132	Tank assignment	116
Optimum	37, 40	Tank details	39, 59, 93, 105
Order code	9	Tank freeze	99
Out of service	38, 40	Tank group	115
Outflow	78	Tank group assignment	128
Overview	19	Tank group filter	129
<b>P</b>		Tank groups	88, 94, 97, 106–107
Password	13	Tank list	106
PD (planned delivery/planned disposal)	38	Tank name	37, 40, 77
PD amount	38	Tank notes	102, 107
Plan delivery	50, 62, 65, 68	Tank partners	41
Plan disposal	50, 62, 65, 68	Tank service status	43
Plan point	40	Tank setup wizard	91
Portal window	16	Tank shape	107
PP (plan point)	37	Tank type	40
Product	37, 40, 77, 112	Tanks at location	110
Product details	113	Technical improvement	7
Product-Tank-Assignment	18, 133	Time stamp	38, 40
Profile	128	Time unit	38
<b>R</b>		Time zone	38, 40, 77, 130
Read only	18, 132	To date	38
Recycling tanks	39, 66	Total inflow	78
Refresh range	50, 69	Total outflow	78
Report group	119	Trademarks	9
<b>S</b>		Turnover rate	79
Safety icons	5	<b>U</b>	
Safety stock	40	Unit	37, 40, 77
Safety stock reached	79	Unit mass	130
Scheduler	18, 133	Units	118
Scheduling	65	Used in tanks	114
SDT (Standard delivery time in days or hours)	40	User	87
SDT (standard delivery time/standard disposal time)	38	User assignment	117, 127
Searching	26	User details	87
Secondaries	46, 98	User interface	13
Setting the resubmission date	61	User preferences	129
		User profile	128
		User roles	88
		User roles and authorization	132

**V**

Value .....	37, 40
Volume unit.....	130

**W**

Workplace	
Analysis .....	76
Event. ....	56
Map. ....	82
My tank view.....	52
Scheduling .....	62, 65
Tank .....	35





[www.addresses.endress.com](http://www.addresses.endress.com)

---