



Level



Pressure



Flow



Temperature



Liquid  
Analysis



Registration



Systems  
Components



Services



Solutions


## Operating Instructions

# LPGmass

MODBUS RS485

Coriolis Mass Flow Measuring System

For LPG (Liquified Petroleum Gas) applications



BA00133D/06/EN/13.10  
71123638

Valid as of version  
V 1.01.XX (device software)

**Endress+Hauser** 

People for Process Automation



## Table of contents

<b>1</b>	<b>Safety</b> .....	<b>5</b>	5.3.7	MODBUS auto-scan buffer .....	24
1.1	Designated use .....	5	5.3.8	Integer scaling of the measured variables ..	26
1.2	Installation, commissioning and operation .....	5	5.3.9	Configuring the device address .....	26
1.3	Operational safety .....	5	<b>6</b>	<b>Commissioning</b> .....	<b>27</b>
1.4	Return .....	6	6.1	Function check .....	27
1.5	Notes on safety conventions and icons .....	7	6.2	Switching on the measuring device .....	27
<b>2</b>	<b>Identification</b> .....	<b>8</b>	6.3	Zero point adjustment .....	27
2.1	Device designation .....	8	6.3.1	Preconditions for a zero point adjustment ..	27
2.1.1	Nameplate of the transmitter .....	8	6.3.2	Performing a zero point adjustment .....	28
2.1.2	Nameplate of the sensor .....	8	6.4	Memory (HistoROM) .....	28
2.1.3	Additional name plate for approval for custody transfer .....	9	6.4.1	HistoROM/T-DAT (sensor and transmitter DAT) .....	28
2.1.4	Nameplate for connections .....	9	<b>7</b>	<b>Maintenance</b> .....	<b>29</b>
2.1.5	Additional sign – position of the optional rupture disk .....	9	7.1	External cleaning .....	29
2.2	Certificates and approvals .....	10	<b>8</b>	<b>Accessories/spare parts</b> .....	<b>30</b>
2.3	Registered trademarks .....	10	8.1	Instrument-specific spare parts .....	30
<b>3</b>	<b>Installation</b> .....	<b>11</b>	8.2	Service-specific accessories .....	30
3.1	Incoming acceptance, transport and storage .....	11	<b>9</b>	<b>Troubleshooting</b> .....	<b>31</b>
3.1.1	Incoming acceptance .....	11	9.1	Self-monitoring .....	31
3.1.2	Transport .....	11	9.2	Diagnosis using light emitting diode (LED) .....	32
3.1.3	Storage .....	11	9.3	Messages (FieldCare) .....	33
3.2	Installation conditions .....	11	9.4	Errors without messages .....	35
3.2.1	Dimensions .....	11	9.5	Spare parts .....	35
3.2.2	Inlet and outlet runs .....	11	9.6	Response of outputs to errors .....	36
3.2.3	Vibrations .....	11	9.7	Removing and installing the meter electronics ..	37
3.2.4	Limiting flow .....	11	9.8	Software history .....	38
3.3	Installation .....	12	9.9	Return .....	38
3.3.1	Turning the transmitter housing .....	12	9.10	Disposal .....	38
3.4	Post-installation check .....	12	<b>10</b>	<b>Technical data</b> .....	<b>39</b>
<b>4</b>	<b>Wiring</b> .....	<b>13</b>	10.1	Technical data at a glance .....	39
4.1	MODBUS RS485 cable specifications .....	13	10.1.1	Applications .....	39
4.2	Connecting the measuring unit .....	14	10.1.2	Function and system design .....	39
4.2.1	Transmitter connection .....	14	10.1.3	Input .....	39
4.2.2	Terminal assignment .....	15	10.1.4	Output .....	39
4.3	Degree of protection .....	15	10.1.5	Power supply .....	40
4.4	Post-connection check .....	16	10.1.6	Performance characteristics .....	41
<b>5</b>	<b>Operation</b> .....	<b>17</b>	10.1.7	Operating conditions: Installation .....	42
5.1	Quick operation guide .....	17	10.1.8	Operating conditions: Environment .....	42
5.2	Operating option .....	18	10.1.9	Operating conditions: Process .....	43
5.2.1	Customer-specific parameter configuration with the FieldCare .....	18	10.1.10	Mechanical construction .....	44
5.3	MODBUS RS485 communication .....	18	10.1.11	Human interface .....	45
5.3.1	MODBUS RS485 technology .....	18	10.1.12	Certificates and approvals .....	45
5.3.2	MODBUS telegram .....	20	10.1.13	Ordering information .....	46
5.3.3	MODBUS function codes .....	21	10.1.14	Accessories/spare parts .....	46
5.3.4	Maximum number of writes .....	22	10.1.15	Documentation .....	46
5.3.5	MODBUS register addresses .....	22			
5.3.6	MODBUS error messages .....	24			

<b>11</b>	<b>Appendix – Instrument functions</b>	<b>47</b>
11.1	Display of function matrix	48
11.2	Block "CUSTODY TRANSFER MEASUREMENT"	51
11.2.1	Group "CUSTODY TRANSFER MEASUREMENT"	51
11.3	Block "MEASURED VARIABLE"	51
11.3.1	Group "MEASURING VALUES"	51
11.3.2	Group "SYSTEM UNITS"	52
11.4	Block "TOTALIZER"	55
11.4.1	Group "TOTALIZER (1 to 3)"	55
11.5	Block "OUTPUTS"	58
11.5.1	Group "PULSE/FREQUENCY OUTPUTS (1 to 2)"	58
11.6	Block "BASIC FUNCTION"	71
11.6.1	Group "MODBUS RS485"	71
11.6.2	Group "PROCESSPARAMETER"	79
11.6.3	Group "SYSTEM PARAMETER"	84
11.6.4	Group "SENSOR DATA"	85
11.7	Block "SUPERVISION"	87
11.7.1	Group "SYSTEM"	87
11.7.2	Group "VERSION-INFO"	91
11.7.3	Group "MESSAGE CATEGORY"	92
11.7.4	Group "MESSAGE HISTORY"	94
	<b>Index</b>	<b>95</b>

# 1 Safety

## 1.1 Designated use

The measuring instrument described in these Operating Instructions is to be used for measuring the mass or volume flow of liquified petroleum gas (LPG).

The mass and volume flow measurement of other fluids is also possible, but LPG-specific functions are not applicable.

Resulting from incorrect use or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.





## 1.2 Installation, commissioning and operation

Note the following points:

- Installation, connection to the electricity supply, commissioning and maintenance of the measuring instrument must be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator. The specialist must have read and understood these Operating Instructions and must follow the instructions they contain.
- The device must be operated by persons authorized and trained by the facility's owner-operator. Strict compliance with the instructions in the Operating Instructions is mandatory.
- Endress+Hauser will be happy to assist in clarifying the corrosion resistance properties of materials wetted by special fluids, including fluids used for cleaning. However, small changes of temperature, concentration or degree of contamination in the process can result in differences in corrosion resistance. Therefore, Endress+Hauser provides no warranty and assumes no liability with regard to corrosion resistance of fluid wetted materials in any given application. The user is responsible for choosing suitable fluid wetted materials in the process.
- The installer must ensure that the measuring system is correctly wired in accordance with the wiring diagrams. The transmitter must be grounded, except in cases where special protective measures have been taken (e.g. galvanically isolated power supply SELV or PELV).
- The user must attach an external switch for disconnecting the power supply in an emergency. The relationship between this switch and the measuring instrument or part of the system in which the instrument is located must be identified clearly and unambiguously.
- Invariably, local regulations governing the opening and repair of electrical devices apply.

## 1.3 Operational safety

Note the following points:

- Measuring systems for use in hazardous environments are accompanied by separate "Ex documentation", which is an integral part of these Operating Instructions. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory. The symbol on the front of this supplementary Ex documentation indicates the approval and the inspection body (  Europe,  USA,  Canada).
- The housing of the sensor is equipped with an optional rupture disk to prevent the pressure in the housing from increasing. As long as the adhesive label (→  9) is intact, the rupture disk is also intact.
- The measuring device complies with the general safety requirements in accordance with EN 61010, the EMC requirements of IEC/EN 61326, and NAMUR recommendation NE 21.
- Due to the performance rate in the electronic components, the maximum heating of the outer housing surfaces is 10 °K. When hot media are passed through the measuring tube, the surface temperature of the housing increases. With regard to the sensor, in particular, you should expect temperatures that can be close to the temperature of the medium. If the temperature of the medium is high, ensure staff are protected against burns and scalds.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and any updates to these Operating Instructions.

- The sensor housing protects the inner electronics and mechanics and is filled with dry nitrogen. The housing of this sensor does not fulfill any additional secondary containment function. However, 15 bar (217.5 psi) can be specified as a reference value for the pressure loading capacity.

In case a danger of measuring tube failure exists due to process characteristics, e.g. with corrosive process fluids, this can cause a mechanical overload of the housing which, in turn, can cause breakage of the housing and thus is associated with an increased hazard potential. Thus it is very important to clarify the compatibility of the medium with the measuring tube and to observe the specified maximum process pressure.

For increased safety, a version with rupture disk (triggering pressure 10 to 15 bar; 145 to 217.5 psi) can be used, which is available for order as a separate option.

## 1.4 Return

The following procedures must be carried out before a flowmeter requiring repair or calibration, for example, is returned to Endress+Hauser:

- Always enclose a duly completed "Declaration of contamination" form. Only then can Endress+Hauser transport, examine and repair a returned device.
- Enclose special handling instructions if necessary, such as a safety data sheet as per Regulation (EC) 1907/2006 REACH.
- Remove all residues. Pay special attention to the grooves for seals and crevices which could contain residues. This is particularly important if the substance is hazardous to health, e.g. flammable, toxic, caustic, carcinogenic, etc.



Note!

You will find a preprinted "Declaration of contamination and cleaning" form at the back of these operating instructions.



Warning!

- Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.
- Costs incurred for waste disposal and injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

## 1.5 Notes on safety conventions and icons

The devices are designed to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures". They can, however, be a source of danger if used incorrectly or for other than the designated use.

Consequently, always pay particular attention to the safety instructions indicated in these Operating Instructions by the following icons:



**Warning!**

"Warning" indicates an action or procedure which, if not performed correctly, can result in injury or a safety hazard. Comply strictly with the instructions and proceed with care.



**Caution!**

"Caution" indicates an action or procedure which, if not performed correctly, can result in incorrect operation or destruction of the measuring instrument. Comply strictly with the instructions.



**Note!**

"Note" indicates an action or procedure which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

## 2 Identification

### 2.1 Device designation

The flow measurement system is a compact measuring instrument.

#### 2.1.1 Nameplate of the transmitter




Fig. 1: Nameplate data of the transmitter (example)

- 1 Order code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits
- 2 Power supply / frequency / power consumption
- 3 Degree of protection
- 4 Permitted ambient temperature
- 5 Cable temperature
- 6 Please refer to operating instructions / documentation
- 7 Reserved for additional information on device version (approvals, certificates)

#### 2.1.2 Nameplate of the sensor




Fig. 2: Nameplate data of the sensor (example)

- 1 Order code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits
- 2 Calibration factor with zero point; 5P-CAL = with 5-point calibration
- 3 Flange nominal diameter
- 4 Nominal diameter device / Nominal pressure
- 5 Materials
- 6 Max. fluid temperature
- 7 Additional information; e.g. 3.1 = with 3.1 B certificate for wetted materials
- 8 Degree of protection
- 9 Permitted ambient temperature
- 10 Please refer to operating instructions / documentation
- 11 Reserved for additional information on device version (approvals, certificates)
- 12 Flow direction



### 2.1.3 Additional name plate for approval for custody transfer




Fig. 3: Additional plate for the approval for custody transfer (example)

- 1 Numbers of the evaluation certificates
- 2 Smallest measured quantity
- 3 Flow measuring range  $Q_{min}$  to  $Q_{max}$  in kg/min

### 2.1.4 Nameplate for connections




Fig. 4: Nameplate specifications for transmitter connections (example)

- 1 Terminal assignment for power supply
- 2 Terminal assignment pulse/frequency/status output
- 3 Terminal assignment pulse/frequency/status output
- 4 Terminal assignment MODBUS RS485

### 2.1.5 Additional sign – position of the optional rupture disk




Fig. 5: Additional sign regarding the position of the optional rupture disk



Note!  
Additional information on the burst pressure of the optional rupture disk → 43.

## 2.2 Certificates and approvals

The devices are designed in accordance with good engineering practice to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures".

The measuring system described in these Operating Instructions thus complies with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

## 2.3 Registered trademarks

FieldCare<sup>®</sup>, Fieldcheck<sup>®</sup>, Applicator<sup>®</sup>

Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH

## 3 Installation

### 3.1 Incoming acceptance, transport and storage

#### 3.1.1 Incoming acceptance

On receipt of the goods, check the following points:

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

#### 3.1.2 Transport

The following instructions apply to unpacking and to transporting the device to its final location:

- Transport the devices in the containers in which they are delivered.
- The covers or caps fitted to the process connections prevent mechanical damage to the sealing faces and the ingress of foreign matter to the measuring tube during transportation and storage. Consequently, do not remove these covers or caps until immediately before installation.

#### 3.1.3 Storage


Note the following points:

- Pack the measuring device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The permitted storage temperature is  $-40$  to  $+80^{\circ}\text{C}$  ( $-40$  to  $+176^{\circ}\text{F}$ ).
- Do not remove the protective covers or caps on the process connections until you are ready to install the device.
- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.

### 3.2 Installation conditions

No special measures such as supports are necessary. Design features of the instrument absorb external forces.

#### 3.2.1 Dimensions

All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation entitled "Technical Information" →  46.



#### 3.2.2 Inlet and outlet runs

No special precautions need to be taken for fittings which create turbulence (valves, elbows, T-pieces, etc.), as long as no cavitation occurs.

#### 3.2.3 Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by pipe vibrations. Consequently, the sensors require no special measures for attachment.

#### 3.2.4 Limiting flow

For corresponding information, refer to →  39 and →  43.

### 3.3 Installation

#### 3.3.1 Turning the transmitter housing

The transmitter housing can be rotated counterclockwise continuously up to 360°.

1. Loosen the Allen setscrew (1) partially, but do not unscrew it all the way.
2. Rotate the transmitter housing into the desired position.
3. Tighten the Allen setscrew (1).




Fig. 6: Rotating the transmitter housing

### 3.4 Post-installation check

Perform the following checks after installing the measuring device in the pipe:

Device condition and specifications	Notes
Is the measuring instrument damaged, particularly the sealing surfaces of the process connection (visual inspection)?	–
Is the adhesive label of the optional rupture disk intact?	→ 9
Does the device correspond to specifications at the measuring point, including process temperature and pressure, ambient temperature, measuring range, etc.?	→ 39 ff.
Installation	Notes
Do the process connections used correspond to the existing process conditions (pressure, temperature) and the specified seal design on the sensor side?	–
Does the arrow on the sensor nameplate match the direction of flow through the pipe?	–
Are the measuring point number and labeling correct (visual inspection)?	–
Process environment / process conditions	Notes
Is the measuring device protected against moisture and direct sunlight?	–

## 4 Wiring



### Warning!

When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.

### 4.1 MODBUS RS485 cable specifications

Cable data	
Characteristic impedance	120 $\Omega$
Cable capacitance	< 30 pF/m
Core cross-section	> 0.34 mm <sup>2</sup> , corresponds to AWG 22
Cable type	Twisted pairs
Loop-resistance	$\leq$ 110 $\Omega$ /km
Shielding	Copper braided shielding or braided shielding and foil shielding

Note the following points for the bus structure:

- All the measuring devices are connected in a bus structure (line).
- The maximum line length (segment length) of the MODBUS RS485 system and a transmission rate of 115200 Baud is 1200 m (4000 ft). The total length of the spurs may not exceed 6.6 m (21.7 ft).
- A maximum of 32 nodes are permitted per segment.
- Each segment is terminated at either end with a terminating resistor.
- The bus length or the number of users can be increased by introducing a repeater.



### Caution!

The legal EMC requirements are fulfilled **only** when the cable shield is grounded on both sides!

## 4.2 Connecting the measuring unit

### 4.2.1 Transmitter connection



#### Warning!

- Risk of electric shock. Switch off the power supply before opening the device. Do not install or wire the device while it is connected to the power supply. Failure to comply with this precaution can result in irreparable damage to the electronics.
  - Risk of electric shock. Connect the protective ground to the ground terminal on the housing before the power supply is applied.
  - Compare the specifications on the nameplate with the local supply voltage and frequency. The national regulations governing the installation of electrical equipment also apply.
1. Detach the safety claw (a) and screw the connection compartment cover (b) off of the transmitter housing.
  2. Feed the power supply cable (d) and the signal cable (c) through the appropriate cable entries.
  3. Carry out the wiring according to the terminal assignment → 15.
  4. Screw the connection compartment cover (b) back on the transmitter housing and retighten the safety claw (a).




Fig. 7: Connecting the transmitter; cable cross-section: max. 2.5 mm<sup>2</sup> (14 AWG)

A = View A

a = Safety claw

b = Terminal compartment cover

c = Signal cable: terminal Nos. 22 to 27  
(shield for MODBUS RS485 is mandatory;  
shield for pulse, frequency and status outputs is not required, but recommended)

d = Cable for power supply: 20 to 28 V AC, 10 to 30 V DC  
Terminal No. 1: L1 for AC, L+ for DC  
Terminal No. 2: N for AC, L- for DC



#### Caution!

- The behavior of the measuring instrument below a supply voltage of 10 VDC is not defined. Correct function can no longer be guaranteed. We recommend switching off the measuring instrument if the supply voltage falls below that specified.
- Operation at a supply voltage of 30 VDC or 28 VAC can destroy the measuring instrument. We recommend limiting the supply voltage to the specified range using corresponding protective elements or other measures.

### 4.2.2 Terminal assignment



Electrical values for outputs →  39

Order version	Terminal No. (outputs)		
	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)
<i>Fixed communication boards (permanent assignment)</i>			
8FE**_*****N	Pulse/frequency/status output 2	Pulse/frequency/status output 1	MODBUS RS485

### 4.3 Degree of protection

The measuring instrument fulfills all the requirements for IP 67.

Compliance with the following points is mandatory following installation in the field or servicing, in order to ensure that IP 67 protection is maintained:

- The housing seals must be clean and undamaged when inserted into their grooves. The seals must be dried, cleaned or replaced if necessary.
- The housing screws and screw covers must be firmly tightened.
- The cables used for connection must be of the specified outside diameter (8 to 12 mm / 0.32 to 0.47").
- The cable entries must be pulled tight (item **a**, →  8).
- The cable must loop down ("water trap") before it enters the cable entry (item **b**, →  8). This arrangement prevents moisture penetrating the entry.



Note!

The cable entries must not point upwards.




Fig. 8: Installation instructions, cable entries

- Remove all unused cable entries and insert plugs instead.
- Do not remove the grommet from the cable entry.





Caution!

Do not loosen the screws of the sensor housing, as otherwise the degree of protection guaranteed by Endress+Hauser no longer applies.

## 4.4 Post-connection check

Perform the following checks after completing electrical installation of the measuring device:

Device condition and specifications	Notes
Are cables or the device damaged (visual inspection)?	–
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate? Is the protective ground connected?	20 to 28 V AC (45 to 65 Hz) 10 to 30 V DC
Do the cables comply with the specifications?	→  40
Do the cables have adequate strain relief?	–
Are the power supply and signal cables correctly connected?	See the wiring diagram inside the cover of the terminal compartment
Are all screw terminals firmly tightened?	–
Are all cable entries installed, firmly tightened and correctly sealed? Cables looped as "water traps"?	→  15
Are all housing covers installed and firmly tightened?	–



## 5 Operation

### 5.1 Quick operation guide

You have the following option for configuring and commissioning the device:




Fig. 9: Method of operating MODBUS RS485 devices

- 1 Configuration/operating program for operating via the service interface FXA291 (e.g. FieldCare)
- 2 Operation via MODBUS RS485 process control system
- 3 Situation sticker of the various DIP switch positions and their function
- 4 Option to attach a seal
- 5 Operation via device-internal DIP switch (4):  
If the DIP switch (4) is pushed upwards, the device restores the factory settings of the communication parameters of the MODBUS RS485 (return it afterwards to its original lower position).
- 6 Operation via device-internal DIP switch (3):  
If the DIP switch (3) is pushed upwards, the device restores the factory settings of all communication parameters of the MODBUS RS485 (return it afterwards to its original lower position).
- 7 Operation via device-internal DIP switch (2):  
If the DIP switch (2) is pushed upwards, the volume flow is calculated with the currently measured density, regardless of the setting configured under "VOLUME CALCULATION". If the DIP switch (2) is pushed back to the lower position, the selection under "VOLUME CALCULATION" again applies → 83.
- 8 Operation via device-internal DIP switch (1):  
If the DIP switch (1) is pushed upwards, the device is in secure operation mode. "Secure" means that no write access of any kind is possible. An exception is the totalizer 3. Its parameters also remains writable in the safe operation; that means that it also can be reset in safe operation. If the DIP switch is pushed back to the lower position, write access is enabled once again.  
This secured/locked operation mode can be used in applications such as legally and metrologically controlled (verified) measuring systems. "CUSTODY TRANSFER MEASUREMENT" → 51.



#### Note!

The DIP switches must stay at least two seconds in the desired position, until the appropriate reaction takes place. The parameters can take several minutes to be reset, after which the device restarts. Meanwhile the light emitting diode permanently shines orange. The power supply must not be switched off while the factory settings are being restored.

## 5.2 Operating option

### 5.2.1 Customer-specific parameter configuration with the FieldCare

FieldCare is Endress+Hauser's FDT-based plant asset management tool and allows the configuration and diagnosis of intelligent field devices. By using status information, you also have a simple but effective tool for monitoring devices. The Proline flowmeters are accessed via a service interface or via the service interface FXA193.

## 5.3 MODBUS RS485 communication

### 5.3.1 MODBUS RS485 technology

The MODBUS is an open, standardized fieldbus system which is deployed in the areas of manufacturing automation, process automation and building automation.



Note!

For detailed information on the MODBUS RS485 technology, refer to [www.modbus.org](http://www.modbus.org)

#### System architecture

The MODBUS RS485 distinguishes between master and slave devices.

##### ■ Master devices

Master devices determine the data traffic on the fieldbus system. They can send data without an external request.

##### ■ Slave devices

Slave devices do not have their own access rights to the data traffic of the fieldbus system, but send their data only in response to a request from a master.




Fig. 10: MODBUS RS485 system architecture

- 1 MODBUS master (PLC, etc.)
- 2 MODBUS RS485
- 3 MODBUS slave (measuring devices, etc.)

### Master/slave communication

A distinction is made between two methods of communication with regard to master/slave communication via MODBUS RS485:

#### ■ Polling (request-response-transaction)

The master sends a request telegram to **one** slave and waits for the slave's response telegram. Here, the slave is contacted directly due to its unique bus address (1 to 247).




Fig. 11: MODBUS RS485 polling data traffic

- 1 MODBUS Master
- 2 MODBUS RS485
- 3 MODBUS Slave
- a Request telegram to this slave
- b Response telegram to master

#### ■ Broadcast message

By means of the global address 0 (broadcast address), the master sends a command to all the slaves in the fieldbus system. The slaves execute the command without reporting back to the master. Broadcast messages are only permitted in conjunction with write function codes.




Fig. 12: MODBUS RS485 polling data traffic


- 1 MODBUS Master
- 2 MODBUS RS485
- 3 MODBUS Slave
- a Broadcast message command to all slaves (request is executed without a response telegram to the master)

### 5.3.2 MODBUS telegram

A request telegram from the master contains the following fields:

Telegram structure:

Slave address	Function code	Data	Check sum
---------------	---------------	------	-----------

- Slave address
  - The slave address can be in an address range from 1 to 247.
  - The master talks to all the slaves simultaneously by means of the slave address 0 (broadcast message).
- Function code
  - The function code defines which action is to be executed.
  - Function codes supported by the measuring device →  21.
- Data
  - Depending on the function code, the following values are transmitted in this data field:
    - Register start address (from which the data are transmitted)
    - Number of registers
    - Write/read data
    - Data length
- Check sum (CRC or LRC check)
  - The checksum forms the end of the message.


The master can send another message to the slave as soon as it has received an answer to the previous message or once the time-out period set at the master has expired. This time-out period can be specified or modified by the user and depends on the slave response time.

If an error occurs during data transfer or if the slave cannot execute the command from the master, the slave returns an error telegram (exception response) to the master.

The slave response telegram consists of fields that contain the requested data or that confirm that the action requested by the master has been executed. It also contains a checksum.

### 5.3.3 MODBUS function codes

The function code defines which action is to be executed. The measuring device supports the following function codes:

Function code	Name in accordance with MODBUS specification	Description
03	READ HOLDING REGISTER	Reads one or more registers of the MODBUS slave. 1 to a maximum of 125 consecutive registers (1 register = 2 byte) can be read with a telegram. <b>Application:</b> Reading measuring instrument parameters with read and write access.
04	READ INPUT REGISTER	Reads one or more registers of the MODBUS slave. 1 to a maximum of 125 consecutive registers (1 register = 2 byte) can be read with a telegram. <b>Application:</b> Reading measuring device parameters with read access.
06	WRITE SINGLE REGISTERS	Writing a <b>single</b> register with a new value. <b>Application:</b> Writes only one measuring device parameter.  <b>Note!</b> Function code 16 is used for writing several registers by means of just one telegram.
08	DIAGNOSTICS	Checks the communication connection between the master and slave. All diagnostics codes are supported.
16	WRITE MULTIPLE REGISTERS	Writes several slave registers with a new value. A maximum of 120 consecutive registers can be written with a telegram. <b>Application:</b> Writing multiple measuring device parameters.
23	READ/WRITE MULTIPLE REGISTERS	Simultaneous reading and writing of 1 to max. 118 registers in a telegram. Write access is executed before read access. <b>Application:</b> Writing and reading multiple measuring device parameters.



Note!

- Broadcast messages are only permitted with function codes 06, 16 and 23.
- The measuring device does not differentiate between function codes 03 and 04. These codes have the same result.

### 5.3.4 Maximum number of writes

If a nonvolatile device parameter is modified via the PROFIBUS, the change is saved in the DAT of the measuring device.

The number of writes to the DAT is technically restricted to a maximum of 1 million. Attention must be paid to this limit since, if exceeded, it results in data loss and measuring device failure. For this reason, avoid constantly writing nonvolatile device parameters via the MODBUS!

### 5.3.5 MODBUS register addresses

Each device parameter has a register address. The master addresses the individual device parameters via this register address.

The register addresses of the individual device parameters can be found in Chapter 12, "Function description", under the parameter description in question.




Fig. 13: Example of how a function description is illustrated in the "Description of Instrument functions" manual

- 1 Name of the function
- 2 Information on communication via MODBUS RS485
  - MODBUS register (information in decimal numerical format, 1-based)
  - Data type: Float, Integer or String
  - Possible ways of accessing the function:
    - read = read access via function codes 03, 04 or 23
    - write = write access via function codes 06, 16 or 23

### Response times

The response time of the measuring device to a request telegram of the MODBUS master is typically 5 ms, if no delay of the response telegram is desired, → 71.

### Data types

The following data types are supported by the measuring device:

- **FLOAT** (floating-point numbers IEEE 754)  
Data length = 4 bytes (2 registers)

Byte 3	Byte 2	Byte 1	Byte 0
SEEEEEEE (MSB)	EMMMMMMM	MMMMMMMM	MMMMMMMM (LSB)

S = sign  
E = exponent  
M = mantissa

■ **INTEGER**

Data length = 2 bytes (1 register)

Byte 1	Byte 0
Most significant byte (MSB)	Least significant byte (LSB)

■ **STRING**

Data length = depends on device parameter,  
e.g. illustration of a device parameter with a data length = 8 bytes (4 registers):

Byte 7		to		Byte 0
first byte		to		last byte

**Byte transmission sequence**

The MODBUS specification does not specify the transmission sequence of the bytes. For this reason, it is important to coordinate the addressing method between the master and slave during commissioning. This can be configured in the measuring device by means of the "BYTE ORDER" parameters (see instrument functions, → 72).

The bytes are transmitted depending on the option selected in the specific "BYTE ORDER" parameter:

**FLOAT:**

Selection	Time transmission sequence			
	1st	2nd	3rd	4th
1 - 0 - 3 - 2*	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)
0 - 1 - 2 - 3	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)
2 - 3 - 0 - 1	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)
3 - 2 - 1 - 0	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)

\* = Factory setting  
S = sign  
E = exponent  
M = mantissa

**INTEGER:**

Selection	Time transmission sequence	
	1st	2nd
1 - 0*	Byte 1 (MSB)	Byte 0 (LSB)
0 - 1	Byte 0 (LSB)	Byte 1 (MSB)

\* = Factory setting  
MSB = most significant byte  
LSB = least significant byte

**STRING:**

Illustration using the example of a **LPGmass** with a data length of 8 bytes.

Selection	Time transmission sequence							
	1st	2nd	3rd	4th	5th	6th	7th	8th
1 – 0 *	Byte 7 <b>L</b>	Byte 6 <b>P</b>	Byte 5 <b>G</b>	Byte 4 <b>m</b>	Byte 3 <b>a</b>	Byte 2 <b>s</b>	Byte 1 <b>s</b>	Byte 0 ↓**
0 – 1	Byte 6 <b>P</b>	Byte 7 <b>L</b>	Byte 4 <b>m</b>	Byte 5 <b>G</b>	Byte 2 <b>s</b>	Byte 3 <b>a</b>	Byte 0 ↓**	Byte 1 <b>s</b>

\* = Factory setting  
 \*\* = mandatory termination  
 MSB = most significant byte  
 LSB = least significant byte

**5.3.6 MODBUS error messages**

If the MODBUS slave detects an error in the request telegram from the master, it sends an error message consisting of the slave address, function code, error code (exception code) and checksum. To indicate that this is an error message, the lead bit of the returned function code is used. The reason for the error is transmitted to the master by means of the exception code. All error codes are supported.

**5.3.7 MODBUS auto-scan buffer**

**Function description**

The measuring device has a special memory area, known as the auto-scan buffer, for grouping nonconsecutive device parameters. This can be used to flexibly group up to 16 device parameters. The master can talk to this complete data block by means of just one request telegram.

**Structure of the auto-scan buffer**

The auto-scan buffer consists of the configuration and the data area. In the configuration area, the "Scan List" specifies which device parameters should be grouped. To do so, the corresponding register address is entered into the scan list. Up to 16 device parameters can be grouped. Float and Integer-type device parameters with read and write access are supported.

No.	Scan list	
	MODBUS configuration Register address (data type = Integer)	Configuration via Configuration program (BASIC FUNCTION → MODBUS RS485 →)
1	5001	SCAN LIST REG. 1
2	5002	SCAN LIST REG. 2
3	5003	SCAN LIST REG. 3
4	5004	SCAN LIST REG. 4
5	5005	SCAN LIST REG. 5
6	5006	SCAN LIST REG. 6
7	5007	SCAN LIST REG. 7
8	5008	SCAN LIST REG. 8
9	5009	SCAN LIST REG. 9
10	5010	SCAN LIST REG. 10
11	5011	SCAN LIST REG. 11
12	5012	SCAN LIST REG. 12



Scan list		
No.	MODBUS configuration Register address (data type = Integer)	Configuration via Configuration program (BASIC FUNCTION → MODBUS RS485 →)
13	5013	SCAN LIST REG. 13
14	5014	SCAN LIST REG. 14
15	5015	SCAN LIST REG. 15
16	5016	SCAN LIST REG. 16

### Access to data via MODBUS

The master uses the register addresses 5051 to 5081 to access the data area of the auto-scan buffer. This data area contains the values of the device parameters defined in the scan list. For example, if the register 2007 was entered for mass flow in the scan list by means of the SCAN LIST REG. 1 function, the master can read out the current measured value of the mass flow in register 5051.

Data area				
Parameter value/Measured values		Access via MODBUS register address	Data type *	Access**
Value of scan list entry No. 1	→	5051	Integer / Float	read/write
Value of scan list entry No. 2	→	5053	Integer / Float	read/write
Value of scan list entry No. 3	→	5055	Integer / Float	read/write
Value of scan list entry No. 4	→	5057	Integer / Float	read/write
Value of scan list entry No. 5	→	5059	Integer / Float	read/write
Value of scan list entry No. 6	→	5061	Integer / Float	read/write
Value of scan list entry No. 7	→	5063	Integer / Float	read/write
Value of scan list entry No. 8	→	5065	Integer / Float	read/write
Value of scan list entry No. 9	→	5067	Integer / Float	read/write
Value of scan list entry No. 10	→	5069	Integer / Float	read/write
Value of scan list entry No. 11	→	5071	Integer / Float	read/write
Value of scan list entry No. 12	→	5073	Integer / Float	read/write
Value of scan list entry No. 13	→	5075	Integer / Float	read/write
Value of scan list entry No. 14	→	5077	Integer / Float	read/write
Value of scan list entry No. 15	→	5079	Integer / Float	read/write
Value of scan list entry No. 16	→	5081	Integer / Float	read/write
* The data type depends on the device parameter entered in the scan list				
** The data access depends on the device parameter entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed by means of the data area.				

### 5.3.8 Integer scaling of the measured variables

The current measured variables such as mass flow, density, temperature etc. are usually represented on the side of the MODBUS Slaves as floating point numbers after IEEE 754 (single Precision 32 bits). Thus the value of a measured variable occupies in each case two MODBUS registers with in each case 16 bits. In order to save storage location on the side of the MODBUS Masters and/or time during the data communication, the possibility insists of making on the side of the MODBUS Slaves an integer scaling of the measured variables on 16 bits. Then the scaled value occupies only one MODBUS register.

In addition for each measured variable a scaling factor  $K$  and a scaling offset  $OS$  ( $\rightarrow$  75 ff.) is given, which are in each case integer values. The appropriate measured variable  $X$  is then scaled as follows on  $Y$  ( $\rightarrow$  74).

$$Y = \text{INT}((X \cdot K) + (32768 - OS))$$

The function INT means that the decimal point portion of the event in the brackets is **cut off** and is not rounded. If the result  $Y$  of the scaling is smaller 0 or larger than the as the largest possible value defined value  $Y_{\max}$  ( $\rightarrow$  75),  $Y_{\max} + 1$  is transferred.

Example:

Current mass flow X	1.2545 kg/min
Mass flow factor K	100
Mass flow offset OS	32768
Integer scaled mass flow Y	$Y = \text{INT}((1.2545 \cdot 100) + (32768 - 32768)) = \text{INT}(125.45 + 0) = 125$

Current mass flow X	- 1.2545 kg/min
Mass flow factor K	100
Mass flow offset OS	0
Integer scaled mass flow Y	$Y = \text{INT}((-1.2545 \cdot 100) + (32768 - 0)) = \text{INT}(-125.45 + 32768) = \text{INT}(32642.55) = 32642$

### 5.3.9 Configuring the device address

The valid device addresses are in the range from 1 to 247. In a MODBUS RS485 network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the MODBUS master. All measuring devices are delivered from the factory with the default device address 247. Configuring the device address  $\rightarrow$  71.

## 6 Commissioning

### 6.1 Function check

Make sure that all final checks have been completed before you start up your measuring point:

- Checklist for "Post-installation check" → 12
- Checklist for "Post-connection check" → 16

### 6.2 Switching on the measuring device

Once the installation checks have been successfully completed, it is time to switch on the supply voltage. The device is now operational.

The measuring device performs a number of power on self-tests. Normal measuring mode commences as soon as startup completes.



Note!

If the startup is not successful, depending on the cause, a corresponding message is displayed in the FieldCare operating program, or the status LED flashes correspondingly (→ 32).

### 6.3 Zero point adjustment

All measuring devices are calibrated with state-of-the-art technology. The zero point obtained in this way is printed on the nameplate. Calibration takes place under reference operating conditions (→ 41). Therefore, a zero point adjustment is generally **not** required!

#### 6.3.1 Preconditions for a zero point adjustment

If you want to carry out a zero point adjustment, note the following points before doing so:

- The calibration can be carried out under stable pressure conditions only.
- The zero point adjustment is carried out a zero flow. This can be achieved, for example, with shutoff valves upstream and/or downstream of the sensor or by using existing valves and gates (→ 14).
  - Normal operation → Valves 1 and 2 open
  - Zero point adjustment *with* process pressure → Valve 1 open / valve 2 closed
  - Zero point adjustment *without* process pressure → Valve 1 open / valve 2 closed
- A zero point adjustment is **not** possible if the function CUSTODY TRANSFER MEASUREMENT is selected or an error message is pending.





Fig. 14: Zero point adjustment and shut-off valves (1 + 2)

A0007910

### 6.3.2 Performing a zero point adjustment

1. Operate the system until operating conditions have settled.
2. Stop the flow ( $v = 0$  m/s).
3. Check the shutoff valves for leaks.
4. Carry out the alignment using the "ZEROPOINT ADJUST" function (→  81).

## 6.4 Memory (HistoROM)

At Endress+Hauser, the term HistoROM refers to various types of data storage modules on which process and measuring device data are stored. By unplugging and plugging such modules, device configurations can be duplicated onto other measuring devices, to cite just one example.

### 6.4.1 HistoROM/T-DAT (sensor and transmitter DAT)

The DAT is an exchangeable data memory in which all sensor-relevant parameters are stored, i.e., diameter, serial number, calibration factor, zero point, and the settings of the transmitter.

## **7 Maintenance**

No special maintenance work is required.

### **7.1 External cleaning**

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing and the seals.

## 8 Accessories/spare parts

Various accessories and spare parts, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. Detailed information on the order code in question can be obtained from the Endress+Hauser service organization.

### 8.1 Instrument-specific spare parts

Accessory	Description	Order code
Electronics module	Complete plug-in electronics module	71034464

### 8.2 Service-specific accessories

Accessory	Description	Order code
Applicator	Software for selecting and configuring flowmeters. Applicator can be downloaded from the Internet or ordered on CD-ROM for installation on a local PC. Contact your Endress+Hauser representative for more information.	DXA80 - *
FieldCare	FieldCare is Endress+Hauser's FDT-based plant asset management tool. It can configure all intelligent field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.	See the product page on the Endress+Hauser Web site: <a href="http://www.endress.com">www.endress.com</a>
FXA291	Service interface connection cable from the measuring device to the PC for operation via FieldCare.	FXA291 - *

## 9 Troubleshooting

### 9.1 Self-monitoring

Exceptional states that arise during operation are detected by the flowmeter and corresponding messages are output:

- Via the outputs, depending on the setting (→ [65](#), → [68](#))
- Via the MODBUS interface, depending on the setting (→ [72](#))
- Via error messages in the "FieldCare" operating program (→ [33](#))
- Via the status LED (→ [32](#), visible only when the device is open)

If multiple messages are pending, the one with the highest priority is output.

The message about a status can be assigned to a category as follows:

#### *OFF*

- When the status occurs, no message is generated.

#### *Error*

- The message belongs to the "Errors" category, meaning that the measuring system cannot continue measuring operation.



#### Note!

The message belongs to the "Notes" category, meaning that the measuring system may be able to continue measuring operation with restrictions.

## 9.2 Diagnosis using light emitting diode (LED)

There is a Light Emitting Diode (LED) on the meter electronics board that allows simple fault diagnostics at any time:

- If the status output was not configured to output errors or notes.
- If fault diagnostics are no longer possible via the FieldCare operating program.



**Warning!**

Risk of explosion! The electronics compartment may not be opened while there is an explosive atmosphere. This type of fault diagnostics can no longer be carried out in Ex-protected areas.




Fig. 15: Fault diagnostics using light emitting diode (a)

Status of light emitting diode (LED)	Status of measuring system
LED illuminated in green	Measuring system OK, creepage is active
LED flashes green (once per second)	Measuring system OK, operation
LED not illuminated	Measuring system no longer working
LED flashes red (three times per second)	<ul style="list-style-type: none"> <li>– Operation not possible</li> <li>– Error (fault message) pending</li> </ul>
LED flashes red/green (once per second)	<ul style="list-style-type: none"> <li>– Operation possible, but may be limited by application conditions.</li> <li>– Notice message pending</li> </ul>
LED flashes red/green (three times per second)	Zero point adjustment running
LED flashes green/orange (approx. 3 seconds long)	Secured/locked operation starts
LED flashes red/orange (approx. 3 seconds long)	Secured/locked operation stops
LED flashes red/(pause)/green (approx. 3 seconds long)	SW update active



## 9.3 Messages (FieldCare)

No. / error message	Cause	Remedy / spare part
# 001 CRITICAL FAIL		Replace the electronics module (→ 37). Spare parts: → 30
# 002 CONFIGURATION FAILURE	Inconsistent parameter configuration	Restore the factory settings.
# 011 AMP HW-EEPROM	Electronics module: Defective EEPROM	Replace the electronics module (→ 37). Spare parts: → 30
# 012 AMP SW-EEPROM	Electronics module: Error when accessing the EEPROM	Restore the factory settings.
# 021 HW-FRAM	Electronics module: Faulty FRAM	Replace the electronics module (→ 37 ff.). Spare parts: → 30
# 022 SW-FRAM	Electronics module: Error when accessing the FRAM	Contact your Endress+Hauser service organization.
# 031 HW-DAT	Sensor DAT: 1. DAT is defective. 2. DAT is not plugged in or is missing.	1. Replace DAT. Spare parts: → 30 Check the spare part set number to ensure that the new, replacement DAT is compatible with the meter electronics. 2. Insert the DAT: → 37
# 032 SW DAT	Sensor: Error when accessing the DAT.	Restore the factory settings.
# 101 STARTUP RUNNING	Measuring instrument is running though the startup procedure.	–
# 355/356 RANGE FRQ.OUT 1/2	Frequency output: The output frequency is out of range.	1. Increase the entered full scale value 2. Reduce flow rate
# 359/360 RANGE PULSE 1/2	Pulse output: Pulse output frequency is out of range.	1. Increase the setting for pulse weighting. 2. Reduce flow rate.
# 379 LOW FREQ.LIM.	The measuring tube oscillation frequency is below the permitted range.  Causes: – Measuring tube damaged – Sensor defective or damaged	Contact your Endress+Hauser service organization.
# 380 UPPER FREQUENCY LIMIT	The measuring tube oscillation frequency is above the permitted range.  Causes: – Measuring tube damaged – Sensor defective or damaged	Contact your Endress+Hauser service organization.
# 381 MEAS. TEMP. CIRC.SHORT	The temperature sensor on the measuring tube is likely defective.	Check whether the connector of the sensor signal cable is correctly plugged into the electronics module before contacting your Endress+Hauser service organization (→ 37).
# 382 MEAS. TEMP. CIRC. OPEN		
# 383 CARR.TEMP. CIRC. SHORT	The temperature sensor on the carrier tube is likely defective.	Check whether the connector of the sensor signal cable is correctly plugged into the electronics module before contacting your Endress+Hauser service organization (→ 37).
# 384 CARR. TEMP. CIRC. OPEN		
# 387 SEN.ASY.EXCEED	One of the sensor coils (on the inlet or outlet side) is probably defective.	Check whether the connector of the sensor signal cable is correctly plugged into the electronics module before contacting your Endress+Hauser service organization (→ 37).

No. / error message	Cause	Remedy / spare part
# 388 ZP-COMP. INSTABLE	External process conditions	Contact your Endress+Hauser service organization.
# 389 ZP-COMP. LIMIT	–	Contact your Endress+Hauser service organization.
# 390 COMMUNIC.DSP	–	Replace the electronics module.
# 586 OSC.AMPL.LIM	The fluid properties do not allow a continuation of the measurement.	Change or improve process conditions.
# 587 TUBE NOT OSC.	Extreme process conditions exist. The measuring system can therefore not be started. The measuring cell or electronics are defective.	Change or improve process conditions. Replace the electronics module (→ 37). Spare parts: → 30
# 692 SIM. MEASURAND	Simulation of measuring variables (e.g. mass flow).	Switch off simulation
# 700 EMPTY PIPE DET. ACTIVE	The density is below the lower limit value defined for the function "EPD VALUE LOW".	Adapt the "EPD" function to the prevailing process conditions.
# 701 EXC.CURR.LIM	The maximum current value for the measuring tube excitation coil has been reached. The instrument continues to work correctly.	This could be cause by liquids contained in the fluid. Change or improve process conditions.
# 702 FLUID INHOM.	The frequency control is not stable because the fluid properties are inhomogenous.	This could be cause by liquids contained in the fluid. Change or improve process conditions.
# 703 FLUID INHOM.	The amplitude control is not stable due to inhomogenous fluid properties.	This could be cause by liquids contained in the fluid. Change or improve process conditions.
# 704 NOISE LIMIT	The failsafe level of the sensor signal is too high.	This could be cause by liquids contained in the fluid. Change or improve process conditions.
# 731 ADJ.ZERO FAIL.	The zero point adjustment is not possible.	Make sure that zero point adjustment is carried out at "zero flow" only ( $v = 0 \text{ m/s}$ ) (→ 27).
# 740 ZEROPOINT ADJ. RUNNING	The zero point adjustment is running.	Wait until the zero point adjustment is finished.
# 800 API TABLE OUT OF RANGE	The density and/or temperature are outside the definition range of API table 53	Change or improve process conditions.
# 801 LOW. PROC. LIMIT TEMP	The temperature has fallen below the lower process limit.	Change the process condition or setting (→ 88).
# 802 UPP. PROC. LIMIT TEMP	The temperature has exceeded the process limit.	Change the process condition or setting (→ 88).
# 803 LOW. PROC. LIMIT DENS.	The density has fallen below the lower process limit.	Change the process condition or setting (→ 88).
# 804 UPP. PROC. LIMIT DENS.	The density has exceeded the upper process limit.	Change the process condition or setting (→ 88).
# 805 LOW. PROC. LIMIT MASSFLOW	The mass flow has fallen below the lower process limit.	Change the process condition or setting (→ 88).
# 806 UPP. PROC. LIMIT MASSFLOW	The mass flow has exceeded the upper process limit.	Change the process condition or setting (→ 88).
# 807 LOW. PROC. LIMIT VOLFLOW	The volume flow has fallen below the lower process limit.	Change the process condition or setting (→ 88).

No. / error message	Cause	Remedy / spare part
# 808 UPP. PROC. LIMIT VOLFLOW	The volume flow has exceeded the upper process limit.	Change the process condition or setting (→ 88).
# 809 CUSTODY TRANSFER MODE STARTED	Custody transfer mode started. The corresponding DIP switches were actuated, → 18.	–
# 810 CUSTODY TRANSFER MODE EXITED	Custody transfer mode exited. The corresponding DIP switches were actuated, → 18.	–

## 9.4 Errors without messages











Symptoms	Rectification
The error cannot be eliminated or another error pattern is present. In these instances, please contact your Endress+Hauser service organization.	<p>The following solutions are possible:</p> <p><b>Request the services of an Endress+Hauser service technician</b> If you request the services of a service technician, please be ready with the following information:</p> <ul style="list-style-type: none"> <li>– Brief error description</li> <li>– Nameplate data (→ 8): order code and serial number</li> </ul> <p><b>Return the devices to Endress+Hauser</b> Procedures must be carried out before you return a flowmeter to Endress+Hauser for repair or calibration. Please → 6. Always enclose a duly completed "Declaration of contamination" form with the flowmeter. You will find a preprinted form at the back of these Operating Instructions.</p> <p><b>Replace the transmitter electronics</b> Electronics module defective → order spare parts → 30</p>

## 9.5 Spare parts

Refer to → Chap. 9.1, → 31 ff. for detailed troubleshooting instructions. The measuring device, moreover, provides additional support in the form of continuous self-diagnosis and storage of error messages that arise.

Fault rectification can entail replacing defective components with tested spare parts. For an overview, refer to → 30.

## 9.6 Response of outputs to errors

Failsafe mode of the outputs	
Output	Failsafe mode
Frequency output	<p> Note! The failsafe mode of the frequency output can be configured in various ways (→  65):</p> <p>FALLBACK VALUE Signal output → 0 Hz</p> <p>HOLD VALUE Last valid value (preceding occurrence of the fault) is output.</p> <p>HIGH VALUE Signal output → maximum possible frequency</p>
Pulse output	<p> Note! The failsafe mode of the pulse output can be configured in various ways (→  68):</p> <p>FALLBACK VALUE Signal output → no pulses</p> <p>HOLD VALUE Last valid value (preceding occurrence of the fault) is output.</p> <p>HIGH VALUE Signal output → maximum possible pulse rate</p>
Status output	<p> Note! The assignment of the status of the output can be defined (→  70). In the event of fault, note or power supply failure → status output not conductive.</p>
Totalizer	<p> Note! The failsafe mode of the totalizer can be configured in various ways (→  56):</p> <p>STOP The totalizers are paused until the error is rectified.</p> <p>HOLD VALUE The totalizers continue to count the flow in accordance with the last valid flow value (before the error occurred).</p>
MODBUS RS485	<p> Note! The failsafe mode of the MODBUS RS485 output can be configured in various ways (→  73):</p> <p>STOP In the event of a fault, the value "NaN" (not a number) is transmitted instead of the current measured value.</p> <p>HOLD VALUE Last valid value (preceding occurrence of the fault) is output.</p>

## 9.7 Removing and installing the meter electronics



### Warning!

- Risk of explosion! The electronics compartment may not be opened while there is an explosive atmosphere.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability.

1. Switch off power supply
2. Remove the cable gland with the Allen screw (1) and insert the cable (2).
3. Remove the securing screw (3) of the protective cover.
4. Push the side snap hooks (2 x item 4) together and pull off the protective cover (5).
5. Unplug the cable connector from the electronics module:
  - Pull off the connector of the sensor signal cable (6) by pulling it forwards.
  - Pull off the connector for the power supply and signal outputs (7) by pulling them upwards.
6. Remove the HistoROM/DAT connector (8).
7. Unscrew the Phillips screws (2 x item 9) and pull out the electronics module (10).
8. Installation is the reverse of the removal procedure.



### Caution!

Use only original Endress+Hauser parts.




Fig. 16: Removing and installing the meter electronics

- |    |   |
|----|---|
| 1  | Allen screw   |
| 2  | Electronics compartment cover                       |
| 3  | Securing screw of the protective cover              |
| 4  | Snap hooks, 2 x                                     |
| 5  | Protective cover                                    |
| 6  | Connector of the sensor signal cable                |
| 7  | Cable connector for power supply and signal outputs |
| 8  | HistoROM/DAT connector                              |
| 9  | Phillips screw, 2 x                                 |
| 10 | Electronics module                                  |

## 9.8 Software history

Date	Software version	Changes to software	Operating Instructions
08.2009	1.01.00	<ul style="list-style-type: none"><li>■ Alternative behavior MODBUS interpreter</li><li>■ Factory settings</li><li>■ Integer scaled measured variables via MODBUS</li></ul>	71123638 / 13.10
12.2006	1.00.00	Original software	71059881 / 07.07

## 9.9 Return

See the information on →  6.

## 9.10 Disposal

Observe the regulations applicable in your country.

## 10 Technical data

### 10.1 Technical data at a glance

#### 10.1.1 Applications

The measuring system is used for mass flow measurement.

#### 10.1.2 Function and system design

---

Measuring principle      Mass flow measurement by the Coriolis principle

---

Measuring system      The measuring system is a compact transmitter consisting of a sensor and a transmitter.

#### 10.1.3 Input

---

Measured variable      

- Mass flow
- Volume flow (measured from the mass flow and density)
- Fluid density
- Fluid temperature (measured with temperature sensors)

---

Measuring range      Measuring ranges for non-custody transfer operation.

DN		$\dot{m}_{\min}$ to $\dot{m}_{\max}$	
[mm]	[inch]	[kg/h]	[lb/min]
8	3/8"	0 to 2000	0 to 73.5
15	1/2"	0 to 6500	0 to 238
25	1"	0 to 18000	0 to 660
40	1 1/2"	0 to 45000	0 to 1650



Note!

The values of the corresponding custody transfer certificate apply for custody transfer operation.

---

Operable flow range      1:100

#### 10.1.4 Output

---

Output signal      *Pulse / frequency output:*

For custody transfer measurement, the two frequency/pulse outputs can be operated in redundant or phase-shifted mode.

- Passive
- Galvanically isolated
- Open Collector
- Max. 30 V DC
- Max. 25 mA
- Frequency output: END VALUE FREQ 100 to 5000 Hz, on/off ratio 1:1
- Pulse output: pulse value and pulse polarity selectable, pulse width configurable (0.1 to 1000 ms)

*Status output:*

- Passive
- Open Collector
- Max. 30 V DC
- Max. 25 mA

*MODBUS RS485:*

- MODBUS device type: slave
- Address range: 1 to 247
- Functions codes supported: 03, 04, 06, 08, 16, 23
- Broadcast: supported with the function codes 06, 16, 23
- Physical interface: RS485 in accordance with standard EIA/TIA-485
- Baud rates supported: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Baud
- Transmission mode: RTU or ASCII
- Response time = typically 5 ms

Signal on alarm

*Pulse / frequency output:*

Selectable behavior

*Status output:*

Selectable behavior

*MODBUS RS485:*

Selectable behavior

Galvanic isolation

All circuits for outputs and power supply are galvanically isolated from each other.

### 10.1.5 Power supply

Electrical connections

→  13 ff.

Supply voltage


24V DC nominal voltage (10 to 30 V DC) / 24V AC nominal voltage (20 to 28 V AC)

Cable entries

*Power supply and signal cables (outputs):*

- Cable entry M20 x 1.5 (8 to 12 mm / 0.32 to 0.47")
- Threads for cable entries, 1/2" NPT, G 1/2"

Cable specifications

Each compatible cable, with a temperature specification at least 20°C (68 °F) higher than the ambient temperature prevailing in the application. We recommend using a cable with a temperature specification of +80°C (176 °F).  
For MODBUS RS485, refer to →  13.



Power consumption AC: < 4 VA  
DC: < 3.2 W

*Typical switch-on current at 24 V DC nominal voltage at  $R_i = 0.1 \Omega$  of the source.*

t [ms]	I [A]
0	10
0.1	8
0.2	7.5
0.5	7
1	6
2	4
5	1.5
10	0.125 (operating current)



Note!

The internal resistance of the source may not exceed  $R_i = 10 \Omega$ .

Power supply failure Bridging of at least 20 ms  
All measuring cell and measuring point data are maintained

Potential equalization This measuring instrument is suitable for potentially explosive atmospheres; refer to the correspondingly information in the specific Ex-specific supplementary documentation.

### 10.1.6 Performance characteristics

Reference operating conditions Error limits following ISO/DIS 11631:

- Fluid: water
- 15 to 45 °C (59 to 113 °F); 2 to 6 bar (29 to 87 psi)
- Calibration rigs returned to national calibration standards
- Zero point calibrated under operating conditions
- Density adjustment carried out

Maximum measured error *Mass flow:*  
 $\pm 0.2\% \pm [(\text{zero point stability} \div \text{measured value}) \cdot 100]\% \text{ o.r.}$

*Volume flow:*  
 $\pm 0.3\% \pm [(\text{zero point stability} \div \text{measured value}) \cdot 100]\% \text{ o.r.}$

*Zero point stability*

DN		Zero point stability	
		[kg/h]	[lb/min]
8	3/8"	0.200	0.007
15	1/2"	0.650	0.024
25	1"	1.80	0.066
40	1 1/2"	4.50	0.165




Fig. 17: Max. measured error in % o.r.

Calculation example

Given: LPGmass DN 25, mass flow = 5000 kg/h

Max. measured error:  $\pm 0.2\% \pm [(zero\ point\ stability \div measured\ value) \cdot 100]\%$  o.r.

Max. measured error  $\rightarrow \pm 0.2\% \pm 1.80\ kg/h \div 5000\ kg/h \cdot 100\% = \pm 0.236\%$

Repeatability

Mass flow:

$\pm 0.10\% \pm [\frac{1}{2} \cdot (zero\ point\ stability \div measured\ value) \cdot 100]\%$  o.r.

Volume flow:

$\pm 0.15\% \pm [\frac{1}{2} \cdot (zero\ point\ stability \div measured\ value) \cdot 100]\%$  o.r.

Influence of medium temperature

When there is a difference between the temperature for zero point adjustment and the process temperature, the typical measured error is  $\pm 0.0003\%$  of the full scale value / °C.

Influence of medium pressure

The following section shows the effect on accuracy of mass flow due to a difference between calibration pressure and process pressure is negligible.

**10.1.7 Operating conditions: Installation**

Installation instructions

$\rightarrow$  11 ff.

Inlet and outlet runs

There are no installation requirements regarding inlet and outlet runs.

System pressure

No special precautions regarding the system pressure are required, but observe the safety instructions on  $\rightarrow$  5 ff.

**10.1.8 Operating conditions: Environment**

Ambient temperature range

-40 to +60 °C (-40 to +140 °F) for measuring instrument  
Install the device at a shady location. Avoid direct sunlight, particularly in warm climatic regions.

Storage temperature

-40 to +80 °C (-40 to +176 °F), preferably at +20 °C (+68 °F)

Degree of protection

Standard: IP 67 (NEMA 4X) for transmitter and sensor

Shock resistance In accordance with IEC 68-2-31 and EN 60721 (Class 2M3)

Vibration resistance In accordance with IEC 68-2-31 and EN 60721 (Class 2M3)

Electromagnetic compatibility In accordance with IEC/EN 61326

### 10.1.9 Operating conditions: Process

Medium temperature range -40 to +125 °C (-40 to +257 °F)

Limiting medium pressure range The material load diagrams (pressure-temperature diagrams) are provided in the separate "Technical Information" document on the device in question, which can be downloaded as a PDF file from [www.endress.com](http://www.endress.com). All available documents are provided in the "Documentation" section, → [46](#).

Optional rupture disk in the sensor housing Triggering pressure in the housing 10 to 15 bar (145 to 218 psi)

Flow rate Refer to the information on → [39](#) ("Measuring range")

Pressure loss (SI units) Pressure loss depends on the properties of the fluid and on its flow. The following formulas can be used to approximately calculate the pressure loss:

#### Pressure loss formulas

Reynolds number	$Re = \frac{2 \cdot \dot{m}}{\pi \cdot d \cdot \nu \cdot \rho}$	A0004623
$Re \geq 2300$ *	$\Delta p = K \cdot \nu^{0.25} \cdot \dot{m}^{1.85} \cdot \rho^{-0.86}$	A0004626
$Re < 2300$	$\Delta p = K1 \cdot \nu \cdot \dot{m} + \frac{K2 \cdot \nu^{0.25} \cdot \dot{m}^2}{\rho}$	A0004628
$\Delta p$ = pressure loss [mbar] $\nu$ = kinematic viscosity [m <sup>2</sup> /s] $\dot{m}$ = mass flow [kg/s]	$\rho$ = fluid density [kg/m <sup>3</sup> ] $d$ = inside diameter of measuring tubes [m] K to K2 = constants (depending on nominal diameter)	

#### Pressure loss coefficient

DN	d[m]	K	K1	K2
8	$5.35 \cdot 10^{-3}$	$5.70 \cdot 10^7$	$7.91 \cdot 10^7$	$2.10 \cdot 10^7$
15	$8.30 \cdot 10^{-3}$	$7.62 \cdot 10^6$	$1.73 \cdot 10^7$	$2.13 \cdot 10^6$
25	$12.00 \cdot 10^{-3}$	$1.89 \cdot 10^6$	$4.66 \cdot 10^6$	$6.11 \cdot 10^5$
40	$17.60 \cdot 10^{-3}$	$4.42 \cdot 10^5$	$1.35 \cdot 10^6$	$1.38 \cdot 10^5$




Fig. 18: Pressure loss diagram for water

Pressure loss (US units)

The pressure loss depends on the nominal diameter and fluid properties. The "Applicator" PC software, which is available from Endress+Hauser, allows you to calculate the pressure loss in US units. The "Applicator" program contains all important device data, enabling you to optimize the measuring system arrangement.

The software is used for the following calculations:

- Nominal diameter of the sensor with fluid properties such as viscosity, density etc.
- Pressure loss behind the measuring point
- Conversion of mass flow into volume flow etc.
- Simultaneous display of variables measured by different measuring instruments
- Determining the measuring ranges

Applicator runs on any IBM-compatible PC with Windows.

**10.1.10 Mechanical construction**

Design / dimensions

The dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document, which can be downloaded as a PDF file from [www.endress.com](http://www.endress.com). A list of the available "Technical Information" documents is provided in the "Documentation" section → 46.

Weight

DN in mm (inch)	8 (3/8")	15 (1/2")	25 (1")	40 (1 1/2")
Weight in kg (lb)	6.7 (14.7)	7.2 (15.8)	8.8 (19.4)	13.7 (30.2)

The weights refer to devices with EN/DIN PN 40 flanges.

Material

Transmitter housing:  
Powder coated die-cast aluminum

Sensor housing:  
Acid-resistant and alkali-resistant external surface, stainless steel 1.4301/304

Process connection:  
All process connection: Stainless steel 1.4404/316L

Measuring tubes:  
Stainless steel 1.4539 /904L

---

Process connections	<ul style="list-style-type: none"> <li>■ VCO coupling</li> <li>■ Tri-Clamp connections</li> <li>■ Flanges according to: <ul style="list-style-type: none"> <li>– EN 1092-1 (DIN 2501, DIN 2512 N)</li> <li>– ANSI B16.5</li> <li>– JIS B2220</li> </ul> </li> <li>■ Connections according to: <ul style="list-style-type: none"> <li>– DIN 11851 (threaded hygienic connection)</li> <li>– DIN 11864-1 Form A (threaded hygienic connection)</li> </ul> </li> </ul>
---------------------	---

### 10.1.11 Human interface

---

Display elements	Status LED
------------------	------------

---

Remote operation	Operation takes place using the "FieldCare" configuration and service program from Endress+Hauser and the MODBUS RS485, which can be used to configure parameters for functions and read measuring values.
------------------	--

### 10.1.12 Certificates and approvals

---

CE mark	The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.
---------	---

---

C-Tick symbol	The measuring system complies with the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
---------------	--

---

Ex approval	Information about currently available Ex versions (ATEX, FM, CSA) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate Ex documentation, which is also available upon request.
-------------	---

---

Pressure measuring device approval	<p>The measuring devices can be ordered with or without PED (Pressure Equipment Directive). If a device with PED is required, this must be ordered explicitly. For devices with nominal diameters less than or equal to DN 25 (1"), this is neither possible nor necessary.</p> <ul style="list-style-type: none"> <li>■ With the identification PED/G1/III on the sensor nameplate, Endress+Hauser confirms conformity with the "Basic safety requirements" of Appendix I of the Pressure Equipment Directive 97/23/EC.</li> <li>■ Devices with this identification (with PED) are suitable for the following types of fluid: <ul style="list-style-type: none"> <li>– Fluids of Group 1 and 2 with a steam pressure of greater or less than 0.5 bar (7.3 psi)</li> <li>– Unstable gases</li> </ul> </li> <li>■ Devices without this identification (without PED) are designed and manufactured according to good engineering practice. They correspond to the requirements of Art. 3, Section 3 of the Pressure Equipment Directive 97/23/EC. Their application is illustrated in Diagrams 6 to 9 in Appendix II of the Pressure Equipment Directive 97/23/EC.</li> </ul>
------------------------------------	---

---

**Measuring instrument approval**

LPGmass is a flowmeter for volume measurement that is suitable as a component in legally controlled measuring systems for LPG (Liquified Petroleum Gas) according to Annex MI-005 of the European Measuring Instruments Directive 2004/22/EC (MID).

LPGmass is qualified according to OIML R117-1 and has been given a MID Evaluation Certificate<sup>1)</sup> confirming its conformity with the basic requirements of the Measuring Instruments Directive.

**Note!**

However, according to the Measuring Instruments Directive, only the complete measuring system (e.g. LPG fuel pump) can be approved, covered by an EC type-examination certificate and identified with a conformity symbol.

---

**Other standards and guidelines**

- EN 60529:  
Degrees of protection by housing (IP code)
- EN 61010-1:  
Safety requirements for electrical equipment for measurement, control and laboratory use
- IEC/EN 61326:  
"Emission in accordance with requirements for Class A".  
Electromagnetic compatibility (EMC requirements)
- EN 60721:  
Shock and vibration resistance
- OIML R117-1:  
Requirements for measuring systems for liquids other than water.

---

### 10.1.13 Ordering information

The Endress+Hauser service organization can provide detailed ordering information and information on the order code.

### 10.1.14 Accessories/spare parts

→ 30

---

### 10.1.15 Documentation

- Flow measuring technology (FA00005D/06)
- Technical Information (TI00080D/06)
- Ex-Supplementary documentation ATEX (II2G): (XA00117D/06)
- Ex-Supplementary documentation FM, CSA (Div. 1): (XA00118D/06)
- Special documentation, Pressure Equipment Directive: (SD00118D/06)

---

1) The Evaluation Certificate results from the WELMEC approach (European Cooperation in Legal Metrology) for modular component certification for measuring systems according to Annex MI-005 (measuring systems for continuous and dynamic measurement of quantities of liquids other than water) of Measuring Instruments Directive 2004/22/EC


## 11 Appendix – Instrument functions

This appendix provides detailed descriptions and information about the individual instrument functions. All instrument functions can be selected and configured using the "FieldCare" configuration program from Endress+Hauser and via MODBUS RS485 → [18](#).


For measuring instruments with customer-specific parameter configuration, certain values and/or settings may differ from the factory settings listed above.


Block CUSTODY TRANSFER MEASUREMENT	→ <a href="#">51</a>
Block MEASURED VARIABLE	→ <a href="#">51</a>
Block TOTALIZER	→ <a href="#">55</a>
Block OUTPUTS	→ <a href="#">58</a>
Block BASIC FUNCTION	→ <a href="#">71</a>
Block SUPERVISION	→ <a href="#">87</a>

### 11.1 Display of function matrix










## 11.2 Block "CUSTODY TRANSFER MEASUREMENT"

### 11.2.1 Group "CUSTODY TRANSFER MEASUREMENT"



Function description CUSTODY TRANSFER MEASUREMENT → CUSTODY TRANSFER MEASUREMENT	
<p> <b>Note!</b> Switching takes place using a hardware switch. For detailed information about the function of the hardware switch, refer to →  17.</p>	
<p><b>CUSTODY TRANSFER MEASUREMENT</b></p> <p><b>MODBUS register:</b> 7551 <b>Data type:</b> Integer <b>Access:</b> Read</p>	<p>Displays whether secured/locked operation mode is active.</p> <p><b>Display:</b> 0 = OFF 1 = ON</p> <p><b>Factory setting:</b> OFF</p>


## 11.3 Block "MEASURED VARIABLE"


### 11.3.1 Group "MEASURING VALUES"





Function description MEASURED VARIABLE → MEASURING VALUES → HMAIN VALUES	
<p> <b>Note!</b> The engineering units of all the measured variables shown here can be set in the "SYSTEM UNITS" group.</p>	
<p><b>MASS FLOW</b></p> <p><b>MODBUS register:</b> 2007 <b>Data type:</b> Float <b>Access:</b> Read</p>	<p>The currently measured mass flow appears on the display.</p>
<p><b>VOLUME FLOW</b></p> <p><b>MODBUS register:</b> 2009 <b>Data type:</b> Float <b>Access:</b> Read</p>	<p>The calculated volume flow appears on the display. The volume flow is calculated from the mass flow and the density →  83.</p>
<p><b>DENSITY</b></p> <p><b>MODBUS register:</b> 2013 <b>Data type:</b> Float <b>Access:</b> Read</p>	<p>The currently measured density or its specific gravity appears on the display.</p>
<p><b>TEMPERATURE</b></p> <p><b>MODBUS register:</b> 2017 <b>Data type:</b> Float <b>Access:</b> Read</p>	<p>The currently measured temperature appears on the display.</p>

### 11.3.2 Group "SYSTEM UNITS"




<b>Function description</b> <b>MEASURED VARIABLE → SYSTEM UNITS</b>	
<p><b>UNIT MASS FLOW</b></p> <p>MODBUS register: 2101</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For selecting the desired unit for the mass flow (mass/time).</p> <p><b>Options:</b></p> <p>Metric: 0 to 3 = gram → g/s; g/min; g/h; g/day 4 to 7 = kilogram → kg/s; kg/min; kg/h; kg/day 8 to 11 = ton → t/s; t/min; t/h; t/day</p> <p>US: 12 to 15 = ounce → oz/s; oz/min; oz/h; oz/day 16 to 19 = pound → lb/s; lb/min; lb/h; lb/day 20 to 23 = ton → ton/s; ton/min; ton/h; ton/day</p> <p><b>Factory setting:</b> Country-dependent (kg/min or lb/min)</p>
<p><b>UNIT MASS</b></p> <p>MODBUS register: 2102</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For selecting the desired unit for the mass.</p> <p><b>Options:</b></p> <p>0; 1; 2 = metric → g; kg; t</p> <p>3; 4; 5 = US → oz; lb; ton</p> <p><b>Factory setting:</b> Country-dependent (kg or lb)</p> <p> <b>Note!</b> The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.</p>

<b>Function description</b>	
<b>MEASURED VARIABLE → SYSTEM UNITS</b>	
<p>UNIT VOLUME FLOW</p> <p>MODBUS register: 2103</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For selecting the desired unit for the volume flow (volume/time).</p> <p><b>Options:</b></p> <p>Metric:                      0 to 3 = cubic centimeter → cm<sup>3</sup>/s; cm<sup>3</sup>/min; cm<sup>3</sup>/h; cm<sup>3</sup>/day                      4 to 7 = cubic decimeter → dm<sup>3</sup>/s; dm<sup>3</sup>/min; dm<sup>3</sup>/h; dm<sup>3</sup>/day                      8 to 11 = cubic meter → m<sup>3</sup>/s; m<sup>3</sup>/min; m<sup>3</sup>/h; m<sup>3</sup>/day                      12 to 15 = milliliter → ml/s; ml/min; ml/h; ml/day                      16 to 19 = liter → l/s; l/min; l/h; l/day                      20 to 23 = hectoliter → hl/s; hl/min; hl/h; hl/day                      24 to 27 = megaliter → Ml/s; Ml/min; Ml/h; Ml/day</p> <p>US:                      28 to 31 = cubic centimeter → cc/s; cc/min; cc/h; cc/day                      32 to 35 = acre foot → af/s; af/min; af/h; af/day                      36 to 39 = cubic foot → ft<sup>3</sup>/s; ft<sup>3</sup>/min; ft<sup>3</sup>/h; ft<sup>3</sup>/day                      40 to 43 = fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day                      44 to 47 = gallon → gal/s; gal/min; gal/h; gal/day                      52 to 55 = barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day                      56 to 59 = barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day                      60 to 63 = barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day                      64 to 67 = Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Imperial:                      68 to 71 = gallon → gal/s; gal/min; gal/h; gal/day                      76 to 79 = barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day                      80 to 83 = Barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p><b>Factory setting:</b> Country-dependent (l/min or US gal/min)</p>
<p>UNIT VOLUME</p> <p>MODBUS register: 2104</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For selecting the desired unit for the volume.</p> <p><b>Options:</b></p> <p>Metric:                      0 to 6 = cm<sup>3</sup>; dm<sup>3</sup>; m<sup>3</sup>; ml; l; hl; Ml</p> <p>US:                      7 to 16 = cc; af; ft<sup>3</sup>; oz f; gal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks);</p> <p>Imperial:                      17; 19; 20 = gal; bbl (beer); bbl (petrochemicals)</p> <p><b>Factory setting:</b> Country-dependent (l or US gal)</p> <p> <b>Note!</b>                      The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.</p>

<b>Function description</b>	
<b>MEASURED VARIABLE → SYSTEM UNITS</b>	
UNIT DENSITY  MODBUS register: 2107  Data type: Integer Access: read/write	For selecting the desired unit for the density.  <b>Options:</b> Metric: 0 to 10 = g/cm <sup>3</sup> ; g/cc; kg/dm <sup>3</sup> ; kg/l; kg/m <sup>3</sup> ; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C  US: 11 to 16 = lb/ft <sup>3</sup> ; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks)  Imperial: 17 to 19 = lb/gal; lb/bbl (beer); lb/bbl (petrochemicals)  <b>Factory setting:</b> Country-dependent (kg/l or g/cc)   Note! SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water density (at water temperature = 4, 15, 20 °C (39, 59, 68 °F)).
UNIT TEMPERATURE  MODBUS register: 2109  Data type: Integer Access: read/write	For selecting the desired unit for the temperature.  <b>Options:</b> 0 = °C (Celsius) 1 = K (Kelvin) 2 = °F (Fahrenheit)  <b>Factory setting:</b> Country-dependent (°C or °F)
UNIT PRESSURE  MODBUS register: 2130  Data type: Integer Access: read/write	For selecting the desired unit for the pressure.  <b>Options:</b> 0 = bara 1 = barg 2 = psia 3 = psig  <b>Factory setting:</b> Country-dependent (barg or psig)

## 11.4 Block "TOTALIZER"


### 11.4.1 Group "TOTALIZER (1 to 3)"




Function description TOTALIZER → TOTALIZER 1 to 3 → CONFIGURATION	
<p> Note! The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.</p>	
<p>ASSIGN</p> <p>MODBUS register:                      Totalizer 1      2601                      Totalizer 2      2801                      Totalizer 3      3001                      Data type:        Integer                      Access:            read/write</p>	<p>For assigning a measured variable to the totalizer in question.</p> <p><b>Options:</b>                      0 = OFF                      1 = MASS FLOW                      2 = VOLUME FLOW</p> <p><b>Factory setting:</b> MASS FLOW</p> <p> Note!                      Selecting 0 = OFF or switching between options resets the totalizer to 0.</p>
<p>UNIT MASS</p> <p>MODBUS register:                      Totalizer 1      2602                      Totalizer 2      2802                      Totalizer 3      3002                      Data type:        Integer                      Access:            read/write</p>	<p>For selecting the unit for the measured variable assigned in the function ASSIGN.</p> <p><b>Options:</b>                      Metric:                      0 to 2 = g; kg; t</p> <p>US:                      3 to 5 = oz; lb; ton</p> <p><b>Factory setting:</b> kg</p>
<p>UNIT VOLUME</p> <p>MODBUS register:                      Totalizer 1      2603                      Totalizer 2      2803                      Totalizer 3      3003                      Data type:        Integer                      Access:            read/write</p>	<p>For selecting the unit for the measured variable assigned in the function ASSIGN.</p> <p><b>Options:</b>                      Metric:                      0 to 6 = cm3; dm3; m3; ml; l; hl; Ml</p> <p>US:                      7 to 16 = cc; af; ft3; oz f; gal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks)</p> <p>Imperial:                      17; 19; 20 = gal; bbl (beer); bbl (petrochemicals)</p> <p><b>Factory setting:</b> 1</p>

<b>Function description</b> <b>TOTALIZER → TOTALIZER 1 to 3 → CONFIGURATION</b>	
<p>MEASURING MODE</p> <p>MODBUS register:  Totalizer 1            2605  Totalizer 2            2805  Totalizer 3            3005  Data type:            Integer  Access:                read/write</p>	<p>For selecting how the totalizer should operate.</p> <p><b>Options:</b>  0 = BIDIRECTIONAL  Positive and negative flow components are measured.</p> <p>1 = FORWARD  Only positive flow components are measured.</p> <p>2 = REVERSE  Only negative flow components are measured.</p> <p><b>Factory setting:</b> 1 = FORWARD</p>
<p>FAIL.SENSITIVITY</p> <p>MODBUS register:  Totalizer 1            2615  Totalizer 2            2815  Totalizer 3            3015  Data type:            Integer  Access:                read/write</p>	<p>Defines the status categories to which the totalizer reacts.</p> <p><b>Options:</b>  0 = OFF  The totalizer does not react to any status.</p> <p>1 = WARNING  The totalizer reacts to warnings.</p> <p>2 = ERRORS  The totalizer reacts to errors.</p> <p>3 = ERRORS AND WARN.  The totalizer reacts to errors and warnings.</p> <p><b>Factory setting:</b> ERRORS</p>
<p>FAILSAFE MODE</p> <p>MODBUS register:  Totalizer 1            2606  Totalizer 2            2806  Totalizer 3            3006  Data type:            Integer  Access:                read/write</p>	<p>Defines how the totalizer behaves when a status occurs of the category to which the totalizer is configured to react.</p> <p><b>Options:</b>  0 = STOP  The totalizer remains at a stop.</p> <p>1 = HOLD VALUE  The totalizer resumes counting with the last value before the status occurred.</p> <p><b>Factory setting:</b> STOP</p>
<p>RESET TOTAL.</p> <p>MODBUS register:  Totalizer 1            2608  Totalizer 2            2808  Totalizer 3            3008  Data type:            Integer  Access:                read/write</p>	<p>Resets the total and the overflow of the totalizer n (1 to 3) to zero.</p> <p><b>Options:</b>  0 = CANCEL  1 = START</p>






Function description TOTALIZER 1 to 3 → OPERATION	
<p> <b>Note!</b> The following function descriptions apply to totalizers 1 to 3.</p>	
<p>SUM</p> <p>MODBUS register:</p> <p>Totalizer 1      2610</p> <p>Totalizer 2      2810</p> <p>Totalizer 3      3010</p> <p>Data type:        Float</p> <p>Access:            Read</p>	<p>Displays the total for the totalizer's measured variable aggregated since the last reset.</p>
<p>OVERFLOW</p> <p>MODBUS register:</p> <p>Totalizer 1      2612</p> <p>Totalizer 2      2812</p> <p>Totalizer 3      3012</p> <p>Data type:        Float</p> <p>Access:            Read</p>	<p>Displays the totalized measured variable of the totalizer since the last reset above 10<sup>7</sup> in the selected unit.</p>

## 11.5 Block "OUTPUTS"

### 11.5.1 Group "PULSE/FREQUENCY OUTPUTS (1 to 2)"



Function description OUTPUTS → PULSE/FREQUENCY OUTPUT 1 to 2 → CONFIGURATION	
<p>OPERATION MODE</p> <p>MODBUS register:</p> <p>Pulse/freq. output 1 3201</p> <p>Pulse/freq. output 2 3401</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>Configuration of the output as a pulse, frequency or status output.</p> <p>The functions available in this function group vary, depending on which option you select here.</p> <p><b>Options:</b>            0 = PULSE            1 = FREQUENCY            2 = STATUS            3 = OFF</p> <p><b>Factory setting:</b>            Pulse/frequency output 1: PULSE            Pulse/frequency output 2: STATUS</p>
<p>CHANNEL 2</p> <p>MODBUS register:</p> <p>Pulse/freq. output 1 3255</p> <p>Pulse/freq. output 2 3455</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>Selection for output of the assigned measured variable on PULS/FREQ.OUT. 2</p> <p><b>Options:</b>            0 = OFF = no output            1 = REDUNDANCY 0° = repeated output without time delay            2 = REDUNDANCY 90° = repeated output with time delay of one-half of a pulse width            3 = REDUNDANCY 180° = repeated output with time delay of an entire pulse width            4 = PHASE SHIFT 0° = repeated output without phase shift            5 = PHASE SHIFT 90° = repeated output with 90° phase shift            6 = PHASE SHIFT 180° = repeated output with 180° phase shift</p> <p><b>Factory setting:</b> OFF</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ REDUNDANCY 0°, REDUNDANCY 90° and REDUNDANCY 180° can be selected in PULSE mode of operation only.</li> <li>■ PHASE SHIFT 0°, PHASE SHIFT 90° and PHASE SHIFT 180° can be selected in PULSE and FREQUENCY modes of operation.</li> </ul>



Note!



The options selected in the functions MODE OF OPERATION and CHANNEL 2, and the resulting effects on the two pulse/frequency/status outputs, are illustrated on the following pages using examples.

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT 1 to 2 → CONFIGURATION																									
<p>Descriptions of pulse/frequency/status outputs</p>	<p>There are two pulse/frequency/status outputs, which can be operated <b>independent</b> or <b>dependent</b> of each other. In PULSE and FREQUENCY modes, flow measurement values can be output; in STATUS mode, statuses can be output. For example, the first pulse/frequency/status output can be used as the pulse output for mass flow, and the second pulse/frequency/status output can be used as the status output for the system status.</p> <p>If, for custody transfer reasons or due to the function of the downstream totalizer counter, a measured value must be output redundantly or phase-shifted, a logical pulse/frequency/status output assigns both physical outputs (selection with parameter CHANNEL 2). The other pulse/frequency/status output is then switched off, regardless of its mode of operation.</p> <p>The parameter CHANNEL 2 is used to select the mode of the measured value output on the second channel. A distinction is made between the redundant pulse output REDUNDANCY in PULSE mode of operation and PHASE SHIFT in PULSE or FREQUENCY mode.</p> <p>Redundant pulse output means that a pulse in the first channel must always be followed by a corresponding pulse in the second channel. On the contrary, the phase shift relates to the period length of the output signal of the logically first channel.</p> <p>The following applies for the examples below:</p> <ul style="list-style-type: none"> <li>■ Wiring of pulse/frequency/status output 1 24 V DC via 1 kW pull-up at terminal 24 (+), terminal 25 (-) at ground, Signal tapped at terminal 24 (+)</li> <li>■ Wiring of pulse/frequency/status output 2 24 V DC via 1 kW pull-up at terminal 22 (+), terminal 23 (-) at ground, Signal tapped at terminal 22 (+)</li> </ul>																								
<p>Example 1 (in metric units)</p>	<p>Mass flow = +3600 kg/h</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Parameter</th> <th style="text-align: center;">IFS output ①</th> <th style="text-align: center;">IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Pulse</td> <td>Status</td> </tr> <tr> <td>2. CHANNEL</td> <td>Off</td> <td>-</td> </tr> <tr> <td>ASSIGN</td> <td>Mass flow</td> <td>Fault</td> </tr> <tr> <td>MEASURING MODE</td> <td>Bidirectional</td> <td>-</td> </tr> <tr> <td>PULSE VALUE</td> <td>0,001 kg</td> <td>-</td> </tr> <tr> <td>PULSE WIDTH</td> <td>0,25 ms</td> <td>-</td> </tr> <tr> <td>SIGNAL FORM</td> <td>Passive positive</td> <td>-</td> </tr> </tbody> </table> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>Output signal:</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz</p> <p>Gauge 0 V DC, because no error status active</p> </div> <div style="flex: 2;"> </div> </div>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Pulse	Status	2. CHANNEL	Off	-	ASSIGN	Mass flow	Fault	MEASURING MODE	Bidirectional	-	PULSE VALUE	0,001 kg	-	PULSE WIDTH	0,25 ms	-	SIGNAL FORM	Passive positive	-
Parameter	IFS output ①	IFS output ②																							
OPERATION MODE	Pulse	Status																							
2. CHANNEL	Off	-																							
ASSIGN	Mass flow	Fault																							
MEASURING MODE	Bidirectional	-																							
PULSE VALUE	0,001 kg	-																							
PULSE WIDTH	0,25 ms	-																							
SIGNAL FORM	Passive positive	-																							







Function description OUTPUTS → PULSE/FREQUENCY OUTPUT 1 to 2 → CONFIGURATION																															
<p>Example 2 (in metric units)</p>	<p>Mass flow = +3600 kg/h</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>IFS output ①</th> <th>IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Pulse</td> <td>Frequency</td> </tr> <tr> <td>2. CHANNEL</td> <td>Off</td> <td>Off</td> </tr> <tr> <td>ASSIGN</td> <td>Mass flow</td> <td>Mass flow</td> </tr> <tr> <td>MEASURING MODE</td> <td>Bidirectional</td> <td>Bidirectional</td> </tr> <tr> <td>PULSE VALUE</td> <td>0,001 kg</td> <td>-</td> </tr> <tr> <td>PULSE WIDTH</td> <td>0,25 ms</td> <td>-</td> </tr> <tr> <td>SIGNAL FORM</td> <td>Passive positive</td> <td>Passive positive</td> </tr> <tr> <td>END VALUE</td> <td>-</td> <td>36000 kg/h</td> </tr> <tr> <td>END VALUE FREQ.</td> <td>-</td> <td>5 kHz</td> </tr> </tbody> </table> <p>Output signal:</p> <p>Pulse with 0,25 ms length Pulse rate = <math>(3600 \text{ kg/h}) / 0,001 \text{ kg}</math> = 1 kHz</p> <p>Frequency <math>f =</math> <math>(3600 \text{ kg/h}) /</math> <math>(36000 \text{ kg/h}) \times</math> <math>5 \text{ kHz} = 500 \text{ Hz}</math></p> <p style="text-align: right; font-size: small;">A0006947-EN</p>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Pulse	Frequency	2. CHANNEL	Off	Off	ASSIGN	Mass flow	Mass flow	MEASURING MODE	Bidirectional	Bidirectional	PULSE VALUE	0,001 kg	-	PULSE WIDTH	0,25 ms	-	SIGNAL FORM	Passive positive	Passive positive	END VALUE	-	36000 kg/h	END VALUE FREQ.	-	5 kHz
Parameter	IFS output ①	IFS output ②																													
OPERATION MODE	Pulse	Frequency																													
2. CHANNEL	Off	Off																													
ASSIGN	Mass flow	Mass flow																													
MEASURING MODE	Bidirectional	Bidirectional																													
PULSE VALUE	0,001 kg	-																													
PULSE WIDTH	0,25 ms	-																													
SIGNAL FORM	Passive positive	Passive positive																													
END VALUE	-	36000 kg/h																													
END VALUE FREQ.	-	5 kHz																													
<p>Example 3 (in metric units)</p>	<p>Mass flow = +3600 kg/h</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>IFS output ①</th> <th>IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Pulse</td> <td>Off*</td> </tr> <tr> <td>2ND CHANNEL</td> <td>Redundancy 90°</td> <td>-</td> </tr> <tr> <td>ASSIGN</td> <td>Mass flow</td> <td>-</td> </tr> <tr> <td>MEASURING MODE</td> <td>Bidirectional</td> <td>-</td> </tr> <tr> <td>PULSE VALUE</td> <td>0,001 kg</td> <td>-</td> </tr> <tr> <td>PULSE WIDTH</td> <td>0,25 ms</td> <td>-</td> </tr> <tr> <td>SIGNAL FORM</td> <td>Passive positive</td> <td>-</td> </tr> </tbody> </table> <p>* because 2ND CHANNEL on IFS 1 is set to Redundancy 90°.</p> <p>Output signal:</p> <p>Pulse with 0,25 ms length Pulse rate = <math>(3600 \text{ kg/h}) / 0,001 \text{ kg}</math> = 1 kHz</p> <p>Pulse with 0,25 ms length Pulse rate = <math>(3600 \text{ kg/h}) / 0,001 \text{ kg}</math> = 1 kHz, <b>lagging</b> half a pulse width, because mass flow is <b>positive</b></p> <p style="text-align: right; font-size: small;">A0006948-EN</p>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Pulse	Off*	2ND CHANNEL	Redundancy 90°	-	ASSIGN	Mass flow	-	MEASURING MODE	Bidirectional	-	PULSE VALUE	0,001 kg	-	PULSE WIDTH	0,25 ms	-	SIGNAL FORM	Passive positive	-						
Parameter	IFS output ①	IFS output ②																													
OPERATION MODE	Pulse	Off*																													
2ND CHANNEL	Redundancy 90°	-																													
ASSIGN	Mass flow	-																													
MEASURING MODE	Bidirectional	-																													
PULSE VALUE	0,001 kg	-																													
PULSE WIDTH	0,25 ms	-																													
SIGNAL FORM	Passive positive	-																													

Function description																									
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 to 2 → CONFIGURATION																									
<p>Example 4 (in metric units)</p>	<p>Mass flow = -3600 kg/h</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>IFS output ①</th> <th>IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Pulse</td> <td>Off *</td> </tr> <tr> <td>2ND CHANNEL</td> <td>Redundancy 90°</td> <td>-</td> </tr> <tr> <td>ASSIGN</td> <td>Mass flow</td> <td>-</td> </tr> <tr> <td>MEASURING MODE</td> <td>Bidirectional</td> <td>-</td> </tr> <tr> <td>PULSE VALUE</td> <td>0,001 kg</td> <td>-</td> </tr> <tr> <td>PULSE WIDTH</td> <td>0,25 ms</td> <td>-</td> </tr> <tr> <td>SIGNAL FORM</td> <td>Passive positive</td> <td>-</td> </tr> </tbody> </table> <p>* because 2ND CHANNEL on IFS 1 is set to Redundancy 90°.</p> <p>Output signal:</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz, <b>advanced</b> half a pulse width, because mass flow is <b>negative</b></p> <p style="text-align: right;"><small>A0006949-EN</small></p>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Pulse	Off *	2ND CHANNEL	Redundancy 90°	-	ASSIGN	Mass flow	-	MEASURING MODE	Bidirectional	-	PULSE VALUE	0,001 kg	-	PULSE WIDTH	0,25 ms	-	SIGNAL FORM	Passive positive	-
Parameter	IFS output ①	IFS output ②																							
OPERATION MODE	Pulse	Off *																							
2ND CHANNEL	Redundancy 90°	-																							
ASSIGN	Mass flow	-																							
MEASURING MODE	Bidirectional	-																							
PULSE VALUE	0,001 kg	-																							
PULSE WIDTH	0,25 ms	-																							
SIGNAL FORM	Passive positive	-																							
<p>Example 5 (in metric units)</p>	<p>Mass flow = +3600 kg/h</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>IFS output ①</th> <th>IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Pulse</td> <td>Off *</td> </tr> <tr> <td>2ND CHANNEL</td> <td>Phase shift 180°</td> <td>-</td> </tr> <tr> <td>ASSIGN</td> <td>Mass flow</td> <td>-</td> </tr> <tr> <td>MEASURING MODE</td> <td>Bidirectional</td> <td>-</td> </tr> <tr> <td>PULSE VALUE</td> <td>0,001 kg</td> <td>-</td> </tr> <tr> <td>PULSE WIDTH</td> <td>0,25 ms</td> <td>-</td> </tr> <tr> <td>SIGNAL FORM</td> <td>Passive positive</td> <td>-</td> </tr> </tbody> </table> <p>* because 2ND CHANNEL on IFS 1 is set to Phase shift 180°.</p> <p>Output signal:</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz, phase-shift 180°.</p> <p style="text-align: right;"><small>A0006950-EN</small></p>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Pulse	Off *	2ND CHANNEL	Phase shift 180°	-	ASSIGN	Mass flow	-	MEASURING MODE	Bidirectional	-	PULSE VALUE	0,001 kg	-	PULSE WIDTH	0,25 ms	-	SIGNAL FORM	Passive positive	-
Parameter	IFS output ①	IFS output ②																							
OPERATION MODE	Pulse	Off *																							
2ND CHANNEL	Phase shift 180°	-																							
ASSIGN	Mass flow	-																							
MEASURING MODE	Bidirectional	-																							
PULSE VALUE	0,001 kg	-																							
PULSE WIDTH	0,25 ms	-																							
SIGNAL FORM	Passive positive	-																							

<b>Function description</b>																									
<b>OUTPUTS → PULSE/FREQUENCY OUTPUT 1 to 2 → CONFIGURATION</b>																									
<p>Example 6 (in metric units)</p>	<p>Mass flow = +3600 kg/h</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>IFS output ①</th> <th>IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Pulse</td> <td>Off *</td> </tr> <tr> <td>2ND CHANNEL</td> <td>Phase shift 180°</td> <td>-</td> </tr> <tr> <td>ASSIGN</td> <td>Mass flow</td> <td>-</td> </tr> <tr> <td>MASURING MODE</td> <td>Bidirectional</td> <td>-</td> </tr> <tr> <td>PULSE VALUE</td> <td>0,001 kg</td> <td>-</td> </tr> <tr> <td>PULSE WIDTH</td> <td>0,25 ms</td> <td>-</td> </tr> <tr> <td>SIGNAL FORM</td> <td><b>Passive negative</b></td> <td>-</td> </tr> </tbody> </table> <p>* because 2ND CHANNEL on IFS 1 is set to Phase shift 180°</p> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>Output signal:</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz</p> <p>Pulse with 0,25 ms length Pulse rate = (3600 kg/h) / 0,001 kg = 1 kHz, phase-shift 180°.</p> </div> <div style="flex: 1;"> </div> </div> <p style="text-align: right; font-size: small;">A0006951-EN</p>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Pulse	Off *	2ND CHANNEL	Phase shift 180°	-	ASSIGN	Mass flow	-	MASURING MODE	Bidirectional	-	PULSE VALUE	0,001 kg	-	PULSE WIDTH	0,25 ms	-	SIGNAL FORM	<b>Passive negative</b>	-
Parameter	IFS output ①	IFS output ②																							
OPERATION MODE	Pulse	Off *																							
2ND CHANNEL	Phase shift 180°	-																							
ASSIGN	Mass flow	-																							
MASURING MODE	Bidirectional	-																							
PULSE VALUE	0,001 kg	-																							
PULSE WIDTH	0,25 ms	-																							
SIGNAL FORM	<b>Passive negative</b>	-																							
<p>Example 7 (in metric units)</p>	<p>Mass flow = +3600 kg/h</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>IFS output ①</th> <th>IFS output ②</th> </tr> </thead> <tbody> <tr> <td>OPERATION MODE</td> <td>Off *</td> <td>Frequency</td> </tr> <tr> <td>2ND CHANNEL</td> <td>-</td> <td>Phase shift 90°</td> </tr> <tr> <td>ASSIGN</td> <td>-</td> <td>Mass flow</td> </tr> <tr> <td>MEASURING MODE</td> <td>-</td> <td>Bidirectional</td> </tr> <tr> <td>SIGNAL FORM</td> <td>-</td> <td><b>Passive negative</b></td> </tr> <tr> <td>END VALUE</td> <td>-</td> <td>36000 kg/h</td> </tr> <tr> <td>END VALUE FREQ.</td> <td>-</td> <td>5 kHz</td> </tr> </tbody> </table> <p>* because 2ND CHANNEL on IFS 2 is set to Phase shift 90°</p> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>Output signal:</p> <p>Frequency f = (3600 kg/h) / (36000 kg/h) x 5 kHz = 500 Hz, <b>lagging</b> 90°, because mass flow is <b>positive</b></p> <p>Frequency f = (3600 kg/h) / (36000 kg/h) x 5 kHz = 500 Hz</p> </div> <div style="flex: 1;"> </div> </div> <p style="text-align: right; font-size: small;">A0006952-EN</p>	Parameter	IFS output ①	IFS output ②	OPERATION MODE	Off *	Frequency	2ND CHANNEL	-	Phase shift 90°	ASSIGN	-	Mass flow	MEASURING MODE	-	Bidirectional	SIGNAL FORM	-	<b>Passive negative</b>	END VALUE	-	36000 kg/h	END VALUE FREQ.	-	5 kHz
Parameter	IFS output ①	IFS output ②																							
OPERATION MODE	Off *	Frequency																							
2ND CHANNEL	-	Phase shift 90°																							
ASSIGN	-	Mass flow																							
MEASURING MODE	-	Bidirectional																							
SIGNAL FORM	-	<b>Passive negative</b>																							
END VALUE	-	36000 kg/h																							
END VALUE FREQ.	-	5 kHz																							




Function description			
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 to 2 → CONFIGURATION			
Example 8 (in metric units)	Mass flow = +3600 kg/h*		
	<b>Parameter</b>	<b>IFS output ①</b>	<b>IFS output ②</b>
	OPERATION MODE	Status	Frequency
	2ND CHANNEL	-	Off
	ASSIGN	Fault	Mass flow
	MEASURING MODE	-	Bidirectional
	SIGNAL FORM	-	Passive positive
	END VALUE	-	36000 kg/h
	END VALUE FREQ.	-	5 kHz
	FAIL SAFE MODE	-	Max. value
FAULT SENSITIVITY	-	Fault	
* but error condition #587 is active			
Output signal:			
Gauge 24 V DC, because fail safe mode is active			
Frequency f = 5 kHz, because highly possible end value frequency			


A0006953-EN







<b>Function description</b>	
<b>OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (frequency)</b>	
<p>ASSIGN</p> <p>MODBUS register: Pulse/freq. output 1 3202 Pulse/freq. output 2 3402 Data type: Integer Access: read/write</p>	<p>Assign a measured variable to the output.</p> <p> <b>Note!</b> Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b> 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW</p> <p><b>Factory setting:</b> MASS FLOW</p>
<p>END VALUE FREQ</p> <p>MODBUS register: Pulse/freq. output 1 3205 Pulse/freq. output 2 3405 Data type: Float Access: read/write</p>	<p>For defining an end value frequency for the frequency output. Assign the corresponding measured value to the measuring range in the function VALUE f HIGH (see below).</p> <p> <b>Note!</b> Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.</p> <p><b>User input:</b> 5-digit fixed-point number: 100 to 5000 Hz</p> <p><b>Factory setting:</b> 1000 Hz</p> <p>Example:</p> <ul style="list-style-type: none"> <li>■ VALUE f HIGH = 1000 kg/h, end value frequency = 1000 Hz: i.e. a frequency of 1000 Hz is output at a flow of 1000 kg/h.</li> <li>■ VALUE f HIGH = 3600 kg/h, end value frequency = 5000 Hz: i.e. a frequency of 5000 Hz is output at a flow of 3600 kg/h.</li> </ul> <p> <b>Note!</b> In the FREQUENCY operating mode, the output signal is symmetrical (on/off ratio = 1:1).</p>
<p>VALUE f HIGH</p> <p>MODBUS register: Pulse/freq. output 1 3209 Pulse/freq. output 2 3409 Data type: Float Access: read/write</p>	<p>In this function, a value is assigned to the END VALUE FREQ. Determine the desired span by defining VALUE f HIGH.</p> <p> <b>Note!</b> Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.</p> <p><b>User input:</b> Floating-point number</p> <p><b>Factory setting:</b> Depends on nominal diameter</p> <div style="text-align: center;">  </div> <p><i>Fig. 10: Behavior of frequency output</i></p> <p>a = Span A = Frequency [%] B = Measured variable (amount) 1 = VALUE f HIGH (END VALUE FREQ)</p> <p> <b>Note!</b> A value greater than VALUE f HIGH cannot be output; otherwise, a message is generated (#355/#356). We recommend providing reserve capacity during parameter configuration.</p>




A0007114




<b>Function description</b>									
<b>OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (frequency)</b>									
<p>MEASURING MODE</p> <p>MODBUS register: Pulse/freq. output 1    3211 Pulse/freq. output 2    3411 Data type:                Integer Access:                    read/write</p>	<p>Use this function to define the measuring mode for the frequency output.</p> <p> <b>Note!</b> Function available only if PULSE or FREQUENCY has been selected in the MODE OF OPERATION function.</p> <p><b>Options:</b> 0 = FORWARD 1 = BIDIRECTIONAL 3 = REVERSE</p> <p><b>Factory setting:</b> FORWARD</p> <p><b>Description of the individual options:</b> <b>FORWARD</b> Only positive flow rates are output. Negative flow rates are cut off. If the output is again on the second PULS/FREQ.OUT., the time delay or phase shift is lagging.</p> <p><b>BIDIRECTIONAL</b> Positive and negative flow rates are output. Only the amount of the flow is relevant for generating the pulses or frequency. If the output is again at the second PULS/FREQ.OUT., the time delay or phase shift is lagging if the flow rate is positive and leading if the flow rate is negative.</p> <p><b>REVERSE</b> Only negative flow rates are output. Positive flow rates are cut off. If the output is again on the second PULS/FREQ.OUT., the time delay or phase shift is leading.</p>								
<p>FAIL.SENSITIVITY</p> <p>MODBUS register: Pulse/freq. output 1    3256 Pulse/freq. output 2    3456 Data type:                Integer Access:                    read/write</p>	<p>Defines the message categories to which the output reacts.</p> <p><b>Options:</b> 0 = OFF = The output does not react to any status. 1 = WARNING = The output reacts to warnings. 2 = ERRORS = The output reacts to errors. 3 = ERRORS AND WARN. = The output reacts to errors and warnings</p> <p><b>Factory setting:</b> ERRORS</p>								
<p>FAILSAFE MODE</p> <p>MODBUS register: Pulse/freq. output 1    3215 Pulse/freq. output 2    3415 Data type:                Integer Access:                    read/write</p>	<p>Defines how the PULS/FREQ.OUT. behaves when a message occurs of the category to which the PULS/FREQ.OUT. is configured to react.</p> <p> <b>Note!</b> Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b> 0 = FALLBACK VALUE Output is 0 Hz. 2 = HOLD VALUE Measured value display on the basis of the last measured value preceding occurrence of the status. 4 = HIGH VALUE Output of the highest possible pulse rate or frequency.</p> <p><b>Factory setting:</b> FALLBACK VALUE</p> <p> <b>Note!</b> If OFF is not selected for CHANNEL 2, the failsafe mode of channel 2 is as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">1. Kanal</th> <th style="text-align: center;">2. Kanal</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">RUHEPEGEL</td> <td style="text-align: center;">MAXIMALWERT</td> </tr> <tr> <td style="text-align: center;">LETZTER WERT</td> <td style="text-align: center;">LETZTER WERT</td> </tr> <tr> <td style="text-align: center;">MAXIMALWERT</td> <td style="text-align: center;">RUHEPEGEL</td> </tr> </tbody> </table>	1. Kanal	2. Kanal	RUHEPEGEL	MAXIMALWERT	LETZTER WERT	LETZTER WERT	MAXIMALWERT	RUHEPEGEL
1. Kanal	2. Kanal								
RUHEPEGEL	MAXIMALWERT								
LETZTER WERT	LETZTER WERT								
MAXIMALWERT	RUHEPEGEL								



Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (frequency)	
<p>OUTPUT SIGNAL</p> <p>MODBUS register: Pulse/freq. output 1    3212 Pulse/freq. output 2    3412 Data type:                Integer Access:                    read/write</p>	<p>Use this function to select the polarity of the output signal.</p> <p> <b>Note!</b> Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b> 0 = PASSIVE/POSITIVE 1 = PASSIVE/NEGATIVE</p> <p><b>Factory setting:</b> PASSIVE/POSITIVE</p> <p><b>Description of the individual options:</b> PASSIVE/POSITIVE The output transistor is <b>nonconductive</b> during the first half of the period of the output signal and <b>conductive</b> during the second half of the period.</p> <p>PASSIVE/NEGATIVE The output transistor is <b>conductive</b> during the first half of the period of the output signal and <b>nonconductive</b> during the second half of the period.</p>

<b>Function description</b>	
<b>OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (pulse)</b>	
<p>ASSIGN</p> <p>MODBUS register:                      Pulse/freq. output 1    3223                      Pulse/freq. output 2    3423                      Data type:                    Integer                      Access:                        read/write</p>	<p>Assign a measured variable to the output.</p> <p> <b>Note!</b>                      Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b>                      0 = OFF                      2 = MASS FLOW                      5 = VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p>
<p>PULSE VALUE</p> <p>MODBUS register:                      Pulse/freq. output 1    3224                      Pulse/freq. output 2    3424                      Data type:                    Float                      Access:                        read/write</p>	<p>Use this function to define the flow at which a pulse is triggered. These pulses can be totaled by an external totalizer, and the total flow quantity since measuring started can be registered in this way.</p> <p> <b>Note!</b>                      Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p><b>User input:</b> Floating-point number</p> <p><b>Factory setting:</b> Depends on nominal diameter</p>
<p>PULSE WIDTH</p> <p>MODBUS register:                      Pulse/freq. output 1    3226                      Pulse/freq. output 2    3426                      Data type:                    Float                      Access:                        read/write</p>	<p>Use this function to enter the pulse width of the output pulse.</p> <p> <b>Note!</b>                      Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p><b>User input:</b> 0.1 to 1000 ms</p> <p><b>Factory setting:</b> 1 ms</p> <p>Pulse output is always with the pulse width (B) entered in this function. The pauses (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width (B = P).</p> <div style="text-align: center;">  </div> <p><i>Fig. 20: Pulse Width</i></p> <p>B = Pulse width entered (the illustration applies to positive pulses)                      P = Pauses between the individual pulses</p> <p> <b>Note!</b>                      When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.).</p> <p> <b>Caution!</b>                      If the pulse rate resulting from the entered pulse value (see above) and the current flow rate is too large to maintain the selected pulse width (the pause interval P is smaller than the entered pulse width B), a message is generated (# 359/360).</p>

<b>Function description</b>									
<b>OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (pulse)</b>									
<p>MEASURING MODE</p> <p>MODBUS register: Pulse/freq. output 1    3228 Pulse/freq. output 2    3428 Data type:                Integer Access:                    read/write</p>	<p>Use this function to define the measuring mode for the pulse output.</p> <p> <b>Note!</b> Function available only if PULSE or FREQUENCY has been selected in the MODE OF OPERATION function.</p> <p><b>Options:</b> 0 = FORWARD 1 = BIDIRECTIONAL 3 = REVERSE</p> <p><b>Factory setting:</b> FORWARD</p> <p><b>Description of the individual options:</b></p> <p><b>BALANCE</b> Positive and negative flow rates are output. Only the amount of the flow is relevant for generating the pulses or frequency. If the output is again at the second PULS/FREQ.OUT., the time delay or phase shift is lagging if the flow rate is positive and leading if the flow rate is negative.</p> <p><b>FORWARD</b> Only positive flow rates are output. Negative flow rates are cut off. If the output is again on the second PULS/FREQ.OUT., the time delay or phase shift is lagging.</p> <p><b>REVERSE</b> Only negative flow rates are output. Positive flow rates are cut off. If the output is again on the second PULS/FREQ.OUT., the time delay or phase shift is leading.</p>								
<p>FAIL.SENSITIVITY</p> <p>MODBUS register: Pulse/freq. output 1    3254 Pulse/freq. output 2    3454 Data type:                Integer Access:                    read/write</p>	<p>Defines the message categories to which the output reacts.</p> <p><b>Options:</b> 0 = OFF = The output does not react to any status. 1 = WARNING = The output reacts to warnings. 2 = ERRORS = The output reacts to errors. 3 = ERRORS AND WARN. = The output reacts to warnings and messages</p> <p><b>Factory setting:</b> ERRORS</p>								
<p>FAILSAFE MODE</p> <p>MODBUS register: Pulse/freq. output 1    3230 Pulse/freq. output 2    3430 Data type:                Integer Access:                    read/write</p>	<p>Defines how the PULS/FREQ.OUT. behaves when a message occurs of the category to which the PULS/FREQ.OUT. is configured to react.</p> <p> <b>Note!</b> Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b> 0 = FALLBACK VALUE Output is 0 Hz. 2 = HOLD VALUE Measured value display on the basis of the last measured value preceding occurrence of the message. 4 = HIGH VALUE Output of the highest possible pulse rate or frequency.</p> <p><b>Factory setting:</b> FALLBACK VALUE</p> <p> <b>Note!</b> If OFF is not selected for CHANNEL 2, the failsafe mode of channel 2 is as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">1st channel</th> <th style="text-align: center;">2nd channel</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">FALLBACK VALUE</td> <td style="text-align: center;">HIGH VALUE</td> </tr> <tr> <td style="text-align: center;">HOLD VALUE</td> <td style="text-align: center;">HOLD VALUE</td> </tr> <tr> <td style="text-align: center;">HIGH VALUE</td> <td style="text-align: center;">FALLBACK VALUE</td> </tr> </tbody> </table>	1st channel	2nd channel	FALLBACK VALUE	HIGH VALUE	HOLD VALUE	HOLD VALUE	HIGH VALUE	FALLBACK VALUE
1st channel	2nd channel								
FALLBACK VALUE	HIGH VALUE								
HOLD VALUE	HOLD VALUE								
HIGH VALUE	FALLBACK VALUE								


A0007100-EN

<b>Function description</b>	
<b>OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (pulse)</b>	
<p>OUTPUT SIGNAL</p> <p>MODBUS register: Pulse/freq. output 1    3229 Pulse/freq. output 2    3429 Data type:                Integer Access:                    read/write</p>	<p>Use this function to select the polarity of the output signal.</p> <p> <b>Note!</b> Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b> 0 = PASSIVE/POSITIVE 1 = PASSIVE/NEGATIVE</p> <p><b>Factory setting:</b> PASSIVE/POSITIVE</p> <p><b>Description of the individual options:</b> PASSIVE/POSITIVE The output transistor is <b>nonconductive</b> during the first half of the output of a pulse and <b>conductive</b> otherwise.</p> <p>PASSIVE/NEGATIVE The output transistor is <b>conductive</b> during the first half of the output of a pulse and <b>nonconductive</b> otherwise.</p>





<b>Function description</b>	
<b>OUTPUTS → PULSE/FREQUENCY OUTPUTS 1 to 2 → CONFIGURATION (status)</b>	
<p>ASSIGN STATUS</p> <p>MODBUS register: Pulse/freq. output 1    3236 Pulse/freq. output 2    3436 Data type:                Integer Access:                    read/write</p>	<p>Use this function to assign a switching function to the status output.</p> <p> <b>Note!</b> Function is not available unless the STATUS setting was selected in the OPERATION MODE function.</p> <p><b>Options:</b> 0 = OFF → nonconductive 1 = ON → conductive 2 = ERROR → nonconductive if error message is present 3 = WARNING → nonconductive if warning message is present 4 = ERROR AND WARN. → nonconductive if error or warning message is present 6 = FLOW DIRECTION → conductive if flow rate is positive and nonconductive if flow rate is negative</p> <p><b>Factory setting:</b> ERRORS</p>
<p>ACTUAL STATUS</p> <p>MODBUS register:    3248 Data type:            Integer Access:                read/write</p>	<p>Use this function to check the current status of the status output.</p> <p> <b>Note!</b> Function is not available unless the STATUS setting was selected in the OPERATION MODE function.</p> <p><b>Display:</b> 0 = NON CONDUCTIVE 1 = CONDUCTIVE</p>

## 11.6 Block "BASIC FUNCTION"


### 11.6.1 Group "MODBUS RS485"




Function description BASIC FUNCTION → MODBUS RS485 → CONFIGURATION	
<p>TRANSMISS. MODE</p> <p>MODBUS register: 4913 Data type: Integer Access: read/write</p>	<p>For selecting the data transfer mode.</p> <p><b>Options:</b> 0 = RTU 1 = ASCII</p> <p><b>Factory setting:</b> RTU</p>
<p>BAUDRATE</p> <p>MODBUS register: 4912 Data type: Integer Access: read/write</p>	<p>For selecting the baud rate.</p> <p><b>Options:</b> 0 = 1200 BAUD 1 = 2400 BAUD 2 = 4800 BAUD 3 = 9600 BAUD 4 = 19200 BAUD 5 = 38400 BAUD 6 = 57600 BAUD 7 = 115200 BAUD</p> <p><b>Factory setting:</b> 19200 BAUD</p>
<p>PARITY</p> <p>MODBUS register: 4914 Data type: Integer Access: read/write</p>	<p>For selecting whether no parity bit or an even or uneven parity bit should be transmitted.</p> <p><b>Options:</b> 0 = EVEN 1 = ODD 2 = NONE/STOP BITS 2 3 = NONE/STOP BITS 1</p> <p><b>Factory setting:</b> EVEN</p>
<p>DELAY TELE. REPLY</p> <p>MODBUS register: 4916 Data type: Float Access: read/write</p>	<p>For entering a minimum delay time after which the measuring device replies to the request telegram of the MODBUS master. This allows communication to be adapted to slow MODBUS RS485 masters.</p> <p><b>User input:</b> 0 to 1000 ms</p> <p><b>Factory setting:</b> 10 ms</p>
<p>FIELD BUS ADDRESS</p> <p>MODBUS register: 4910 Data type: Integer Access: read/write</p>	<p>For entering the device address.</p> <p><b>User input:</b> 1 to 247</p> <p><b>Factory setting:</b> 247</p>


<b>Function description</b>	
<b>BASIC FUNCTION → MODBUS RS485 → CONFIGURATION</b>	
BYTEORDER FLOAT  MODBUS register: 4924 Data type: Integer Access: read/write	Select the transmission sequence of bytes for the data type Float.  <b>Options:</b> 0 = 0 - 1 - 2 - 3 1 = 3 - 2 - 1 - 0 2 = 2 - 3 - 0 - 1 3 = 1 - 0 - 3 - 2  <b>Factory setting:</b> 1 - 0 - 3 - 2   Note! <ul style="list-style-type: none"> <li>■ The transmission sequence must suit the MODBUS master.</li> <li>■ For more information, refer to the keyword "Byte transmission sequence", → 23.</li> </ul>
BYTEORDER STRING  MODBUS register: 4922 Data type: Integer Access: read/write	Select the transmission sequence of bytes for the data type String.  <b>Options:</b> 0 = 0 - 1 1 = 1 - 0  <b>Factory setting:</b> 1 - 0   Note! <ul style="list-style-type: none"> <li>■ The transmission sequence must suit the MODBUS master.</li> <li>■ For more information, refer to the keyword "Byte transmission sequence", → 23.</li> </ul>
BYTEORDER INT  MODBUS register: 4923 Data type: Integer Access: read/write	Select the transmission sequence of bytes for the data type Integer.  <b>Options:</b> 0 = 0 - 1 1 = 1 - 0  <b>Factory setting:</b> 1 - 0   Note! <ul style="list-style-type: none"> <li>■ The transmission sequence must suit the MODBUS master.</li> <li>■ For more information, refer to the keyword "Byte transmission sequence", → 23.</li> </ul>
TAG NAME  MODBUS register: 4901 Data type: String (16) Access: read/write	For entering a tag name for the measuring device.  <b>User input:</b> max. 15-character text, permissible: A-Z, 0-9, +, -, punctuation marks  <b>Factory setting:</b> " _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ " (No text)   Note! For the MODBUS, the input must end with the termination (binary null).
FAIL.SENSITIVITY  MODBUS register: 4921 Data type: Integer Access: read/write	Defines the message categories to which the data transmission reacts.  <b>Options:</b> 0 = OFF = The data transmission does not react to any messages. 1 = WARNING = The data transmission reacts to warnings. 2 = ERRORS = The data transmission reacts to errors. 3 = ERRORS AND WARN. = The data transmission reacts to errors and warnings  <b>Factory setting:</b> ERRORS




Function description BASIC FUNCTION → MODBUS RS485 → CONFIGURATION	
<p>FAILSAFE MODE</p> <p>MODBUS register: 4920 Data type: Integer Access: read/write</p>	<p>Defines how the measured value output behaves when a message occurs of the category to which it is configured to react.</p> <p><b>Options:</b> 0 = STOP = The data transmission returns "NaN" 1 = HOLD VALUE = The data transmission returns the last value before the message occurred.</p> <p><b>Factory setting:</b> STOP</p>
<p><b>INTERPRETER MODE</b></p> <p>MODBUS Register: 4925 Datentyp: Integer Access: read/write</p>	<p>Defines how the interpreter of telegram receipt behaves.</p> <p><b>Options:</b> 0 = STANDARD = Behavior in accordance with MODBUS standard, i.e. the two last received bytes are the check sum CRC16. 1 = IGNORE SURPLUS BYTES = the two bytes for the check sum CRC16 are determined from the telegram length which can be expected, if possible from the function code. Surplus bytes at the end of the actual telegram are ignored. This behavior does not correspond to the MODBUS standard.</p> <p><b>Factory setting:</b> STANDARD</p> <p> <b>Note!</b> The selection has only a meaning in the RTU mode. In the ASCII mode the equipment always behaves in accordance with the MODBUS standard.</p>














Function description BASIC FUNCTION → PROCESSPARAMETER → SCAN LIST REGISTER	
<p>SCAN LIST REGISTER 1 TO 16</p> <p>MODBUS register: SCAN LIST REG. 1 5001 SCAN LIST REG. 2 5002 SCAN LIST REG. 3 5003 SCAN LIST REG. 4 5004 SCAN LIST REG. 5 5005 SCAN LIST REG. 6 5006 SCAN LIST REG. 7 5007 SCAN LIST REG. 8 5008 SCAN LIST REG. 9 5009 SCAN LIST REG. 10 5010 SCAN LIST REG. 11 5011 SCAN LIST REG. 12 5012 SCAN LIST REG. 13 5013 SCAN LIST REG. 14 5014 SCAN LIST REG. 15 5015 SCAN LIST REG. 16 5016 Data type: Integer Access: read/write</p>	<p>By entering the register address (1-based), up to 16 device parameters can be grouped in the auto-scan buffer where they are assigned to the scan list registers 1 to 16. The data of the device parameters assigned here are read out via the register addresses 5051 to 5081.</p> <p><b>User input:</b> 1 to 65535</p> <p><b>Factory setting:</b> 1</p>








<b>Function description</b>	
BASIC FUNCTION → PROCESSPARAMETER → SCALED INTEGER	
<p><b>MASS FLOW</b></p> <p>MODBUS register: 2 Data type: Integer Access: read</p>	<p>This function shows the current measured mass flow as scaled integer.</p> <p> Note! Details for scaling → 26.</p>
<p><b>DENSITY</b></p> <p>MODBUS register: 3 Data type: Integer Access: read</p>	<p>This function shows the current measured density as scaled integer.</p> <p> Note! Details for scaling → 26.</p>
<p><b>TEMPERATURE</b></p> <p>MODBUS register: 4 Data type: Integer Access: read</p>	<p>This function shows the current measured temperature as scaled integer.</p> <p> Note! Details for scaling → 26.</p>
<p><b>VOLUME FLOW</b></p> <p>MODBUS register: 5 Data type: Integer Access: read</p>	<p>This function shows the calculated volume flow as scaled integer.</p> <p> Note! Details for scaling → 26.</p>
<p><b>PRESSURE</b></p> <p>MODBUS register: 7 Data type: Integer Access: read</p>	<p>This function shows the adjusted pressure as scaled integer.</p> <p> Note! Details for scaling → 26.</p>
<p><b>TOTALIZER</b></p> <p>MODBUS register: TOTALIZER 1: 8 TOTALIZER 2: 9 Data type: Integer Access: read</p>	<p>This function shows the value of the totalizer as scaled integer.</p> <p> Note! The totalizer 1 must be assigned on mass flow, the totalizer 2 on volume flow. Details for scaling → 26.</p>




<b>Function description</b>	
BASIC FUNCTION → PROCESSPARAMETER → SCALED INTEGER CONFIGURATION	
<p><b>MAX. INTEGER</b></p> <p>MODBUS register: 18 Data type: Integer Access: read/write</p>	<p>Input of the general maximum integer value for the scaling.</p> <p><b>User input:</b> 0 to 65534 <b>Factory settings:</b> 65534</p> <p> Note! Details for scaling → 26.</p>
<p><b>FACTOR MASS FLOW</b></p> <p>MODBUS register: 29 Data type: Integer Access: read/write</p>	<p>Input of the factor of the scaled integer for the mass flow.</p> <p><b>User input:</b> 0 to 65535 <b>Factory settings:</b> 1</p> <p> Note! Details for scaling → 26.</p>
<p><b>OFFSET MASS FLOW</b></p> <p>MODBUS register: 19 Data type: Integer Access: read/write</p>	<p>Input of the offset of the scaled integer for the mass flow.</p> <p><b>User input:</b> 0 to 65536 <b>Factory setting:</b> 32768</p> <p> Note! Details for scaling → 26.</p>
<p><b>FACTOR DENSITY</b></p> <p>MODBUS register: 30 Data type: Integer Access: read/write</p>	<p>Input of the factor of the scaled integer for the density.</p> <p><b>User input:</b> 0 to 65536 <b>Factory setting:</b> 1</p> <p> Note! Details for scaling → 26.</p>
<p><b>OFFSET DENSITY</b></p> <p>MODBUS register: 20 Data type: Integer Access: read/write</p>	<p>Input of the offset of the scaled integer for the density.</p> <p><b>User input:</b> 0 to 65535 <b>Factory setting:</b> 32768</p> <p> Note! Details for scaling → 26.</p>

<b>Function description</b>	
BASIC FUNCTION → PROCESSPARAMETER → SCALED INTEGER CONFIGURATION	
<p><b>FACTOR TEMPERATURE</b></p> <p>MODBUS register: 31 Data type: Integer Access: read/write</p>	<p>Input of the factor of the scaled integer for the temperature.</p> <p><b>User input:</b> 0 to 65536 <b>Factory setting:</b> 1</p> <p> Note! Details for scaling →  26.</p>
<p><b>OFFSET TEMPERATURE</b></p> <p>MODBUS register: 21 Data type: Integer Access: read/write</p>	<p>Input of the offset of the scaled integer for the temperature.</p> <p><b>User input:</b> 0 to 65535 <b>Factory setting:</b> 32736</p> <p> Note! Details for scaling →  26.</p>
<p><b>FACTOR VOLUME FLOW</b></p> <p>MODBUS register: 32 Data type: Integer Access: read/write</p>	<p>Input of the factor of the scaled integer for the volume flow.</p> <p><b>User input:</b> 0 to 65536 <b>Factory setting:</b> 1</p> <p> Note! Details for scaling →  26.</p>
<p><b>OFFSET VOLUME FLOW</b></p> <p>MODBUS register: 22 Data type: Integer Access: read/write</p>	<p>Input of the offset of the scaled integer for the volume flow.</p> <p><b>User input:</b> 0 to 65535 <b>Factory setting:</b> 32738</p> <p> Note! Details for scaling →  26.</p>
<p><b>FACTOR PRESSURE</b></p> <p>MODBUS register: 34 Data type: Integer Access: read/write</p>	<p>Input of the factor of the scaled integer for the pressure.</p> <p><b>User input:</b> 0 to 65536 <b>Factory setting:</b> 1</p> <p> Note! Details for scaling →  26.</p>
<p><b>OFFSET PRESSURE</b></p> <p>MODBUS register: 24 Data type: Integer Access: read/write</p>	<p>Input of the offset of the scaled integer for the pressure.</p> <p><b>User input:</b> 0 to 65535 <b>Factory setting:</b> 32738</p> <p> Note! Details for scaling →  26.</p>


<b>Function description</b>	
BASIC FUNCTION → PROCESSPARAMETER → SCALED INTEGER CONFIGURATION	
<p><b>FACTOR TOTALIZER</b></p> <p>MODBUS register: Data type: 35 Access: 36 Integer read/write</p>	<p>Input of the factor of the scaled integer for the totalizer status.</p> <p><b>User input:</b> 0 to 65536</p> <p><b>Factory setting:</b> 1</p> <p> <b>Note!</b> The totalizer 1 must be assigned on mass flow, the totalizer 2 on volume flow. Details for scaling →  26.</p>
<p><b>OFFSET TOTALIZER</b></p> <p>MODBUS register: Data type: 25 Access: 26 Integer read/write</p>	<p>Input of the offset of the scaled integer for the totalizer status.</p> <p><b>User input:</b> 0 to 65535</p> <p><b>Factory setting:</b> 32738</p> <p> <b>Note!</b> The totalizer 1 must be assigned on mass flow, the totalizer 2 on volume flow. Details for scaling →  26.</p>





<b>Function description</b>																																																																	
BASIC FUNCTION → PROCESSPARAMETER → SCALED INTEGER CONFIGURATION																																																																	
<p><b>SLOT 1 to 32</b></p> <p>MODBUS register:</p> <table border="0"> <tr><td>Slot 1:</td><td>655</td></tr> <tr><td>Slot 2:</td><td>656</td></tr> <tr><td>Slot 3:</td><td>657</td></tr> <tr><td>Slot 4:</td><td>658</td></tr> <tr><td>Slot 5:</td><td>659</td></tr> <tr><td>Slot 6:</td><td>660</td></tr> <tr><td>Slot 7:</td><td>661</td></tr> <tr><td>Slot 8:</td><td>662</td></tr> <tr><td>Slot 9:</td><td>663</td></tr> <tr><td>Slot 10:</td><td>664</td></tr> <tr><td>Slot 11:</td><td>665</td></tr> <tr><td>Slot 12:</td><td>666</td></tr> <tr><td>Slot 13:</td><td>667</td></tr> <tr><td>Slot 14:</td><td>668</td></tr> <tr><td>Slot 15:</td><td>669</td></tr> <tr><td>Slot 16:</td><td>670</td></tr> <tr><td>Slot 17:</td><td>671</td></tr> <tr><td>Slot 18:</td><td>672</td></tr> <tr><td>Slot 19:</td><td>673</td></tr> <tr><td>Slot 20:</td><td>674</td></tr> <tr><td>Slot 21:</td><td>675</td></tr> <tr><td>Slot 22:</td><td>676</td></tr> <tr><td>Slot 23:</td><td>677</td></tr> <tr><td>Slot 24:</td><td>678</td></tr> <tr><td>Slot 25:</td><td>679</td></tr> <tr><td>Slot 26:</td><td>680</td></tr> <tr><td>Slot 27:</td><td>681</td></tr> <tr><td>Slot 28:</td><td>682</td></tr> <tr><td>Slot 29:</td><td>683</td></tr> <tr><td>Slot 30:</td><td>684</td></tr> <tr><td>Slot 31:</td><td>685</td></tr> <tr><td>Slot 32:</td><td>686</td></tr> </table> <p>Data type: Integer Access: read/write</p>	Slot 1:	655	Slot 2:	656	Slot 3:	657	Slot 4:	658	Slot 5:	659	Slot 6:	660	Slot 7:	661	Slot 8:	662	Slot 9:	663	Slot 10:	664	Slot 11:	665	Slot 12:	666	Slot 13:	667	Slot 14:	668	Slot 15:	669	Slot 16:	670	Slot 17:	671	Slot 18:	672	Slot 19:	673	Slot 20:	674	Slot 21:	675	Slot 22:	676	Slot 23:	677	Slot 24:	678	Slot 25:	679	Slot 26:	680	Slot 27:	681	Slot 28:	682	Slot 29:	683	Slot 30:	684	Slot 31:	685	Slot 32:	686	<p>By the input of the register address (based on 0) up to 32 equipment parameters can be grouped. The readout of the data is made by the register addresses 687/688 for Slot 1, 689/690 for Slot 2 etc. up to 749/750 for Slot 32.</p> <p><b>User input:</b> 0 to 65535</p> <p><b>Factory setting:</b> 0</p> <p> <b>Note!</b> For the readout of the data always two registers are reserved, if the value has the data type floating POINT and thus two registers occupied.</p>
Slot 1:	655																																																																
Slot 2:	656																																																																
Slot 3:	657																																																																
Slot 4:	658																																																																
Slot 5:	659																																																																
Slot 6:	660																																																																
Slot 7:	661																																																																
Slot 8:	662																																																																
Slot 9:	663																																																																
Slot 10:	664																																																																
Slot 11:	665																																																																
Slot 12:	666																																																																
Slot 13:	667																																																																
Slot 14:	668																																																																
Slot 15:	669																																																																
Slot 16:	670																																																																
Slot 17:	671																																																																
Slot 18:	672																																																																
Slot 19:	673																																																																
Slot 20:	674																																																																
Slot 21:	675																																																																
Slot 22:	676																																																																
Slot 23:	677																																																																
Slot 24:	678																																																																
Slot 25:	679																																																																
Slot 26:	680																																																																
Slot 27:	681																																																																
Slot 28:	682																																																																
Slot 29:	683																																																																
Slot 30:	684																																																																
Slot 31:	685																																																																
Slot 32:	686																																																																

### 11.6.2 Group "PROCESSPARAMETER"





Function description BASIC FUNCTION → PROCESSPARAMETER → CONFIGURATION	
<p>ASSIGN LF-CUTOFF</p> <p>MODBUS register: 5101 Data type: Integer Access: read/write</p>	<p>Use this function to assign the measured variable to which the low flow cut off pertains.</p> <p><b>Options:</b> 1 = MASS FLOW 2 = VOLUME FLOW</p> <p><b>Factory setting:</b> MASS FLOW</p>
<p>ON-VAL.LF-CUTOFF</p> <p>MODBUS register: 5138 Data type: Float Access: read/write</p>	<p>Use this function to assign a value to the switch-on point for low flow cut off.</p> <p>Low flow cut off is active if the value entered is not equal to 0.</p> <p><b>User input:</b> Floating-point number</p> <p><b>Factory setting:</b> Depends on nominal diameter</p> <p> <b>Note!</b> The low flow cut-off value is implicitly 150% of the on-value. Thus the low flow cut-off has a hysteresis.</p>


<b>Function description</b>	
<b>BASIC FUNCTION → PROCESSPARAMETER → CONFIGURATION</b>	
<p>PRESS.SHOCK SUPP</p> <p>MODBUS register: 5140 Data type: Float Access: read/write</p>	<p>The closure of a valve can cause brief but severe movements of the fluid which the measuring system registers. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".</p> <p> <b>Note!</b> Note that pressure shock suppression cannot be used unless the low flow cut off is active, (see function ON-VAL.LF-CUTOFF → 79). Use this function to define the time span for active pressure shock suppression.</p> <p>Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off (see point a in graphic).</p> <p>When pressure shock suppression is activated, the flow is set to null.</p> <p>Deactivation of the pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point b in graphic). The actual flow value is not displayed and output until the specified time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point c in the graphic)</p>  <p style="text-align: right;"><small>A0001285-EN</small></p> <p><b>Fig. 21: Pressure shock suppression</b></p> <ul style="list-style-type: none"> <li><i>m</i> On-value (creepage)</li> <li><i>n</i> Off-value (creepage)</li> <li><i>a</i> Active when value falls below the on-value of the low flow cut off</li> <li><i>b</i> Deactivated after specified time expires</li> <li><i>c</i> Flow values are again used to calculate the pulses</li> <li>■ Suppressed values</li> <li><i>Q</i> Flow</li> </ul> <p><b>User input:</b> 0.00 to 10.0 s</p> <p><b>Factory setting:</b> 0.00 s</p>






Function description	
BASIC FUNCTION → PROCESSPARAMETER → CONFIGURATION	
<p>EPD VALUE LOW</p> <p>MODBUS register: 5110 Data type: Float Access: read/write</p>	<p>Use this function to set a lower threshold for the measured density value. If the value falls below this threshold, the measuring tube is considered empty. Message #700 appears.</p> <p><b>User input:</b> Floating-point number</p> <p><b>Factory setting:</b> 0 kg/l or 0 g/cc</p>
<p>EPD RESPONSETIME</p> <p>MODBUS register: 5108 Data type: Float Access: read/write</p>	<p>Use this function to define a time span for which the activation criterion for an error has to be satisfied without interruption before the function is activated.</p> <p><b>User input:</b> 0 to 100 s</p> <p><b>Factory setting:</b> 1.0 s</p>





Function description	
BASIC FUNCTION → PROCESSPARAMETER → ADJUSTMENT	
<p>ZEROPOINT ADJUST</p> <p>MODBUS register: 5121 Data type: Integer Access: read/write</p>	<p>This function enables a zero point adjustment to be carried out. The new zero point determined by the measuring system is adopted by the function ZERO POINT.</p> <p><b>Options:</b> 0 = CANCEL 1 = START 2 = ERRORS</p> <p><b>Factory setting:</b> CANCEL</p> <p> <b>Caution!</b> Before carrying this out, please refer to the detailed description of the procedure for a zero point adjustment → 27.</p>
<p>ZEROPOINT</p> <p>MODBUS register: 7527 Data type: Float Access: read/write</p>	<p>This function shows the current zero point correction value for the sensor.</p> <p><b>Display:</b> max. 5-digit number: -99999 to +99999</p> <p><b>Factory setting:</b> Depends on calibration</p>
<p>PROGRESS</p> <p>MODBUS register: 6797 Data type: Integer Access: read/write</p>	<p>Displays the progress of a zero point adjustment as a percentage of the duration.</p> <p><b>Display:</b> 0 to 100%</p>




<b>Function description</b>	
<b>BASIC FUNCTION → PROCESSPARAMETER → PRESSURE CORRECTION</b>	
<p>PRESSURE MODE</p> <p>MODBUS register: 5184 Data type: Integer Access: read/write</p>	<p>Use this function to configure an automatic pressure correction. In this way, the effect of a pressure deviation between the calibration and process pressures on the measured error for mass flow is compensated for (see the chapter on "Accuracy", → 41).</p> <p><b>Options:</b> 0 = OFF 1 = ON (a fixed process pressure for pressure correction is specified).</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b> Measuring cells in which the pressure has only a negligible effect on the accuracy do not need this correction.</p>
<p>PRESSURE</p> <p>MODBUS register: 5185 Data type: Float Access: read/write</p>	<p>Use this function to enter the value for the process pressure which should be used during pressure correction.</p> <p> <b>Note!</b> Function is not available unless the ON selection was selected in the PRESSURE MODE function.</p> <p><b>User input:</b> Floating-point number</p>





Function description BASIC FUNCTION → PROCESSPARAMETER → VOLUME CALCULATION	
<p><b>VOLUME CALCULATION</b></p> <p>MODBUS register: 5052 Data type: Integer Access: read/write</p>	<p>Use this function to select the type of volume calculation.</p> <p><b>Options:</b>                      0 = MEASURED DENSITY (the density measured by the device is used)                      1 = FIXED DENSITY (a fixed density is specified, e.g. if the fluid is known)                      2 = API TABLE (the density is taken from API table 53; the basis is the density and temperature measured by the device)</p> <p><b>Factory setting:</b> MEASURED DENSITY</p> <p> <b>Note!</b> For setting the corresponding DIP switch → 17.</p>
<p>FIXED DENSITY</p> <p>MODBUS register: 5130 Data type: Float Access: read/write</p>	<p>Use this function to specify a fixed density of the fluid.</p> <p><b>User input:</b> Floating-point number</p> <p> <b>Note!</b> This function is not available unless FIXED DENSITY was selected in the VOLUME CALCULATION function.</p>

### 11.6.3 Group "SYSTEM PARAMETER"




Function description BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
<p> <b>Caution!</b> The settings configured under these functions allow the calibration officer to adjust the respective measuring values. Once the device is sealed, these settings can no longer be changed. Modifying these values in non-custody transfer mode may result in false measurements and thus is not recommended.</p>	
INSTL.DIR. SENSOR  MODBUS register: 5501 Data type: Integer Access: read/write	Use this function to reverse the sign of the flow direction, if necessary.  <b>Options:</b> 0 = FORWARD (flow in direction of arrow) 1 = REVERSE (flow opposite to direction of arrow)  <b>Factory setting:</b> NORMAL
FLOW DAMPING  MODBUS register: 5510 Data type: Float Access: read/write	For setting the damping of the mass flow measured value. It can be used to reduce the spread. The reaction time of the measuring device increases with every increase in the damping. The damping acts on all functions and outputs of the measuring device.  <b>User input:</b> 0 to 100 s <b>Factory setting:</b> 0 s
M. FACTOR MASS FLOW  MODBUS register: 5519 Data type: Float Access: read/write	Use this function to enter the factor for adjustment of the mass flow.  <b>User input:</b> Floating-point number <b>Factory setting:</b> 1
M. OFFSET MASSFL  MODBUS register: 5521 Data type: Float Access: read/write	Use this function to enter the offset for adjustment of the mass flow.  <b>User input:</b> Floating-point number <b>Factory setting:</b> 0
M. FACTOR VOLUME FLOW  MODBUS register: 5523 Data type: Float Access: read/write	Use this function to enter the factor for adjustment of the volume flow.  <b>User input:</b> Floating-point number <b>Factory setting:</b> 1
M. OFFSET VOLFL.  MODBUS register: 5525 Data type: Float Access: read/write	Use this function to enter the offset for adjustment of the volume flow.  <b>User input:</b> Floating-point number <b>Factory setting:</b> 0
M. FACTOR DENS.  MODBUS register: 5527 Data type: Float Access: read/write	Use this function to enter the factor for adjustment of the density.  <b>User input:</b> Floating-point number <b>Factory setting:</b> 1
M. OFFSET DENS.  MODBUS register: 5529 Data type: Float Access: read/write	Use this function to enter the offset for adjustment of the density.  <b>User input:</b> Floating-point number <b>Factory setting:</b> 0

<b>Function description</b> BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
<p>M. FACTOR TEMP.</p> <p>MODBUS register: 5531 Data type: Float Access: read/write</p>	<p>Use this function to enter the factor for adjustment of the temperature.</p> <p><b>User input:</b> Floating-point number</p> <p><b>Factory setting:</b> 1</p> <p> <b>Note!</b> The entered value corresponds to the absolute temperature in Kelvin. Example: - Current temperature = 26.85 °C corresponds to 300 Kelvin - Thus if a value of 1.01 is entered, the temperature changes to 303 Kelvin, corresponding to 29.85 °C.</p>
<p>M. OFFSET TEMP.</p> <p>MODBUS register: 5533 Data type: Float Access: read/write</p>	<p>Use this function to enter the offset for adjustment of the temperature.</p> <p><b>User input:</b> Floating-point number</p> <p><b>Factory setting:</b> 0</p> <p> <b>Note!</b> The unit of the entered value is always Kelvin. Example: - Current temperature = 26.85 °C corresponds to 300 Kelvin - Thus if a value of 1 is entered, the temperature changes to 301 Kelvin, corresponding to 27.85 °C.</p>

### 11.6.4 Group "SENSOR DATA"




<b>Function description</b> BASIC FUNCTION → SENSOR DATA → CONFIGURATION	
<p>K-FACTOR</p> <p>MODBUS register: 7513 Data type: Float Access: Read</p>	<p>This function shows the calibration factor for the sensor.</p>
<p>ZEROPOINT</p> <p>MODBUS register: 7527 Data type: Float Access: read/write</p>	<p>Shows the zero point for the sensor.</p>
<p>NOMINAL DIAMETER</p> <p>MODBUS register: 7525 Data type: Integer Access: Read</p>	<p>This function shows the nominal diameter for the sensor.</p> <p><b>Display:</b> 6 = DN 08 or 5/16" 8 = DN 15 or 1/2" 11 = DN 25 or 1" 14 = DN 40 or 1 1/2"</p>







Function description BASIC FUNCTION → SENSOR DATA → DENSITY COEFFICIENT	
C0 MODBUS register: 7501 Data type: Float Access: Read	Displays the density coefficient C0.
C1 MODBUS register: 7503 Data type: Float Access: Read	Displays the density coefficient C1.
C2 MODBUS register: 7505 Data type: Float Access: Read	Displays the density coefficient C2.
C3 MODBUS register: 7507 Data type: Float Access: Read	Displays the density coefficient C3.
C4 MODBUS register: 7509 Data type: Float Access: Read	Displays the density coefficient C4.
C5 MODBUS register: 7511 Data type: Float Access: Read	Displays the density coefficient C5.

## 11.7 Block "SUPERVISION"

### 11.7.1 Group "SYSTEM"







Function description SUPERVISION → SYSTEM → OPERATION	
<p>ACTUAL SYS.COND</p> <p>MODBUS register: 6801 Data type: Integer Access: Read</p>	<p>Displays the present system condition.</p> <p><b>Display:</b> 0 = "SYSTEM OK" or Displays the message with the highest priority.</p> <p> <b>Note!</b> The number of the message is output via MODBUS RS485, → 33.</p>
<p>OPERATION HOURS</p> <p>MODBUS register: 6810 Data type: Float Access: Read</p>	<p>The operating hours of the device appear on the display.</p> <p><b>Display:</b></p> <ul style="list-style-type: none"> <li>■ Hours of operation &lt; 10 hours → display format = 0:00:00 (hr:min:sec)</li> <li>■ Hours of operation 10 to 10,000 hours → display format = 0000:00 (hr:min)</li> <li>■ Hours of operation &gt; 10,000 hours → display format = 000000 (hr)</li> </ul>
<p>PROGRAM CODE CRC</p> <p>MODBUS register: 8933 Data type: String Access: Read</p>	<p>Display of the CRC checksum of the program code.</p> <p> <b>Note!</b> The CRC checksum of the program code is cyclically recalculated to check its consistency.</p>
<p>SYSTEM RESET</p> <p>MODBUS register: 6817 Data type: Integer Access: read/write</p>	<p>Use this function to perform a reset of the measuring system.</p> <p><b>Options:</b> 0 = CANCEL 1 = RESTART SYSTEM (restart without interrupting power supply) 2 = RESET DELIVERY</p> <p><b>Factory setting:</b> CANCEL</p> <p> <b>Note!</b> The parameters can take several minutes to be reset, after which the device restarts. The power supply must not be switched off while the factory settings are being restored.</p>
<p>PROGRESS</p> <p>MODBUS register: 6797 Data type: Integer Access: Read</p>	<p>Displays the progress of restoring the default values.</p> <p><b>Display:</b> 0 to 100%</p>





Function description SUPERVISION → SYSTEM → PROCESS LIMITS	
LOW. LIMIT MASSFL.  MODBUS register: 6781 Data type: Float Access: read/write	Use this function to enter the lower process limit for the mass flow. If value falls below this limit, message #805 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> depends on nominal diameter and country
UPP. LIMIT MASSFL.  MODBUS register: 6783 Data type: Float Access: read/write	Use this function to enter the upper process limit for the mass flow. If value exceeds this limit, message #806 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> Depends on nominal diameter and country
LOW. LIMIT VOLFL.  MODBUS register: 6785 Data type: Float Access: read/write	Use this function to enter the lower process limit for the volume flow. If value falls below this limit, message #807 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> Depends on nominal diameter and country
UPP. LIMIT VOLFL.  MODBUS register: 6787 Data type: Float Access: read/write	Use this function to enter the upper process limit for the volume flow. If value exceeds this limit, message #808 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> Depends on nominal diameter and country
LOW. LIMIT TEMP.  MODBUS register: 6789 Data type: Float Access: read/write	Use this function to enter the lower process limit for the temperature. If value falls below this limit, message #801 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> -55°C or -67°F
UPP. LIMIT TEMP.  MODBUS register: 6791 Data type: Float Access: read/write	Use this function to enter the upper process limit for the temperature. If value exceeds this limit, message #802 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> +130°C or +266°F
LOW. LIMIT DENS.  MODBUS register: 6793 Data type: Float Access: read/write	Use this function to enter the lower process limit for the pressure. If value falls below this limit, message #803 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> 0 kg/l or 0 g/cc
UPP. LIMIT DENS.  MODBUS register: 6795 Data type: Float Access: read/write	Use this function to enter the upper process limit for the density. If value exceeds this limit, message #804 is output.  <b>User input:</b> Floating-point number  <b>Factory setting:</b> 4 kg/l or 4 g/cc






Function description SUPERVISION → SYSTEM → SIMULATION	
<p>SIM. MEASURAND</p> <p>MODBUS register: 6813 Data type: Integer Access: read/write</p>	<p>Use this function to set the inputs, outputs and totalizers to their corresponding defined flow-response modes in order to check whether they respond correctly. During this time, message #692, "SIM. MEASURAND", appears on the display.</p> <p><b>Options:</b>            0 = OFF            1 = MASS FLOW            2 = VOLUME FLOW            4 = DENSITY            6 = TEMPERATURE</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Caution!</b>            ■ The measuring device cannot be used for measuring while this simulation is in progress.            ■ The setting is not saved in the event of a power failure.</p>
<p>VALUE SIM. MEAS.</p> <p>MODBUS register: 6814 Data type: Float Access: read/write</p>	<p>For entering a user-selectable value (e.g. 30 kg/min) to check the associated functions in the device itself and downstream signal loops.</p> <p> <b>Note!</b>            This function is not available unless the function SIM. MEASURAND is active.</p> <p><b>User input:</b> Floating-point number</p> <p> <b>Caution!</b>            The setting is not saved in the event of a power failure.</p>




Function description SUPERVISION → SYSTEM → CONFIGURATION	
<p><b>ALARM DELAY</b></p> <p>MODBUS register: 6808 Data type: Float Access: read/write</p>	<p>Enter a time span for which the criteria for an error have to be satisfied without interruption before a message is generated.</p> <p><b>User input:</b> 0 to 100 s (in one-second increments)</p> <p><b>Factory setting:</b> 0 s</p> <p> <b>Caution!</b> If this function is activated, fault and notice messages are delayed by the time corresponding to the setting before being transmitted to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages may not be delayed, a value of 0 seconds must be entered here.</p>
<p><b>PERMANENT STORAGE</b></p> <p>MODBUS register: 6907 Data type: Integer Access: read/write</p>	<p>Enter whether permanent storage of all parameters in the DAT has been switched on or off.</p> <p><b>Options:</b> 0 = OFF 1 = ON</p> <p><b>Factory setting:</b> ON</p> <p><b>Description of the individual options:</b></p> <p><b>OFF</b> Changes of settings are not stored permanently. After a power failure, the settings are the same as they were before OFF was selected. This function is recommended if a setting is frequently changed via MODBUS, as the number of write actions to the DAT allowed is limited to 1,000,000.</p> <p><b>ON</b> Every change of the settings is stored permanently. After selecting ON, the measuring instrument carries out a restart and then has the same settings as before OFF was selected.</p>

### 11.7.2 Group "VERSION-INFO"




Function description SUPERVISION → VERSION-INFO → AMPLIFIER	
SOFTWARE REVISION AMPLIFIER	Use this function to view the software revision number of the amplifier.
MODBUS register:	7039
Data type:	String (16)
Access:	Read



Function description SUPERVISION → VERSION-INFO → SENSOR	
SERIAL NUMBER	The serial number of the device appears on the display.
MODBUS register:	7003
Data type:	String (16)
Access:	Read
SENSOR TYPE	The sensor type appears on the display.
MODBUS register:	7012
Data type:	String (16)
Access:	Read
SOFTWARE REVISION DAT	Use this function to view the software revision number of the software used to program the DAT.
MODBUS register:	7021
Data type:	String (16)
Access:	Read


### 11.7.3 Group "MESSAGE CATEGORY"




<b>Function description</b>	
<b>SUPERVISION → MESSAGE CATEGORY → 300 to 899</b>	
300 to 899  MODBUS register: 355            10038 356            10039 358            10041 359            10042 360            10043 361            10044 362            10045 379            10026 380            10027 381            10028 382            10029 383            10030 384            10031 385            10032 386            10033 387            10034 388            10070 389            10071  586            10035 587            10036	Set the category of a message.  <b>Options:</b> 0 = OFF = No status is activated. 1 = WARNING = The status in the "Warning" category. 2 = ERROR = The status is in the "Error" category.  <b>Factory setting:</b> 300 to 399 = ERROR 500 to 599 = ERROR 700 to 799 = Note 800 = Note 801 to 899 = OFF
(continued on next page)	

<b>Function description</b>	
<b>SUPERVISION → MESSAGE CATEGORY → 300 to 899</b>	
700	10050
701	10046
702	10047
703	10048
704	10049
705	10037
706	10051
707	10052
708	10053
709	10054
710	10055
800	10056
801	10057
802	10058
803	10059
804	10060
805	10061
806	10062
807	10063
808	10064
809	10065
810	10066
Data type:	Integer
Access:	read/write

### 11.7.4 Group "MESSAGE HISTORY"



Function description SUPERVISION → MESSAGE HISTORY → PREVIOUS SYSTEM CONDITIONS	
PREV.SYS.COND n	Displays the last 16 messages to occur.
MODBUS register: Fault/notice message:	Note! For more information, refer to the keyword "System or process error messages."
1	6842
2	6843
3	6844
4	6845
5	6846
6	6847
7	6848
8	6849
9	6850
10	6851
11	6852
12	6853
13	6854
14	6855
15	6856
16	6857
Data type:	Integer
Access:	Read



Function description SUPERVISION → MESSAGE HISTORY → OPERATION HOURS	
SYS.CON.OP HOUR n	This displays the status of the operating hours counter at which a message has occurred.
MODBUS register:	<b>Display:</b>
1	8901
2	8903
3	8905
4	8907
5	8909
6	8911
7	8913
8	8915
9	8917
10	8919
11	8921
12	8923
13	8925
14	8927
15	8929
16	8931
Data type:	Float
Access:	Read

# Index

## A

Accessories .....	30
Ambient temperature .....	42
Applications .....	39
Applicator (selection and configuration software) .....	30
Approvals .....	10, 45
Auto-scan buffer .....	24

## B

Block	
BASIC FUNCTION .....	71
CUSTODY TRANSFER MEASUREMENT .....	51
MEASURED VARIABLE .....	51
OUTPUTS .....	58
SUPERVISION .....	87
TOTALIZER .....	55
Broadcast message .....	19
Byte transmission sequence .....	23

## C

Cable entries	
Degree of protection .....	15
Technical data .....	40
Cable specifications .....	40
CE mark .....	45
Certificates .....	10, 45
Cleaning	
External cleaning .....	29
Commissioning .....	27
Zero point adjustment .....	27
Configuring the device address .....	26
Configuring the MODBUS device address .....	26
Connecting the measuring unit .....	14
Connecting the transmitter .....	14
Connection	
See Electrical connection	

## D

Data types .....	22
Degree of protection .....	15, 42
Designated use .....	5
Device designation .....	8
Diagnosis using LED .....	32
Display of function matrix .....	48
Disposal .....	38
Documentation .....	46

## E

Electrical connection	
Degree of protection .....	15
Measuring unit .....	14
Post-connection check (checklist) .....	16
Electrical connections .....	40
Error messages (MODBUS) .....	24
European Pressure Equipment Directive (PED) .....	45
Ex approval .....	45
External cleaning .....	29

External standards .....	46
--------------------------	----

## F

Failsafe mode of the outputs .....	36
FieldCare .....	18
Flow rate .....	43
Frequency output	
Technical data .....	39
Function	
300 to 899 .....	92
ACTUAL STATUS (status output) .....	70
ACTUAL SYS.COND .....	87
ALARM DELAY .....	90
ASSIGN (frequency output) .....	64
ASSIGN (pulse output) .....	67
ASSIGN (totalizers 1 to 3) .....	55
ASSIGN LF-CUTOFF .....	79
ASSIGN STATUS (status output) .....	70
BAUDRATE .....	71
BYTEORDER FLOAT .....	72
BYTEORDER INT. ....	72
BYTEORDER STRING .....	72
CHANNEL 2 .....	58
CUSTODY TRANSFER MEASUREMENT .....	51
DELAY TELE.REPLY .....	71
DENSITY .....	51
DENSITY COEF. C0 .....	86
DENSITY COEFFICIENT C1 .....	86
DENSITY COEFFICIENT C2 .....	86
DENSITY COEFFICIENT C3 .....	86
DENSITY COEFFICIENT C4 .....	86
DENSITY COEFFICIENT C5 .....	86
END VALUE FREQ .....	64
EPD RESPONSETIME .....	81
EPD VALUE LOW .....	81
FAIL.SENSITIVITY (frequency output) .....	65
FAIL.SENSITIVITY (MODBUS RS485) .....	72
FAIL.SENSITIVITY (pulse output) .....	68
FAIL.SENSITIVITY (Totalizer 1 to 3) .....	56
FAILSAFE MODE (frequency output) .....	65
FAILSAFE MODE (MODBUS RS485) .....	73
FAILSAFE MODE (pulse output) .....	68
FAILSAFE MODE (Totalizer 1 to 3) .....	56
FIELD BUS ADDRESS .....	71
FIXED DENSITY .....	83
FLOW DAMPING .....	84
INSTL.DIR.SENSOR .....	84
K-FACTOR .....	85
LOW. LIMIT DENS. ....	88
LOW. LIMIT MASSFL. ....	88
LOW. LIMIT TEMP. ....	88
LOW. LIMIT VOLFL. ....	88
M. FACTOR DENS. ....	84
M. FACTOR TEMP. ....	85
M. FACTOR VOLFL. ....	84
M. FACTOR.MASSFL. ....	84

M. OFFSET DENS. ....	84	Function matrix .....	48
M. OFFSET MASSFL .....	84	<b>G</b>	
M. OFFSET TEMP. ....	85	Galvanic isolation .....	40
M. OFFSET VOLFL.....	84	Group	
MASS FLOW .....	51	CUSTODY TRANSFER MEASUREMENT.....	51
MEASURING MODE (frequency output) .....	65	MEASURING VALUES .....	51
MEASURING MODE (pulse output) .....	68	MESSAGE CATEGORY.....	92
MEASURING MODE (totalizers 1 to 3) .....	56	MESSAGE HISTORY.....	94
NOMINAL DIAMETER .....	85	MODBUS RS485.....	71
ON-VAL.LF-CUTOFF. ....	79	PROCESSPARAMETER.....	79
OPERATION HOURS.....	87	PULSE/FREQUENCY OUTPUTS (1 to 2).....	58
OPERATION MODE .....	58	SENSOR DATA.....	85
OUTPUT SIGNAL (frequency output).....	66	SYSTEM .....	87
OUTPUT SIGNAL (pulse output) .....	69	SYSTEM PARAMETER .....	84
OVERFLOW (totalizers 1 to 3).....	57	SYSTEM UNITS .....	52
PARITY .....	71	TOTALIZER (1 to 3) .....	55
PERMANENT STORAG .....	90	VERSION-INFO .....	91
PRESS.SHOCK SUPP .....	80	<b>H</b>	
PRESSURE.....	82	HistoROM/DAT (memory).....	28
PRESSURE MODE.....	82	<b>I</b>	
PREV.SYS.COND 1 to 16.....	94	Identification .....	8
PROGRAM CODE CRC .....	87	Incoming acceptance .....	11
PROGRESS .....	81, 87	Influence of medium pressure .....	42
PULSE VALUE.....	67	Influence of medium temperature .....	42
PULSE WIDTH .....	67	Inlet and outlet runs .....	11
RESET TOTAL. (totalizers 1 to 3).....	56	Input variables .....	39
SCAN LIST REGISTER 1 TO 16.....	73	Installation .....	11–12
SENSOR TYPE.....	91	Installation conditions.....	11
SERIAL NUMBER .....	91	Dimensions.....	11
SIM. MEASURAND.....	89	Inlet and outlet runs .....	11
SUM (totalizers 1 to 3).....	57	Limiting flow.....	11
SW-REV. AMP.....	91	Vibrations .....	11
SW-REV. DAT .....	91	Installation, commissioning and operation .....	5
SYS.CON.OPHOUR 1...16.....	94	Installing the meter electronics .....	37
SYSTEM RESET .....	87	Instrument functions .....	47
TAG NAME.....	72	<b>L</b>	
TEMPERATURE .....	51	Limiting flow .....	11
TRANSMISS. MODE .....	71	Limiting medium pressure range .....	43
UNIT DENSITY .....	54	<b>M</b>	
UNIT MASS.....	52	Maintenance .....	29
UNIT MASS (totalizers 1 to 3) .....	55	Master/slave communication .....	19
UNIT MASS FLOW .....	52	Material .....	44
UNIT PRESSURE .....	54	Material load diagram .....	43
UNIT TEMPERATURE.....	54	Maximum measured error .....	41
UNIT VOLUME.....	53	Measured variable .....	39
UNIT VOLUME (totalizers 1 to 3) .....	55	Measuring instrument approval.....	46
UNIT VOLUME FLOW .....	53	Measuring principle .....	39
UPP. LIMIT DENS. ....	88	Measuring range.....	39
UPP. LIMIT MASSFL.....	88	Measuring system.....	39
UPP. LIMIT TEMP.....	88	Mechanical construction.....	44
UPP. LIMIT VOLFL.....	88	Medium temperature range .....	43
VALUE f HIGH .....	64	Memory .....	28
VALUE SIM. MEAS.....	89	Memory (HistoROM) .....	28
VOLUME CALCULATION.....	83	Messages (FieldCare) .....	33
VOLUME FLOW .....	51	Meter electronics (installation) .....	37
ZERO POINT ADJUSTMENT.....	81		
ZEROPOINT .....	81		
ZEROPOINT (sensor data) .....	85		
Function code.....	21		



MODBUS RS485	
Auto-scan buffer	24
Byte transmission sequence	23
Data types	22
Error messages	24
Function code	21
Master/slave devices	18
Max. writes	22
Register addresses	22
Response times	22
System architecture	18
Technical data	40
Technology	18
Telegram	20
MODBUS RS485 cable specifications	13
MODBUS RS485 communication	18
<b>N</b>	
Nameplate	8
Nameplate data	
Transmitter	8
<b>O</b>	
Operable flow range	39
Operating conditions (environment)	42
Operating conditions (installation)	42
Operating conditions (process)	43
Operating option	18
Operation	17
Operational safety	5
Order code	
Accessories	30
Transmitter	8
Output	39
Output signal	39
<b>P</b>	
Parameter configuration	
FieldCare	18
Performance characteristics	41
Influence of medium pressure	42
Influence of medium temperature	42
Maximum measured error	41
Reference operating conditions	41
Repeatability	42
Polling	19
Post-installation check	12
Potential equalization	41
Power consumption	41
Power supply	40
Power supply failure	41
Pressure	
Device approval (PED)	45
Pressure loss (formulas, pressure loss diagrams)	43–44
Process connections	45
Process error (without message)	35
Pulse output	
See Frequency output	
<b>R</b>	
Reference operating conditions	41
Register address	22
Register addresses for MODBUS	22
Remote operation	45
Repeatability	42
Return	6
Rupture disk	43
<b>S</b>	
Safety conventions	7
Safety instructions	5
Serial number	8
Shock resistance	43
Signal on alarm	40
Software (history)	38
Spare parts	30
Standards, guidelines	45
Storage	11
Storage temperature	42
Supply voltage	40
Switching on the measuring device	27
<b>T</b>	
Technical data at a glance	39
Terminal assignment	15
Trademarks	10
Transmitter	
Electrical connection	14
Transmitter connection	14
Transport	11
Troubleshooting	31
Troubleshooting and remedy	31
Turning the transmitter housing	12
<b>V</b>	
Vibrations	11
<b>W</b>	
Weight	44
Wiring	
See Electrical connection	
Writes (max.)	22
<b>Z</b>	
Zero point adjustment	27



## Declaration of Hazardous Material and De-Contamination Erklärung zur Kontamination und Reinigung

RA No.

Please reference the Return Authorization Number (RA#), obtained from Endress+Hauser, on all paperwork and mark the RA# clearly on the outside of the box. If this procedure is not followed, it may result in the refusal of the package at our facility.  
Bitte geben Sie die von E+H mitgeteilte Rücklieferungsnummer (RA#) auf allen Lieferpapieren an und vermerken Sie diese auch außen auf der Verpackung. Nichtbeachtung dieser Anweisung führt zur Ablehnung ihrer Lieferung.

Because of legal regulations and for the safety of our employees and operating equipment, we need the "Declaration of Hazardous Material and De-Contamination", with your signature, before your order can be handled. Please make absolutely sure to attach it to the outside of the packaging.

Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination und Reinigung", bevor Ihr Auftrag bearbeitet werden kann. Bringen Sie diese unbedingt außen an der Verpackung an.

Type of instrument / sensor

Geräte-/Sensortyp \_\_\_\_\_

Serial number

Seriennummer \_\_\_\_\_

Used as SIL device in a Safety Instrumented System / Einsatz als SIL Gerät in Schutzeinrichtungen

Process data / Prozessdaten

Temperature / Temperatur \_\_\_\_\_ [°F] \_\_\_\_\_ [°C]

Pressure / Druck \_\_\_\_\_ [psi] \_\_\_\_\_ [ Pa ]

Conductivity / Leitfähigkeit \_\_\_\_\_ [µS/cm]

Viscosity / Viskosität \_\_\_\_\_ [cp] \_\_\_\_\_ [mm<sup>2</sup>/s]

Medium and warnings

Warnhinweise zum Medium



	Medium / concentration Medium / Konzentration	Identification CAS No.	flammable entzündlich	toxic giftig	corrosive ätzend	harmful/ irritant gesundheitsschädlich/ reizend	other * sonstiges*	harmless unbedenklich
Process medium Medium im Prozess								
Medium for process cleaning Medium zur Prozessreinigung								
Returned part cleaned with Medium zur Endreinigung								

\* explosive; oxidising; dangerous for the environment; biological risk; radioactive

\* explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv

Please tick should one of the above be applicable, include safety data sheet and, if necessary, special handling instructions.

Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.

Description of failure / Fehlerbeschreibung \_\_\_\_\_

Company data / Angaben zum Absender

Company / Firma _____	Phone number of contact person / Telefon-Nr. Ansprechpartner: _____
Address / Adresse _____	Fax / E-Mail _____
_____	Your order No. / Ihre Auftragsnr. _____

"We hereby certify that this declaration is filled out truthfully and completely to the best of our knowledge. We further certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free of any residues in dangerous quantities."

"Wir bestätigen, die vorliegende Erklärung nach unserem besten Wissen wahrheitsgetreu und vollständig ausgefüllt zu haben. Wir bestätigen weiter, dass die zurückgesandten Teile sorgfältig gereinigt wurden und nach unserem besten Wissen frei von Rückständen in gefährlicher Menge sind."

\_\_\_\_\_  
(place, date / Ort, Datum)

\_\_\_\_\_  
Name, dept./Abt. (please print / bitte Druckschrift)

\_\_\_\_\_  
Signature / Unterschrift

[www.endress.com/worldwide](http://www.endress.com/worldwide)

---

**Endress+Hauser**   
People for Process Automation

---