


the sensor people

**AMS 300*i***  
Optical Laser Measurement System  
RS 422/RS 232



en 03-2014/12 50113376  
We reserve the right to  
make technical changes

© 2014

Leuze electronic GmbH + Co. KG

In der Braike 1

D-73277 Owen - Teck / Germany

Phone: +49 7021 573-0

Fax: +49 7021 573-199

<http://www.leuze.com>

[info@leuze.de](mailto:info@leuze.de)

## The main menus

```
AMS 300i 120
Leuze electronic
  GmbH & Co. KG
SW: V 1.3.0 HW:1
SN: -----
```



```
Network information
Active: RS232/RS422
Data format: 8:n:1
Baudrate: --- kbit/s
```



```
I01 LSR PLB RS422
I02 TMP ATT RS232
ERR
+ 87.000m
```



```
Parameter
Parameter handling
RS422/RS232
Position value
I/O
Other
```



```
Language selection
o Deutsch
o English
o Español
o Français
o Italiano
```



```
Service
Status messages
Diagnostics
Expanded diagnostics
```

## Device information - main menu

This menu item contains detailed information on

- Device model,
- Manufacturer,
- Software and hardware version,
- Serial number.

No entries can be made via the display.

## Network information - main menu

Explanations of the active interface, data format and baud rate.

No entries can be made via the display.

## Status- and measurement data - main menu

- Display of status-, warning-, and error messages.
- Status overview of the switching inputs/outputs.
- Bar graph for the reception level.
- Activated interface.
- Measurement value.

No entries can be made via the display.  
See "Indicators in the display" on page 37.

## Parameter - main menu

- Configuration of the AMS.
- See "Parameter menu" on page 42.

## Language selection - main menu





- Selection of the display language.
- See "Language selection menu" on page 45.

## Service - main menu

- Display of status messages.
- Display of diagnostic data.

No entries can be made via the display.  
See "Service menu" on page 46.

## Device buttons:

-  Navigate upward/laterally
-  Navigate downward/laterally
-  ESCAPE leave
-  ENTER confirm

## Input of values

```
100
<-0123456789 save
Standard ----- Unit
126 | |
```

 Delete character

 Enter digit

save +  Save input

<b>1</b>	<b>General information</b>	<b>4</b>
1.1	Explanation of symbols	4
1.2	Declaration of conformity	4
1.3	Description of functions AMS 300i	5
<b>2</b>	<b>Safety</b>	<b>6</b>
2.1	Intended use	6
2.2	Foreseeable misuse	7
2.3	Competent persons	7
2.4	Disclaimer	8
2.5	Laser safety notices	8
<b>3</b>	<b>Fast commissioning / operating principle</b>	<b>11</b>
3.1	Mounting the AMS 300i	11
3.1.1	Mounting the device	11
3.1.2	Mounting the reflector	11
3.2	Connecting the voltage supply	12
3.3	Display	12
3.4	AMS 300i on the RS 422/RS 232	12
3.4.1	Transmission of data by means of the RS 422	12
3.4.2	Transmission of data by means of the RS 232	12
<b>4</b>	<b>Specifications</b>	<b>13</b>
4.1	Specifications of the laser measurement system	13
4.1.1	General specifications AMS 300i	13
4.1.2	Dimensioned drawing AMS 300i	15
4.1.3	Type overview AMS 300i	16
<b>5</b>	<b>Installation and mounting</b>	<b>17</b>
5.1	Storage, transportation	17
5.2	Mounting the AMS 300i	18
5.2.1	Optional mounting bracket	20
5.2.2	Parallel mounting of the AMS 300i	21
5.2.3	Parallel mounting of AMS 300i and DDLs optical data transmission	22
5.3	Mounting the AMS 300i with laser beam deflector unit	23
5.3.1	Mounting the laser beam deflector unit With integrated mounting bracket	23
5.3.2	Dimensioned drawing of US AMS 01 deflector unit	24

5.3.3	Mounting the US 1 OMS deflector unit without mounting bracket . . . . .	25
<b>6</b>	<b>Reflectors . . . . .</b>	<b>26</b>
6.1	General information . . . . .	26
6.2	Description of the reflective tape . . . . .	26
6.2.1	Specifications of the self-adhesive foil . . . . .	27
6.2.2	Specifications of the reflective tape on a metal plate . . . . .	27
6.2.3	Dimensioned drawing of reflective tape on a metal plate . . . . .	28
6.2.4	Specifications of heated reflectors . . . . .	29
6.2.5	Dimensioned drawing of heated reflectors . . . . .	30
6.3	Selecting reflector sizes . . . . .	31
6.4	Mounting the reflector . . . . .	32
6.4.1	General information . . . . .	32
6.4.2	Mounting the reflector . . . . .	32
6.4.3	Table of reflector pitches . . . . .	35
<b>7</b>	<b>Electrical connection . . . . .</b>	<b>36</b>
7.1	Safety notices for the electrical connection . . . . .	36
7.2	PWR – voltage supply / switching input/output . . . . .	37
7.3	RS 422 BUS IN . . . . .	37
7.4	RS 232 BUS IN . . . . .	38
7.5	Service . . . . .	38
<b>8</b>	<b>Display and control panel AMS 300i . . . . .</b>	<b>39</b>
8.1	Structure of the control panel . . . . .	39
8.2	Status display and operation . . . . .	39
8.2.1	Indicators in the display . . . . .	39
8.2.2	LED status displays . . . . .	41
8.2.3	Control buttons . . . . .	42
8.3	Menu description . . . . .	43
8.3.1	The main menus . . . . .	43
8.3.2	Parameter menu . . . . .	44
8.3.3	Language selection menu . . . . .	47
8.3.4	Service menu . . . . .	48
8.4	Operation . . . . .	48
<b>9</b>	<b>RS 422/RS 232 interface . . . . .</b>	<b>50</b>
9.1	General Information about the RS 422/RS 232 interface . . . . .	50

9.2	RS 422 electrical connection.....	50
9.3	RS 232 electrical connection.....	51
9.4	RS 422/RS 232 interface data.....	51
9.4.1	Default settings of the RS 422 interface.....	51
9.4.2	Default settings of the RS 232 interface.....	51
9.4.3	Parameter setting for AMS 300i.....	51
9.4.4	Communication protocol (binary protocol).....	52
<b>10</b>	<b>Diagnostics and troubleshooting .....</b>	<b>55</b>
10.1	Service and diagnostics in the display of the AMS 300i.....	55
10.1.1	Status messages .....	55
10.1.2	Diagnostics .....	56
10.1.3	Expanded diagnostics .....	56
10.2	General causes of errors.....	57
10.2.1	Power LED .....	57
10.3	Interface errors.....	57
10.3.1	BUS LED.....	57
10.4	Status display in the display of the AMS 300i.....	57
<b>11</b>	<b>Type overview and accessories .....</b>	<b>59</b>
11.1	Type key.....	59
11.2	Type overview AMS 300i (RS 422/RS 232).....	59
11.3	Overview of reflector types.....	60
11.4	Accessories .....	60
11.4.1	Accessory mounting bracket .....	60
11.4.2	Accessory deflector unit.....	60
11.4.3	Accessory M12 connector .....	60
11.4.4	Accessory ready-made cables for voltage supply.....	61
11.4.5	Accessory ready-made cables for RS 232.....	62
11.4.6	Cables for RS 422.....	63
<b>12</b>	<b>Maintenance.....</b>	<b>64</b>
12.1	General maintenance information.....	64
12.2	Repairs, servicing .....	64
12.3	Disassembling, packing, disposing .....	64

## 1 General information

### 1.1 Explanation of symbols

The symbols used in this operating manual are explained below.



**Attention!**

*This symbol precedes text messages which must strictly be observed. Failure to comply with this information results in injuries to personnel or damage to the equipment.*



**Attention Laser!**

*This symbol warns of possible danger caused by hazardous laser radiation.*



**Notice!**

*This symbol indicates text passages containing important information.*

### 1.2 Declaration of conformity

The AMS 300*i* absolute measuring optical laser measurement system was designed and manufactured in accordance with applicable European directives and standards.

The AMS series is "UL LISTED" according to American and Canadian safety standards and fulfills the requirements of Underwriter Laboratories Inc. (UL).



**Notice!**

*The Declaration of Conformity for these devices can be requested from the manufacturer.*











The manufacturer of the product, Leuze electronic GmbH + Co. KG in D-73277 Owen/Teck, possesses a certified quality assurance system in accordance with ISO 9001.



**1.3 Description of functions AMS 300*i***

The AMS 300*i* optical laser measurement system calculates distances to fixed as well as moving system parts. The distance to be measured is calculated according to the principle of the propagation time of radiated light. Here, the light emitted by the laser diode is reflected by a reflector onto the receiving element of the laser measurement system. The AMS 300*i* uses the "propagation time" of the light to calculate the distance to the reflector. The high absolute measurement accuracy of the laser measurement system and the fast integration time are designed for position control applications.

With the AMS 3xx*i* product series, Leuze electronic makes available a range of internationally relevant interfaces. Note that each interface version listed below corresponds to a different AMS 3xx*i* model.

- 
**AMS 304*i***
- 
**AMS 348*i***
- 
**AMS 355*i***
- 
**AMS 358*i***
- 
**AMS 335*i***
- 
**AMS 338*i***
- 
**AMS 308*i***
- 
**AMS 384*i***
- 
**AMS 301*i***
- 
**AMS 300*i***



## 2 Safety

This sensor was developed, manufactured and tested in line with the applicable safety standards. It corresponds to the state of the art.

### 2.1 Intended use

The AMS is an absolute measuring optical laser measurement system which allows distance measurement of up to 300m against a reflector.

#### **Areas of application**

The AMS is designed for the following areas of application:

- Positioning of automated, moving plant components
- Travel and lifting axes of high-bay storage devices
- Repositioning units
- Gantry crane bridges and their trolleys
- Lifts
- Electroplating plants



#### **CAUTION**

##### **Observe intended use!**

- ↪ Only operate the device in accordance with its intended use. The protection of personnel and the device cannot be guaranteed if the device is operated in a manner not complying with its intended use.  
Leuze electronic GmbH + Co. KG is not liable for damages caused by improper use.
- ↪ Read the technical description before commissioning the device. Knowledge of this technical description is an element of proper use.

#### **NOTICE**

##### **Comply with conditions and regulations!**

- ↪ Observe the locally applicable legal regulations and the rules of the employer's liability insurance association.



#### **Attention**

*For UL applications, use is permitted exclusively in Class 2 circuits according to NEC (National Electric Code).*

## 2.2 Foreseeable misuse

Any use other than that defined under "Intended use" or which goes beyond that use is considered improper use.

In particular, use of the device is not permitted in the following cases:

- Rooms with explosive atmospheres
- Circuits relevant to safety
- For medicinal purposes

**NOTICE**

**Do not modify or otherwise interfere with the device.**

- ↳ Do not carry out modifications or otherwise interfere with the device.
- The device must not be tampered with and must not be changed in any way.
- The device must not be opened. There are no user-serviceable parts inside.
- Repairs must only be performed by Leuze electronic GmbH + Co. KG.

## 2.3 Competent persons

Connection, mounting, commissioning and adjustment of the device must only be carried out by competent persons.

Prerequisites for competent persons:

- They have a suitable technical education.
- They are familiar with the rules and regulations for occupational safety and safety at work.
- They are familiar with the technical description of the device.
- They have been instructed by the responsible person on the mounting and operation of the device.

***Certified electricians***

Electrical work must be carried out by a certified electrician.

Due to their technical training, knowledge and experience as well as their familiarity with relevant standards and regulations, certified electricians are able to perform work on electrical systems and independently detect possible dangers.

In Germany, certified electricians must fulfill the requirements of accident-prevention regulations BGV A3 (e.g. electrician foreman). In other countries, there are respective regulations that must be observed.

## 2.4 Disclaimer

Leuze electronic GmbH + Co. KG is not liable in the following cases:

- The device is not being used properly.
- Reasonably foreseeable misuse is not taken into account.
- Mounting and electrical connection are not properly performed.
- Changes (e.g., constructional) are made to the device.

## 2.5 Laser safety notices



### ATTENTION LASER RADIATION – LASER CLASS 2

#### Never look directly into the beam!

The device satisfies the requirements of IEC 60825-1:2007 (EN 60825-1:2007) safety regulations for a product in **laser class 2** as well as the U.S. 21 CFR 1040.10 regulations with deviations corresponding to "Laser Notice No. 50" from June 24th, 2007.

- ↵ Never look directly into the laser beam or in the direction of reflecting laser beams. If you look into the beam path over a longer time period, there is a risk of injury to the retina.
- ↵ Do not point the laser beam of the device at persons!
- ↵ Interrupt the laser beam using a non-transparent, non-reflective object if the laser beam is accidentally directed towards a person.
- ↵ When mounting and aligning the device, avoid reflections of the laser beam off reflective surfaces!
- ↵ CAUTION! The use of operating or adjusting devices other than those specified here or carrying out of differing procedures may lead to dangerous exposure to radiation.
- ↵ Adhere to the applicable legal and local regulations regarding protection from laser beams.
- ↵ The device must not be tampered with and must not be changed in any way. There are no user-serviceable parts inside the device. Repairs must only be performed by Leuze electronic GmbH + Co. KG.

**NOTICE**

**Affix laser information and warning signs!**

Laser information and warning signs are attached to the device (see figure 2.1):

In addition, self-adhesive laser warning and information signs (stick-on labels) are supplied in several languages (see figure 2.2).

↪ Affix the laser information sheet to the device in the language appropriate for the place of use.

When using the device in the US, use the stick-on label with the "Complies with 21 CFR 1040.10" notice.

↪ Affix the laser information and warning signs near the device if no signs are attached to the device (e.g., because the device is too small) or if the attached laser information and warning signs are concealed due to the installation position.

Affix the laser information and warning signs so that they are legible without exposing the reader to the laser radiation of the device or other optical radiation.




Figure 2.1: Laser apertures, laser warning signs




Figure 2.2: Laser warning and information signs – supplied stick-on labels

### 3 Fast commissioning / operating principle

**Notice!**

Below, you will find a **short description for the initial commissioning** of the AMS 300*i*. Detailed explanations for the listed points can be found throughout the handbook.

#### 3.1 Mounting the AMS 300*i*

The AMS 300*i* and the corresponding reflector are mounted on two mutually opposing, plane-parallel, flat walls.




Figure 3.1: Schematic illustration of mounting

**Attention!**

For error-free position measurement, there must be an unobstructed line-of-sight between the AMS 300*i* and the reflector.

##### 3.1.1 Mounting the device

The laser is mounted on a vertical wall using 4 screws (M5).

Alignment is performed using 2 adjustment screws. Adjust so that the laser light spot is positioned at the center of the reflector. The alignment is to be secured with the knurled nut and locked with the M5 nut.

**Further information can be found in chapter 5.2 and chapter 5.3.**

##### 3.1.2 Mounting the reflector

The reflector is mounted on a vertical wall with 4 screws (M5). The reflector is angled using the included shims. Incline the reflector by approx. 1°.

**Detailed information can be found in chapter 6.4.**



### 3.2 Connecting the voltage supply

The laser measurement system is connected using M12 connectors. The voltage supply is connected via the PWR M12 connection.

**Detailed information can be found in chapter 7.**

### 3.3 Display

Once the laser measurement system is supplied with voltage, the device status as well as the measured position values can be read on the display. The display automatically switches to the display of the measurement values.

Use the up/down buttons   to the left of the display to read and change a wide range of data and parameters.

Depending on connected interface, the network address or IP addresses must be configured via the display.

**Detailed information can be found in chapter 8.**

### 3.4 AMS 300*i* on the RS 422/RS 232

The AMS 300*i* can transmit position values either via the RS 422 or the RS 232. Activating both interfaces simultaneously is not possible.

#### 3.4.1 Transmission of data by means of the RS 422

The RS 422 is activated by default.

The transmission parameters are listed above the menu structure or on the fold-out page at the end of the technical description.

The parameters can be adjusted after activation of parameter enabling.

**Further information can be found in chapter 8.3 and chapter 9.4.4.**

#### 3.4.2 Transmission of data by means of the RS 232

##### **Activation of the RS 232 interface**

- Activating parameter enabling
- Deactivating of the RS 422 interface – activation OFF
- Activation of the RS 232 interface – activation ON
- Deactivating of parameter enabling

The RS 232 transmits the data with the preset parameters. These are listed above the menu structure or on the fold-out page at the end of the technical description.

The parameters can be adjusted after activation of parameter enabling.

**Further information can be found in chapter 8.3 and chapter 9.4.4.**

## 4 Specifications

### 4.1 Specifications of the laser measurement system

#### 4.1.1 General specifications AMS 300*i*

Measurement data	AMS 300 <i>i</i> 40 (H)	AMS 300 <i>i</i> 120 (H)	AMS 300 <i>i</i> 200 (H)	AMS 300 <i>i</i> 300 (H)
Measurement range	0.2 ... 40m	0.2 ... 120m	0.2 ... 200m	0.2 ... 300m
Accuracy	± 2mm	± 2mm	± 3mm	± 5mm
Consistency <sup>1)</sup>	0.3mm	0.5mm	0.7mm	1.0mm
Light spot diameter	≤ 40mm	≤ 100mm	≤ 150mm	≤ 225mm
Measurement value output			1.7ms	
Integration time			8ms	
Resolution	adjustable, see chapter of the individual interfaces			
Temperature drift			≤ 0.1 mm/K	
Ambient temperature sensitivity			1 ppm/K	
Air pressure sensitivity			0.3ppm/hPa	
Traverse rate			≤ 10m/s	
<b>Electrical data</b>				
Supply voltage <i>V</i> <sub>in</sub> <sup>2)</sup>			18 ... 30VDC	
Current consumption			without device heating: ≤ 250mA / 24VDC with device heating: ≤ 500mA / 24VDC	
<b>Optical data</b>				
Transmitter			laser diode, red light, wavelength 650 ... 690nm	
Laser class			2 acc. to EN 60825-1, CDRH	
<b>Interfaces</b>				
Baud rate in kbit/s				
	RS 422		19.2 / 38.4 / 57.6 / 115.2 /	
	RS 232		19.2 / 38.4 / 57.6 / 115.2 /	
<b>Operating and display elements</b>				
Keyboard			4 buttons	
Display			monochromatic graphical display, 128 x 64 pixels	
LED			2 LEDs, two-colored	



## Inputs/outputs

Quantity	2, programmable
Input	protected against polarity reversal
Output	max. 60mA, short-circuit proof

## Mechanical data

Housing	cast zinc and aluminum
Optics	glass
Weight	approx. 2.45kg
Protection class	IP 65 acc. to EN 60529 <sup>3)</sup>

## Environmental conditions

Operating temperature	
without device heating	-5°C ... +50°C
with device heating	-30°C ... +50°C <sup>4)</sup>
Storage temperature	-30°C ... +70°C
Air humidity	max. 90% rel. humidity, non-condensing

## Mechanical/electrical loading capacity

Vibrations	acc. to EN 60068-2-6
Noise	acc. to EN 60060-2-64
Shock	acc. to EN 60068-2-27
EMC	acc. to EN 61000-6-2 and EN 61000-6-4 <sup>5)</sup>

- 1) Statistical error: 1 sigma; minimum switch-on time: 2min.
- 2) For UL applications: only for use in "Class 2" circuits acc. to NEC.
- 3) With screwed-on M12 plugs or mounted caps.
- 4) With devices with heating, the switch on/off area of the internal heating can be extended to prevent condensation from forming. A 100% prevention of the formation of condensation cannot be guaranteed due to the limited heating capacity of the AMS 300*i*.
- 5) This is a Class A product. In a domestic environment this product may cause radio interference, in which case the operator may be required to take adequate measures.



The AMS 300*i* is designed in accordance with safety class III for supply with PELV (protective extra-low voltage).

4.1.2 Dimensioned drawing AMS 300*i*




Figure 4.1: Dimensioned drawing AMS 300*i*

4.1.3 Type overview AMS 300*i*

**AMS 300*i* (RS 422/RS 232)**

Type designation	Description	Part no.
AMS 300 <i>i</i> 40	40m operating range, RS 422/RS 232 interface	50113661
AMS 300 <i>i</i> 120	120m operating range, RS 422/RS 232 interface	50113662
AMS 300 <i>i</i> 200	200m operating range, RS 422/RS 232 interface	50113663
AMS 300 <i>i</i> 300	300m operating range, RS 422/RS 232 interface	50113664
AMS 300 <i>i</i> 40 H	40m operating range, RS 422/RS 232 interface, integrated heating	50113665
AMS 300 <i>i</i> 120 H	120m operating range, RS 422/RS 232 interface, integrated heating	50113666
AMS 300 <i>i</i> 200 H	200m operating range, RS 422/RS 232 interface, integrated heating	50113667
AMS 300 <i>i</i> 300 H	300m operating range, RS 422/RS 232 interface, integrated heating	50113668

Table 4.1: Type overview AMS 300*i*

## 5 Installation and mounting

### 5.1 Storage, transportation



#### **Attention!**

When transporting or storing, package the device so that it is protected against collision and humidity. Optimum protection is achieved when using the original packaging. Heed the required environmental conditions specified in the technical data.

#### **Unpacking**

- ↳ Check the packaging for any damage. If damage is found, notify the post office or shipping agent as well as the supplier.
- ↳ Check the delivery contents using your order and the delivery papers:
  - Delivered quantity
  - Device type and model as indicated on the nameplate
  - Brief manual

The name plate provides information as to what AMS 300*i* type your device is. For specific information, please refer to chapter 11.2.

#### **Name plates**




Figure 5.1: Device name plate using the AMS 300*i* as an example




#### **Notice!**

Please note that the shown name plate is for illustration purposes only; the contents do not correspond to the original.

- ↳ Save the original packaging for later storage or shipping.

If you have any questions concerning your shipment, please contact your supplier or your local Leuze electronic sales office.

 Observe the applicable local regulations when disposing of the packaging materials.

## 5.2 Mounting the AMS 300*i*




Figure 5.2: Mounting the device

The AMS 300*i* and the corresponding reflector are mounted on two mutually opposing, plane-parallel, flat walls or system parts. For error-free position measurement, there must be an unobstructed line-of-sight connection between the AMS 300*i* and the reflector.

Use M5 screws to fasten the laser measurement system. Secure the screws with a toothed lock washer to protect against loosening caused by vibrations.

***Aligning the laser light spot in the center of the reflector***

The laser light spot has to be aligned so that it always hits the center of the opposing reflector, both at close range as well as at the maximum measurement distance. **To align, use the two M5 Allen screws** ("A" in figure 5.2). When aligning please ensure that the knurled nut and the lock nut ("B" in figure 5.2) are opened wide.

***Attention!***

*To prevent the laser measurement system from moving out of alignment during continuous operation, subsequently hand-tighten the knurled nut and counterlock with the nut with WAF4 hexagon socket ("B" in figure 5.2). Knurled nut and nut must not be tightened until alignment has been completed.*

***Attention!***

*The device must not be opened. Failure to comply will render the guarantee void. Warranted features cannot be guaranteed after the device has been opened.*

### 5.2.1 Optional mounting bracket

A mounting bracket for mounting the AMS 300*i* on a flat, horizontal surface is available as an optional accessory.

Type designation: MW OMS/AMS 01

Part no.: 50107255




Figure 5.3: Optional mounting bracket

5.2.2 Parallel mounting of the AMS 300*i*

**Definition of the term "parallel spacing"**

As shown in figure 5.4, dimension X describes the "parallel spacing" of the inner edges of the two laser light spots on the reflector.




Figure 5.4: Minimum parallel spacing X between adjacent AMS 300*i*

The diameter of the light spot increases with distance.

	AMS 300 <i>i</i> 40 (H)	AMS 300 <i>i</i> 120 (H)	AMS 300 <i>i</i> 200 (H)	AMS 300 <i>i</i> 300 (H)
Max. measurement distance	40m	120m	200m	300m
Light spot diameter	≤ 40mm	≤ 100mm	≤ 150mm	≤ 225mm

Thus, the center-to-center spacing of the two AMS 300*i* devices with respect to one another can be calculated as a function of the maximum measurement distance.

To define the minimum parallel spacing between two AMS 300*i*, it is necessary to distinguish between three different arrangements of AMS 300*i* and reflectors.

**The AMS 300*i* are mounted stationary and in parallel on one plane. Both reflectors move independently of one another at different distances to the AMS 300*i*.**

Minimum parallel spacing X of the two laser light spots:  
 **$X = 100\text{mm} + (\text{max. measurement distance in mm} \times 0.01)$**

**The AMS 300*i* are mounted stationary and in parallel on one plane. Both reflectors move in parallel at the same distance to the AMS 300*i*.**

- Measurement distance up to 120m: minimum parallel spacing  $X \geq 600\text{mm}$
- Measurement distance up to 200m: minimum parallel spacing  $X \geq 750\text{mm}$
- Measurement distance up to 300m: minimum parallel spacing  $X \geq 750\text{mm}$



***The reflectors are mounted stationary and in parallel on one plane.***

***Both AMS 300*i* move independently of one another at different or the same distances to the reflectors.***

Measurement distance **up to 120m**: minimum parallel spacing **X ≥ 600mm**

Measurement distance **up to 200m**: minimum parallel spacing **X ≥ 750mm**

Measurement distance **up to 300m**: minimum parallel spacing **X ≥ 750mm**



**Notice!**

*Please note that when the AMS 300*i* are mounted in a mobile manner, travel tolerances could cause the two laser light spots to move towards each other.*

*Take the travel tolerances of the vehicle into account when defining the parallel spacing of adjacent AMS 300*i*.*

### 5.2.3 Parallel mounting of AMS 300*i* and DDLS optical data transmission

The optical data transceivers of the DDLS series and the AMS 300*i* do not interfere with one another. Depending on the size of the used reflector, the DDLS can be mounted with a minimum parallel spacing of 100mm to the AMS 300*i*. The parallel spacing is independent of the distance.

### 5.3 Mounting the AMS 300*i* with laser beam deflector unit

#### General information

The two available deflector units are used for the 90° deflection of the laser beam, see "Accessory deflector unit" on page 60.



#### Attention!

The deflector units are designed for a maximum range of 40m. Longer distances on request.

#### 5.3.1 Mounting the laser beam deflector unit With integrated mounting bracket

The AMS 300*i* is screwed onto the mechanism of the US AMS 01 deflector unit. The mirror can be mounted for three deflection directions:

1. Upward beam deflection
2. Beam deflection to the left
3. Beam deflection to the right

The deflector unit is mounted on plane-parallel, flat walls or plant components. For error-free position measurement, there must be an interruption-free line-of-sight between the AMS 300*i*... and the deflection mirror as well as between the mirror and the reflector.

Use the M5 screws to mount the deflector unit. Secure the screws with a toothed lock washer to protect against loosening caused by vibrations.




Figure 5.5: Mounting variants of the US AMS 01 laser beam deflector unit



### 5.3.3 Mounting the US 1 OMS deflector unit without mounting bracket

The US 1 OMS deflector unit and the AMS 300*i* are mounted separately.



**Notice!**

When mounting, make certain that the laser light spot of the AMS 300*i* is aligned in the center of the deflection mirror.




Figure 5.7: Photo and dimensioned drawing of the US 1 OMS deflector unit

Alignment of the laser light spot on the reflector is performed as described in chapter 5.2.

## 6 Reflectors

### 6.1 General information

The AMS 300*i* measures distances against a reflective tape specified by Leuze electronic. All provided specifications for the AMS 300*i*, such as the operating range or accuracy, can only be achieved with the reflective tape specified by Leuze electronic.

The reflective tapes are available as adhesive tapes, affixed to a metal plate and with an integrated heater especially for use at low temperatures. Reflective tapes with heating have the designation "**Reflective tape ...x...-H**", where "**H**" is an abbreviation for the heating variant.

The reflective tapes/reflectors must be ordered separately. The choice of size is left to the user. In chapter 6.3, recommendations on reflector size are provided as a function of the distance that is to be measured. In any case, the user must check to determine whether the recommendation is suitable for the respective application.

### 6.2 Description of the reflective tape

The reflective tape consists of a white, microprism-based reflective material. The microprisms are protected with a highly transparent, hard protective layer.

Under certain circumstances, the protective layer may lead to surface reflections. The surface reflections can be directed past the AMS 300*i* by positioning the reflective tape at a slight incline. The inclination of the reflective tape/reflectors is described in chapter 6.4.2. The required pitch can be found in table 6.1 "Reflector pitch resulting from spacer sleeves" on page 35.

The reflective tapes are provided with a protective foil that can easily be pulled off. This must be removed from the reflector before the complete system is put into operation.

**6.2.1 Specifications of the self-adhesive foil**

	<b>Part</b>		
Type designation	<b>Reflective tape 200x200-S</b>	<b>Reflective tape 500x500-S</b>	<b>Reflective tape 914x914-S</b>
Part no.	50104361	50104362	50108988
Foil size	200x200mm	500x500mm	914x914mm
Recommended application temperature for adhesive tape	+5°C ... +25°C		
Temperature resistance, affixed	-40°C ... +80°C		
Mounting surface	The mounting surface must be clean, dry and free of grease.		
Cutting the tape	Cut with a sharp tool, always on the side of the prism structure.		
Cleaning	Do not use any agents that act with a grinding effect. A conventional household detergent can be used as a cleaning agent. Rinse with clear water and dry the surface.		
Storing the foil	Store in a cool and dry place.		

**6.2.2 Specifications of the reflective tape on a metal plate**

The reflective tape is affixed to a metal plate. Included with the metal plate are spacers for positioning at an incline - for avoiding surface reflections - (see chapter 6.4.2 "Mounting the reflector").

	<b>Part</b>		
Type designation	<b>Reflective tape 200x200-M</b>	<b>Reflective tape 500x500-M</b>	<b>Reflective tape 914x914-M</b>
Part no.	50104364	50104365	50104366
Foil size	200x200mm	500x500mm	914x914mm
Outer dimensions of the metal plate	250x250mm	550x550mm	964x964mm
Weight	0.8kg	4kg	25kg
Cleaning	Do not use any agents that act with a grinding effect. A conventional household detergent can be used as a cleaning agent. Rinse with clear water and dry the surface.		
Storing the reflector	Store in a cool and dry place.		

6.2.3 Dimensioned drawing of reflective tape on a metal plate




Figure 6.1: Dimensioned drawing of reflectors

Part	Reflective tape (mm)		Reflector plate (mm)		
	xL	yL	XL	YL	L
Reflective tape 200x200-M	200	200	250	250	214
Reflective tape 500x500-M	500	500	550	550	514
Reflective tape 914x914-M	914	914	964	964	928

**6.2.4 Specifications of heated reflectors**

The reflective tape is affixed to a heated, thermally insulated base. The insulation results in a very high energetic efficiency.

Only the reflective tape is kept at the specified temperature by the integrated heater. Through the insulation on the back, the generated heat cannot be transferred via the steel construction. Energy costs are greatly reduced in the case of continuous heating.

	<b>Part</b>		
Type designation	<b>Reflective tape 200x200-H</b>	<b>Reflective tape 500x500-H</b>	<b>Reflective tape 914x914-H</b>
Part no.	50115020	50115021	50115022
Voltage supply	230VAC		
Power	100W	600W	1800W
Current consumption	~ 0.5A	~ 3A	~ 8A
Length of the supply line	2 m		
Size of the reflective tape	200x200mm	500x500mm	914x914mm
Outer dimensions of the base material	250x250mm	550x550mm	964x964mm
Weight	0.5kg	2.5kg	12kg
Temperature control	Controlled heating with the following switch-on and switch-off temperatures, measured at the reflector surface.		
Switch-on temperature	~ 5°C		
Switch-off temperature	~ 20°C		
Operating temperature	-30°C ... +70°C		
Storage temperature	-40°C ... +80°C		
Air humidity	Max. 90%, non-condensing.		
Cleaning	Do not use any agents that act with a grinding effect. A conventional household detergent can be used as a cleaning agent. Rinse with clear water and dry the surface.		
Storing the reflector	Store in a cool and dry place.		



6.2.5 Dimensioned drawing of heated reflectors




Figure 6.2: Dimensioned drawing of heated reflectors

Part	Reflective tape (mm)		Insulated base plate (mm)		
	xL	yL	XL	YL	L
Reflective tape 200x200-H	200	200	250	250	214
Reflective tape 500x500-H	500	500	550	550	514
Reflective tape 914x914-H	914	914	964	964	928

### 6.3 Selecting reflector sizes

Depending on system design, the reflector can be mounted so that it travels on the vehicle or it can be mounted at a fixed location.



**Attention!**

The reflector sizes shown below are a recommendation from Leuze electronic for on-vehicle mounting of the AMS 300*i*. For stationary mounting of the AMS 300*i*, a smaller reflector is generally sufficient for all measurement distances.

On the basis of the system planning and design, always check whether mechanical travel tolerances may require the use of a reflector larger than that which is recommended. This applies, in particular, when the laser measurement system is mounted on a vehicle. During travel, the laser beam must reach the reflector without interruption. For on-vehicle mounting of the AMS 300*i*, the reflector size must accommodate any travel tolerances that may arise and the associated "wandering" of the light spot on the reflector.

**Overview of reflector types**

Recommended reflector sizes			
AMS 300 <i>i</i> selection (Operating range in m)	Recommended reflector size (H x W)	Type designation ...-S = Self-adhesive ...-M = metal plate ...-H = heating	Part no.
AMS 300 <i>i</i> 40 (max. 40m)	200x200mm	Reflective tape 200x200-S Reflective tape 200x200-M Reflective tape 200x200-H	50104361 50104364 50115020
AMS 300 <i>i</i> 120 (max. 120m)	500x500mm	Reflective tape 500x500-S Reflective tape 500x500-M Reflective tape 500x500-H	50104362 50104365 50115021
AMS 300 <i>i</i> 200 (max. 200m)	749x914mm 914x914mm	Reflective tape 749x914-S Reflective tape 914x914-M Reflective tape 914x914-S Reflective tape 914x914-H	50104363 50104366 50108988 50115022
AMS 300 <i>i</i> 300 (max. 300m)	749x914mm 914x914mm	Reflective tape 749x914-S Reflective tape 914x914-M Reflective tape 914x914-S Reflective tape 914x914-H	50104363 50104366 50108988 50115022

## 6.4 Mounting the reflector

### 6.4.1 General information

#### **Self-adhesive reflective tapes**

The reflective tapes of the "Reflective tape ...x...-S" self-adhesive series must be affixed to a flat, clean and grease-free surface. We recommend using a separate metal plate, which is to be provided on-site.

As described in table 6.1, the reflective tape must be angled.

#### **Reflective tapes on metal**

The reflective tapes of the "Reflective tape ...x...-M" series are provided with corresponding mounting holes. Spacer sleeves are provided in the packet for achieving the necessary pitch angle. For further information see table 6.1.

#### **Heated reflectors**

The reflective tapes of the "Reflective tape ...x...-H" series are provided with corresponding mounting holes. Due to the voltage supply affixed on the rear, the reflector cannot be mounted flat. Included in the package are four distance sleeves in two different lengths. Use the distance sleeves to achieve a base separation to the wall as well as the necessary pitch for avoiding surface reflection. For further information see table 6.1.

The reflector is provided with a 2m-long connection cable for supplying with 230VAC. Connect the cable to the closest power outlet. Observe the current consumptions listed in the specifications.



#### **Attention!**

*Connection work must be carried out by a certified electrician.*

### 6.4.2 Mounting the reflector

The combination of laser measurement system and reflective tape/reflector is mounted so that the laser light spot hits the tape as centered as possible and without interruption.

For this purpose, use the alignment elements provided on the AMS 300i... (see chapter 5.2 "Mounting the AMS 300i"). If necessary, remove the protective foil from the reflector.



#### **Attention!**

The "TOP" label mounted on the reflectors should be aligned the same as the connections of the AMS 300i.

#### **Example:**

*If the AMS 300i is mounted so that the M12 connections are on the top, the "TOP" label of the reflector is also on the top. If the AMS 300i is mounted so that the M12 connections are on the side, the "TOP" label of the reflector is also on the side.*



**Notice!**

The reflector must be angled. To do this, use the spacer sleeves. Angle the reflectors so that the surface reflections of the foil seal are deflected to the left, right or upwards, chapter 6.4.3 gives the correct pitch with respect to the reflector size and, thus, the length of the spacers.

**Reflective tapes ...-S and ...-M**




Figure 6.3: Reflector mounting




Figure 6.4: Pitch of the reflector

**Reflective tapes ...-H**




Figure 6.5: Mounting of heated reflectors




Figure 6.6: Pitch of the heated reflector

**6.4.3 Table of reflector pitches**

<b>Reflector type</b>	<b>Pitch resulting from spacer sleeves <sup>1)</sup></b>	
Reflective tape 200x200-S Reflective tape 200x200-M	<b>2 x 5mm</b>	
Reflective tape 200x200-H	<b>2 x 15mm</b>	<b>2 x 20mm</b>
Reflective tape 500x500-S Reflective tape 500x500-M	<b>2 x 10mm</b>	
Reflective tape 500x500-H	<b>2 x 15mm</b>	<b>2 x 25mm</b>
Reflective tape 749x914-S	<b>2 x 20mm</b>	
Reflective tape 914x914-S Reflective tape 914x914-M	<b>2 x 20mm</b>	
Reflective tape 914x914-H	<b>2 x 15mm</b>	<b>2 x 35mm</b>

1) Spacer sleeves are included in the delivery contents of reflective tape ...-M and ...-H

Table 6.1: Reflector pitch resulting from spacer sleeves



**Notice!**

*Reliable function of the AMS 300i and, thus, max. operating range and accuracy can only be achieved with the reflective tape specified by Leuze electronic. No function can be guaranteed if other reflectors are used!*

## 7 Electrical connection

The AMS 300*i* laser measurement systems are connected using variously coded M12 connectors. This ensures unique connection assignments.



### Notice!

The corresponding mating connectors and ready-made cables are available as accessories for all cables. For further information, see chapter 11 "Type overview and accessories".



Figure 7.1: Connections of the AMS 300*i*

### 7.1 Safety notices for the electrical connection



#### Attention!

Before connecting the device, be sure that the supply voltage agrees with the value printed on the name plate.

The device may only be connected by a qualified electrician.

Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly.

If faults cannot be corrected, the device should be removed from operation and protected against possible use.



#### Attention!

For UL applications, use is permitted exclusively in Class 2 circuits according to NEC (National Electric Code).



The laser measurement systems are designed in accordance with safety class III for supply by PELV (protective extra-low voltage with reliable disconnection).



### Notice!

Protection class IP65 is achieved only if the connectors and caps are screwed into place!

Described in detail in the following are the individual connections and pin assignments.

### 7.2 PWR – voltage supply / switching input/output

PWR (5-pin plug, A-coded)			
<p style="text-align: center;">PWR</p> <p style="text-align: center;">I/O 1</p> <p style="text-align: center;">2</p> <p style="text-align: center;">3 GND 1 VIN</p> <p style="text-align: center;">4</p> <p style="text-align: center;">5</p> <p style="text-align: center;">I/O 2</p> <p style="text-align: center;">FE</p> <p style="text-align: center;">M12 plug (A-coded)</p>	Pin	Name	Remark
	1	VIN	Positive supply voltage +18 ... +30VDC
	2	I/O 1	Switching input/output 1
	3	GND	Negative supply voltage 0VDC
	4	I/O 2	Switching input/output 2
	5	FE	Functional earth
	Thread	FE	Functional earth (housing)

Table 7.1: Pin assignment PWR

Further information on configuring the input/output can be found in chapter 8 and chapter 9.

### 7.3 RS 422 BUS IN

RS 422 BUS IN (5-pin plug, B-coded)			
<p style="text-align: center;">BUS IN RS 422</p> <p style="text-align: center;">Tx+</p> <p style="text-align: center;">4 Rx-</p> <p style="text-align: center;">1 Rx+ 3 GND ISO</p> <p style="text-align: center;">2</p> <p style="text-align: center;">Tx-</p> <p style="text-align: center;">M12 connector (B-coded)</p>	Pin	Name	Remark
	1	Rx	RS 422 receiving line
	2	Tx-	RS 422 transmission line
	3	GND ISO	RS 422 reference potential
	4	Tx	RS 422 transmission line
	5	Rx-	RS 422 receiving line
	Thread	FE	Functional earth (housing)

Table 7.2: RS 422 BUS IN pin assignment



## 7.4 RS 232 BUS IN


RS 232 BUS IN (5-pin plug, B-coded)			
BUS IN RS 232	Pin	Name	Remark
 <p>M12 connector (B-coded)</p>	1	NC	Not used
	2	TxD	RS 232 transmission line
	3	GND ISO	RS 232 reference potential
	4	NC	Not used
	5	RxD	RS 232 receiving line
	Thread	FE	Functional earth (housing)

Table 7.3: RS 232 BUS IN pin assignment

## 7.5 Service


Service (5-pin socket, A-coded)			
SERVICE	Pin	Name	Remark
 <p>M12 socket (A-coded)</p>	1	NC	Not used
	2	RS232-TX	Transmission line RS 232/service data
	3	GND	Voltage supply 0VDC
	4	RS232-RX	Receiving line RS 232/service data
	5	NC	Not used
	Thread	FE	Functional earth (housing)

Table 7.4: Service pin assignments



**Notice!**

The service interface is designed only for use by Leuze electronic!

## 8 Display and control panel AMS 300i

### 8.1 Structure of the control panel




Figure 8.1: Structure of the control panel using the AMS 304i PROFIBUS device variant as an example



**Notice!**

The figure is for illustration purposes only and does not correspond to AMS 300i with respect to bus/interface info.

### 8.2 Status display and operation

#### 8.2.1 Indicators in the display

**Status and warning messages in the display**

- IO1 **Input 1 or output 1 active:**  
Function depending on configuration.
- IO2 **Input 2 or output 2 active:**  
Function depending on configuration.

- LSR    **Warning - laser prefailure message:**  
Laser diode old, device still functional, exchange or have repaired.
- TMP    **Warning - temperature monitoring:**  
Permissible internal device temperature exceeded / not met.
- PLB    **Plausibility error:**  
Implausible measurement value. Possible causes: light beam interruption, outside of measurement range, permissible internal device temperature considerably exceeded or traverse rate >10m/s.  
Depending on the configuration, either zero or the last valid measurement value is output at the interfaces.
- ATT    **Warning received signal:**  
Laser outlet window or reflector soiled or fogged by rain, water vapor or fog. Clean or dry surfaces.
- ERR    **Internal hardware error:**  
The device must be sent in for inspection.


**Bar graph**



Indicates the **strength of the received laser light**.  
The center bar represents the **ATT** warning threshold. The distance value remains valid and is output at the interfaces.  
If no bar graph is available, the **PLB** status information appears at the same time. The measurement value has thus been assessed as being implausible. Depending on the configuration, either zero or the last valid measurement value is output at the interfaces.

**Interface info**

The designation "RS 422" or "RS 232" in the display shows the respectively active interface.



**Maximum position value**

- The measured position value is displayed in the configured unit of measurement.
- +87.000m    With the **metric** setting, the measurement value is always displayed in meters with **three decimal places**.
- +87.0in    With the **inch** setting, the measurement value is always displayed in inches with **one decimal place**.

8.2.2 LED status displays

**PWR LED**

PWR



**Off**

**Device OFF**

- No supply voltage

PWR



**Flashing green**

**Power LED flashes green**

- No measurement value output
- Voltage connected
- Self test running
- Initialization running
- Boot process running

PWR



**Green continuous light**

**Power LED green**

- AMS 300i ok
- Measurement value output
- Self test successfully finished
- Device monitoring active

PWR



**Red flashing**

**Power LED flashes red**

- Device ok but warning message (ATT, TMP, LSR) set in display
- Light beam interruption
- Plausibility error (PLB)

PWR



**Red continuous light**

**Power LED red**

- No measurement value output; for details, see Display

**BUS LED**

BUS



**Flashing green**

**BUS LED flashes green**

- Initialization of the host interface

BUS







**Green continuous light**



**BUS LED green**


- Host interface active
-


### 8.2.3 Control buttons

-  **Up**      Navigate upward/laterally.
-  **Down**      Navigate downward/laterally.
-  **ESC**      Exit menu item.
-  **ENTER**      Confirm/enter value, change menu levels.

#### ***Navigating within the menus***

The menus within a level are selected with the up/down buttons  .


The selected menu item is activated with the enter button .






Press the ESC button  to move up one menu level.





When one of the buttons is actuated, the display illumination is activated for 10min.




#### ***Setting values***

If input of a value is possible, the display looks like this:




-  +  Delete character
-  +  Enter digit
- save** +  Save




Use the   and  buttons to set the desired value. An accidental, incorrect entry can be corrected by selecting <-l and then pressing .

Then use the   buttons to select **save** and save the set value by pressing .

#### ***Selecting options***

If options can be selected, the display looks like this:




Select the desired option with the   buttons. Activate the option by pressing .

### 8.3 Menu description

#### 8.3.1 The main menus

After voltage has been applied to the laser, device information is displayed for several seconds. The display then shows the measurement window with all status information.



#### Device information - main menu

This menu item contains detailed information on

- Device model,
- Manufacturer,
- Software and hardware version,
- Serial number.


No entries can be made via the display.



#### Network information - main menu

- Explanations of the active interface, data format and baud rate.

No entries can be made via the display.




#### Status and measurement data - main menu

- Display of status-, warning-, and error messages
- Status overview of the switching inputs/outputs.
- Bar graph for the reception level.
- Activated interface.
- Measurement value.


No entries can be made via the display.

See "Indicators in the display" on page 39.




#### Parameter - main menu

- Configuration of the AMS.
- See "Parameter menu" on page 44.



#### Language selection - main menu

- Selection of the display language.
- See "Language selection menu" on page 47.



#### Service - main menu

- Display of status messages.
- Display of diagnostic data.

No entries can be made via the display.

See "Service menu" on page 48.



**Notice!**

**The rear cover** of this manual includes a **fold-out page** with the complete **menu structure**. It describes the menu items in brief.


**8.3.2 Parameter menu**

**Parameter handling submenu**

The following functions can be called up in the Parameter handling submenu:

- Lock and enable parameter entry
- Set up a password
- Reset the AMS 300i to default settings.

Table 8.1: Parameter handling submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
Parameter enabling			ON / OFF The standard setting (OFF) prevents unintended parameter changes. With parameter enabling activated (ON), the display is inverted. In this state, it is possible to change parameters manually.	OFF
Password	Activate password		ON / OFF To enter a password, parameter enabling must be activated. If a password is assigned, changes to the AMS 300i can only be made after the password is entered. The master password 2301 bridges the individually set password.	OFF
	Password entry		Configuration option of a four-digit numerical password	
Parameters to default			By pressing the enter button  after selecting <b>Parameters to default</b> , all parameters are reset to their standard settings without any further security prompts. In this case, English is selected as the display language.	

Additional important information on parameter handling can be found at the end of the chapter.

**RS 422/RS 232 submenu**

Table 8.2: RS 422/RS 232 submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
Selection			RS422 / RS232 Selection of the RS 422 or RS 232 communication interface. The interface is to be connected to the bus via the M12 connection plug.	RS 422
Baud rate			19.2kbit/s / 38.4kbit/s / 57.6kbit/s / 115.2kbit/s Selection of the baud rate for serial communication. The baud rate must be the same at the transmission and reception sides to enable communication.	38.4kbit/s

Table 8.2: RS 422/RS 232 submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
Format			... 8,n,1 / ... 8,e,1 / ... 8,o,1 Selection of the data mode for serial communication. Designation is done in number of data bits, parity (N=none, E=even, O=odd) and number of stop bits. For example, "8N1" therefore means 8 data bits, no parity, 1 stop bit.	8,n,1
Output cycle			Value input Output cycle of data in multiples of the AMS 300i measurement cycle of 1.7 ms. The parameter is only valid when the cyclical transmission of the position values is selected. Cyclical transmission is selected via the protocol.	1
Position resolution			0.01 mm / 0.1 mm / 1 mm / 10 mm / free resolution The measurement value can be displayed in these resolutions. The value of the free resolution is determined in the "Position value" submenu in the "Value of free resolution" parameter.	0.1 mm
Velocity resolution			1 mm/s / 10 mm/s / 100 mm/s	1 mm/s

**Position value submenu**

Table 8.3: Position value submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
Measurement unit			Metric/Inch Specifies the units of the measured distances	Metric
Count direction			Positive/Negative Positive: The measurement value begins at 0 and increases with increasing distance. Negative: The measurement value begins at 0 and decreases with increasing distance. Negative distance values may need to be compensated with an offset or preset.	Positive
Offset			Output value=measurement value+offset. The resolution of the offset value is independent of the selected "Resolution position" and is entered in mm or inch/100. The offset value is effective immediately following entry. If the preset value is activated, this has priority over the offset. Preset and offset are not offset against each other.	0mm
Preset			The preset value is accepted by means of teach pulse. The teach pulse can be applied to a hardware input of the M 12 PWR connector. The hardware input must be appropriately configured. See also configuration of the I/Os.	0mm
Free resolution value			The measurement value can be resolved in increments of 1/1000 within the 5 ... 50000 value range. If, e.g., a resolution of 0.875 mm per digit is required, the parameter is set to 875. In the activated interface, the measurement value display must also be set to "free resolution" ("Resolution position" parameter).	1000
Error delay			ON / OFF Specifies whether, in the event of an error, the position value immediately outputs the value of the "Position value in the case of error" parameter or the last valid position value for the configured error delay time.	ON/100 ms



Table 8.3: Position value submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
Position value in the case of error			Last valid value / zero Specifies which position value is output after the error delay time elapses.	Zero

**I/O submenu**

Table 8.4: I/O submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
I/O 1	Port configuration		Input/Output Defines whether I/O 1 functions as an output or input.	Output
	Switching input	Function	No function/preset teach/laser ON/OFF	No function
		Activation	Low active/High active	Low active
	Switching output	Function	Pos. limit value 1 / Pos. limit value 2 / Velocity / Intensity (ATT) / Temp. (TMP) / Laser (LSR) / Plausibility (PLB) / Hardware (ERR) The individual functions are "ORed" on the selected switching output.	Plausibility (PLB), hardware (ERR)
		Activation	Low active/High active	Low active
	I/O 2	Port configuration		Input/Output Defines whether I/O 2 functions as an output or input.
Switching input		Function	No function/preset teach/laser ON/OFF	No function
		Activation	Low active/High active	Low active
Switching output		Function	Pos. limit value 1 / Pos. limit value 2 / Velocity / Intensity (ATT) / Temp. (TMP) / Laser (LSR) / Plausibility (PLB) / Hardware (ERR) The individual functions are "ORed" on the selected switching output.	Intensity (ATT), Temp. (TMP), Laser (LSR)
		Activation	Low active/High active	Low active
Limit values		Upper pos. limit 1	Activation	ON / OFF
	Limit value input		Value input in mm or inch/100	0
	Lower pos. limit 1	Activation	ON / OFF	OFF
		Limit value input	Value input in mm or inch/100	0
	Upper pos. limit 2	Activation	ON / OFF	OFF
		Limit value input	Value input in mm or inch/100	0
	Lower pos. limit 2	Activation	ON / OFF	OFF
		Limit value input	Value input in mm or inch/100	0
	Max. velocity	Activation	ON / OFF	OFF

Table 8.4: I/O submenu


Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
		Max. velocity	Value input in mm/s or inch/100s	0

**Other submenu**

Table 8.5: Other submenu

Level 3	Level 4	Level 5	Selection/configuration option Description	Standard
Heating control			Standard (10°C ... 15°C)/Extended (30°C ... 35°) Defines a switch-on/switch-off range for the heating control. The extended switch-on/switch-off range for heating may provide relief in the event of condensation problems. There is no guarantee that no condensation will occur on the optics in the extended switch-on/switch-off range due to the limited heating capacity. This parameter is available as standard, but functions only for devices with integrated heating (AMS 300i... H).	Standard
Display illumination			10 minutes/ON Display illumination is switched off after 10 minutes or, if the parameter is set to "ON", illumination is always on.	10 min.
Display contrast			Weak/Medium/Strong The display contrast may change at extreme temperature values. The contrast can subsequently be adapted using the three levels.	Medium
Service RS232	Baud rate		57.6 kbit/s / 115.2 kbit/s The service interface is only available to Leuze internally.	115.2 kbit/s
	Format		8,e,1 / 8,n,1 The service interface is only available to Leuze internally.	8,n,1

**8.3.3 Language selection menu**




There are 5 display languages available:

- German
- English
- Spanish
- French
- Italian

The AMS 300i is delivered from the factory with the display preset to English.

To change the language, no password needs to be entered nor must password enabling be activated. The display language is a passive operational control and is, thus, not a function parameter, per se.

### 8.3.4 Service menu




A more detailed description of the individual functions can be found in chapter 10.

## 8.4 Operation


Described here is an operating process using parameter enabling as an example.



### **Parameter enabling**

During normal operation parameters can only be viewed. If parameters are to be changed, the ON menu item in the Parameter -> Parameter handling -> Parameter enable menu must be activated. To do this, proceed as follows:






In the main menu, press the enter button to enter the Parameter menu.





Use the   buttons to select the Parameter handling menu item.

Press the enter button to enter the Parameter handling menu.



In the Parameter handling menu, use the   buttons to select the Parameter enabling menu item.

Press the enter button to enter the Parameter enabling menu.

In the Parameter enabling menu, use the   buttons to select the ON menu item.



Press the enter button to switch on parameter enabling.

The PWR LED illuminates orange; the display is inverted. You can now set the individual parameters on the display.

Press the ESC button twice to return to the Parameter menu.



**Viewing and editing parameters**

As long as parameter enabling is activated, the entire AMS 300i display is inverted. Communication between the control and the AMS 300i via the RS 422/RS 232 interface is also active when parameter enabling is active.



**Notice!**

Changes to parameters via display entry have immediate effect. If a password was stored, parameter enabling is not possible until this password is entered, see "Password for parameter enabling" below.

**Password for parameter enabling**

Parameter entry on the AMS 300i can be protected with a four-digit numerical password. With the AMS 300i, the password is entered via the display. If parameter enabling has been activated after successfully entering the password, parameters can be changed via the display.



**Notice!**

The **master password 2301** can enable the AMS 300i at any time.

## 9 RS 422/RS 232 interface

### 9.1 General Information about the RS 422/RS 232 interface

The AMS 300*i* features an integrated RS 422 interface and a RS 232 interface. The RS 422 interface is active on delivery; alternatively, the RS 232 can be activated. The respectively active interface appears in the display.



**Notice!**

To activate / deactivate the affected interface, parameter enabling must be activated (see "Parameter enabling" on page 48.).




**Notice!**

Both interfaces can be contacted via the M12 connection for BUS IN. Either the RS 422 or the RS 232 can be activated.




Figure 9.1: Interfaces of the AMS 300*i*

### 9.2 RS 422 electrical connection

RS 422 BUS IN (5-pin plug, B-coded)			
BUS IN RS 422	Pin	Name	Remark
 <p>M12 connector (B-coded)</p>	1	Rx+	RS 422 receiving line
	2	Tx-	RS 422 transmission line
	3	GND ISO	RS 422 reference potential
	4	Tx+	RS 422 transmission line
	5	Rx-	RS 422 receiving line
	Thread	FE	Functional earth (housing)

### 9.3 RS 232 electrical connection

RS 232 BUS IN (5-pin plug, B-coded)			
BUS IN RS 232	Pin	Name	Remark
 <p>M 12 connector (B-coded)</p>	1	NC	Not used
	2	TxD	Transmission line RS 232
	3	GND ISO	RS 232 reference potential
	4	NC	Not used
	5	RxD	RS 232 receiving line
	Thread	FE	Functional earth (housing)

### 9.4 RS 422/RS 232 interface data

#### 9.4.1 Default settings of the RS 422 interface

The RS 422 interface is activated on delivery.

Designation	Value range	Default
Activation	ON / OFF	ON
Baud rate in kbit/s	19.2 / 38.4 / 57.6 / 115.2 /	38,4
Data format	8,n,1 / 8,e,1 / 8, o, 1	8,n,1

#### 9.4.2 Default settings of the RS 232 interface

The RS 232 interface is deactivated on delivery.

Designation	Value range	Default
Activation	ON / OFF	OFF
Baud rate in kbit/s	19.2 / 38.4 / 57.6 / 115.2 /	38,4
Data format	8,n,1 / 8,e,1 / 8, o, 1	8,n,1

#### 9.4.3 Parameter setting for AMS 300*i*

An overview of all parameters to be set is listed in the fold-out page at the end of the manual.

All parameters can be set via the panel/display

Basic operation of the display is described in chapter 8.4.

In order to change parameters, parameter enabling must be activated.



**Notice!**

*Changed parameters have an immediate effect on the interface.*

### 9.4.4 Communication protocol (binary protocol)

#### Querying AMS 300*i* data (request)

The request to transfer the measured distances or the speed or the control of the laser diode (ON/OFF) is controlled via a protocol which is 3 bytes long.



#### Notice!

The protocol is valid for both interfaces (RS 422 and RS 232).

#### Query / request to the AMS 300*i*

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	1	1	0	0	0	0	0	0
1	CMD	CMD	CMD	CMD	CMD	CMD	CMD	CMD
2	XOR	XOR	XOR	XOR	XOR	XOR	XOR	XOR

**Byte 0:** Control byte reserve.  
Bit 7 and bit 6 must be set to logical 1.

**Byte 1:** CMD  
Command = Data request to the AMS 300*i*.

Binary coding	Hex coding	Function
1111 0001	F1	Request of an individual distance value
1111 0010	F2	Cyclical request of the distance value <sup>1)</sup>
1111 0011	F3	Stop cyclical transfer
1111 0100	F4	Laser diode on
1111 0101	F5	Laser diode off
1111 0110	F6	Request of an individual velocity value
1111 0111	F7	Cyclical request of the velocity value *
1111 1000	F8	Single request of position and velocity value

1) The output cycle is set to 1 x 1.7 ms by default.

Under RS 422 and RS 232 in the parameter menu, the output cycle for cyclically requested data can be configured in a range of (1 ... 20) x 1.7ms.

**Byte 2:** XOR linking from byte 0 and byte 1  
An uneven binary 1 number (calculated column by column from top to bottom) sets the XOR bit to 1.

#### Example

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	1	0	1	1	1	1	0	0
1	1	1	1	1	0	1	1	0
XOR	0	1	0	0	1	0	1	0

The XOR checksum is entered by the sender (control) in the query protocol and checked by the receiver (AMS 300*i*). A protocol is correctly transmitted when the XOR checksum of the transmitter is equal to the XOR checksum of the receiver. If the XOR comparison is negative (different checksums), the protocol from the AMS 300*i* is not accepted. The AMS 300*i* does not send an acknowledgement to an uneven checksum.

**Answer of the AMS 300*i* data (response) for the CMD query from F1<sub>h</sub> to F7<sub>h</sub>**

The AMS 300*i* data (response) is output in a 6 byte length.



**Notice!**

The output of data is the same for both interfaces (RS 422 and RS 232).

**Answer / response of the AMS 300*i***

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	Laser	I/O2	I/O1	0	0	0	0
1	Ready	LSR	TMP	ERR	ATT	PLB	OVFL	SIGN
2	D23	D22	D21	D20	D19	D18	D17	D16
3	D15	D14	D13	D12	D11	D10	D09	D08
4	D07	D06	D05	D04	D03	D02	D01	D00
5	XOR	XOR	XOR	XOR	XOR	XOR	XOR	XOR

**Answer of the AMS 300*i* data for the query from F8<sub>h</sub>**

The AMS 300*i* data (response) is output in an 8 byte length.



**Notice!**

The output of data is the same for both interfaces (RS 422 and RS 232).

**Answer / response of the AMS 300*i***

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	LASER	I02	I01	0	0	0	0
1	READY	LSR	TMP	ERR	ATT	PLB	OVFL	SIGN
2	D23	D22	D21	D20	D19	D18	D17	D16
3	D15	D14	D13	D12	D11	D10	D9	D8
4	D7	D6	D5	D4	D3	D2	D1	D0
5	V15	V14	V13	V12	V11	V10	V9	V8
6	V7	V6	V5	V4	V3	V2	V1	V0
7	XOR	XOR	XOR	XOR	XOR	XOR	XOR	XOR

- Laser: Laser status; laser ON = 0; laser OFF = 1
- I/O1 / I/O2: I/O status: signal level inactive = 0; signal level active = 1
- Ready: status AMS 300*i*: not ready = 0, ready = 1
- LSR: Laser diode: OK = 0, warning = 1
- TMP: Temperature warning: OK = 0, warning = 1
- ERR: Device error: OK = 0, error = 1
- ATT: Decreasing received signal level: OK = 0, warning = 1
- PLB: Implausible measurement value: OK = 0, warning = 1
- OVFL: Measurement value cannot be represented in 24 bits: OK = 0, warning = 1
- Sign: Measurement value sign: 0 = positive, 1 = negative
- D23 - D00: Distance value or velocity value D23 = MSB, D00 = LSB
- V15 - V00: Velocity value V15 = MSB, V00 = LSB



XOR: XOR linking of byte 0 to byte 4  
 An uneven binary 1 number (calculated column by column from top to bottom) sets the XOR bit to 1.

### Example


Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	1	0	1	1	1	1	0	0
1	1	1	1	1	0	1	1	0
XOR	0	1	0	0	1	0	1	0

The XOR checksum is entered by the AMS 300*i* in the answer protocol and checked by the receiver (control). A protocol is correctly transmitted when the XOR checksum of the transmitter is equal to the XOR checksum of the receiver. If the XOR comparison is negative (different checksum), the protocol is discarded by the control or the control will output an error message.

## 10 Diagnostics and troubleshooting

### 10.1 Service and diagnostics in the display of the AMS 300*i*

In the main menu of the AMS 300*i*, expanded "Diagnostics" can be called up under the Service heading.




From the Service main menu, press the enter button (↵) to access the underlying menu level.

Use the up/down buttons (▲ ▼) to select the corresponding menu item in the selected level; use the enter button (↵) to activate the selection.

Return from any sub-level to the next-higher menu item by pressing the ESC button (⏏).

#### 10.1.1 Status messages

The status messages are written in a ring memory with 25 positions. The ring memory is organized according to the FIFO principle. No separate activation is necessary for storing the status messages. Power OFF clears the ring memory.



#### *Basic representation of the status messages*

**n: Type / No. / 1**

Meaning:

**n:** memory position in the ring memory

**Type:** type of message:

**I** = info, **W** = warning, **E** = error, **F** = severe system error


**No:** internal error detection

**1:** frequency of the event (always "1", since no summation occurs)

The status messages within the ring memory are selected with the up/down buttons (▲ ▼). The enter button (↵) can be used to call up **detailed information** on the corresponding status messages with the following details:


### **Detailed information about a status message**

- Type:** type of message + internal counter  
**UID:** Leuze internal coding of the message  
**ID:** description of the message  
**Info:** not currently used


Within the detailed information, the enter button  can be pressed again to activate an **action menu** with the following functions:



- Acknowledge message
- Delete message
- Acknowledge all
- Delete all

## 10.1.2 Diagnostics

The diagnostics function is activated by selecting the `Diagnostics` menu item. The ESC button  deactivates the diagnostics function and clears the contents of the recordings.

The recorded diagnostic data are displayed in 2 fields. In the upper half of the display, status messages of the AMS and the bar graph are displayed. The lower half contains information that assists in a Leuze-internal evaluation.



Use the up/down buttons   to scroll in the bottom half between various displays. The contents of the scrollable pages are intended solely for Leuze for internal evaluation.

The diagnostics have no influence on the communication to the host interface and can be activated during operation of the AMS 300*i*.

## 10.1.3 Expanded diagnostics

The `Expanded diagnostics` menu item is used for Leuze-internal evaluation.

## 10.2 General causes of errors

### 10.2.1 Power LED

See also chapter 8.2.2.

Error	Possible error cause	Measure
PWR LED "OFF"	No supply voltage connected	Check supply voltage.
	Hardware error	Send in device.
PWR-LED "flashes red"	Light beam interruption	Check alignment.
	Plausibility error	Traverse rate >10m/s.
PWR-LED "static red"	Hardware error	For error description, see display, It may be necessary to send in the device.

Table 10.1: General causes of errors

## 10.3 Interface errors

### 10.3.1 BUS LED

After the AMS 300*i* is started, the **BUS** LED is always on.

## 10.4 Status display in the display of the AMS 300*i*

Display	Possible error cause	Measure
<b>PLB</b> (implausible measurement values)	Laser beam interruption	Laser spot must always be incident on the reflector.
	Laser spot outside of reflector	Traverse rate < 10 m/s?
	Measurement range for maximum distance exceeded	Restrict traversing path or select AMS with larger measurement range.
	Velocity greater than 10 m/s	Reduce velocity.
	Ambient temperature far outside of the permissible range (TMP display; PLB)	Select AMS with heating or ensure cooling.
<b>ATT</b> (insufficient received signal level)	Reflector soiled	Clean reflector or glass lens.
	Glass lens of the AMS soiled	
	Performance reduction due to snow, rain, fog, condensing vapor, or heavily polluted air (oil mist, dust)	Optimize usage conditions.
	Laser spot only partially on the reflector	Check alignment.
<b>TMP</b> (operating temperature outside of specification)	Protective foil on the reflector	Remove protective foil from reflector.
	Ambient temperatures outside of the specified range	In case of low temperatures, remedy may be an AMS with heating. If temperatures are too high, provide cooling or change mounting location.
<b>LSR</b> Laser diode warning	Laser diode prefailure message	Send in device at next possible opportunity to have laser diode replaced. Have replacement device ready.
<b>ERR</b> Hardware error.	Indicates an uncorrectable error in the hardware	Send in device for repair.

**Notice!**

Please use **chapter 10 as a master copy** should servicing be required.

Cross the items in the "Measures" column which you have already examined, fill out the following address field and fax the pages together with your service contract to the fax number listed below.

**Customer data (please complete)**

<b>Device type:</b>	
<b>Company:</b>	
<b>Contact partner / department:</b>	
<b>Phone (direct):</b>	
<b>Fax:</b>	
<b>Street / No:</b>	
<b>ZIP code/City:</b>	
<b>Country:</b>	

**Leuze Service fax number:**

**+49 7021 573 - 199**

## 11 Type overview and accessories

### 11.1 Type key

AMS 3xx i yyy H

Heating option	H =	With heating
Sensing distance	40	Max. operating range in m
	120	Max. operating range in m
	200	Max. operating range in m
	300	Max. operating range in m
	i =	Integrated fieldbus technology
Interface	00	RS 422/RS 232
	01	RS 485
	04	PROFIBUS DP / SSI
	08	TCP/IP
	35	CANopen
	38	EtherCAT
	48	PROFINET RT
	55	DeviceNet
	58	Ethernet/IP
	84	Interbus

AMS Absolute Measuring System

### 11.2 Type overview AMS 300*i* (RS 422/RS 232)

Type designation	Description	Part no.
AMS 300/40	40m operating range, RS 422/RS 232 interface	50113661
AMS 300/120	120m operating range, RS 422/RS 232 interface	50113662
AMS 300/200	200m operating range, RS 422/RS 232 interface	50113663
AMS 300/300	300m operating range, RS 422/RS 232 interface	50113664
AMS 300/40 H	40m operating range, RS 422/RS 232 interface, integrated heating	50113665
AMS 300/120 H	120m operating range, RS 422/RS 232 interface, integrated heating	50113666
AMS 300/200 H	200m operating range, RS 422/RS 232 interface, integrated heating	50113667
AMS 300/300 H	300m operating range, RS 422/RS 232 interface, integrated heating	50113668

Table 11.1: Type overview AMS 300*i*

## 11.3 Overview of reflector types

Type designation	Description	Part no.
Reflective tape 200x200-S	Reflective tape, 200x200 mm, self-adhesive	50104361
Reflective tape 500x500-S	Reflective tape, 500x500 mm, self-adhesive	50104362
Reflective tape 914x914-S	Reflective tape, 914x914 mm, self-adhesive	50108988
Reflective tape 200x200-M	Reflective tape, 200x200 mm, affixed to aluminum plate	50104364
Reflective tape 500x500-M	Reflective tape, 500x500 mm, affixed to aluminum plate	50104365
Reflective tape 914x914-M	Reflective tape, 914x914 mm, affixed to aluminum plate	50104366
Reflective tape 200x200-H	Heated reflective tape, 200 x 200 mm	50115020
Reflective tape 500x500-H	Heated reflective tape, 500 x 500 mm	50115021
Reflective tape 914x914-H	Heated reflective tape, 914 x 914 mm	50115022

Table 11.2: Overview of reflector types

## 11.4 Accessories

### 11.4.1 Accessory mounting bracket

Type designation	Description	Part no.
MW OMS/AMS 01	Mounting bracket for mounting the AMS 300 <i>i</i> to horizontal surfaces	50107255

Table 11.3: Accessory mounting bracket

### 11.4.2 Accessory deflector unit

Type designation	Description	Part no.
US AMS 01	Deflector unit with integrated mounting bracket for the AMS 300 <i>i</i> . Variable 90° deflection of the laser beam in various directions	50104479
US 1 OMS	Deflector unit without mounting bracket for simple 90° deflection of the laser beam	50035630

Table 11.4: Accessory deflector unit

### 11.4.3 Accessory M12 connector

Type designation	Description	Part no.
KD 02-5-BA	M12 connector, B-coded socket, BUS IN	50038538
KD 095-5A	M12 connector, A-coded socket, Power (PWR)	50020501

Table 11.5: Accessory M12 connector






### 11.4.5 Accessory ready-made cables for RS 232




**Notice!**

The RS 232 interface is wired via a SSI/IBS connection cable.

**Contact assignments of RS 232 connection cable**

RS 232 connection cable (5-pin socket, B-coded)			
	Pin	Name	Core color
	1	NC	<b>yellow</b>
	2	TxD	<b>green</b>
	3	GND ISO	<b>gray</b>
	4	NC	<b>pink</b>
	5	RxD	<b>brown</b>
	Thread	FE	<b>bare</b>



**Specifications of the RS 232 connection cable**

**Operating temperature range**      in rest state: -40°C ... +80°C  
 in motion: -5°C ... +80°C

**Material**                                      the lines comply with the RS 232 requirements, free of halogens, silicone and PVC

**Bending radius**                              > 80mm, suitable for drag chains

**Order codes for RS 232 connection cables**

Type designation	Description	Part no.
KB SSI/BS-2000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 2 m	50104172
KB SSI/BS-5000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 5 m	50104171
KB SSI/BS-10000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 10 m	50104170
KB SSI/BS-15000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 15 m	50104169
KB SSI/BS-20000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 20 m	50104168
KB SSI/BS-25000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 25 m	50108447
KB SSI/BS-30000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 30 m	50108446
KB SSI/BS-2000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 2 m	50104172
KB SSI/BS-5000-BA	M 12 socket, B-coded, for SSI/Interbus, axial connector, open cable end, cable length 5 m	50104171

**11.4.6 Cables for RS 422**

No ready-made cables are available for the RS 422.

In accordance with the RS 422 pin assignment (see chapter 9.2), a cable suitable for Interbus can be connected to the KD 02-5-BA M 12 connector with part no. 50038538.

To prevent electromagnetic couplings (EMC), we recommend using only shielded cables with twisted wire pairs.

## 12 Maintenance

### 12.1 General maintenance information

With normal use, the laser measurement system does not require any maintenance by the operator.

#### **Cleaning**

In the event of dust build-up or if the (ATT) warning message is displayed, clean the device with a soft cloth; use a cleaning agent (commercially available glass cleaner) if necessary. Also check the reflector for possible soiling.



#### **Attention!**

*Do not use solvents and cleaning agents containing acetone. Use of such solvents could blur the reflector, the housing window and the display.*


### 12.2 Repairs, servicing



#### **Attention!**

*Access to or changes on the device, except where expressly described in this operating manual, are not authorized. The device must not be opened. Failure to comply will render the guarantee void. Warranted features cannot be guaranteed after the device has been opened.*

Repairs to the device must only be carried out by the manufacturer.

 *Contact your Leuze distributor or service organization should repairs be required. The addresses can be found on the inside of the cover and on the back.*



#### **Notice!**

*When sending the laser measurement systems to Leuze electronic for repair, please provide an accurate description of the error.*

### 12.3 Disassembling, packing, disposing

#### **Repacking**

For later reuse, the device is to be packed so that it is protected.

#### **Notice!**

*Electrical scrap is a special waste product! Observe the locally applicable regulations regarding disposal of the product.*

**A**

Accessories ..... 59  
 Accessory deflector unit ..... 60  
 Accessory mounting bracket ..... 60  
 Accessory ready-made cables ..... 61  
 Accuracy ..... 13  
 Air humidity ..... 14  
 Alignment ..... 19

**B**

BUS LED ..... 41

**C**

Cleaning ..... 64  
 Communication protocol (binary protocol) .. 52  
 Connections  
     PWR IN ..... 37  
     RS 232 BUS IN ..... 38  
     RS 422 BUS IN ..... 37  
     Service ..... 38  
 Control buttons ..... 42  
 Control panel ..... 39

**D**

Declaration of conformity ..... 4  
 Deflector unit  
     Maximum ranges ..... 23  
     With integrated mounting bracket ..... 23  
     Without mounting bracket ..... 25  
 Deflector unit US 1 OMS  
     Dimensioned drawing ..... 25  
 Deflector unit US AMS 01  
     Dimensioned drawing ..... 24  
 Description of functions ..... 5  
 Diagnostics ..... 55  
 Dimensioned drawing of AMS 3xxi ..... 15  
 Display ..... 39

**E**

Electrical connection ..... 36, 50  
     Safety notices ..... 36  
 Expanded diagnostics ..... 56  
 Explanation of symbols ..... 4

**F**

Fast commissioning ..... 11

**G**

General causes of errors ..... 57

**H**

Heated reflectors  
     Dimensioned drawing ..... 30  
     Specifications ..... 29

**I**

Installation ..... 17  
 Interface ..... 50  
 Interface errors ..... 57  
 Interface info in display ..... 40  
 Internal hardware error ..... 40

**L**

LSR status display ..... 57





















































**M**

Main menu  
     Device information ..... 43  
     Language selection ..... 43  
     Network information ..... 43  
     Parameter ..... 43  
     Service ..... 43  
 Maintenance ..... 64  
 Measurement range ..... 13  
 Measurement value output ..... 13  
 Menus  
     Language selection menu ..... 47  
     Main menu ..... 43  
     Parameter menu ..... 44  
     Service menu ..... 48  
 Mounting ..... 18  
     with laser beam deflector unit ..... 23  
 Mounting bracket(optional) ..... 20  
 Mounting distances ..... 21

**N**

Name plates ..... 17

<b>O</b>	
operating	11
Operating principle	11
Operating temperature	14
Operation	39, 48
Output of AMS 300i data	53
Overview of reflector types	60
<b>P</b>	
Packaging	17
Parameter enabling	48, 49
Parameter menu	
I/O	46
Maximum position value	45
Other	47
Parameter handling	44
RS 422/RS 232	44
Plausibility error	40
Prefailure message	40
PWR LED	41
<b>Q</b>	
Quality assurance	4
Querying AMS 300i data (request)	52
<b>R</b>	
Received signal	40
Reflective tape	
Dimensioned drawing	28
Specifications	27
Reflector	26
Mounting	32
Pitch	35
Size	31
Type overview	31
Repair	64
RS 232 interface	
Default settings	51
RS 422 interface	
Default settings	51
<b>S</b>	
Sensing distance	59
Servicing	64
Specifications	13
Dimensioned drawing	15
General specifications	13
Reflective tapes	26
Status and measurement data - main menu	43
Status- and warning messages	39
Status display	39
ATT	57
ERR	57
PLB	57
TMP	57
Status display in the display	57
Status displays	41
Status messages	55
Storage	17
Storage temperature	14
Supply voltage	13
Surface reflections	33
Symbols	4
<b>T</b>	
Temperature monitoring	40
Transport	17
Troubleshooting	55
Type overview	16, 59

Level 1	Level 2	Level 3	Level 4	Level 5	Selection/configuration option	Detailed information on
 : selection	 : selection  : back	 : selection  : back	 : selection  : back	 : selection  : back	 : selection  : activate  : back	
Device information						page 41
Network information						page 41
Status- and measurement data						page 41
Parameter	 Parameter handling	 Parameter enabling			ON / OFF	page 42
		 Password	 Activate password		ON / OFF	
 Password entry				Configuration option of a four-digit numerical password		
		 Parameters to default			All parameters are reset to their factory settings	
 RS 422/RS 232	 Selection	 Baud rate			RS 422/RS 232	page 42
		 Data format			19.2 kbit/s / 38.4 kbit/s / 57.6 kbit/s / 115.2 kbit/s	
		 Output cycle			... 8,n,1 / ... 8,e,1 / ... 8,o,1	
		 Position resolution			Value input: 0.01 mm / 0.1 mm / 1 mm / 10 mm / free resolution	
		 Velocity resolution			1 mm/s / 10 mm/s / 100 mm/s	
		 Measurement unit			Metric/Inch	
 Maximum position value	 Count direction	 Offset			Positive/Negative	page 43
		 Preset			Value input:	
		 Error delay			Value input	
		 Position value in the case of error			ON / OFF	
		 Free resolution value			Last valid value / zero	
		 Port configuration			5 ... 50000	
		 I/O 1			Input/Output	
 I/O	 I/O 1	 Port configuration			Input/Output	page 44
		 Switching input	 Function		No function/preset teach/laser ON/OFF	
		 Switching output	 Activation		Low active/High active	
	 I/O 2	 Port configuration			Pos. limit value 1 / pos. limit value 2 / speed / intensity (ATT) / temp. (TMP) / laser (LSR) / plausibility (PLB) / hardware (ERR)	
	 Switching input	 Activation		Low active/High active		
	 Switching output	 Activation		Low active/High active		
 Limit values	 Upper pos. limit 1	 Upper pos. limit 1			ON / OFF	
		 Limit value input			Value input in mm or inch/100	

		⊖	Lower pos. limit 1	⊖	Activation	ON / OFF	
				⊖	Limit value input	Value input in mm or inch/100	
		⊖	Upper pos. limit 2	⊖	Activation	ON / OFF	
				⊖	Limit value input	Value input in mm or inch/100	
		⊖	Lower pos. limit 2	⊖	Activation	ON / OFF	
				⊖	Limit value input	Value input in mm or inch/100	
		⊖	Max. velocity	⊖	Activation	ON / OFF	
				⊖	Max. velocity	Value input in mm/s or inch/100s	
⊖	Other	⊖	Heating control			Standard/extended (10° C ... 15° C/30° C ... 35° C)	page 45
		⊖	Display background			10 minutes/ON	
		⊖	Display contrast			Weak/Medium/Strong	
		⊖	Service RS232	⊖	Baud rate	57.6 kbit/s / 115.2 kbit/s	
				⊖	Format	8,e,1 / 8,n,1	
⊖	Language selection	⊖				Deutsch / English / Español / Français / Italiano	page 45
⊖	Service	⊖	Status messages			Number of readings, reading gates, reading rate / non-reading rate etc.	page 46
		⊖	Diagnostics			Exclusively for service purposes by Leuze electronic	
		⊖	Expanded diagnostics			Exclusively for service purposes by Leuze electronic	