

Model Number

UMC3000-30H-I-5M-FA

Single head system

Features

- Front of converter and housing manufactured entirely from stainless steel
- Hygienic design, easy to clean
- Degree of protection IP68 / IP69K
- Programmable via DTM with PACTWARE

Description

Functional description

The enclosure and converter of this ultrasonic sensor form a hermetically sealed unit. Due to its special design, this sensor is EHEDG compliant, and together with an appropriate end stop (see accessories) are especially suitable for applications where there are increased hygiene requirements, such as in the manufacture and handling of food.

For reliable operation, due to the special design of this sensor, only mounting accessories in the accessories list must be used, even in applications without special hygiene requirements.

Diagrams

Characteristic response curve



General specifications
Sensing range
Unusable area
Standard target plate
Transducer frequency
Response delay
LED green
LED yellow
LED red
Electrical specifications
No-load supply current la
Time delay before availability t _v
Input/Output
Input/output type
Input impedance
Output rated operating current
Pulse length
Pulse interval
Synchronization frequency
Multiplex operation
Input
Input type
Level (evaluation limit 1)
Level (evaluation inflit 2)
Pulse length
Output
Output type
Resolution
Bepeat accuracy
Load impedance
Temperature influence
Ambient conditions
Storage temperature
Mechanical specifications
Connection type
Core cross-section
Degree of protection
Housing
Hodding
Transducer
Mass Footony cottingo
Output
ouput
Supplementary information
Supplementary mormation
Compliance with standards and directives
Standard conformity
Standards
Approvals and certificates
CCC approval

Technical data

UMC3000-30H-I-5M-FA

	200 3000 mm
	240 3000 mm
	0 200 mm
	approx, 100 kHz
	≤ 200 ms
	Operating display
	object in evaluation range
	error
	10 30 V DC
	≤ 50 mA
t _v	≤ 400 ms
	1 synchronization connection, bidirectional
	4 V 0B
nt	< 12 mA
	≥ 200 µs
	≥ 2 ms
	$\leq 20 \text{ Hz}$
	\leq 20/n Hz, n = number of sensors n \leq 10 (factory setting: 5)
	1 program input
	0 1 V
	3 V U _B
	> 12 kΩ
	2 5 s
	1 analog output 4 20 mA Evolution range $[mm]/2000$, however > 0.4 mm
CUINA	$\leq 0.2 \%$ of full-scale value
cuive	≤ 0.1 % of full-scale value
	$\leq 500 \Omega$ at U _B $\geq 14V$
	\leq 300 Ω at U _B < 14V
	\leq 1.5 % of full-scale value
	-25 60 °C (-13 140 °F)
	-40 65 C (-40 165 F)
	cable PUR, 5 m, With FDA approval
	5 x 0.5 mm ²
	IP68 / IP69K
	Stainless steel 1.4404 / AISI 316L
	LED window: VMQ Elastosil LR 3003/Shore 50 A
	31amess Steer 1.4435 / AIST 316L 425 a
	720 y
	evaluation limit A1: 240 mm
	evaluation limit A2: 3000 mm
	output function: rising slope
	Switch settings of the external programming adapter
	"output load": pull-down
	"output logic": noninv
Id	
	EN 60947-5-2:2007
	IEC 60947-5-2:2007
	EN 60947-5-7:2003
	IEU 00947-5-7:2003
	CCC approval / marking not required for products rated
	200 4

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group USA: +1 www.pepperl-fuchs.com fa-info@us.p

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

UMC3000-30H-I-5M-FA

A2

A

A2

Object distance

Additional Information

A1

A2

Rising ramp A1 < A2

Falling ramp A2 < A1

Zero line

A1 = 0 mm

Programming the evaluation limits

Blind area

Dimensions



Electrical Connection



Accessories

UC-PROG1 Programming adapter

V15S-G-0,3M-PUR-WAGO

Male cordset, M12, 5-pin, PUR cable with WAGO terminals

MH-30H-01-FA

Mounting aid, 30 mm acc. to EHEDG

Mounting

Comply with the minimum permissible bending radius of 70 mm, if you install the connecting cable!



For reliable operation, you must use the included sensor mounting aid. This also applies for applications without special hygiene requirements.

Programming

- The sensor can be adapted to specific application requirements by programming. There are two types of programming. Basic functions can be configured using the teach-in process. These include the function for setting the measuring range 1.
- limits and the output function. The teach-in process is connected either with $+U_B$ (1 level) or $-U_B$ (0 level)

2. Connecting a programming adapter (see Accessories) to the serial interface on the sensor provides an extensive range of configurable functions. Refer to the programming adapter description for instructions. A male cordset with WAGO terminals is required to connect the programming adapter (see Accessories)

Note

- The sensor can only be programmed during the first 5 minutes after switching on. This time is extended during the actual programming process. The option of programming the sensor is revoked if no programming activities take place for 5 minutes.
- You have the option of aborting the programming process at any time without adopting the modified sensor settings. Simply discontinue programming. After 10 seconds, the sensor exits programming, switches to normal operating mode and adopts the previous valid settings.

Programming the evaluation limits

Note:

2

A flashing red LED during the programming process indicates unreliable object detection. In this case, adjust the alignment of the object until the yellow LED flashes. Only then are the settings stored in the memory of the sensor.

Teach-in of the evaluation limit (A1)

- Position the target object at the evaluation limit (A1) 1.
- 2. 3.
- Connect the teach-in for 2 sec with +Ug or -Ug Disconnect the teach-in process. The yellow LED begins to flash after 2 secs and the sensor is ready for teach-in^{*}).

fa-info@us.pepperl-fuchs.com

- Connect the teach-in process within 8 secs for > 2 sec with -UB. Disconnect the teach-in process within 8 secs. The green LED flashes three times briefly for confirmation. The evaluation 4 5.
- limit (A1) has now been taught in.

Teach-in of the evaluation limit (A2)

www.pepperl-fuchs.com

1. Position the target object at the evaluation limit (A2)

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Date of issue: 2015-04-30 217779_eng.xml

Release date: 2015-04-30 15:33

- 2
- Connect the teach-in for > 2 sec with $+U_B$ or $-U_B$ Disconnect the teach-in process. The yellow LED begins to flash after 2 secs and the sensor is ready for teach-in^{*}). 3.
- 4 Connect the teach-in process within 8 secs for > 2 sec with +UB.
- Disconnect the teach-in process within 8 secs. The green LED flashes three times briefly for confirmation. The evaluation limit (A2) has now been taught in. 5

¹) If there are no objects within the sensor detection range while the sensor is ready for teach-in, this is indicated by fast flashing of the yellow LED. Teach-in is possible, however. In programming evaluation limit A1, this is set to 0 mm (zero line). In programming evaluation limit A2, this is set to the measurement range upper limit.

Programming the output function

You can choose between "rising ramp" and "falling ramp" for the output function of the sensor. The position of the programmed evaluation limits is critical here. If the evaluation limit A1 is closer to the sensor than A2, the output function is "rising ramp" If the evaluation limit A2 is closer to the sensor than A1, the output function is "falling ramp"

Display LEDs

The sensor features 3 display LEDs to indicate various operating modes

Operating mode	Green LED	Yellow LED	Red LED
Normal operation	Lights	Target within evaluation range	Unstable target
Programming the evaluation limits			
Target detected	Off	Flashes	Off
Unstable target	Off	Off	Flashes
Confirmation of successful programming	Flashes 3x	Off	Off

Synchronisation

The sensor has a synchronisation input for suppressing mutual interefence by third-party ultrasonic signals. If this input is not connected, the sensor works with internally generated clock pulses. It can be synchronised by connecting external rectangular pulses and through corresponding parameterisation via the DTM module for PACTware TM Each falling pulse edge triggers the sending of an individual ultrasonic pulse. If the signal at the synchronisation input carries ≥ 1 s low level, the sensor returns to normal, unsynchronised operating mode. This is also the case when the synchronisation input is disconnected from external signals (see note below).

If there is a high level > 1 s at the synchronisation input, the sensor enters standby mode. This is indicated by the flashing green LED. In this operating mode, the most recent output statuses are retained. For external synchronisation, please observe the software description.

Note:

- If the synchronisation option is not being used, the synchronisation input must be earthed (0 V).
- The synchronisation option is not available during programming, which means that the sensor cannot be programmed during synchronisation.

The following synchronisation methods are possible:

- 1. Multiple sensors (for max. number see Technical data) can be synchronised by simply connecting their synchronisation inputs. In this case, the sensors operate in a selfsynchronised sequence in multiplex mode. Only one sensor transmits at any given time (see note below).
- Multiple sensors (for max. number see Technical data) can be synchronised by simply connecting their synchronisation inputs. As a result of parameterisation via the DTM 2. module for PACTwareTM, one of the sensors operates as a master and the others as slaves (see Interface description). In this case, the sensors operate synchronously, i.e. simultaneously in master/slave mode, whereby the master sensor performs the role of an intelligent external clock pulse generator.
- 3. Multiple sensors can be triggered jointly by an external signal. In this case, the sensors are triggered in parallel and operate synchronously, i.e. simultaneously. All sensors must be parameterised for external control by means of parameterisation via the DTM module for PACTwareTM (see Software description).
- 4. Multiple sensors are triggered with a delay by an external signal. In this case, only one sensor operates with external synchronisation at any given time (see note below). All sensors must be parameterised for external control by means of parameterisation via the DTM module for PACTwareTM (see Software description).
- 5. A high level (+U_B) or a low level (-U_B) at the synchronisation input puts the sensor in standby mode in the case of external parameterisation.

The response time of the sensors increases proportionally to the number of sensors in the synchronisation chain. Multiplexing means that the measurement cycles of the individual sensors run one after the other.

Note:

The synchronisation connection of the sensors delivers an output current at low level and an input impedance at high level. Please note that the synchronising device must have the following drive capability:

Drive current with $+U_B \ge n^*$ high level/input impedance (n = number of sensors to be synchronised)

Drive current with 0 V: \geq n * output current (n = number of sensors to be synchronised)

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs

