

















Technical Information

Analog Transmitter AT1000 AT1

Alarm Transmitter for Mechanical Level Gauges



Application

AT1 analog transmitter is designed to be installed to the LT, and LTC series float level gauge. One of the main functions of the transmitter is to transmit the level gauge's signals into voltage, electric current, and resistance output signals.

Because this model has a variety of output signal types, it has an extensive connection compatibility with various level setting devices.

In addition, the alarm and adjustment contact signals are equipped with up to six points, enabling the operator to direct the valves and pumps with this transmitter alone.

This transmitter enhances the capacity of your level gauge by enabling you to operate the device from remote locations.

AT1 transmitter can be utilized in wide range of industries. The dependability of this device has been tested and proven over the years in a variety of uses.

Application includes: water tanks, sewage plants, oil depots, chemical solvent storage tanks, petroleum refineries, foods, paints, and organic chemicals.

Features and Benefits

- Transmits the tank level by analog signals.
- Select between voltage and electric current for the output signal according to the the purpose.
- Easy maintenance due to simple mechanism



Table of Contents

run	ction and System Design
Ο	perating System
Tec	hnical Data
Ο	utput
A	ccuracy
Po	ower Supply
	ower Consumption
	oad Impedance
	mbient Temperature
	orage Temperature
	leasuring Range
	ysteresis
	, able Entry
	ransmission Line (per one contact)
	larm Contact
	ontact Rating
	egree of Protection
	olor
	reight

Operating Conditions: Wiring	.5
Wire Connection	
1. AC: 4 - 20mA or 10 - 50mA Output	. 5
2. AC: 0 - 1mA, 0 - 20mA, 0 - 10mV or 0 - 1V Output	
3. DC: 4 - 20mA or 10 - 50mA Output	
4. DC: 0 - 10mA, 0 - 20mA, 0 - 10mV or 0 - 1V output	. 5
5. With Alarm Contacts	. 6
External Dimensions	.7
Flame Proof	
Weather Proof	
Cable Entery	
Operating Conditions: Installation	. 8
Installation of Transmitter	. 8
Certificates and Approval	.9
Ex Approval	. 9
Protection Class	. 9
Ordering Information	10
AT1	10
Oocumentation	11
Technical Information	11
Operating Instructions	11

Function and System Design

Operating System

The remote signal is produced by the rotation angle of the brush on the potentiometer, as indicated in the below figure.

The brush rotation corresponds to the tank level. The resistance value is determined and transmitted based on the position of the brush.




Figure 1: Potentiometer

It is possible to apply a direct current to this potentiometer, as indicated in the figure below. The resistance value is converted to direct current or direct voltage and is output.




Figure 2: Voltage and Current of Potentiometer

Technical Data

	Technical Data							
Output	4-20mA, 10-50mA, 0-1mA, 0-20mA, 0-10mV, 0-1V							
Accuracy	Accuracy Analog Output 4 - 20mA, 10 - 50mA Output: Within ±0.5%							
	Accuracy	AII	alog Output	0 - 20m	4 - 20mA, 10 - 50mA Output: Within ±0.5% 0 - 20mA, 0 - 10mV, 0 - 1V Output: Within ±0.7% 0 - 1mA Output: within ±1.5%			
		Ala	rm Contact Output	± 0.5%	± 0.5% (for full span)			
Power Supply	DC24V (DC20~40V valid), AC100V/110V/200V/220V ±10%, 50/60Hz							
Power Consumption	Approximately	5VA						
Load Impedance					1		1	
			Voltage	20VDC	24VDC	40VDC	100VAC 110VAC 200VAC 220VAC	
			4~20mA	200Ω	400Ω	1100Ω	630Ω	
	Current Outp		10~50mA	80Ω	160Ω	440Ω	250Ω	
	(Max. Impedar	nce)	0~1mA	18kΩ	22kΩ	38kΩ	25kΩ	
			0~20mA	900Ω	1100Ω	1900Ω	1330Ω	
	Voltage Outp (Min. Impedar		0~10mV			000Ω		
	(**************************************	,	0~1V		≥ 3			
Storage Temperature	-20 ~ +60 °C		~ +40 °C (Accuracy	coverage : o ····				
Measuring Range	0 - 1.5m, 2.5m, 3m, 3.5m, 4m, 5m, 6m, 8m, 10m, 12m, 14m, 16m, 20m, 25m 30m							
Hysteresis	Within 2% of measuring range							
Cable Entry	Flameproof with cable gland (B): G3/4 TF16-11, G1 TF22-15, G1-1/4 TF28-20 Flameproof (E): G3/4, G1-1/2 Weather proof (W): G3/4, G1-1/2, NPT3/4, NPT1, M25							
Transmission Line (per one contact)	DC: two or three lines AC: four lines							
Alarm Contact	2, 4, 6 points, Micro switch (SPDT) Select any of the following contact: A contact (normal open) B contact (normal close) C contact (transfer)							
Contact Rating	TIIS Ex d rating: 250V 4.2A, 1050VA, 180W Allowable contact rating: Alarm 2 points (A, B, C contact) 220VAC 2.8A, 125VDC 0.5A Alarm 4 points (A, B contact) 220VAC 2.8A, 125VDC 0.5A Alarm 4 points (C contact) 220VAC 2.2A, 125VDC 0.5A Alarm 6 points (A, B, C contact) 220VAC 2.2A, 125VDC 0.5A							
Degree of Protection	Weather proof: Flame proof : d							
Color	Silver							
Weight Weather proof: approximately 7kg Flame proof: approximately 13kg								

Operating Conditions: Wiring

Wire Connection

To ensure the accuracy of the transmitter and receiver, it is important to set the wiring and connection of the circuit to be within the accepted range. Because AT1 transmitter has several output signals, be careful of the impedance that is caused by the circuit resistance as a result of electric output

1. AC: 4 - 20mA or 10 - 50mA Output

(For alarm contact equipped model, refer to 5 also)




Figure 3: AC Power 1

2. AC: 0 - 1mA, 0 - 20mA, 0 - 10mV or 0 - 1V Output

(For alarm contact equipped model, refer to 5 also)




Figure 4: AC Power 2

3. DC: 4 - 20mA or 10 - 50mA Output

(For alarm contact equipped model, refer to 5 also)




Figure 5: DC Power 1

4. DC: 0 - 10mA, 0 - 20mA, 0 - 10mV or 0 - 1V output

(For alarm contact equipped model, refer to 5 also)




Figure 6: DC Power 2

5. With Alarm Contacts

In case of with contacts in 1, 2, 3, 4, the following circuits are provided.

A Contact (Normal Open)




Figure 7: A Contact

B Contact (Normal Close)




Figure 8: B Contact

C Contact (Transfer Contact)




Figure 9: C Contact

External Dimensions

Flame Proof

Alarm Contacts: 0, 2, 4, 6




Figure 10: Flame Proof

Weather Proof

Alarm contacts: 0, 2 In case of Cable Entry G3/4,NPT3/4




Figure 11: Weather Proof 1

Alarm contacts: 0, 2, 4, 6




Figure 12: Weather Proof 2

Cable Entery

070:Cable Entry	A	В
A	Thread G 3/4	
В	Thread G 3/4	Thread G 3/4
С	Thread G 1-1/2	
D	Thread G 1-1/2	Thread G 3/4
Е	Gland G 3/4 TF16-11	
F	Gland G 3/4 TF16-11	Gland G 3/4 TF16-11
G	Gland G1 TF 22-15	
Н	Thread NPT1	
K	Thread M25	
M	Gland G1-1/4 TF28-20	Gland G 3/4 TF16-11
Q	Thread NPT3/4	
R	Thread NPT 3/4	Thread NPT 3/4

Operating Conditions: Installation

Installation of Transmitter




Figure 13: Transmitter and Float Tank Gauge



Caution!

When installing the transmitter with cable grands, ensure to use cable glands which are attached to the transmitter. Select an option for cable glands in the feature 070 of the order structure (refer to "2.2 Ordering Information").

Ex Approval

TIIS, with cable gland
TIIS d2G4

TIIS, (Cable entry)
TIIS d2G4

Protection Class IP65

Ordering Information

AT1

1	_									
010		ıtput:								
	1	4 - 20mA								
	2	10 - 50mA								
	3		0 - 1mA							
	4 5		0 - 20mA							
			0 - 10mVDC							
	6		0 - IVDC							
l	9 Special version, TSP-no. to be spec.									
020		Power T	ype:							
		1 AC								
		2 DC								
030		Alarn	n O11	tput:						
030			Not u	-						
			2 - pc							
			4 – pc							
			6 – pc							
040										
040		1 1	ppro		oof d2C4_TIIS_L cable gland					
		B E			oof d2G4, TIIS + cable gland oof d2G4, TIIS					
		W			proof IP65					
		Y			ersion, TSP-no. to be spec.					
I		-	1							
050				nctio						
			0		c version					
			9	Spec	ial version, TSP-no. to be spec.					
060				Pow	er Supply :					
				1	100VAC, 50/60Hz					
				2	110VAC, 50/60Hz					
				3	200ACV, 50/60Hz					
				5 24VDC						
				Y	Special version, TSP-no. to be spec.					
070					Cable Entry:					
					A 1 x thread G 3/4					
					B 2 x thread G 3/4					
					C 1 x thread G 1-1/2					
					D 1 x thread G 1-1/2, 1x G 3/4					
					E 1 x gland G 3/4, TF16-11					
					F 2 x gland G 3/4, TF16-11					
					G 1 x gland G 1, TF22-15					
					H 1 x thread NPT1					
				1 1	K 1 x thread M25					
					M 1 x gland G 1-1/4, TF28-20,1x gland G 3/4, TF16-11					
					R 2 x thread NPT3/4					
					Y Special version, TSP-no. to be spec.					
I		1 1 1	I	1						
080					Installation gauge:					
					1 LT1100/LT1200/LT3100/LT3200 R:300mm low pressure LT version					
					2 LT1400/LT1600/LT3400/LT3600 R:300mm high pressure LT version					
					3 LTC2100 L:600mm 4 LTC2230/LTC2240 R:600mm					
					9 Special version, TSP-no. to be spec.					
l				1 I						
090					Measuring Range					
					A 1.5m					
					1 2.5m					
					C 3m					
					D 3.5m					
					E 4m					
					2 5m F 6m					
					G 8m 3 10m					
l		1 1 1		1 1	10m					

090	Measuring Range		
	12m		
	14m		
	4 16m		
	20m		
	K 25m		
	6 30m		
	9 Special version, TSP-no. to be spec.		
100	Alarm Contact		
	0 Not used		
	1 A= normal open		
	2 B= normal closed		
	3 C= transfer contact		
110	Color		
	0 Silver		
	9 Special version, TSP-no. to be spec.		
AT1-			

Documentation

Technical Information

TI00458G

Float Gauge LT11/LT12/LT14/LT16

TI1121G

Float Gauge LTC2230/LTC2240

Operating Instructions

BA00414G

Analog Transmitter AT10000 AT1

Endress + Hauser Yamanashi Co., Ltd. 862-1 Mitsukunugi Sakaigawa-cho Fuefuki-shi Yamanashi, 406-0846 Japan

Phone: ++81 55 266 4964 Fax: ++81 55 266 4969 http://www.endress.com

