


Wiring diagram




1. -BAT
2. -BAT
3. CAN L
4. +BAT
5. +BAT
6. CAN H
7. ADDRESS L
8. ADDRESS H
9. CAN L
10. Not connected
11. Not connected
12. CAN H

1. DIN A
2. DIN B
3. DIN C
4. DIN D
5. DIN E
6. DOUT/DIN F
7. -V REF
8. +V REF
9. +BAT
10. VIN A
11. VIN B
12. -BAT



Mating connector kit: 5031 048

Installation IQAN-LL/LM

Publ.no: M5010009/7A
Ed. A






CAN module addressing



For further information see:
HY17-8330/UK Instructions



IQAN-LM



IQAN-LL

