


ID-04 - CONFIGURATION



USB (5V)

This is the basic setup for a single USB ID-04 Imager.




System Matrix

Product	Part Number	Description
(1) ID-04 Imager	ID-04-IM1-X-U	Imager, USB

Stand-Alone (5V)

This is the basic setup for a single ID-04 Imager.



System Matrix

Product	Part Number	Description
(1) ID-04 Imager	D-04-IM1-X-S	Imager, RS-232
(2) Communication Cable	VSID-SD-5/15-S	Sub-D 15 pin, flying leads