
Safety light curtain





Electrical connection

Dimensions

Model Number

SLC30-450-S

Slave module for master slave mode

Features

- ٠ Sensing range up to 15 m
- Resolution 30 mm (hand protection) ٠
- Protection field height up to 1650 mm
- Self-monitoring (type 4 according to • IEC/EN 61496-1)
- Master/Slave detection, Plug and ٠ Play
- Start/Restart disable ٠
- Protection degree IP67 •
- Integrated function display .
- Pre-fault indication •
- Safety outputs OSSD in potential-se-• parated semiconductor design or with monitored, compelled connection NC-contacts
- ٠ Optional with ATEX certificates for zone 2 and 22 and protection degree IP66 (Option 133)


Accessories

PG SLC-450

Protective glass panes for SLC series

BA SLC

laser alignment aid for safety light



cutrtains series SLC

Subject to modifications without notice Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

fa-info@pepperl-fuchs.com

Germany: +49 621 776-4411


Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





1

Technical data	
General specifications	
Effective detection range	0.2 15 m
Light source	IRED
Light type	modulated infrared light
Approvals	TÜV, UL
Tests	IEC/EN 61496
Safety type according to IEC/EN 61496	4
Marking	CE
Width of protected area	0.2 15 m
Protection field height	450 mm
Number of beams	24
Operating mode	in the master
Optical resolution	30 mm
Angle of divergence	< 5 °
Functional safety related parameters	
Safety Integrity Level (SIL)	SIL 3
Performance level (PL)	PL e
Category	Cat. 4
Mission Time (T _M)	20 a
PFH _d	1.35 E-8
Туре	4
Indicators/operating means	
Operating display	in the master
Diagnostics display	in the master
Function display	in the master
Pre-fault indication	in the master
Controls	in the master
Electrical specifications	
Operating voltage U _B	from master
No-load supply current I ₀	from master
Protection class	
Input	
Test input	in the master
Function input	in the master
Output	
Safety output	in the master
Signal output	in the master
Response time	depends on height of protective field
Ambient conditions	
Ambient temperature	0 55 °C (32 131 °F)
Storage temperature	-25 70 °C (-13 158 °F)
Relative humidity	max. 95 %, not condensing
Mechanical specifications Housing length L	560 mm
Protection degree	IP67
Connection	M20 cable gland ,
Connection	terminal compartment with screw terminals, lead cross-section max. 1.5 mm ²
Material	
Housing	extruded aluminum profile, RAL 1021 (yellow) coated
Optical face	Plastic pane
Mass	Per 1650 g
General information	
System components	
Emitter	SLC30-450-T-S
Receiver	SLC30-450-R-S
Compliance with standards and directi-	
ves	
Directive conformity	
Machinery Directive 2006/42/EC	EN ISO 13849-1:2008 EN 61496-1:2004/A1:2008
EMC Directive 2004/108/EC	EN 61000-6-4:2007 + A1:2011
Standard conformity	
Standards	IEC 61496-2:2006 EN 50178:1997
Approvals and certificates	
CE conformity	CE
UL approval	cULus Listed
CCC approval	Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.
TÜV approval	ΤÜV

Curves/Diagrams







Notes

Response times of cascading units

If cascading units are set up, the response time of the entire SLC, consisting of a master and a slave, must be determined. The overall number of beams for master and slave can be determined from technical data sheets. Depending on the type of output, the resulting response time can be read from the table.

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Number of beams	Response time in milliseconds	
	Semiconductor output	Relay output
8	10	30
16	10	30
24	12	32
32	14	34
40	16	36
48	18	38
56	20	40
64	22	42
72	24	44
80	26	46
88	28	48
96	30	50

SLC14-300/31 32 beams Example: Master: Slave: SLC60-90-S+ 24 beams 56 beams

56 beams, OSSD relay --> response time = 40 ms.

Notes

Master slave mode

SLC (semiconductor)
or
SLC/31 (relay)
SLCS

Using slaves makes it possible to lengthen protective fields or to form protective fields that lie in more than just one level. When you select slaves that can be connected, you should take into consideration that the maximum number of 96 light rays must not be exceeded.

There are slaves for transmitters and receivers. These may simply be connected to the master light curtain. As many as 2 slaves may be connected respectively to the transmitter and receiver unit.

Installation:

- 1 The end cap should be screwed off for the light curtain (without cable gland).
- 2 The plug-in jumper on the connectors of the printed circuit board, which is now visible, should be removed.
- 3 The slave is designed so that the cap located on the cable connector can be plugged directly onto the open end of the light curtain with the printed circuit board.
- 4 After you have screwed on the connection cap, the system is complete.

System accessories

- Mounting set SLC
- Test rods SLC14/SLC30/SLC60
- Protective glass pieces for SLC (to protect the optically functional surface)
- Lateral screwed connection SLC
- Profile alignment aid
- Laser alignment aid SLC
- Mirror for SLC (for securing hazardous areas on multiple sides)
- Ground pillar UC SLP/SLC
- Housing for pillar Enclosure UC SLP/SLC
- Collision protector Damping UC SLP/SLC

Germany: +49 621 776-4411

fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

