RTD Converter

Features

- 1-channel
- · Converter for 2-, 3- and 4-wire Pt100, slide wire sensors
- Installation in Zone 2, Zone 22, or safe area
- · Simulation mode for service operations (forcing)
- · Line fault detection (LFD)
- · Permanently self-monitoring
- · Module can be exchanged under voltage

Function

The RTD converter accepts 2-, 3-, 4-wire RTD signals (Pt100) from the hazardous area.

Open and short-circuit line faults are detected.

The input is galvanically isolated from the bus and the power supply.



CE

Assembly



Connection

m٧ 6 5 COM • 4 З 2 1 Zone 2 Refer to "General Notes Relating to Pepperl+Fuchs Product Information"



Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com

Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com 1

Supply	
Connection	backplane bus
Rated voltage Un	12 V DC, only in connection with the power supplies LB9***
Power consumption	0.45 W
Internal bus	
Connection	backplane bus
Interface	manufacturer-specific bus to standard com unit
Input	
Number of channels	1
Suitable sensors	2-, 3- , 4-wire connection, thermocouple , 400 Ω slide-wire sensors
Connection	2-wire connection: 5, 6 3-wire connection: 1, 5, 6 4-wire connection: 1, 2, 5, 6
Lead resistance	\leq 50 Ω per strand
Measurement range	10 400 Ω (500 Ω incl. line resistance)
Measuring current	200 μΑ
Line fault detection	can be switched on/off for each channel via configuration tool
Short-circuit	< 10 Ω
Open-circuit	
Smallest span	20 Ω for 0.1 % accuracy
Linearity error	max. 0.1 %
Conversion time	≤ 20 ms without LFD ≤ 150 ms with LFD
Transfer characteristics	
Deviation	
Influence of ambient temperature	max. 0,1 %/10 K
Indicators/settings	
LED indicator	LED green: supply LED red: line fault
Coding	optional mechanical coding via front socket
Directive conformity	
Electromagnetic compatibility	
Directive 2004/108/EC	EN 61326-1
Conformity	
Electromagnetic compatibility	NE 21
Degree of protection	IEC 60529
Environmental test	EN 60068-2-14
Shock resistance	EN 60068-2-27
Vibration resistance	EN 60068-2-6
Damaging gas	EN 60068-2-42
Relative numidity	EN 60068-2-56
Ambient conditions	
Ambient temperature	-20 60 °C (-4 140 °F)
Storage temperature	-25 85 °C (-13 185 °F)
Shock resistance	$\frac{1}{2}$ shock type L shock duration 11 ms, shock amplitude 50 m/s ² number of shock directions 6, number of shocks
	per direction 100
Vibration resistance	trequency range 5 500 Hz, amplitude 5 13.2 Hz \pm 1.5 mm, 13.2 100 Hz 1g, sweep rate 1 octave/min, duration 10 sweeps 5 Hz - 100 Hz - 5 Hz
Damaging gas	tor plugs: 21 days in 25 ppm SO ₂ , at 25 °C and 75 % rel. humidity, device G3
Mechanical specifications	
Degree of protection	IP20 when mounted on backplane
Connection	removable front connector with screw flange (accessory) wiring connection via spring terminals (0.14 1.5 mm ²) or screw terminals (0.08 1.5 mm ²)
Mass	approx. 90 g
Dimensions	16 x 100 x 103 mm (0.63 x 3.9 x 4 in)
Data for application in connection with Ex-areas	
Statement of conformity	PF 08 CERT 1234 X
Group, category, type of protection	(x) II 3 G Ex nA [ic] IIC T4 Gc
Electrical isolation	
Input/power supply, internal bus	safe electrical isolation acc. to EN 60079-11, voltage peak value 375 V
Directive conformity	
Directive 94/9/EC	EN 60079-0:2009 EN 60079-11:2007 EN 60079-15:2010

Refer to "General Notes Relating to Pepperl+Fuchs Product Information". Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com

Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com



2

International approvals	
IECEx approval	BVS 09.0037X
Approved for	Ex nAc [ic] IIC T4
General information	
System information	The module has to be mounted in appropriate backplanes (LB9***) in Zone 2 or outside hazardous areas. Here, the corresponding declaration of conformity has to be observed. For use in hazardous areas (e.g. Zone 2 or Zone 22) the module must be installed in an appropriate enclosure.
Supplementary information	EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperl- fuchs.com.

