

(\mathbf{F}) CANopen

Model Number

CSS58

Features

- Industrial standard housing Ø58 mm
- **Recessed hollow shaft**
- 16 Bit singleturn
- Galvanically isolated CAN interface
- . 2 limit switches
- 8 programmable cams
- Velocity and acceleration output
- Event triggered process data transfer

Description

Absolute encoders deliver an absolute step value for each angle setting. All these values are represented by code samples on one or more code disks which are sampled by a photoelectric array. The absolute encoder has a maximum basic resolution of 65536 steps per revolution (16 Bits). The encoders integrated CAN bus interface supports all CANopen functions. The following operating modes can be programmed, and can be selectively turned on or off:

- Polled mode
- Cyclic mode
- Sync mode

The absolute encoder is mounted directly onto the application shaft, without any coupling. Rotation of the encoder is prevented by a torque rest. The bus electronics module is integrated into the removable housing cover. This makes it possible to mount or replace the encoder and the bus electronics separately during installation or service.

Technical data

General specifications Detection type Device type Functional safety related parameters MTTFd Mission Time (T_M)

L_{10h} Diagnostic Coverage (DC) Electrical specifications Operating voltage U_B No-load supply current I0

Linearity Output code Code course (counting direction)

Interface

Interface type Resolution Single turn Overall resolution Transfer rate Standard conformity

Connection

Terminal compartment Standard conformity Degree of protection

Climatic testing Emitted interference Noise immunity Shock resistance

Vibration resistance Ambient conditions

Operating temperature

Storage temperature Mechanical specifications Material

Combination 1

Combination 2 (Inox)

Mass

Rotational speed Moment of inertia Starting torque Tightening torque, fastening screws Shaft load Angle offset Axial offset Radial offset

photoelectric sampling Singleturn absolute encoder

80 a 20 a

1.9 E+11 at 6000 rpm and 20/40 N axial/radial shaft load 0%

10 ... 30 V DC max. 230 mA at 10 V DC max. 100 mA at 24 V DC ± 2 LSB at 16 Bit, ± 1 LSB at 13 Bit, ± 0,5 LSB at 12 Bit binary code cw ascending (clockwise rotation, code course ascending) cw descending (clockwise rotation, code course descendina)

CANopen

up to 16 Bit up to 16 Bit max. 1 MBit/s communication profile: DS 301 device profiles: DS 406 and DS 417, programmable according to class 2

in removable housing cover

DIN EN 60529, IP65 IP66 (with shaft seal) DIN EN 60068-2-30 , no moisture condensation EN 61000-6-4:2007 EN 61000-6-2:2005 DIN EN 60068-2-27, 100 g, 6 ms DIN EN 60068-2-6, 20 g, 10 ... 2000 Hz

-40 ... 85 °C (-40 ... 185 °F) -40 ... 85 °C (-40 ... 185 °F)

housing: powder coated aluminum flange: aluminum shaft: stainless steel housing: stainless steel flange: stainless steel shaft: stainless steel approx. 550 g (combination 1) approx. 1100 g (combination 2) max. 12000 min -30 gcm² ≤ 3 Ncm (version without shaft seal) max. 1.8 Nm

± 0.9 ° static: ± 0.3 mm, dynamic: ± 0.1 mm static: ± 0.5 mm, dynamic: ± 0.2 mm

Approvals and certificates

UL approval

cULus Listed, General Purpose, Class 2 Power Source


eng

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com



1

Dimensions




Electrical connection

Terminal	Cable	Explanation
\perp	-	Ground connection for power supply
(+)	Red	Power supply
(-)	Black	Power supply
G	-	CAN ground
L	Blue	CAN low
Н	White	CAN high
G	-	CAN ground
L	Blue	CAN low
Н	White	CAN high

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com






Adjusting the participant address

The participant address can be adjusted with the rotary switches. The address can be defined between 1 and 96, and may only be assigned once. The addresses 97 ... 99 are reserved.

Adjusting the termination resistor

The terminating resistor R_T (121 Ω) can be connected to the circuit by means of the switch:







member X



] (



Baud rate adjustment

Baud rate [kBit/s]	Switch position	Baud rate [kBit/s]	Switch position
20	0	500	5
50	1	800	6
100	2	1000	7
125	3	reserved	8
250	4	set baud rate by SDO message and LSS	9

LED-indicators

CAN Run (green)	State	Description
flickering	AutoBitrate / LSS	Auto-bitrate detection is in progress or LSS services are in progress
blinking	PREOPERATIONAL	Encoder is in state PREOPERATIONAL
single flash	STOPPED	Encoder is in state STOPPED
double flash		reserved
triple flash	Program / Firmware download	a software download is running on the encoder
on	OPERATIONAL	the encoder is in state OPERATIONAL
Err (red)	State	Description
off	no error	the encoder is in working condition
flickering	AutoBitrate / LSS	Auto-bitrate detection is in progress or LSS services are in progress
blinking	invalid configuration	general configuration error
single flash	Warning limit reached	at least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames)
double flash	Error control event	a guard event (NMT-slave or NMT-master) or a heartbeat event (heartbeat consumer) has occured
triple flash	Sync. error	the sync. message has not been received within the configured communication cycle period time out (see objekt 1006h)
quadruple flash	Error, event-timer	an expected PDO has not been received before the even-timer elapsed
on	Bus off	the CAN controller is bus off

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




Programmable CAN operating modes

Mode	Explanation
Polled mode	The connected host requests the current actual position value via a remote transmission request telegram. The abso- lute encoder reads in the current position, calculates all parameters that have been set and sends back the process actual value through the same CAN identifier.
Cyclic mode	The absolute encoder sends the current actual process value cyclically, without being prompted by the host. The cycle time can be programmed in milliseconds for values between 1 ms and 65536 ms.
Sync mode	After the sync telegram has been received by the host, the absolute encoder sends the current actual process value. If multiple nodes should respond to the sync telegram, the individual nodes report one after the other according to their CAN identifier. There is no programming of an offset time. The sync counter can be programmed so that the rotary encoder does not transmit until after a defined number of sync telegrams.

Programmable rotary encoder parameters

Parameter	Explanation
Operating parameter	The direction of rotation (complement) can be specified by parameter as the operating parameter. This para- meter determines the direction of rotation in which the output code will ascend or descend.
Resolution per revolution	The "Resolution" parameter is used to program the rotary encoder so that a desired number of steps can be implemented in reference to one revolution.
Preset value	The preset value is the desired position value that must be achieved for a specific physical setting of the axis. The preset value parameter is used to set the actual position value to the desired actual process value.
2 limit switches	A total of two positions can be programmed. The absolute encoder sets one bit to high state in the 32 Bit actual process value if a value falls outside the range between these two positions.
8 cam switches	Up to 8 position values can be programmed as cams. By reaching these values bits in object 6300h Cam state register are set.

Order code



PEPPERL+FUCHS

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com