SIEMENS



Desigo™ RXC

Room controller, basic module

RXC30.1/ RXC30.5

for chilled ceiling/radiator control and for control of lighting, with LONMARK®-compatible bus communications

The RXC30 controller is used for the control of temperature and lighting in individual rooms.

- PI or PID control (depending on application) for chilled ceilings and radiators
- Switch control of two groups of lights
- · Extension modules available for control of lighting and blinds
- Downloadable application software
- LONMARK®-compatible bus communications
- · For use in the Desigo building automation and control system
- Control of 2 x 2 thermic valve actuators (AC 24 V) or one AC 24 V 3-position valve actuator (only with special applications)
- Volt-free relay contacts for lighting control (12 A)
- Operating voltage AC 230 V

Application

The RXC30 controller is optimized for the control of radiators and chilled ceilings and for on/off control of lighting in individual rooms. The controller can be used in conjunction with extension modules RXC40 and RXC41, allowing additional control of dimmable lights and electric motors for blinds.

For operation, either conventional room units and momentary contact switches, or integrated room units with a bus connection, may be used.

Building Technologies

The controller application is determined by downloadable application software, also referred to simply as the "application". The various applications and the associated functions are described in detail in the Desigo RXC applications library. (V1: CA2A3810, V2: CA110300).

The controllers are delivered with basic application 00030.

The basic application, which contains only I/O module functions, is overwritten with the definitive application in the commissioning phase. The RXT10 commissioning and service tool is used for this purpose (see "Commissioning").

Use as an I/O module

In conjunction with a building automation and control system, the RXC30 controller can also be used as a universal I/O module, e.g. to register digital signals or to control various equipment (ON/OFF or pulse control with AC 24 V or volt-free relay contacts). In this case, the controller is loaded with basic application 00030. The inputs can then be read and the outputs overridden via the building automation and control system.

Functions

The controller functions are determined by the selected application and its parameters. For a detailed description of functions, refer to the Desigo RXC applications library (V1: CA2A3810, V2: CA110300).

When Desigo RXC is integrated into a building automation and control system, additional functions become available, such as time scheduling, central control of setpoints etc. (refer to the Desigo INSIGHT documentation for further information).

Types

Туре	SSN	Description
RXC30.1		Room controller, basic module
RXC30.5	S55373-C114	
RXZ30.1		Accessory: Terminal covers

Ordering

When ordering, please specify the quantity, product name and type code. The controllers are delivered with basic application 00030.

The RXZ30.1 terminal covers are supplied in packs of 1 pair and must be ordered separately.

Example:

30	Room controllers	RXC30.5/00030
30	Pairs of terminal covers	RXZ30.1

The RXC30 can be used in conjunction with extension modules RXC40 for lighting control (data sheet 3842) and RXC41 for the control of blinds (data sheet 3843). For this purpose, the RXC30 controller must be loaded with an application corresponding to the selected combination. Possible combinations and the associated applications are described in the Desigo RXC applications library (V1: CA2A3810, V2: CA110300).

For operation, a room unit from the QAX... series may be used in conjunction with conventional momentary contact switches for lighting control. Alternatively, the flexible room units, QAX50.1 or QAX51.1 may be used.

See the RX hardware overview, CA2N3804, for a summary of the available field devices.

Mechanical design

The RXC30 controller consists of a housing base, a housing cover and the printed circuit board with connection terminals. The controllers also have a connector base for the extension modules, a tool socket, a service LED and a service pin.



Terminal covers

Terminal covers (RXZ30.1) are available as an option, to protect the connection terminals from physical contact and dirt. **The terminal covers must be used on equipment mounted outside the control panel or distributor box.** When fitting the terminal covers, make sure that they snap into position correctly. These covers also provide strain relief for the cables connecting the extension modules. The service LED remains visible when the terminal covers are in place, and the service pin can be operated with a pointed implement.



Removing the terminal cover

Label	Bar code, Code 39	
	(ID number)	3840Z01 02
	Protection standard	
	Temperature range (0 … 50 °C)	SIEMENS RXC30.5/00030 AC 230/2 12/4
	Observe the warning notes in this data sheet	S55373 - C114 50/60Pz T50 IP20 (30) Origin: Switzerland 080112A 33725 ID: 001086169900 Hex Semers Switzerland Ltd
	Test date, series (Z, A, B, C…) Serial No.	AC 230V~ at common at AC 230V~ AC
	Neuron ID	
	Factory-loaded application	
	Definitively loaded	
	application	
	Loodion	
Note	Options f - Hand-	for use of the labeling fields "Appl." and "Loc.": written entry of the location and the actual application or
	– Printe	d adhesive label (printed from the RXI10 commissioning and service tool)
Connection	All conne	ection terminals are detachable plug-in terminals. To avoid incorrect wiring,
terminals	terminals	which can be connected to AC 230 V (supply and relay outputs) are
	physicall	y separate from the other terminals. The terminals are arranged so that in
	normal c	ircumstances, all incoming and outgoing cables can be connected without
	crossing.	
STOP Note!	Cable res terminals	straints must be used for the wires to
	be secur	ed with cable ties (see diagram).
Warning!	Ensure	that the power is off before inserting or removing plug-in terminals
	Connoci	
Communication	The RXC	30 controller communicates with other devices via the following interfaces:
	 LONW the Oth LON PPS2 Interals Tool s RX 	ORKS® bus (terminals CLA and CLB) for communication with: system controller PXR or the NIDES.RX interface (to Desigo) er Desigo RXC devices MARK®-compatible 3 rd party devices (e.g. presence detector) (terminals CP– and CP+): erface to the QAX room units. (In addition to PPS2, the LONWORKS® bus is to looped to the tool socket on the room unit.) ocket (RJ45) on the controller or room unit, for: T10 commissioning and service tool (LONWORKS® bus)
	– RX	T20.1 service terminal (PPS2)
	PE bu	s (plug-in connection):
	– Inte	erface to the RXC40 and RXC41 extension modules.
4/14		

The diagram below shows the wiring of the LONWORKS® bus and PPS2 interface when a QAX... room unit is connected. It also shows the options for connecting the RXT10 commissioning and service tool and the RXT20.1 service terminal.



The controller operates with an AC 230 V mains supply voltage. The controlled devices (valves) are supplied directly from the controller. This means that a separate AC 24 V supply is not necessary for the RXC30 controller and the associated field devices.

RXC40 and RXC41 extension modules	The plug-in c cations and t extension mo applications. See the Desi	connection for the extension modules incorporates both the communi- the power supply. The power supply is limited to a maximum of two nodules. The possible combinations are determined by the available a. sigo RXC applications library (V1: CA2A3810, V2: CA110300).		
Signal inputs	The cables for the AC230 V and mains vo	for signal inputs D1 D4 (SELV / PELV) must be routed separately from V cables and must comply with SELV / PELV requirements. The low voltage voltage must not be routed in the same cable.		
Important	Only volt-fre inputs D3 ar contacts (e.e	nly volt-free pulsed momentary contact switches may be connected to signal puts D3 and D4. Signal inputs D1 and D2 may be used for volt free permanent intacts (e.g. window switches).		
Power supply cables up to AC 250 V	 The dimenant of the dimenant on loc Connection can be lood If serial with rupted if the on the PCI Different p AC 230 V 	The dimensions and fuse protection for the supply cables depend on the total load and on local regulations. Connection terminals for the supply voltage are duplicated, so that the supply cables can be looped on the controller. The cables must be secured with cable restraints. If serial wiring is applied on the terminal block 19 21, the connection will be inter- rupted if the block is removed from the controller (the jumpers 18-19 and 20-21 are on the PCB, not in the block, see terminal diagram on page 9). Different phases may be connected to the terminals18 / 19 (L) and 22 (Q13) AC 230 V conductors must be secured with cable ties.		
AC 250 V volt-free relay outputs	 The volt-free relay outputs may be used to switch filament lamps up to 2.5 kW or fluorescent lamps up to 1.5 kVA. The cable dimensions depend on the connected load and the local installation regulations. Neutral and protective conductors are looped on the controller so that there is no need for external terminals. The circuits must be protected with external fuses (max. 16 A, Q13) as there are no internal fuses. Different phases may be used for the terminals18 / 19 (L) and 22 (Q13) The relays are not suitable for SELV / PELV circuits The cables must be secured with cable restraints. 			
AC 24 V switching outputs	The simultan Example: The maximur sequence. Th time. When using s (see technica	eous load on output Y1 (heating) Y2 (cooling) m load is 5 VA for th his is acceptable bea small loads (< 2VA), al data, Triac outputs	s Y1 and Y2 must not exceed 6 VA. 2 thermic valve actuators, type STP73 2 thermic valve actuators, type STP73 e heating sequence and 5 VA for the cool cause the two sequences never operate a the voltage tolerance may be > + 20% s below)	5 W 5 W ing t the same

Rail mounting

The housing base is designed for snapmounting on DIN rails, type EN50022-35x7.5 (can be released with a screwdriver)



Surface mounting There are four drill holes for screwmounting (see "Dimensions" for drilling template). The housing base is fitted with raised supports. Screws: Max. diameter 3.5 mm

When mounting, note the following:

• The controller should not be freely accessible after mounting

The controller can be mounted in any orientation and fixed as follows:

- Ensure adequate air circulation to dissipate heat generated during operation.
- Easy access is required for service personnel
- Local installation regulations must be observed.

The mounting instructions and a drilling template are printed on the controller packaging.

The controller and extension modules (RXC40 and RXC41) must be mounted on the same DIN rail.



If different types of extension module are used, they must be arranged in the following order: RXC30 \rightarrow RXC40 \rightarrow RXC41

Commissioning

The RXC30.1 controller is commissioned with the RXT10 commissioning and service tool. This is connected to the LONWORKS® bus via a tool socket (on the controller or room unit).

The commissioning procedure for the entire Desigo RXC range is described in detail in the RXT10 user manual, document CM110669.

Mounting with extension modules

Note

Labeling	The labeling fields "Appl." and "Loc." are used to indicate the application actually loaded and the location of the controller, either in writing or by use of printed adhesive labels (see "Label" under "Mechanical design").
Function test	All applications (including basic applications 00030) allow direct interrogation of the inputs and control of the outputs using the RXT10 commissioning and service tool. This makes it possible to test the installation and to operate connected plant provisionally before the complete Desigo RXC system is commissioned.
Note	The LONWORKS® bus plug (terminals 16 and 17) can be removed and reconnected at any time, even while the controller is in operation. Only the original bus plug may be used.
STOP Note!	 In the event of a long-term short circuit (approx. 4 minutes) or overload, the thermal fuse in the transformer may trip. Subsequently, the device must be exchanged. The controller is not protected against accidental connection to AC 230 V on the SELV / PELV side. Mains AC 230 V for the supply and for the relays must be disconnected before plugging and unplugging the terminal blocks (danger of electric shock!)

If serial wiring is applied on the terminal block 19 ... 21, the connection will be interrupted if the block is removed from the controller (the jumpers 18-19 and 20-21 are on the PCB, not in the block, see terminal diagram on page 9).

Technical data

⚠ Power supply	Operating voltage	AC 230 V ± 10 %	
	Rated voltage	AC 230 V	
	Frequency	50/60 Hz	
	Power consumption including extension		
	modules and field devices	Max. 12 VA	
	Internal fuse	Thermal, non-resetting	
Operating data	Control algorithm	PI or PID	
Inputs			
Signal inputs D1, D2	Quantity	2	
(for volt-free contacts)	Contact voltage	RXC30.5: DC 19 V	
(RXC30.1: DC 33 V	
	Contact current	DC 8 mA	
	Contact transfer resistance	Max. 100 Ω	
	Contact insulation resistance	Min. 50 kΩ	
	(not suitable for pulse control)		
Signal inputs D3, D4	Quantity	2	
(for volt-free momentary	Contact voltage	DC 33 V	
contact switches)	Contact current	DC 8 mA	
,	Contact transfer resistance	Max. 100 Ω	
	Contact insulation resistance	Min. 50 kΩ	
Outputs			
AC24 V triac outputs, Y1, Y2	Quantity	2	
	Output voltage	AC 24 V +/-20%	
		(may exceed +20% with loads < 2VA)	
		control of 2 x 2 thermic valve actuators AC 24 V	
		ON/OFF, PDM	
		or one AC 24 V 3-position valve actuator	
		(only if supported by application)	
	Output current	Max. 0.5 A	
	Total nominal load	Max. 6 VA	
	(at both outputs simultaneously)	(e.g. 2 thermic valves, type STA73 per	
	· · · ·	heating and cooling sequence	

⚠ Relay outputs Q14, Q24	Quantity Relay type Contact rating External fuse (Q13) Switching voltage Nominal current, resistive / inductive Filament lamps Fluorescent lamps	2 Single pole 16 A Max. AC 250 V Max. AC 250 V Max. AC 12 (4) A ($\cos \varphi = 0.6$) (VDE approved for 16A) Max. 2.5 kW Max. 1.5 kVA (compensation: max. 60 µE)
	i	
Interfaces	Number of reem units connectable	Mox 1
	Interface type for room unit	PPS2
	for RXT10	LonWorks®
	PPS2 baud rate	4.8 kBit/s
	LONWORKS® baud rate	78 kBit/s
LONWORKS® DUS	Transceiver	On RXC30.1: FTT-10A, on RXC30.5: FT 5000
	Baud rate	78 kBit/s
	Bus topology, bus termination	See installation guide, CA110334
Interface to extension modules	Interface type	Serial PE bus (for power supply and data)
Cable connections	Plug-in terminal blocks Solid conductors Stranded conductors without connector sleeves Stranded conductors with connector sleeves (DIN 46228/1)	Rising cage terminals 1 x 0.2 2.5mm2 or 2 x 0.2 1.0 mm2 1 x 0.2 2.5mm2 or 2 x 0.2 1.5 mm2 1 x 0.25 2.5mm2 or 2 x 0.25 1.0 mm2
	Connecting cable for extension modules	10-core ribbon cable
	Single cable lengths	See also installation guide, CA110334
	Signal inputs D1 D4	Max. 100 m with diameters \geq 0.6 mm
	AC24 V triac outputs , Y1, Y2 Relay outputs Q14, Q24	Max. 100m where $A \ge 1.5 \text{ mm}^2$
	Interface to room unit	Max. 115 m where $A = 0.75 \text{ mm}^2$
		(including tool connecting cable)
	Cable type	2- or 4-core, twisted pair, unscreened
	LONWORKS® bus	See installation guide, CA110334
	Tool connecting cable	Max. 3 m
Housing protection standard	Protection standard to EN 60529	
	With terminal covers, wall-mounted, no DIN rail	IP30
Protection class	Suitable for use in systems with protection class	or
Ambient conditions	Operation	Class 3K5 to IEC 60721-3-3
	l emperature	0 50 °C
	Transport	Class 2K3 to IEC 60721-3-2
	Temperature	– 25 65 °C
	Humidity	< 95 %rh
Standards and directives	Product safety Automatic electronic controls for household and similar use Electromagnetic compatibility Immunity (industrial & residential)	EN 60730-1 EN 60730-1
	Emissions (residential)	EN 60730-1
	CE compliance	0004400750
	Meets requirements of EMC Directive	2004/108/EC 2006/95/EC
	RoHS compliance	2011/65/EU
	UL compliance	UL916
	C-Tick conformity (EMC)	AS/NZS 61000-6-3
Environmental compatibility	The product environmental declaration	ISO 14001 (Environment)
	CA2E3840 contains data on RoHS com-	ISO 9001 (Quality)
	pliance, materials composition, packaging, environmental benefit disposal	
Dimensions	See dimension diagrams	a.c.
Weight	wight excluding packaging	0.59 kg
mongine		0.00 Ny



Signal input for volt-free contacts

- D1 Signal input 1
- GND 2 Signal ground
- D2 3 Signal input
- GND 4 Signal ground

Triac outputs

- Y1 5 AC 24 V, 0.5 A switching output
- G 6 AC 24 V actuator supply
- Y2 7 AC 24 V, 0.5 A switching output
- G 8 AC 24 V actuator supply

Signal input for volt-free momentary contact switches

- D3 9 Signal input
- GND 10 Signal ground
- D4 11 Signal input
- Room unit
- CP-PPS2 ground 12
- CP+ PPS2 data 13
- CLA 14 Data A
- CLB 15 Data B

LONWORKS® bus (plug-in)

- CLB 16 Data B CLA 17 Data A

Power supply

- L 18 Phase conductor AC 230 V L 19
 - Phase conductor AC 230 V

+/- 10%

- 20 Neutral conductor AC 230 V
- Ν 21 Neutral conductor AC 230 V

Relay outputs

Ν

- Q13 22 Common contact for Q14 and Q24
- 23 Neutral conductor, max. AC 250 V Ν
- ΡE 24 Protective earth conductor
- Q14 25 N/O contact max. AC 250 V, 12 A
- Ν 26 Neutral conductor, max. AC 250 V
 - ΡE 27 Protective earth conductor
 - Q24 28 N/O contact max. AC 250 V, 12 A
 - Ν 29 Neutral conductor, max. AC 250 V
 - ΡE 30 Protective earth conductor

Note! то

- Observe the technical data for the relay outputs.
- · Local installation regulations must be observed.

Tool socket

Standard RJ45 tool socket for LONWORKS® devices.



1 LONWORKS®, Data A (CLA)

- 2 LONWORKS®, Data B (CLB)
- 3 Not used
- 4 Not used

5 Not used 6 Not used

- 7 PPS2 (CP+)
- 8 PPS2 (CP-)

Connector for extension modules



G0	Ground	G	AC 24 V
ADDRz	Module address	RDY	Handshake
ATTNz	Handshake	DATA	Data
VCC	DC 5 V	CLK	Clock
DG	Electronics ground	DG	Electronics ground

Connection diagrams

Connection of field devices, room unit, LONWORKS® bus and power supply



Twisted pair

N1

B1

Note

For information on actuators compatible with the RXC30 controller, refer to the relevant application descriptions. See Desigo RXC applications library (V1: CA2A3810, V2: CA110300).

Parallel connection of several thermic actuators

Up to 2 thermic actuators can be connected directly to the room controller. In the case of more than 2 actuators a power amplifier is required.

The same principle applies to outputs Y2 \dots Y4. Note that the simultaneous load on outputs Y1 ... Y4 must not exceed 9.5 VA.

Power consumption at input X1 of the UA1T: 0.5 VA.

Note! STO

Mixed operation: Connecting thermic actuators to the controller as well as to the power amplifier is NOT allowed.

Differing voltage of the internal transformer of the controller and the supply of the power amplifier may cause big differences in the position of the valves.



N1 RXC30

N2 UA1T (see data sheet CA2N3591)

AC 24 V thermic valve actuator Y1

AC 24 V thermic valve actuator (max. 2 STP73 / STP73 actuators per Y1 output on the UA1T) Y1.1

Notes

- The UA1T requires an AC 24 V supply voltage
- The UA1T is not suitable for the connection of 3-position actuators.

3840A05

All dimensions in mm

Without terminal covers





With terminal covers





3840M01

Drilling diagram



Building Technologies

© 2000 - 2014 Siemens Switzerland Ltd.

Subject to change