155 130

180

MA 4.7/MA 4D.7

Connector unit for BPS 37

Œ 6

O SWO

۲

10

क़

8.4

70

90

118.01

25

D

6

Dimensioned drawing



May be used with BPS 37

10 - 30 V

DC

- The integrated failure-safe parameter • memory for the BPS data (EEPROM) permits exchanging the BPS without reconfiguration
- Integrated two-line display with 16 characters each (MA 4D.7 only)
- Additional RS232 service interface (9-pin sub D connector), operating mode switch service/ standard operation
- Terminals for switching inputs and outputs, including supply voltage
- Rotary switch for setting resolution
- Jumper for gray/binary switching



Accessories:

(available separately)

- Bar code positioning system BPS 37
- Cable KB 031-3000 for connecting the connector unit with the BPS 37



Resolution setting

щ

- в Connector for LCD display
- С Gray/binary setting
- D Service/operation switch
- Е Terminal strip

Α

в

A

G

F

Ε

Α

ш

Connection BPS

Service interface

F

G

MA 4.7/MA 4D.7

Tables

Specifications

心

Electrical data Operating voltage U_B Power consumption Switching input Switching output

Housing Dimensions Weight Connection type Environmental data

Ambient temp. (operation/storage) Protection class Valid standards document Air humidity Indicators

Indicators LED green Display

Description

The MA 4.7 or MA 4D.7 is a connector unit for the bar code positioning system BPS 37. It significantly simplifies the electrical installation, commissioning and maintenance of the respective BPS. The figure shows the combination of the connector unit and a BPS 37.

The connector unit permits the storage of the current parameter set in the BPS into a non-volatile EEPROM to protect against power supply disruptions. This has the advantage that the BPS does not have to be reconfigured when it is exchanged. After plug-in, the parameters are loaded automatically into the BPS memory.

The MA 4D.7 D model also has a two-line display with 16 characters each for the display of parameters and operating values.

MA 4.7

IP 54 IEC 801

switch 1

10 ... 30VDC 0.2 VA

diecast aluminium

0.665 kg cable with connector

12 ... 30VDC I_{max} = 100mA output voltage = operating voltage

130 x 90 x 33mm (H x W x D)

-10°C ... +50°C/-20°C ... +60°C

max. 90% rel. humidity, non-condensing

LCD display – two lines with 16 characters each

MA 4D.7

[′]0.672 kg

Remarks

The BPS must not be plugged in when the power is on.

Order guide

	Туре
Connector unit for BPS 37 without display	MA 4.7
Connector unit for BPS 37 with display	MA 4D.7
Connector cable between the BPS 37 and MA 4.7/MA 4D.7	KB 031-3000

Order code 500 37324 500 37325 500 35355

MA 4.7/MA 4D.7

Operating elements

Rotary switch: setting the resolution

Position	Resolution	Vmax in m/s	Output level	V check	
0 1	0.01 mm	Deactivated	Software standard, high = no measurement value Software standard, high = no measurement value	Deactivated	
2	0.1 mm	Deactivated	Software standard, high = no measurement value	Deactivated	
3	1mm	Deactivated	Software standard, high = no measurement value	Deactivated	
4	10mm	Deactivated	Software standard, high = no measurement value	Deactivated	
5	100mm	Deactivated	Software standard, high = no measurement value	Deactivated	
0	Software	Deactivated	Soliware standard, nigh = no measurement value Below Vmax - bigh, no values - low, above Vmax - low	Active	
8	Software	2	Below Vmax = high, no values = low, above Vmax = low	Active	
9	Software	3	Below Vmax = high, no values = low, above Vmax = low	Active	
Α	Software	4	Below Vmax = high, no values = low, above Vmax = low	Active	
Function		If the set speed limit is exceeded, the switching output is deactivated. If the BPS cannot measure the speed (i.e. no measurement values can be recorded), the switching output is deactivated.			
		The output is fail safe	, i.e. the unit functions correctly as long as the switching output is	high.	
Adjusting parameters		All parameters which are not affected by the switch position can be changed. For example, in switch position 7, 8, 9 or A the resolution can be changed using the "BPS Config" program or the switching output can be inverted.			
Jumper		Gray/binary switching	I		
-					
Interface mo	ode				
DIP switch		SERV: service interface active/ host interface deactivated BETR: Host interface active			
Service con	nector				
Sub-D connector, 9 pin		RS 232 interface for service/setup operation Default data format: 9600 Baud, 8 data bits, 1 stop bit, no parity (adjustable) 2=RxD, 3=TxD, 5=GND			
Connector for PCB connect	or BPS 37 or	connection	n for the BPS 37		
SSI interface	9				
Terminals 1/2		SSI Data +			
Ierminals 3/4		SSI Data -			
Terminal 7		SSI Clock -			
Switched in	put	054			
Terminal 9 Terminal 11		SE1 - switching input 1, 12 30 V DC VDD, SE - supply voltage switching input, equal to V, IN device			
Terminal 12		GND_SE - supply voltage switching input, equal to GND_IN device 12 30VDC switching input asymmetric to GND			
Switching o	utput				
Terminal 14 Terminal 16		SA1 - swit	ching output 1 – external supply voltage switching output 0VDC		
		Load must be connected asymmetrically to GND.			
		The switch VDD_SA = GND_SA =	<pre>ning voltage for the output is generated by the operating voltage \ = VDD_IN = GND_IN</pre>	/_IN:	
Operating ve	oltage	_			
	Connection terminals for the operating voltage of the MA 4.7 (10 30 V used.		n terminals for the operating voltage of the MA 4.7 (10 30 VDC	c) and for the BPS	
		Dual designents.	in of the voltage supply connections for insertion or for the supply	of further compo-	
Torminala 17	10	Attention	PE must be connected for interference rejection!		
Terminals 19-20		V_IN OPER	perating voltage 0VDC		
Terminals 21-	-22	PE protect	tive earth, grounding		

MA 4.7/MA 4D.7

Circuitry of the connector unit



Indicators

心

A LED labelled "SWO" is located on top of the connector unit. It indicates the state of the switching output 1. In addition, the MA 4D.7 features the 2 x 16-character LCD display.



In the standard setting, the LED indicates that no positioning data can be identified. Please refer to the Technical Description BPS 37 for further states of the switching output.

Operating the MA 4D.7 LCD display

If the LCD display is configured and ready for operation, the required information such as position is shown automatically.

In the standard setting, the indicated value is displayed intermittently.

Notice:

If the CCD output interval is reduced using the "BPS Config" program, the output rate at the SSI interface is also reduced.