# Thru-beam sensor



**Model Number** 

## M7/MV7/59/76a/82b/103/115

Thru-beam sensor

## with 2 m fixed cable

#### **Features**

- Reliable sensor for standard applicati-٠ ons
- Miniature design with versatile moun-٠ ting options
- Automatic adjustment of sensitivity • via TEACH-IN
- Resistant against noise: reliable operation under all conditions
- Certified by ECOLAB ٠

## **Product information**

Small, robust, effective, and reliable - these are the properties of the ML7 sensor series. Due to their small size, number of versions, and two different lens positions, they are particularly suited for installation in tight spaces. The robust design and high quality of Pepperl+Fuchs mean they can also be used under harsh environmental conditions. The efficient technology, switching frequencies up to 1000 Hz, high resistance to ambient light, and 4-in-1 output make the series suitable for non-contact object detection.





#### **Electrical connection**

Dimensions





## Indicators/operating means



Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



M7/MV	7/59/	76a/8	32b/1	03/1	15

Technical data			Accessories	
System components			Montagekit OMH-MI 7-01	
Emitter		M7/76a/115	Mounting set consisting of bracket OMH-	
Receiver		MV7/59/82b/103/115	MI -01 sheet OMH-MI 7-03 and faste-	
General specifications			ning material	
Effective detection range		0 3.5 m		
Threshold detection range		4.5 m	Montagekit OMH-ML7-02	
Light source		LED	Mounting set consisting of bracket OMH-	
Light type		modulated visible red light	ML-02 sheet OMH-ML7-03, and faste-	
Target size		min. 7 mm	ning material	
Diameter of the light spot		approx. 180 mm at a distance of 3.5 m		
Angle of divergence		approx. 3 °	OMH-ML7-01	
Ambient light limit		40000 Lux	Mounting bracket	
Functional safety related para	meters			
MTTF <sub>d</sub>		1130 a	OMH-ML7-02	
Mission Time (T <sub>M</sub> )		20 a	Mounting bracket	
Diagnostic Coverage (DC)		60 %		
Indicators/operating means			Eiving plate	
Operating display		Receiver: LED green, flashes in case of short-circuit Emitter: LED green	Other suitable accessories can be found at	
Function display		Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control	www.pepperl-fuchs.com	
Controls		Receiver: TEACH-IN key		
Electrical specifications				
Operating voltage	UB	10 30 V DC , class 2		
Ripple		max. 10 %		
No-load supply current	Ι <sub>Ο</sub>	Emitter: ≤ 17 mA Receiver: ≤ 15 mA		
Input				
Test input		emitter deactivation at +U <sub>B</sub>		
Output				
Pre-fault indication output		1 PNP, inactive when level falls below function reserve after approx. 5 s. Immediately inactive if the beam is interrupted 4 times during the flashtime.		
Switching type		dark on		
Signal output		1 PNP output, short-circuit protected, reverse polarity protected, open collector		
Switching voltage		max. 30 V DC		
Switching current		max. 100 mA		
Voltage drop	U <sub>d</sub>	≤ 1.5 V DC		
Switching frequency	f	1000 Hz		
Response time		0.5 ms		
Ambient conditions				
Ambient temperature		-20 60 °C (-4 140 °F)		
Storage temperature		-40 75 °C (-40 167 °F)		
Mechanical specifications				
Protection degree		IP67 / IP69K		
Connection		2 m fixed cable		
Material				
Housing		PC (glass-fiber-reinforced Makrolon)		
Optical face		РММА		
Mass		approx. 100 g (emitter and receiver)		
Compliance with standards an ves	d directi			
Standard conformity				
Product standard		EN 60947-5-2:2007 IEC 60947-5-2:2007		
Standards		EN 50178, UL 508		
Approvais and certificates				
Protection class		<li>ii, rated voltage ≤ 250 V AC with pollution degree 1-2 accor- ding to IEC 60664-1</li>		
UL approval		CULus		
CCC approval		CCC approval / marking not required for products rated $\leq$ 36 V		

Date of issue: 2013-05-13 127433\_eng.xml Release date: 2013-04-18 13:47

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

Germany: +49 621 776 4411

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

### **Curves/Diagrams**





# **Teach-In**

Connect the sensors to operating voltage, the green LEDs green lights up constantly.

- The receiver operates at max. sensitivity (delivery status) or with the last teached values.
- · Mount transmitter and receiver opposite each other and align roughly.
- Adjust the transmitter to the receiver.
- Press the Teach-In button on the receiver as an acknowledgement the green LED will quickly turn off one time.
- Press the Teach-In button on the receiver until both LEDs green and yellow are blinking in parallel (2 Hz). Release the Teach-In button now. • While the green and yellow LEDs are blinking alternating (2 Hz) on the receiver the unit is in the internal set up procedure.
- Teach-In successful: Both LEDs green and yellow on the receiver are on. The unit is ready to use and in switching mode now.
- Teach-In not successful: Both LEDs on the receiver are flashing alternating (4 Hz) for approx. 5 seconds. Afterwards the sensor returns to max. sensitivity setting. Please retry the Teach-In procedure beginning by step 1.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

