# 







# **Electrical connection**

Dimensions

## Model number

## VBA-4E4A-KE5-ZEJQ/R

Cabinet module 4 inputs and 4 relay outputs

### Features

- Housing with push-in connection ٠ technology and mechanically coded terminal blocks
- Housing width 19 mm, installation in • the switch cabinet on DIN mounting rail
- Selectable supply to the sensors: Ex-• ternal or from the module
- Function display for bus, internal sen-• sor supply, inputs, and outputs

AS-Interface EXT D 4 inputs IN1 . IN4 8888 0000 AS-Interface 1 15 EXT 10 -O-11 1003 2 12 \* 13 MO 4 14 3 for 3-wire sensors 1001 1001 1-6 1-5 ADDR 1-7 8 1-Switch position "EXT" l+ 9 10 l+ "INT" ഹത്ര PWR l+ 11 卪 12 l+ 14 13 1005 O13 15 16 014 FAULT 4 outputs O1 ... O4 O23 17 1003 18 O24 O33 19 ðŌĠ 20 O34 O43 21 1007 22 044 013 ... 043 23 24 ASI+ 25 26 ASI+ ASI- 27 28 ASI-014 ... 044

## Indicating / Operating means





www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



# AS-Interface sensor/actuator module

The AS-Interface connecting module VBA-4E4A-KE5-ZEJQ/R is a switch cabinet module with 4 inputs and 4 relay outputs. The housing is only 19 mm wide and takes up little space in the switch cabinet. The module is mounted by snapping onto the 35 mm DIN

The connection is made via removable 4-pin push-in terminal blocks. For AS-i+ and AS-i-, two connections are available in each case; these connections are bridged in the terminal block. If the terminal block is disconnected from the module, the link between these con-

rail in compliance with EN 50022.

Function

Technical data		
General specifications		
Slave type	A/B slave	
AS-Interface specification	V3.0	
Required master specification	≥ V3.0	
Indicators/operating means		
	Fault display; Red LED red: Communication fault or address i red, flashing: Overload, internal input	s 0 supply
LED PWR	AS-Interface voltage; green LED green: voltage OK	
	switching state (input): 4 LED vellow	
LED OUT	Switching state (output); 4 LED yellow	
Electrical specifications		
Auxiliary voltage (input) UEXT	12 30 V DC PELV	
Rated operating voltage Ue	26.5 31.6 V from AS-Interface	
Rated operating current I <sub>e</sub>	$\leq$ 35 mA (without sensors) / max. 230	mA
Surge protection	overvoltage category II	
Input		
Number/Type	4 inputs for 3-wire sensors (PNP), DC	
Supply	trom AS-Interface (switch position INT U <sub>EXT</sub> (switch position EXT)	, basic setting) or external
Voltage	21 31 V DC (INT)	protected (INIT)
	< 5.6 mA (max )	
Switching point	according to DIN EN 61131-2 (type 1)	
0 (unattenuated)	≤ 0.5 mA	
1 (attenuated)	≥2 mA	
Signal delay	< 1 ms (input/AS-Interface)	
Output		
Number/Type	4 relay outputs, normally open	
Supply	none	
Nominal load		
Per contact	2 A/30 VDC; 2 A/250 VAC	
Control circuit	< 17 mA per relay (from AS-Interface)	
Switching delay	< 10 ms (AS-Interface/contact)	
Usage category	DC-13 and AC-14	
Switching		
Mechanical	5 x 10 <sup>7</sup>	
Electrical	$2 \times 10^{3}$ (250 VAC, 2 A, $\cos \phi = 0.4$ )	
	aste inclution. Detection valters	050 \/off
Input/AS-Interface	Switch position INT: None Switch sett rated insulation voltage 92 Veff	ing EXT: safe isolation,
Output/Output	Basic insulation, rated insulation volta	ge 250 V <sub>eff</sub> , in phase
Output/AS-Interface	safe isolation, Rated insulation voltage	e 252 Veff
Programming instructions		
Profile	S-7.A.7	
ID code	Λ	
ID1 code	7	
ID2 code	7	
Data bits (function via AS-Interface)	input	output
D0	IN1	01
D1	IN2	O2
D2	IN3	03
D3 Decementer hite (averagementels via AC i)	IN4	O4
P0	function         Communication monitoring         P0 = 0 monitoring = off, the outputs maintain the status if communication fails         P0 = 1 monitoring = on, i.e. if communication fails, the outputs are deenergised (basic setting)	
P1	Input filter P1 = 0 input filter on, pulse suppressio P1 = 1 input filter off (basic setting)	$on \le 2 ms$
P2	Synchronous mode P2 = 0 synchronous mode on P2 = 1 synchronous mode off (basic setting)	
P3	notusea	
Ambient temperature	-25 60 °C (-13 140 °E)	
Storage temperature	-25 85 °C (-13 185 °F)	
Relative humidity	90 %, noncondensing	

#### nections is retained. The terminal blocks for the inputs and outputs are mechanically coded. The supply to the inputs and the connected sensors can be fed either from the internal supply of the module from the AS-Interface or via an external U<sub>EXT</sub> voltage source. A switch located on the side of the module changes the source. The internal input supply is displayed via the INT LED. The relevant IN and OUT LEDs display the current switching status of the inputs and outputs. Notes: The device is equipped with a communication monitor, which deactivates the outputs if the AS-Interface does not communicate with the module for more than 40 ms. The communication monitor can be deactivated via the parameter P0. Filters that suppress pulses

with a duration of 2 ms or less at the inputs can be connected via the parameter P1. Parameter P2 activates the AS-Interface synchronous mode.

#### Installation, Commissioning, and Maintenance

Install the device in a closed electrical plant where only electricians or persons with appropriate electrical training have access.

The relevant laws, guidelines, and standards that apply for the application or intended use must be observed.

The device must be installed in a switch cabinet or switch box that meets protection class IP54 as a minimum.

#### **Requirements for AS-Interface power** supply

PELV according to IEC 60204-1. Safely separated according to EN 50178 / IEC 62103. The AS-Interface power supply voltage must not exceed 36 V in case of error.

#### **Daisy-Chaining Devices**

Insulation to the outer surfaces of the housing: Basic insulation in accordance with EN 60947-1. To provide reliable and double insulation, devices in the direct vicinity must have basic insulation as a minimum.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

2

www.pepperl-fuchs.com

Germany: +49 621 776 4411 USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs



# AS-Interface sensor/actuator module

# VBA-4E4A-KE5-ZEJQ/R

Altitude	≤ 2000 m
Shock and impact resistance	15 g, 11 ms in 6 spatial directions, 3 shocks 10 g, 16 ms in 6 spatial directions, 1000 shocks
Vibration resistance	0.35 mm 10 57 Hz , 5 g 57 150 Hz, 20 cycles
Pollution Degree	2
Mechanical specifications	
Degree of protection	IP20 Installation in an enclosure with a minimum protection class of IP54 required
Connection	Removable push-in terminals rated connection capacity: rigid: 0.20 mm <sup>2</sup> – 1.5 mm <sup>2</sup> flexible (without wire end ferrule): 0.20 mm <sup>2</sup> 2.5 mm <sup>2</sup> flexible (with wire end ferrule): 0.25 mm <sup>2</sup> 1.5 mm <sup>2</sup>
Material	
Housing	PA 66-FR
Mass	125 g
Mounting	DIN mounting rail
Compliance with standards and directi ves	-
Directive conformity	
Directive conformity Low Voltage Directive 2006/95/EC	EN 60664-1:2007
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity Noise immunity	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013 EN 61000-6-2:2005, EN 61326-1:2006, EN 62026:2013
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013 EN 61000-6-2:2005, EN 61326-1:2006, EN 62026:2013 EN 61000-6-4:2007
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013 EN 61000-6-2:2005, EN 61326-1:2006, EN 62026:2013 EN 61000-6-4:2007 EN 61131-2:2004
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input Electrical isolation	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013 EN 61000-6-2:2005, EN 61326-1:2006, EN 62026:2013 EN 61000-6-4:2007 EN 61131-2:2004 EN 60664-1:2007
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input Electrical isolation Degree of protection	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013 EN 61000-6-2:2005, EN 61326-1:2006, EN 62026:2013 EN 61000-6-4:2007 EN 61131-2:2004 EN 60664-1:2007 EN 60529:2000
Directive conformity Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input Electrical isolation Degree of protection Fieldbus standard	EN 60664-1:2007 EN 61000-6-2:2005, EN 61000-6-4:2007, EN 62026:2013 EN 61000-6-2:2005, EN 61326-1:2006, EN 62026:2013 EN 61000-6-4:2007 EN 61131-2:2004 EN 60664-1:2007 EN 60529:2000 EN 62026:2013

Do not connect inputs and outputs, which are supplied via the module from AS-interface or via auxiliary power, with power supply and signal circuits with external potentials.

# Accessories

VBP-HH1-V3.0-KIT AS-Interface Handheld with accessory

VBP-HH1-V3.0 AS-Interface Handheld

## VAZ-PK-1,5M-V1-G

Adapter cable module/hand-held programming device

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

www.pepperl-fuchs.com fa-info@us.peppe

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

