Monitoring Technique

VARIMETER Frequency Relay BA 9837, AA 9838





- According IEC/EN 60255-1
- Detection of under- or overfrequency
- Adjustable response value
- Optionally 1 or 2 changeover contacts
- Width 45 mm

Approvals and Markings



Application

The frequency relay can be used especially in applications where the rotor frequency of a slip-ring motor must be measured. The rotor frequency is reciprocal proportional to the speed (see diagram rotor frequency at contercurrent braking).

This behaviour allows to find speed depending switching values and can be used for start up and contercurrent braking of motors on cranes.

Function

The device compares 2 frequencies. The measuring frequency is compared to an internally generated, settable frequency reference.

With bridge on X1-X2 the output relay deenergises when the measuring frequency is higher then the setted frequency. The relay energises again when the measuring frequency drops under the setted frequency x hysteresis.


With bridge on X2-X3 the output relay energises when the measuring frequency is higher then the setted frequency. The relay deenergises again when the measuring frequency drops under the setted frequency x hysteresis.

An indicating LED shows that the frequency signal is connected. At low frequency the LED flashes. A second LED indicates the state of the output relay.


Notes


Terminals X1, X2, X3 should only be connected together with the corresponding wire links. Do not connect external voltage, neutral or ground. The measuring input is designed for an amplitude of AC 8...500 V. Higher values AC 12...800 V can be achieved by connecting a series resistor, type IK 5110 into the measuring circuit either to terminal n or o.

Function Diagram



Circuit Diagrams





BA 9837.11,

AA 9837.11, AA 9838.11

BA 9837.12, AA 9837.12

Connection Terminals

Terminal designation	Signal designation
A1	+ / L
A2	- / N
n, o	Measuring input
X1, X3	Control input
X2	Control output
11, 12, 14, 21, 22, 24	Changeover contacts

Technical Data

Input

Measuring input: AC Amplitude AC 8 ... 500 V r.m.s internal resistance: > 400 k Ω

Setting range:

BA 9837, AA 9837: 5 ... 15 Hz 40 ... 120 Hz 10 ... 30 Hz 100 ... 300 Hz

20 ... 60 Hz 200 ... 600 Hz 30 ... 90 Hz

AA 9838: 20 ... 80 Hz

infinite on absolute scale Settina:

Response value: ≥ setting value

Hysteresis:

BA 9837, AA 9837: 0.8 ... 0.97 of response value

AA 9838: 0.96 of response value

Accuracy: < +1% Temperature influence: < ± 0.15 % /°C

Influence of auxiliary

supply: $< \pm 0.5$ % at 0.8 ... 1.1 U_{N}

Auxiliary Circuit

Auxiliary voltage U_H: BA 9837, AA 9837:

AC 24, 42, 110, 127, 230, 240 V

50 / 60 Hz ± 5 %

1 changeover contact

AA 9838: AC 48, 110, 230 V Voltage range of U_H: 0.8 ... 1.1 U_H Nominal consumption U.: < 3 VA

Output

Contacts

BA 9837.11, AA 9837.11,

Nominal frequency of U.:

AA 9838.11:

BA 9837.12, AA 9837.12:

2 chanceover contacts Switching delay:

bridge X1-X2 bridge X2-X3 setting range (Hz) 500 - 800 650 - 1 000 5 - 15 10 - 30 250 - 300 600 - 800 20 - 60 300 - 430 120 - 150 20 - 80 100 - 120 290 - 430 30 - 90 90 - 120 280 - 400 40 - 120 60 - 80 140 - 210 100 - 300 70 - 120 25 - 45 70 - 100 200 - 600 15 - 25 switching delay in ms

Technical Data

Thermal current I_{th}: 6 A

Switching capacity IEC/EN 60 947-5-1

to AC 15, AC 230 V: 3 A / AC 230 V

Electrical life IEC/EN 60 947-5-1 to AC 15, at 3 A, AC 230 V: 2.5 x 105 switching cycles

Short circuit strength IEC/EN 60 947-5-1 max. fuse rating: 4 A gL

> 30 x 106 switching cycles Mechanical life:

General Data

Operating mode: Continuous operation Temperature range:

Operation: - 20 ... + 60°C Storage: - 20 ... + 70°C < 2.000 m Altitude:

Clearance and creepage

distances

rated impulse voltage / pollution degree: 4 kV / 2 IEC 60 664-1

EMC

Electrostatic discharge: 8 kV (air) IEC/EN 61 000-4-2

HF-irradiation

80 MHz ... 2,7 GHz: 10 V / m IEC/EN 61 000-4-3 Fast transients: IEC/EN 61 000-4-4 2 kV

Surge voltages

between

wires for power supply: 2 kV IEC/EN 61 000-4-5 between wire and ground: IEC/EN 61 000-4-5 4 kV Interference suppression: Limit value class B EN 55 011

Degree of protection

Housing: IP 40 IEC/EN 60 529 IP 20 Terminals: IFC/FN 60 529

Thermoplastic with V0 behaviour Housing:

according to UL subject 94

Vibration resistance: Amplitude 0.35 mm,

frequency 10 ... 55 Hz, IEC/EN 60 068-2-6 Climate resistance: 20 / 060 / 04 IEC/EN 60 068-1

Terminal designation: EN 50 005

2 x 2.5 mm² solid or Wire connection:

2 x 1.5 mm² stranded wire with sleeve

DIN 46 228-1/-2/-3/-4

Flat terminals with self-lifting

Wire fixing: clamping piece IEC/EN 60 999-1

35 x 50 mm and

35 x 60 mm 0.8 Nm

Mounting: DIN rail IEC/EN 60 715

Weight: 250 g

Dimensions

Width x height x depth: 45 x 77 x 127 mm

Standard Type

Screw mounting:

Fixing torque:

BA 9837.11 30 / 90 Hz AC 230 V AC 50 / 60 HZ

Article number: 0050216

1 changeover contact Output:

Measuring frequency: 30 / 90 Hz Auxiliary voltage U_H: 230 V Width: 45 mm

2 27.07.16 en / 752


Variants

Frequency relay with 2 changeover contacts and internal bridges

(X1, X2, X3)

BA 9837.12/010: with internal bridge X1 - X2 with internal bridge X2 - X3 BA 9837.12/020: AA 9837.12/010: with internal bridge X1 - X2 AA 9837.12/020: with internal bridge X2 - X3

Ordering example for variants




Accessories

IK 5110:

Series resist or for higher measuring voltage AC 12 ... 800 V eff. Article number: 0015751

Characteristics



Measuring sensitivity

The diagram shows the sensitivity of the input of the frequency relay AA 9837. If the measuring voltage is lower then the curve values the frequency cannot be measured anymore. Please note.

Superimposed interference voltages on the measuring input with a ration.

above the curve values can influence the measuring results.


- frequency on input

- highest value of the actual frequency range

Example:

$$U_{meB}$$
: 10 V; measuring frequency: f = 4 800 Hz chosen frequency range: 100 - 300 Hz, $f_{max} = 300$ Hz $\frac{f}{f_{max}} = \frac{4\ 800\ Hz}{300\ Hz} = 16$

The meauring frequency is detected, as the measuring voltage is above the response curve.



t₁ nominal speed reached


t ½ start braking t 3 standstill (end of braking to avoid reverse start)

Rotor frequency at countercurrent braking

When reversing the phases for braking the rotor frequency changes and drops proportional to the speed to mains frequency. E.g. when the rotor frequency is 5 Hz at nominal speed, it to 95 Hz. When the motor is at stand still the rotor frequency is nominal frequency. At this point the frequency relay has to give the signal to stop braking, before the motor starts up in the opposite direction.

3 27.07.16 en / 752

Connection Example



Motor control with starting resistance

Start:

To achieve an optimum speed depending starting inertia, different starting resistors are switched into the rotor circuit, when certain speed values are reached. Often this procedure is controlled with timers, but with small loads the motor reaches the speed to switch over much faster then with high loads and the motor still runs on the lower stage. When the switching of the resistors is controlled speed depending by frequency relays, the start up cycles can be shortened and the plant can be used more effective.