# SIEMENS



DESIGO™ PX

# **Operator unit**

# **PXM20**

Networkable operator unit for viewing and operating one or several DESIGO PX automation stations.

- High-grade display with adjustable contrast
- Simple key operation with direct access to the required plant information
- Generic operation and display of plant functions (alarm handling, time schedulers, calendars, setpoint adjustments, display of current values, etc.)
- Integrated acoustic and/or visual collective alarm
- Graphic online-trend function
- Support of integrated access protection in the overall DESIGO system
- Ability to add or delete new users
- Automatic logout
- Heating curve graphics
- System date and time setting
- Wiring test for IOs
- Context-sensitive help function
- Installation in modular automation station PXC..-U or remote

The PXM20 operator unit ensures the convenient display and operation of DESIGO PX automation stations via BACnet network communication. The graphics-based display with clear text and direct access via the keyboard ensure a most user-friendly operation.

## Functions

All values visible in the system can be displayed in accordance with the defined operator profile. Typical displays: · Display of current values Setpoint and parameter settings Maintenance and error messages Alarm lists and single alarm messages with acknowledgement option and/or reset • Time schedulers (7-day schedules and exception programs) Plant switching · Login and password inputs An integrated collective alarm message system with acoustic and visual indication is provided. **Operating concept** As the PXM20 operator unit is designed for end-user operation the operating concept concentrates on the simplest and clearest possible display following intuitive operating principles rather then displaying as many values as possible. • Any text is displayed as clear text in the chosen language. To ensure a clear orientation for any operator the two top display lines (header lines) always show which building services system or which function is currently in operation. The basic concept of the operation ensures that it is always possible to select direct, with the click of a button on the keyboard, the plant information shown on the relevant line (direct access keys). • Any settings or modifications (for example in graphics) can be followed direct on the display (e.g. graphics display for scheduler). The basic concept also ensures that all information and help functions can be called up any time (info key). User's guide The PXM20 functionality is described in detail in the following document: DESIGO V2.35, Operator unit PXM20 / PXM20-E, User's guide, CM110754en. 1 2 Indicators and operator controls 00262 3 ÷Δ÷ Δ 6  $\bigcirc$ ΘĐΘ SIEMENS

2/8

7

5

6

	<ol> <li>Display</li> <li>Navigation keys (<i>direct access</i> keys and <i>PageUp/PageDown</i> keys): The <i>direct access</i> keys allow direct access to the relevant line. Possible functions:         <ul> <li>Select value and start the value adjustment</li> <li>Confirm new value</li> <li>Start function</li> <li>Open object</li> </ul> </li> </ol>	
	<ul> <li>The PageUp and PageDown keys are provided for page scrolling if a page contains more values than can be shown on the display at the same time.</li> <li>Alarm LED: The alarm LED lights up or flashes if an alarm is present in the system.</li> <li>Page Up-, Page Down keys</li> <li>Edit keys: These keys allow the colored values to be modified (c1&gt; and c&gt;) and</li> </ul>	
	<ul> <li>5 Edit keys: These keys allow the selected values to be modified (&lt;+&gt; and &lt;=&gt;) and confirmed (&lt;,→&gt;).</li> <li>6 ESC key (Undo and GoUp): When editing a value the editing process can be cancelled by using the Undo key (previous value will be displayed again). Otherwise the GoUp key selects the hierarchically higher object. This key is placed between the two blocks containing the navigation and editing keys because, according to its function, it belongs to both.</li> <li>7 <? > Info key: This key selects the information mode for the next keyboard click.</li> </ul>	
Generic operation and display	Due to the application program each menu tree is different. Navigation through the menu tree is based on the so-called <i>ClickDown</i> procedure using the navigation keys.	
Alarms and events	If the PXM20 receives an alarm or an event appears on the display a pop-op window appears with the relevant information.	
Visual and acoustic alarm	When an alarm is present the alarm LED flashes and changes to steady light when all alarms have been acknowledged. The acoustic alarm is provided as an option and can be activated optionally when an alarm is triggered.	
AlarmViewer	Alarms are written into the AlarmViewer with a symbol, a description and a time/date stamp in chronological order. An acknowledgement mask to acknowledge alarms can be called up in the AlarmViewer. After acknowledgement the alarm entry disappears from the AlarmViewer; however, it will continue to be saved in the history list. Further details can be viewed in the alarm history (e.g. out of service, overridden, deadband, present value, etc.) The PXM20 history can contain max. 60 entries; the older ones are deleted.	
Scheduler	The Scheduler allows the user a time-dependent switch on/off and the programming of time-dependent setpoint adjustments. The Scheduler consists of a 7-day schedule and an exception program.	



Mon Tue Wed Thu Fri Sun Mon

 $\begin{array}{ccccccc} 1 & 2 & 3 \\ 8 & 9 & 10 \\ 15 & 16 & 17 \\ 22 & 23 & 24 \\ 29 & 30 \end{array}$ 

September 1999 📢

EXCEPTIONS (

4 5

18 19 25 26 With the help of the navigation and editing keys it is very simple to create, modify, delete or copy a 7-day schedule in this mask. For each day an individual *"road map"* is programmed.

If the field *EXCEPTION OVERVIEW* is clicked in the 7-day schedule (see above) the current monthly overview appears and shows as inverted all the days which are affected by an exception. All other months can be called up as overview by using the top *direct access* key.

Exception programs

7-day schedule

Home/./Schedule +Exceptions Overview

In the exception program, too, the exceptions are created, modified or deleted by using the navigation and editing keys. It is possible to define exception days (e.g. a bank holiday) as well as exception periods (e.g. holiday periods).

Click the EXCEPTIONS field to display a list of all programmed exceptions.



4/8

## 1 PXM20 operator unit

## Compatibility

Device	Туре	Data sheet
Compact automation stations	PXC	N9211
Modular automation stations	PXCU	N9221
Compact automation stations	PXCD or PXCT.D	N9215
Modular automation stations	PXCD	N9222

#### Accessories

Description	Туре
Connection cable, length 3.0 m (order separately)	PXA-C1
Adapter cableRS232 – RJ45 to connect a PXA-C1 to a PC (order separately)	PXA-C2
Mounting frame for mounting on the wall or on the control panel door (order separately)	PXA-H1

#### Design

The PXM20 operator unit is contained in a robust plastic housing, ideally suited for its many different mounting methods.

All indicators and controls are mounted on the front cover of the unit (see page 2). The connections for the automation stations are incorporated on the back of the unit (see page 7).

#### **Mounting instructions**

The PXM20 is suitable for control panel front mounting or vertical panels (e.g. remote operating panels or similar units). The unit is also suitable for DIN rail snap-mounting. In addition, the PXM20 can be mounted direct on any modular automation station.

Commissioning	
Wiring test	When using networkable PXM20 units it is possible to carry out a wiring test of connected field devices even without a loaded application program. The field devices are shown with the current value and unit.
Switchless	Commissioning before programming:
commissioning	The wiring test supports the reading of all I/Os of compact automation stations, and modular – as long as the modules have an address key. In addition the wiring test supports writing to all outputs. This means you can switch on fans, pumps, lamps etc., or drive valves to a defined position.
	The outputs keep their state as long as the automation station is powered.
Firmware download	It is possible to download firmware via the RS232 interface.

# Disposal

**Technical data** 

T	
∕à∖	

The device is classified as waste electronic equipment in terms of the European Directive 2002/96/EC (WEEE) and should not be disposed of as unsorted municipal waste.

The relevant national legal rules are to be adhered to. Regarding disposal, use the systems setup for collecting electronic waste. Observe all local and applicable laws.

General device data	Operating voltage	AC 24 V ± 20 %
	Safety extra-low voltage SELV	
	Protective extra-low voltage PELV	HD 384
	Frequency	50/60 Hz
	Power consumption	AC 24 V max, 12 VA
		DC 12 40 V max 5 W
	Internal fuse	Thermic, automatic reset
Operating data	Main processor	Freescale PowerPC
oporating data		Neuron 3150
	Data backup in case of power failure	
	Applications parameter (FLASH)	> 10 years
Keyboard		Keyboard with plastic membrane and
reyboard	Type	pressure point
	Key area	7 x 7 mm
	Switching pressure	2 1 N
		0.6 0.7 mm
	Operating life	> 1 million operations
	Material front mombrane	Polycarbonato
	Material, nont membrane	
	Material, contacts	conductive silver,
Diaplay	Machanical	shap-on discs gold-plated
Display		E STN Block & White
	Diaplay area	F-STIN, BIACK & WITHE
	Display alea	123 X 00 11111
	No. of dols	$240 \times 120 \text{ dols}$
	Dot size	$0.47 \times 0.47$ IIIII
		0.50 x 0.50 mm
		20 · 1
	Contrast ratio	20.1
	Brightness Viewing engle	60.0 CO/m
	Viewing angle	
	Viewing direction	6 0 CIOCK
	Background lighting	CCFL (cold cathode fluorescent lamp)
		5 min = 80 % brightness
	Life time lamp	20,000 operating nours
late of a sec	Describe ed	= 64 % brightness
Interfaces	Download	RS232
	Iransceiver	FII-10A
	Baud rate	78 kBit/s
Mounting options	<ul> <li>– For control panel mounting, remote</li> </ul>	e operating panels, etc.
	– – DIN rails	
	<ul> <li>– Direct on modular automation stati</li> </ul>	ions
Connections	See page 7	
6/8		

Housing protection standard	Protection standard to EN 60529	IP 40 (built-in), else IP30
Protection class	Isolation protection class	III
Ambient conditions	Operation	Class 3K5 to IEC 721
	Temperature	0 45 °C
	Humidity	< 85 % rh
	Transport	Class 2K3 to IEC 721
	Temperature	– 25 65 °C
	Humidity	< 95 % rh
Industry standards	Product safety	
	Automatic electronic controls for	
	household and similar use	EN 60730-1
	Special requirements for energy controllers	EN 60730-2-11
	Electromagnetic compatibility	
	Interference immunity	EN 61000-6-2 (industry)
	Emitted interference	EN 61000-6-3 (residential)
	Meets requirements for CE marking:	
	Electromagnetic compatibility	2004/108/EC
	UL-Approbation	UL 916: PAZX, PAZX7
Environmental compatibility	The product environmental declaration	ISO 14001 (Environment)
	CA1E9231 contains data on environmentally	ISO 9001 (Quality)
	compatible product design and assessments	SN 36350 (Environmentally compatible
	(RoHS compliance, materials composition,	products)
	packaging, environmental benefit, disposal)	2002/95/EC (RoHS)
Dimensions	117 x 210 x 37 mm (H x W x D)	See "Dimensions", page 7

<sup>1)</sup> Background color changes slightly depending on ambient temperature. This phenomen is reversible.

# Connections



7/8



© 2003 - 2009 Siemens Switzerland Ltd