	Technical data	
	General specifications	
	Sensing range	30 400 mm
	Adjustment range Unusable area	50 400 mm 0 30 mm
	Standard target plate	100 mm x 100 mm
	Transducer frequency	approx. 310 kHz
	Response delay	approx. 50 ms
	Indicators/operating means LED yellow	solid yellow: object in the evaluation range
	-	yellow, flashing: program function, object detected
	LED red	solid red: Error
	Electrical specifications	red, flashing: program function, object not detected
_	Operating voltage U _B	15 30 V DC , ripple 10 % _{SS}
	No-load supply current I0	≤ 30 mA
	Input Input time	1 average instat
	Input type	1 program input lower evaluation limit A1: -U _B +1 V, upper evaluation lim
C US		A2: +4 V +U _B
		input impedance: > 4.7 k Ω , pulse duration: \geq 1 s
lodel Number	Output Output type	1 analog output 0 10 V
	Resolution	0.17 mm
JB400-12GM-U-V1		
Single head system	Deviation of the characteristic curve Repeat accuracy	± 1 % of full-scale value ± 0.5 % of full-scale value
ingle nead cycloni	Load impedance	> 1 kOhm
eatures	Temperature influence	± 1.5 % of full-scale value
Analog output 0 10 V	Ambient conditions	
	Ambient temperature Storage temperature	-25 70 °C (-13 158 °F) -40 85 °C (-40 185 °F)
Measuring window adjustable	Mechanical specifications	
Program input	Connection type	Connector M12 x 1 , 4-pin
Temperature compensation	Protection degree Material	IP67
· ·	Housing	brass, nickel-plated
Diagrams	Transducer	epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT 25 g
Characteristic response curve	Compliance with standards and	23 g
	directives	
stance Y [mm]	Standard conformity	EN 00047 5 7:0000
	Standards	EN 60947-5-7:2003 IEC 60947-5-7:2003
200		EN 60947-5-2:2007
100		IEC 60947-5-2:2007
2 1		
	Approvals and certificates	al II was bisteri. O sa saral Duma sa s
100	UL approval CSA approval	cULus Listed, General Purpose cCSAus Listed, General Purpose
200	CCC approval	CCC approval / marking not required for products rated
		≤36 V
0 100 200 300 400 500 600 700 800		
↓Y Distance X [mm]	
X		
Curve 1: flat surface 100 mm x 100 mm		
Curve 2: round bar, Ø 25 mm		

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





object range

Additional Information

A1

A2

Rising ramp A1 < A2:

Falling ramp A2 < A1:

Programmed analogue output function


A2

A1

Dimensions

M12x1 M12x1 T7/ (Torque) max. 10 Nm LED M12x1 © M12x1

Electrical Connection



U			— Teach Input
�	4 (BK) 3 (BU)	-	Analog output
			OB OB

Core colors in accordance with EN 60947-5-2.

Pinout



Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)



2

Accessories

UB-PROG2 Programming unit

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

BF 12 Mounting flange, 12 mm

BF 12-F Mounting flange with dead stop, 12 mm

V1-G-2M-PVC Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

UVW90-M12 Ultrasonic -deflector

Adjusting the evaluation limits

The ultrasonic sensor features an analogue output with two teachable evaluation limits. These are set by applying the supply voltage $-U_B$ or $+U_B$ to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. The lower evaluation limit A1 is taught with $-U_B$, A2 with $+U_B$.

Two different output functions can be set:

- 1. Analogue value increases with rising distance to object (rising ramp)
- 2. Analogue value falls with rising distance to object (falling ramp)

TEACH-IN rising ramp (A2 > A1)

- Position object at lower evaluation limit
- TEACH-IN lower limit A1 with UB
- Position object at upper evaluation limit
- TEACH-IN upper limit A2 with + U_B

TEACH-IN falling ramp (A1 > A2):

- Position object at lower evaluation limit
- TEACH-IN lower limit A2 with + U_B
- Position object at upper evaluation limit
- TEACH-IN upper limit A1 with U_B

Default setting

-	
A1:	unusable area
A2:	nominal sensing range
Mode of operation:	rising ramp

LED Displays

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN evaluation limit		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	on	off
Normal mode (evaluation range)	off	on
Fault	on	previous state

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF 12, BF 12-F or BF 5-30 must be used. In case of direct mounting of the sensor in a through hole, it has to be fixed at the middle of the housing thread.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



