




 ϵ





Dimensions





Model Number

M7/MV7/59/76a/102/143

Thru-beam sensor with 4-pin, M8 x 1 connector


Features

- Reliable sensor for standard applicati-
- Miniature design with versatile mounting options
- Automatic adjustment of sensitivity via TEACH-IN
- Resistant against noise: reliable operation under all conditions
- Certified by ECOLAB

Product information

Small, robust, effective, and reliable - these are the properties of the ML7 sensor series. Due to their small size, number of versions, and two different lens positions, they are particularly suited for installation in tight spaces. The robust design and high quality of Pepperl+Fuchs mean they can also be used under harsh environmental conditions. The efficient technology, switching frequencies up to 1000 Hz, high resistance to ambient light, and 4-in-1 output make the series suitable for non-contact object detection.

Electrical connection




- O = Light on
- = Dark on

Pinout



Indicators/operating means



1	Operating display gre		
2	Signal display (Receiver) yellow		
3	Teach-In button (Receiver)		
4	Optical center		

Technical data

Technical data				
System components				
Emitter		M7/76a/143		
Receiver		MV7/59/102/143		
General specifications				
Effective detection range		0 3.5 m		
Threshold detection range		4.5 m		
Light source		LED		
Light type		modulated visible red light		
Target size		min. 7 mm		
Diameter of the light spot		approx. 180 mm at a distance of 3.5 m		
Angle of divergence		approx. 3°		
Ambient light limit		40000 Lux		
Functional safety related parameter	ers	1100 a		
MTTF _d		1130 a 20 a		
Mission Time (T _M) Diagnostic Coverage (DC)		60 %		
= ' '		00 /0		
Indicators/operating means		Receiver: LED green, flashes in case of short-circuit Emitter:		
Operating display		LED green		
Function display		Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control		
Controls		Receiver: TEACH-IN key		
Electrical specifications		40 00 1 0		
· · · · · · · · · · · · · · · · · · ·	U _B	10 30 V DC , class 2 max. 10 %		
Ripple No-load supply current	ı	max. 10 % Emitter: ≤ 17 mA		
	l ₀	Receiver: ≤ 15 mA		
Input				
Test input		emitter deactivation at +U _B		
Output		douls on		
Switching type Signal output		dark on 1 NPN output, short-circuit protected, reverse polarity protected, open collector		
Switching voltage		max. 30 V DC		
Switching current		max. 100 mA		
	Ud	≤ 1.5 V DC		
= :	f	1000 Hz		
Response time		0.5 ms		
Ambient conditions				
Ambient temperature		-20 60 °C (-4 140 °F)		
Storage temperature		-40 75 °C (-40 167 °F)		
Mechanical specifications				
Protection degree		IP67 / IP69K		
Connection Material		M8 x 1 connector, 4-pin		
Housing		PC (glass-fiber-reinforced Makrolon)		
Optical face		PMMA		
Connector		plastic		
Mass		approx. 20 g (emitter and receiver)		
Compliance with standards and d ves	irecti-			
Standard conformity				
Product standard		EN 60947-5-2:2007 IEC 60947-5-2:2007		
Standards		EN 50178, UL 508		
Approvals and certificates				
Protection class		II, rated voltage \leq 250 V AC with pollution degree 1-2 according to IEC 60664-1		
UL approval		cULus		
CCC approval		CCC approval / marking not required for products rated \leq 36 V		

Accessories

Montagekit OMH-ML7-01

Mounting set consisting of bracket OMH-ML-01 sheet OMH-ML7-03, and fastening material

Montagekit OMH-ML7-02

Mounting set consisting of bracket OMH-ML-02 sheet OMH-ML7-03, and fastening material

OMH-ML7-01

Mounting bracket

OMH-ML7-02

Mounting bracket

OMH-ML7-03

Fixing plate

V31-WM-2M-PUR


4-pin, M8 socket, PUR cable


V31-GM-2M-PUR

4-pin, M8 socket, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

Curves/Diagrams





Teach-In

Connect the sensors to operating voltage, the green LEDs green lights up constantly.

The receiver operates at max. sensitivity (delivery status) or with the last teached values.

- Mount transmitter and receiver opposite each other and align roughly.
- Adjust the transmitter to the receiver.
- Press the Teach-In button on the receiver as an acknowledgement the green LED will quickly turn off one time.
- Press the Teach-In button on the receiver until both LEDs green and yellow are blinking in parallel (2 Hz). Release the Teach-In button now.
- While the green and yellow LEDs are blinking alternating (2 Hz) on the receiver the unit is in the internal set up procedure.
- Teach-In successful: Both LEDs green and yellow on the receiver are on. The unit is ready to use and in switching mode now.
- Teach-In not successful: Both LEDs on the receiver are flashing alternating (4 Hz) for approx. 5 seconds. Afterwards the sensor returns to max. sensitivity setting. Please retry the Teach-In procedure beginning by step 1.