



CE







## **Model Number**

## M7/MV7/59/76a/102/115

Thru-beam sensor with 2 m fixed cable


## **Features**

- Reliable sensor for standard applications
- Miniature design with versatile mounting options
- Automatic adjustment of sensitivity via TEACH-IN
- Resistant against noise: reliable operation under all conditions
- · Certified by ECOLAB

## **Product information**


Small, robust, effective, and reliable - these are the properties of the ML7 sensor series. Due to their small size, number of versions, and two different lens positions, they are particularly suited for installation in tight spaces. The robust design and high quality of Pepperl+Fuchs mean they can also be used under harsh environmental conditions. The efficient technology, switching frequencies up to 1000 Hz, high resistance to ambient light, and 4-in-1 output make the series suitable for non-contact object detection.

## **Dimensions**






## **Electrical connection**



- O = Light on
- = Dark on

## Indicators/operating means



1	Operating display	green
2	Signal display (Receiver)	yellow
3	Teach-In button (Receiver)	
	Ontical center	

#### **Technical data** System components Emitter M7/76a/115 MV7/59/102/115 General specifications Effective detection range 0 35 m Threshold detection range 4.5 m LED Light source Light type modulated visible red light Target size min. 7 mm Diameter of the light spot approx. 180 mm at a distance of 3.5 m Angle of divergence approx. 3 40000 Lux Ambient light limit Functional safety related parameters 1130 a $MTTF_d$ Mission Time (T<sub>M</sub>) 20 a Diagnostic Coverage (DC) 60 % Indicators/operating means Receiver: LED green, flashes in case of short-circuit Emitter: Operating display LED green Function display Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control Receiver: TEACH-IN key Controls **Electrical specifications** Operating voltage 10 ... 30 V DC , class 2 $U_B$ max 10 % Ripple Emitter: ≤ 17 mA No-load supply current $I_0$ Receiver: ≤ 15 mA Input Test input emitter deactivation at +UB Output Switching type 1 NPN output, short-circuit protected, reverse polarity protected, Signal output open collector Switching voltage max. 30 V DC Switching current max. 100 mA Voltage drop $U_{d}$ ≤ 1.5 V DC Switching frequency 1000 Hz Response time 0.5 ms **Ambient conditions** Ambient temperature -20 ... 60 °C (-4 ... 140 °F) -40 ... 75 °C (-40 ... 167 °F) Storage temperature **Mechanical specifications** Protection degree IP67 / IP69K Connection 2 m fixed cable Material Housing PC (glass-fiber-reinforced Makrolon) Optical face approx. 100 g (emitter and receiver) Mass Compliance with standards and directives Standard conformity EN 60947-5-2:2007 Product standard IEC 60947-5-2:2007 Standards EN 50178, UL 508 Approvals and certificates II, rated voltage ≤ 250 V AC with pollution degree 1-2 accor-Protection class ding to IEC 60664-1 **UL** approval cULus

### **Accessories**

### Montagekit OMH-ML7-01

Mounting set consisting of bracket OMH-ML-01 sheet OMH-ML7-03, and fastening material

# Montagekit OMH-ML7-02

Mounting set consisting of bracket OMH-ML-02 sheet OMH-ML7-03, and fastening material

## OMH-ML7-01

Mounting bracket

#### OMH-ML7-02

Mounting bracket

## **OMH-ML7-03**

Fixing plate


Other suitable accessories can be found at www.pepperl-fuchs.com


PEPPERL+FUCHS

CCC approva

CCC approval / marking not required for products rated ≤36 V

## **Curves/Diagrams**





## Teach-In

Connect the sensors to operating voltage, the green LEDs green lights up constantly.

The receiver operates at max. sensitivity (delivery status) or with the last teached values.

- Mount transmitter and receiver opposite each other and align roughly.
- Adjust the transmitter to the receiver.
- Press the Teach-In button on the receiver as an acknowledgement the green LED will quickly turn off one time.
- Press the Teach-In button on the receiver until both LEDs green and yellow are blinking in parallel (2 Hz). Release the Teach-In button now.
- While the green and yellow LEDs are blinking alternating (2 Hz) on the receiver the unit is in the internal set up procedure.
- Teach-In successful: Both LEDs green and yellow on the receiver are on. The unit is ready to use and in switching mode now.
- Teach-In not successful: Both LEDs on the receiver are flashing alternating (4 Hz) for approx. 5 seconds. Afterwards the sensor returns to max. sensitivity setting. Please retry the Teach-In procedure beginning by step 1.