











#### **Model Number**

## M71/MV71/59/76a/103/115

Thru-beam sensor with 2 m fixed cable


#### **Features**

- Reliable sensor for standard applications
- Miniature design with front optical face
- Automatic adjustment of sensitivity via TEACH-IN
- Resistant against noise: reliable operation under all conditions
- · Certified by ECOLAB


#### **Product information**

Small, robust, effective, and reliable - these are the properties of the ML7 sensor series. Due to their small size, number of versions, and two different lens positions, they are particularly suited for installation in tight spaces. The robust design and high quality of Pepperl+Fuchs mean they can also be used under harsh environmental conditions. The efficient technology, switching frequencies up to 1000 Hz, high resistance to ambient light, and 4-in-1 output make the series suitable for non-contact object detection.

#### **Dimensions**



### **Electrical connection**



- O = Light on
- = Dark on

www.pepperl-fuchs.com

#### Thru-beam sensor **Technical data** System components Emitter M71/76a/115 MV71/59/103/115 General specifications Effective detection range 0 35 m Threshold detection range 4.5 m LED Light source Light type modulated visible red light Target size min. 7 mm Diameter of the light spot approx. 180 mm at a distance of 3.5 m Angle of divergence approx. 3 40000 Lux Ambient light limit Functional safety related parameters $MTTF_d$ 1130 a Mission Time (T<sub>M</sub>) 20 a Diagnostic Coverage (DC) 60 % Indicators/operating means Receiver: LED green, flashes in case of short-circuit Emitter: Operating display LED green Function display Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control Receiver: TEACH-IN key Controls **Electrical specifications** Operating voltage 10 ... 30 V DC , class 2 $U_B$ max 10 % Ripple No-load supply current Emitter: ≤ 17 mA $I_0$ Receiver: ≤ 15 mA Input emitter deactivation at +U<sub>B</sub> Test input Output Switching type 1 PNP output, short-circuit protected, reverse polarity protected, Signal output open collector

max. 30 V DC

max. 100 mA

-20 ... 60 °C (-4 ... 140 °F) -40 ... 75 °C (-40 ... 167 °F)

PC (glass-fiber-reinforced Makrolon)

approx. 100 g (emitter and receiver)

≤ 1.5 V DC

IP67 / IP69K

2 m fixed cable

EN 60947-5-2:2007

IEC 60947-5-2:2007

EN 50178, UL 508

ding to IEC 60664-1

cULus

1000 Hz 0.5 ms

 $U_{d}$ 

#### Accessories

OMH-ML7-01

Mounting bracket

**OMH-ML7-02** 

Mounting bracket

**OMH-ML7-03** 

Fixing plate

Other suitable accessories can be found at www.pepperl-fuchs.com

Switching voltage

Switching current

Switching frequency

Storage temperature

Mechanical specifications

Protection degree

Voltage drop

Response time

Ambient conditions

Ambient temperature

Connection

Optical face

Standard conformity

Product standard

Approvals and certificates

Standards

Protection class

**UL** approval

CCC approva

Compliance with standards and directi-

Material Housing


Mass


ves

II, rated voltage ≤ 250 V AC with pollution degree 1-2 accor-

CCC approval / marking not required for products rated ≤36 V

# **Curves/Diagrams**





## Teach-In

Connect the sensors to operating voltage, the green LEDs green lights up constantly.

The receiver operates at max. sensitivity (delivery status) or with the last teached values.

- Mount transmitter and receiver opposite each other and align roughly.
- Adjust the transmitter to the receiver.
- Press the Teach-In button on the receiver as an acknowledgement the green LED will quickly turn off one time.
- Press the Teach-In button on the receiver until both LEDs green and yellow are blinking in parallel (2 Hz). Release the Teach-In button now.
- While the green and yellow LEDs are blinking alternating (2 Hz) on the receiver the unit is in the internal set up procedure.
- Teach-In successful: Both LEDs green and yellow on the receiver are on. The unit is ready to use and in switching mode now.
- Teach-In not successful: Both LEDs on the receiver are flashing alternating (4 Hz) for approx. 5 seconds. Afterwards the sensor returns to max. sensitivity setting. Please retry the Teach-In procedure beginning by step 1.