







# **Model Number**

## UB1000-18GM75-E23-V15


Single head system

### **Features**

- · 2 switch outputs
- Selectable sound lobe width
- **Program input**
- **Temperature compensation**
- Very small unusable area

## **Diagrams**

# Characteristic response curve







# **Technical data**

General specifications	
Sensing range	70 1000 mm
Adjustment range	90 1000 mm
Unusable area	0 70 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 255 kHz
Response delay	approx. 125 ms

Indicators/operating means

LED yellow indication of the switching state flashing: program function object detected I FD red "Error", object uncertain in program function: No object detected

**Electrical specifications** 

Operating voltage U<sub>B</sub> 10 ... 30 V DC , ripple 10  $\%_{SS}$ 

No-load supply current I<sub>0</sub> ≤ 50 mA Input

Input type 1 program input,

operating range 1: -U<sub>B</sub> ... +1 V, operating range 2: +4 V ... +U<sub>B</sub>

input impedance: > 4.7 k $\Omega$ ; program pulse:  $\geq$  1 s

Output Output type 2 switch outputs PNP, NO/NC

Rated operating current I<sub>e</sub> 2 x 100 mA, short-circuit/overload protected Voltage drop U<sub>d</sub> ≤ 3 V

≤ 1 % Repeat accuracy Switching frequency f max. 3 Hz

Range hysteresis H 1 % of the set operating distance Temperature influence ± 1.5 % of full-scale value

Ambient conditions -25 ... 70 °C (-13 ... 158 °F) Ambient temperature

Storage temperature -40 ... 85 °C (-40 ... 185 °F) **Mechanical specifications** 

Connection type Connector M12 x 1, 5-pin

IP67 Degree of protection

Material Housing brass, nickel-plated

Transducer epoxy resin/hollow glass sphere mixture; foam

polyurethane, cover PBT

Mass 60 g

Factory settings Output 1 Switching point: 90 mm

output function: Switch point operation mode

output behavior: NO contact

Output 2 Switching point: 1000 mm output function: Switch point operation mode

output behavior: NC contact

Beam width

Compliance with standards and directives

Standard conformity

Standards EN 60947-5-2:2007

IEC 60947-5-2:2007


# Approvals and certificates

UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

CCC approval CCC approval / marking not required for products rated


www.pepperl-fuchs.com

# **Dimensions**



# **Electrical Connection**

Standard symbol/Connections: (version E23, pnp)



Core colours in accordance with EN 60947-5-2.

# **Pinout**




Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)
5	GY	(gray)

# **Additional Information**

# **Programmed switching output function**



Switch point 2 -> ∞: Switch output 2, (N.C.)
Detection of object presence

2

### **Accessories**

### UB-PROG3

Programming unit

#### **OMH-04**

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

#### BF 18

Mounting flange, 18 mm

#### BF 18-F

Mounting flange with dead stop, 18 mm

#### BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

### UVW90-K18

Ultrasonic -deflector

### V15-G-2M-PVC

Female cordset, M12, 5-pin, PVC cable

### V15-W-2M-PUR

Female cordset, M12, 5-pin, PUR cable

M<sub>18</sub>K-VE

# **Description of Sensor Functions**

### Programming procedure

The sensor features two switch outputs with one programmable switch point, each. Programming the switch points is done by applying the supply voltage  $-U_B$  (switch output 1) or  $+U_B$  (switch output 2) to the Teach-In input. The supply voltage must be applied to the Teach-In input for at least 1 s. LEDs indicate whether the sensor has recognized the target during the programming procedure.

#### Note

Switching points may only be specified directly after Power on. A time lock secures the adjusted switching points against unintended modification 5 minutes after Power on. To modify the switching points later, the user may specify the desired values only after a new Power On.

### Note:

If a programming adapter UB-PROG3 is used for the programming procedure, button A1 is assigned to -U<sub>B</sub> and button A2 is assigned to +U<sub>B</sub>.

## **Programming switch ouputs**

### Switch point for switch output 1

- 1. Place the target at the desired switch point position of switch output 1
- 2. Program the switch point by applying -U<sub>B</sub> to the Teach-In input (corresponding yellow LED flashes)
- 3. Disconnect the Teach-In input from -U<sub>B</sub> to save the switch point

# Switch point for switch output 2

- 1. Place the target at the desired switch point position of switch output 2
- 2. Program the switch point by applying +U<sub>B</sub> to the Teach-In input (corresponding yellow LED flashes)
- 3. Disconnect the Teach-In input from +U<sub>B</sub> to save the switch point

# Programming detection of object presence

- 1. Cover the sensor face with hand or remove all objects from sensing range
- 2. Apply - $U_B$  to the Teach-In input (red LED flashes)
- 3. Disconnect the Teach-In input from  $U_{\mbox{\footnotesize B}}$
- 4. Apply +U<sub>B</sub> to the Teach-In input (red LED flashes)
- 5. Disconnect the Teach-In input from  $+U_B$

**Note:** Only one switch output can be configured for detection of presence of objects. If the sensor detects an object within the maximum detection range, the switch output switches.

# Adjusting the sound cone characteristics:

The ultrasonic sensor enables two different shapes of the sound cone, a wide angle sound cone and a small angle sound cone.

# 1. Small angle sound cone

- · switch off the power supply
- connect the Teach-In input wire to -UB
- · switch on the power supply
- the red LED flashes once with a pause before the next.
- yellow LED: permanently on: indicates the presence of an object or disturbing object within the sensing range
- disconnect the Teach-In input wire from -U<sub>B</sub> and the changing is saved

## 2. Wide angle sound cone

- · switch off the power supply
- connect the Teach-In input wire with +UB
- · switch on the power supply
- the red LED double-flashes with a long pause before the next.
- yellow LED: permanently on: indicates an object or disturbing object within the sensing range
- disconnect the Teach-In input wire from  $+U_B$  and the changing is saved

### **Factory settings**

See technical data.



-Ö- pause -Ö-

204534\_eng.xml

Date of issue: 2015-03-31

2015-03-31 16:09

# **Display**

The sensor provides LEDs to indicate various conditions.

	Red LED	Yellow LED 1	Yellow LED 2
During Normal operation			
Proper operation	Off	Switching state	Switching state
		output 1	output 2
Interference (e.g. compressed air)	On	remains in previous	remains in previous
		state	state
Programming of output 1			
Object detected	Off	Flashes	Off
No object detected	Flashes	Off	Off
Object uncertain (programming invalid)	On	Off	Off
Programming of output 2			
Object detected	Off	Off	Flashes
No object detected	Flashes	Off	Off
Object uncertain (programming invalid)	On	Off	Off

## Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.