	Technical data	
	General specifications	
	Measurement range	object thickness (d) : 0 30 mm
	Unusable area	0 15 mm
	Reference distance h	50 60 mm
	Standard target plate	10 mm x 10 mm
	Transducer frequency	approx. 850 kHz
	Response delay Indicators/operating means	approx. 12 ms
	LED yellow	solid: object in evaluation range
	LED red	solid red: Error
		red, flashing: program function, object not detected
	Electrical specifications	
•	Operating voltage U _B	15 30 V DC , ripple 10 % _{SS}
	No-load supply current I ₀ Time delay before availability t _v	≤ 30 mA ≤ 200 ms
	Input	≤ 200 ms
	Input type	1 funtion input
	Pro ZPro	0-level: -U _B or unwired
0 00		1-level: +4 V +U _B
	Output	input impedance: > 4.7 k Ω
odel Number	Output Output type	1 analog output 0 10 V
	Resolution	0.17 mm
3H60/30-12GM-U-V1		
nale head system	Deviation of the characteristic curve	± 1 % of full-scale value
ngle head system	Repeat accuracy	± 0.5 % of full-scale value
eatures	Load impedance Ambient conditions	> 1 kOhm
	Ambient temperature	-25 70 °C (-13 158 °F)
Thickness measurement with ana-	Storage temperature	-40 85 °C (-40 185 °F)
log output 0 10 V	Mechanical specifications	, , , , , , , , , , , , , , , , , , ,
Automatic compensation of the re-	Connection type	Connector M12 x 1 , 4-pin
ference distance, deactivateable	Degree of protection	IP67
Extremely narrow projection cone	Material Housing	brass, nickel-plated
	Transducer	epoxy resin/hollow glass sphere mixture; foam
Short response time	Tanoddoor	polyurethane, cover PBT
	Mass	25 g
agrams	Compliance with standards and directives	
	Standard conformity	
naracteristic response curve	Standards	EN 60947-5-2:2007
		IEC 60947-5-2:2007
nce Y [mm]		EN 60947-5-7:2003
25		IEC 60947-5-7:2003
15		
10	Approvals and certificates	
5	UL approval	cULus Listed, General Purpose
0	CSA approval	cCSAus Listed, General Purpose
-5	CCC approval	CCC approval / marking not required for products rate
-10		≤36 V
-15		
-20		
-25		
Distance X [mm]		
— — — X		
=		

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com


Release date: 2014-06-13 11:46 Date of issue: 2014-06-13 204917_eng.xml


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com


Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




Dimensions








Normal operation



Electrical Connection

Standard symbol/Connections:



Core colors in accordance with EN 60947-5-2.

Pinout



Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Accessories

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

BF 12 Mounting flange, 12 mm

BF 12-F Mounting flange with dead stop, 12 mm

V1-G-2M-PVC

Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

Functional description

This sensor is used to measure the thickness of objects. It teaches itself by independently switching to a reference object. The distance h to this object serves as a reference distance and defines the object thickness 0 mm. This reference distance can be dynamically tracked in order to compensate for external influences. This guarantees a high measurement accuracy of the sensor over the entire temperature range.

Automatic teach-in process

Immediately after the supply voltage is connected, the sensor automatically references itself to the reference object and teaches in the distance as the reference distance. The distance h between the sensor surface and the reference object must lie within the valid range for the reference distance (see Technical Data). The sensor then immediately reverts to normal operation. If no reference object is detected, the red LED flashes (Fault).

Normal operation

In normal operation, the sensor outputs a value at the analog output, which is proportional to the thickness of the object. The object thickness 0 mm (measurement to the reference object) is represented in this by the minimum analog value and the largest measurable object thickness (see Technical Data) is represented by the maximum analog value.

Dynamic tracking of the reference distance

The dynamic tracking of the reference distance can be activated and deactivated by means of the function input circuitry (see Function Input).

Dynamic tracking activated:

(Function input open or connected with $-U_B$)

When measuring an object, the sensor must detect the reference point again within no longer than four seconds in order to be re-referenced to it. Otherwise the object is interpreted as the reference. Then, in accordance with a PTI characteristic with a time constant of 14 s, this distance value becomes the new reference distance.

If the object is incorrectly taught-in as the reference and then moves outside the sensor's detection field so that the greater distance to the actual reference object is measured, the sensor immediately reacts. The new, greater distance is taught-in as the reference without delay.

Dynamic tracking deactivated:

(Function input connected with $+U_B$)

The reference distance automatically taught-in when the sensor is switched on is retained during the entire operation.

Function input

The function input is used to activate/deactivate the dynamic tracking of the reference distance (see above).

LED indicator

Indication as a function of operating status	Red LED	Yellow LED
Teach-in control limit: No reference object detected or reference object at an incorrect distance	Flashes	Off
Normal operation		
Measurement on object	Off	On
Measurement on reference	Off	Off
Fault	On	Last valid status

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF 12, BF 12-F or BF 5-30 must be used. In case of direct mounting of the sensor in a through hole, it has to be fixed at the middle of the housing thread.

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

