







## **Model Number**

# UB800-18GM40A-E5-V1


Single head system

### **Features**

- Short design, 40 mm
- Function indicators visible from all directions
- · Switch output
- 5 different output functions can be set
- Program input
- · Temperature compensation

## **Diagrams**

## Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

## **Technical data**

General specifications	
Sensing range	50 800 mm
Adjustment range	70 800 mm
Unusable area	0 50 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 255 kHz
Response delay	approx. 100 ms

### Indicators/operating means LED green

LED yellow	indication of the switching state
	flashing: program function object detected

LED red solid red: Error red, flashing: program function, object not detected

Power on

Electrical specifications Operating voltage  $U_B$  10 ... 30 V DC , ripple 10  $\%_{SS}$ 

No-load supply current I<sub>0</sub> ≤ 20 mA

Input

Input type  $\begin{array}{c} \text{1 program input} \\ \text{operating distance 1: -U}_{\text{B}} \ldots \text{+1 V, operating distance 2: +6 V} \end{array}$ 

input impedance: > 4,7 k $\Omega$  program pulse:  $\geq$  1 s

 Output

 Output type
 1 switch output E5, PNP NO/NC, programmable

 Rated operating current I<sub>e</sub>
 200 mA , short-circuit/overload protected

Default setting Switch point A1: 70 mm Switch point A2: 800 mm Voltage drop  $U_d$   $\leq$  3 V Repeat accuracy  $\leq$  1 %

Switching frequency f

Range hysteresis H

Temperature influence

≤ 4 Hz

1 % of the set operating distance

± 1.5 % of full-scale value

 Ambient conditions
 -25 ... 70 °C (-13 ... 158 °F)

 Storage temperature
 -20 ... 85 °C (-40 ... 185 °F)

Mechanical specifications

Connection type Connector M12 x 1 , 4-pin
Protection degree IP67
Material

Housing brass, nickel-plated
Transducer epoxy resin/hollow glass sphere mixture; foam

Transducer epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT

Mass 25 g

Compliance with standards and directives

Standard conformity
Standards EN 60947-5-2:2007

Approvals and certificates


UL approval cULus Listed, General Purpose
CSA approval cCSAus Listed, General Purpose
CSC approval (modified not approximate rated)


IEC 60947-5-2:2007

CCC approval / marking not required for products rated

≤36 V


## **Dimensions**





# **Electrical Connection**

Standard symbol/Connections: (version E5, pnp)



Core colours in accordance with EN 60947-5-2.

## **Pinout**




Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)

# **Additional Information**

## Programmable output modes



5. A1 ->  $\infty$ , A2 ->  $\infty$ : Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

### **Accessories**

### **UB-PROG2**

Programming unit

#### **OMH-04**

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

#### BF 18

Mounting flange, 18 mm

#### **BF 18-F**

Mounting flange with dead stop, 18 mm

#### BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

### V1-G-2M-PVC

Female cordset, M12, 4-pin, PVC cable

#### V1-W-2M-PUR

Female cordset, M12, 4-pin, PUR cable

### Adjusting the switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage  $-U_B$  or  $+U_B$  to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with  $-U_B$ , A2 with  $+U_B$ .

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. one switching point, normally-open function
- 4. one switching point, normally-closed function
- 5. Detection of object presence

## **TEACH-IN** window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Set target to far switching point
- TEACH-IN switching point A2 with +UB

## **TEACH-IN** window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +UB
- Set target to far switching point
- TEACH-IN switching point A1 with -U<sub>B</sub>

### **TEACH-IN** switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB

# TEACH-IN switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +UB

## **TEACH-IN** detection of objects presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB
- TEACH-IN switching point A2 with +U<sub>B</sub>

### **LED Displays**

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN switching point:		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	On	off
Normal operation	off	Switching state
Fault	on	Previous state

eng.xml