







Model Number

UB300-18GM40-E4-V1


Single head system

Features

- Short design, 40 mm
- Function indicators visible from all directions
- Switch output
- 5 different output functions can be
- **Program input**
- **Temperature compensation**

Diagrams

Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: flat surface 10 mm x 10 mm Curve 3: round bar, Ø 25 mm



Technical data General specifications

acticiai specifications	
Sensing range	35 300 mm
Adjustment range	50 300 mm
Unusable area	0 35 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 390 kHz
Response delay	approx. 50 ms

Indicators/operating means

LED green LED yellow indication of the switching state

flashing: program function object detected LED red

Power on

red, flashing: program function, object not detected

Electrical specifications Operating voltage U_B 10 ... 30 V DC , ripple 10 $\%_{SS}$

No-load supply current I₀ ≤ 20 mA

Input

Input type 1 program input operating distance 1: -U_B ... +1 V, operating distance 2: +6 V

input impedance: > 4,7 k Ω program pulse: \geq 1 s

Output 1 switch output E4, NPN, NO/NC, programmable Output type Rated operating current I_e 200 mA, short-circuit/overload protected

Switch point A1: 50 mm Switch point A2: 300 mm Default setting Voltage drop U_d ≤ 3 V Repeat accuracy ≤ 1 % Switching frequency f ≤ 13 Hz

Range hysteresis H 1 % of the set operating distance

Temperature influence ± 1.5 % of full-scale value Ambient conditions

Ambient temperature -25 ... 70 °C (-13 ... 158 °F) -40 ... 85 °C (-40 ... 185 °F) Storage temperature

Mechanical specifications Connection type Connector M12 x 1, 4-pin

Degree of protection IP67 Material

Housing brass, nickel-plated

epoxy resin/hollow glass sphere mixture; foam Transducer

polyurethane, cover PBT

Mass 25 g

Compliance with standards and directives

Standard conformity Standards FN 60947-5-2:2007

IEC 60947-5-2:2007


Approvals and certificates

UL approval cULus Listed. General Purpose cCSAus Listed, General Purpose CSA approval

CCC approval CCC approval / marking not required for products rated


≤36 V

Dimensions



Additional Information


Programmable output modes



5. A1 -> ∞, A2 -> ∞: Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

Electrical Connection

Standard symbol/Connections: (version E4, npn)



Core colours in accordance with EN 60947-5-2.

Pinout

Connector V1



Accessories

UB-PROG2

Programming unit

OMH-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

RF 18

Mounting flange, 18 mm

BF 18-F

Mounting flange with dead stop, 18 mm

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V1-G-2M-PVC

Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR

Female cordset, M12, 4-pin, PUR cable

Adjusting the switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage $-U_B$ or $+U_B$ to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with $-U_B$, A2 with $+U_B$.

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. one switching point, normally-open function
- 4. one switching point, normally-closed function
- 5. Detection of object presence

TEACH-IN window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Set target to far switching point
- TEACH-IN switching point A2 with +U_B

TEACH-IN window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Set target to far switching point
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB

TEACH-IN switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +UB

TEACH-IN detection of objects presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB
- TEACH-IN switching point A2 with +UB

LED Displays

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN switching point:		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	On	off
Normal operation	off	Switching state
Fault	on	Previous state

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.