



# 

## **Model Number**

### SBL-8-H-900-IR/59/65b/73/120

Background suppression sensor with 4-pin, M12 x 1 connector

### Features

- Background suppression sensor for roller conveyors
- For installation between the rollers on a roller conveyor
- Very small black-white difference
- Adjustable detection range


### **Product information**

Sensors of the SBL series are used to easily control material flow on roller conveyors in material handling and other branches.


The SBL series is a precise background suppression sensor according to the 3 element method. The sensor features superior background suppression and a very good ambient light immunity. Material and transport container of all colors and opacities are reliably detected.

The special design allows the sensor to be mounted between the rollers of a roller conveyor or any other conveying unit. Mounting between the rollers is easy and protects the sensor.





# Electrical connection






Pinout



# Indicators/operating means



1	Signal display	yellow	
2	Sensing range adjuster		

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




			Accessories
าร		40 000 mm	OMH-SBL-01
		40 900 mm 40 340 mm	Mounting bracket for sensors of SBL
		40 900 mm	ries
•		340 900 mm	V1-G-2M-PVC
		standard white 200 mm x 200 mm	
		IRED	Female cordset, M12, 4-pin, PVC cab
		modulated infrared light , 880 nm	V1-G-5M-PVC
ce (6 %/90 %	%)	< 10 %	Female cordset, M12, 4-pin, PVC cab
spot	,0)	approx. 60 mm at detection range 900 mm	
opor		continuous light 30000 Lux , Fluorescent lamp 5000 Lux	V1-W-2M-PUR
ated paran	notore		Female cordset, M12, 4-pin, PUR cab
ateu paran		1100 a	
		20 a	V1-W-5M-PUR
(DC)		0%	Female cordset, M12, 4-pin, PUR cab
means			
means		LED yellow: lights when object is detected	Schraubendreher 0,5 x 3,0 mm
		Detection range adjuster	Screwdriver
ne		Detection range adjuster	Other suitable accessories can be found
ons	11	24 VDC -20% +10%	www.pepperl-fuchs.com
	UB		
nt	_	max. 10 %	
nt	I <sub>0</sub>	max. 20 mA	
		dark on	
		2 PNP, complementary, short-circuit protected, open collectors	
		max. 30 V DC	
	,	max. 100 mA	
	f	100 Hz	
		5 ms	
		-20 50 °C (-4 122 °F)	
		-30 60 °C (-22 140 °F)	
tions			
		IP65	
		4-pin, M12 x 1 connector	
		plastic	
		plastic lens	
		approx. 50 g	
ndards and	a airect	I-	
		EMC Directive 2004/108/EC	
		EN 60947-5-2:2007	
		IEC 60947-5-2:2007	
esistance		IEC / EN 60068. half-sine, 40 g in each X, Y and Z directions	
)		IEC / EN 60068-2-6. Sinus. 10 -1000 Hz, 10 g in each X, Y and Z	
		directions	
liestes			
icates		al II up Listed Close 2 Power Course Time 1 analogue	
		cULus Listed, Class 2 Power Source, Type 1 enclosure	
		CCC approval / marking not required for products rated $\leq$ 36 V	
ns			
nce in de	etectio	on distance	
letection dist			
	+		
	+		
1	1		1

Technical data General specification

Detection range min.

Detection range

### Detection range max. Adjustment range Reference target Light source Light type Black/White difference Diameter of the light s Ambient light limit Functional safety rela MTTF<sub>d</sub> Mission Time (T<sub>M</sub>) **Diagnostic Coverage** Indicators/operating Function indicator Control elements Electrical specificatio Operating voltage Ripple No-load supply current Output Switching type Signal output Switching voltage Switching current Switching frequency Response time Ambient conditions Ambient temperature Storage temperature Mechanical specifica Protection degree Connection Material Housing Optical face Mass Compliance with star ves Directive conformity Standard conformity Product standard Shock and impact re Vibration resistance Approvals and certif UL approval CCC approval Curves/Diagram



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"


Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

Date of issue: 2013-12-05 223835\_eng.xml



### **Options:**

Sensors with the version -V are equipped with a solenoid valve and can directly control a 3/2 way pneumatic actuator, without any-interaction of an external system controlling unit (PLC). As soon as conveyed goods are detected, the diffuse mode sensor gives an electrical-signal to the pneumatic solenoid valve, which is then activated.

Sensors with the control logic option -SL-(V) allows up to 50 diffuse mode sensors to be connected-to each other (data and power), depending on the current consumption of sensor and solenoid valve. An additional supply power and data bus cable is used to interconnect the sensors with control logic option -SL. All necessary functions for controlling the material flow of conveyed goods are supported, such as: single feed, single release, slug release, external motor and solenoid valve control. It is also possible to energize the valves of all sensors included in the cascade by slug release (VT). To do this, apply the positive supply voltage (+UB) on the input VT of the first sensor.

Sensors with timing function -Z features the adjustment of the ON- and OFF delay of the output independently. This optimizes control of the solenoid valve. A zero pressure accumulation of the conveyed goods can be realized with application of time ONand OFF delay of the output. The ON- and OFF delay to control the switching of the solenoid valve may be adjusted between 0 and 2 seconds.

Additional power supply between every 20 to 25 sensors can be realized by the use of the power in feed junction V1S-TEE-V1/ V1S in combination with a cable V1-G-...-PVC. This features to practically connect any number of SBL sensors in series. Attention should be paid to the maximum rated current of the cable and the connectors which usually is max. I = 4 A. For more details on the maximum rated current of single components, please refer to our datasheet values. For the electrical supply of the sensors the country specific standards have to be considered.

#### Note:

Use a screwdriver to adjust the sensing range. We strongly recommend to use the screwdriver given in the accessories section.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

