## **Features**

- 4-channel
- Analog output module for 0/4 mA ... 20 mA
- Installation in Zone 2, Zone 22, or safe area
- HART communication via field bus or service bus
- Simulation mode for service operations (forcing)
- Line fault detection (LFD): one LED per channel
- · Permanently self-monitoring
- Module can be exchanged under voltage

## **Function**


The device drives positioners, proportional valves, I/P converters, or local indicators.

Open and short circuit line faults are detected.

The outputs are galvanically isolated from the bus and the power supply.


# **Assembly**

#### Front view





### Connection



Zone 2

Supply		
Connection		backplane bus
Rated voltage	U <sub>n</sub>	12 V DC , only in connection with the power supplies LB9***
Power loss		1.5 W
Power consumption		3 W
Internal bus		
Connection		backplane bus
Interface		manufacturer-specific bus to standard com unit
Output		
Number of channels		4
Suitable field devices		proportional valves, I/P converter, local indicators
Connection		channel I: 1+, 2-; channel II: 3+, 4-; channel III: 5+, 6-; channel IV: 7+, 8-
Current		0 25 mA short-circuit protected
Load		$750\Omega$ max.
Line fault detection		can be switched on/off for each channel via configuration tool, configurable via configuration tool
Short-circuit		Ex works settings: < 50 $\Omega$ configurable between 0 26 mA
Open-circuit		deviation of preset output value > 0.5 mA
Watchdog		within 0.5 s the device goes in safe state, e.g. after loss of communication
Transfer characteristics		
Deviation		
After calibration		0.1 % of the signal range at 20 °C (68 °F)
Influence of ambient temperature		0.1 %/10 K of the signal range
Refresh time		100 ms
Indicators/settings		
LED indicator		Power LED (P) green: supply
ELD IIIdiodioi		Diagnostic LED (I) red: module fault, red flashing: communication error, white: fixed parameter set (parameters from com unit are ignored), white flashing: requests parameters from com unit Status LED (1-4) red: line fault (lead breakage or short circuit)
Coding		optional mechanical coding via front socket
Directive conformity		
Electromagnetic compatibility		
Directive 2004/108/EC		EN 61326-1:2006
Conformity		
Electromagnetic compatibility		NE 21:2007
Degree of protection		IEC 60529:2000
Environmental test		EN 60068-2-14:2009
Shock resistance		EN 60068-2-27:2009
Vibration resistance		EN 60068-2-6:2008
Damaging gas		EN 60068-2-42:2003
Relative humidity		EN 60068-2-78:2001
Ambient conditions		
Ambient temperature		-20 60 °C (-4 140 °F) , 70 °C (non-Ex)
Storage temperature		-25 85 °C (-13 185 °F)
Relative humidity		95 % non-condensing
Shock resistance		shock type I, shock duration 11 ms, shock amplitude 50 m/s <sup>2</sup> , number of shock directions 6, number of shocks per direction 100
Vibration resistance		frequency range 5 500 Hz, amplitude 5 13.2 Hz ± 1.5 mm, 13.2 100 Hz 1g, sweep rate 1 octave/min, duration 10 sweeps 5 Hz - 100 Hz - 5 Hz
Damaging gas		for plugs: 21 days in 25 ppm SO <sub>2</sub> , at 25 °C and 75 % rel. humidity, device G3
Mechanical specification	ıs	
Degree of protection		IP20 when mounted on backplane
Connection		removable front connector with screw flange (accessory)
Mass		wiring connection via spring terminals (0.14 1.5 mm <sup>2</sup> ) or screw terminals (0.08 1.5 mm <sup>2</sup> ) approx. 150 g
Dimensions		32 x 100 x 103 mm (1.26 x 3.9 x 4 in)
Data for application in co	onnection	02 A 100 A 100 Hilli (1.20 A 0.3 A 4 Hil)
with Ex-areas		RVS 12 ATEX E 115 Y
Statement of conformity		BVS 12 ATEX E 115 X
Group, category, type of protection		⟨ы⟩ II 3 G Ex nA [ic] IIC T4 Gc
Electrical isolation		and all adviced installed and to ENI COOTO 44 configuration and to ENI COOTO 44 configuration and the COTO VI
Output/power supply, internal bus		safe electrical isolation acc. to EN 60079-11, voltage peak value 375 V
Directive conformity		EN 99979 9 9999
Directive 94/9/EC		EN 60079-0:2009 EN 60079-11:2007 EN 60079-15:2010
International approvals		



IECEx approval	BVS 11.0068X
Approved for	Ex nAc [ic] IIC T4
General information	
System information	The module has to be mounted in appropriate backplanes (LB9***) in Zone 2 or outside hazardous areas. Here, the corresponding declaration of conformity has to be observed. For use in hazardous areas (e. g. Zone 2 or Zone 22) the module must be installed in an appropriate enclosure.
Supplementary information	EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperl-fuchs.com.