	Technical data	
	General specifications	
	Sensing range	800 10000 mm
	Adjustment range Unusable area	800 10000 mm 0 800 mm
	Standard target plate	100 mm x 100 mm
	Transducer frequency	approx. 60 kHz
	Nominal ratings Time delay before availability t _v	280 ms
	Limit data	2001113
	Permissible cable length	max. 300 m
	Indicators/operating means LED yellow	solid: switching state switch output
		flashing: misadjustment
	Electrical specifications	041/00
	Rated operating voltage U _e Operating voltage U _B	24 V DC 15 30 V (including ripple)
C∈ (SP.∞ c(VL)us	- P	In supply voltage interval 15 20 V sensitivity reduced to
	Ripple	20% 0% ≤ 10 %
	No-load supply current I ₀	≤ 10 % ≤ 75 mA
	Input/Output	
Model Number	Input/output type 0 Level	1 synchronization connection, bidirectional ≤ 3 V
UC10000-F260-IE9R2-Y250793	1 Level	15 30 V
	Input impedance	typ. 0.9 kΩ
Single head system	Number of sensors Switching output	max. 10
Features	Output type	2 switch outputs PNP, NC
Adjustable Bracket	Repeat accuracy	± 15 mm
•	Operating current IL	150 mA , short-circuit/overload protected ≤ 3 V
Large sensing range	Voltage drop Switch-on delay	≤ 3 V 800 ms
 Programmable by means of Inter- 	Analog output	
face (see accessories) and SON- PROG	Output type	1 current output 0 20 mA rising slope
	Default setting Linearity error	800 10000 mm ≤ 1.5 %
 1 analog output, 0-20 mA current 	Load resistor	\leq 300 Ω
source	Ambient conditions	-25 70 °C (-13 158 °F)
2 switch outputs	Ambient temperature Storage temperature	-25 70 °C (-13 158 °F) -40 85 °C (-40 185 °F)
 Synchronization options 	Shock resistance	30 g , 11 ms period
 Temperature compensation 	Vibration resistance Mechanical specifications	10 55 Hz , Amplitude ± 1 mm
	Connection type	screw terminals, PG 13.5 cable gland
Description	Degree of protection	IP65
This ultrasonic sensor is a contactless distance sensor	Material Housing	UP 1225 SF/R8
based on the echo run time principle. It is suitable for	Transducer	epoxy resin/hollow glass sphere mixture; polyurethane foam
the detection of solid, liquid or powder sound-reflecting	Installation position	any position
objects. The unique sensor design allows easy move-	Mass Compliance with standards and	1800 g
ment of the direction of sound radiation in all spatial di-	directives	
rections by up to 10° without additional an additional assembly device.	Standard conformity	
assembly device.	Standards	EN 60947-5-2:2007 IEC 60947-5-2:2007
Diagrams		120 00347-3-2.2007
Diagrams		
E Characteristic response curve		
	Approvals and certificates	al II us Listed, Canaral Burnasa
Distance Y [mm]	UL approval CSA approval	cULus Listed, General Purpose cCSAus Listed, General Purpose
C61 1800 1600 1600 1200	CCC approval	CCC approval / marking not required for products rated
00 1400 1200 1000		≤36 V
of issue: 2014-10-14		
-400 -600 -800		
5 -1000		
-1800		
$ \begin{array}{c} 6\\ \overline{4} \overline{} \longrightarrow \chi $		
Curve 1: flat surface 100 mm x 100 mm		
ର୍ଦ୍ଧି Curve 2: round bar, Ø 25 mm ଞ୍ର		
a g		
Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm		
Ĕ	I	
Refer to "General Notes Relating to Pepperl+Fuchs Product Information Pepperl+Fuchs Group USA: +1 330 486 0001		1 1: +65 6779 9091
		pperl-fuchs.com



UC10000-F260-IE9R2-Y250793



112

Ш


Dimensions

A


160 ø 8.5 97.6 09 Ġ \bigcirc

Additional Information

Area definitions



Electrical Connection



Accessories

DA5-IU-C Digital display unit

3RX4000-PF PC interface

V15S-G-2M-PVC Cable connector, M12, 5-pin, PVC cable

V1-M20-80

Receptacles, M12/M20; plastic version

Danger! This product must not be used in applications in which the safety of persons depends on the device

function. This product is not a safety component in accordance with the EU Machinery Directive.


Assembly and connection

When installing the sensor, make sure that the space filled by the sound cone is free from interfering objects. Objects in the blind zone cause cause false signals. Implement suitable measures to ensure that objects cannot enter the blind zone.

The electrical connection is made via screw terminals. The connections are protected against reverse polarity, short circuits and overloads. Shielded cables are recommended if there is electrical interference.

Setting

The detection range limits $S_{min} \mbox{ and } S_{max} \mbox{ are fixed (see Technical data).}$ Within these limits, the switch points A and E are set using a potentiometer. Switch point A must be smaller than switch point E. If this is not the case, the LED flashes and correct switching is not possible.



fa-info@us.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Parameterisation via SONPROG

The following parameters can be changed via the SONPROG parameterisation software:

- Measuring range limits S_{min} and S_{max}
- Switch-on and switch-off points E and A
- Blind zone
- Averaging
- Analogue limits
- Analogue characteristic, rising/falling

Operation

Within the detection range, which is restricted by the detection range limits S_{min} and S_{max} , the object distance is detected. Objects with an even, smooth surface can have a maximum inclination of 3° to the direction of sound propagation. With rough, uneven surfaces the angular deviation can be bigger. The actual value depends significantly on the object finish and should be obtained experimentally if necessary.

Behaviour of the switch outputs:

- If the object is at a distance > E, both switch outputs are in standby mode.
- If the object is between E and A, switch output S is activated and switch output SX is in standby mode.
- If the object is at a distance < A, switch output SX is activated and switch output S is in standby mode.

Behaviour of the analogue output:

The object distance between the detection range limits (S_{min} , S_{max}) are displayed in the form of an analogue output signal at the analogue output. The analogue output delivers its minimum value at distance S_{min} and its maximum value at distance S_{max} . The characteristic between the two measuring range limits is linear. Outside of S_{max} the analogue output retains its maximum value.

Display:

The sensor has an LED. It lights up continuously when the output terminal S is carrying a voltage. It flashes when switch points A and E are set incorrectly (see Setting). Function input XI

The sensor is placed in standby mode by connecting a low level at the function input XI (blocked release). The sensors then performs no measurements. The switch outputs retain the most recent status. As soon as function input XI is disconnected from the low level or a high level is connected (release), the sensor resumes its normal function after the release period has expired.

The function input XI can be used during operation for the synchronisation of multiple sensors in the event of mutual interefence. The following synchronisation modes are possible:


- Triggering of each individual sensor with a separate control signal, e.g. by a PLC (external synchronisation).
- Connection of the function inputs XI of all sensors and joint triggering with an external control signal, e.g. by a PLC (external synchronisation, common-mode operation).
- Connection of the function inputs XI of all sensors and without triggering with an external signal (internal synchronisation, multiplex mode).

Maintenance

The ultrasonic sensor is maintenance-free. However, the converter surface must not be wet, damaged, painted or covered with material deposits.

Connecting the PC interface 3RX4000-PF to use SONPROG

This sensor can be parameterised using SONPROG for an optimum adaptation to the application. Therefore the sensor provides communication with the 3RX4000-PF PC interface. To connect to the 3RX4000-PF PC interface a 4- or 5-pin M12 male cable connector is reqired. We recommend e. g. an adapter V1-M20-80 or a cable connector V15S-G-2M-PVC. Please connect the wires to the sensors terminals as shown, below.



The terminals I_A/U_A (analog output) and SX (2^{na} switching output) are not needed for programming.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

