
# Automation light grid





# **Model Number**

#### LGM8 Serie

Light grid

with fixed cable with 4-pin, M12 x 1 connector, and fixed cable with 8-pin, M12 x 1, connector


#### **Features**

- Measuring automation light grid with • switching output
- Optical resolution 8 mm
- Super-fast object detection, even with 3-way beam crossover
- Object identification using integrated object recognition
- IO-link interface for service and pro-. cess data
- Temperature range to -30 °C
- Output of an analog measured value, • can be selected from a number of measuring functions

#### **Product information**

Automation light grids in the LGM Series are designed to measure small to large objects. The slimline light grids are modular in design and are available with various beam gaps and field heights. The entire signal evaluation process is carried out within the device. The lightweight systems can be integrated elegantly into their surroundings, from both a technical and a visual perspective. As a result, machines and plants operating in temperature ranges between -30 °C ... +60 °C can be designed to more compact dimensions.

#### Transmitter Receiver +UB 1 +UB 2 SC Range 3 ٠0V 4 C/Q 0 V 5 0 Test 6 n.c.




**Pinout** 

2

3


4

**Electrical connection** 



7

#### Indicators/operating means



$\overline{1}$	1	Menu button	yellow	7	not used	yellow
וע	2	Operating indicator	green	8	Object floating	yellow
	3	Status display	yellow	9	Crossing	yellow
	4	Q object	yellow	10	Peripheral beam tolerance	yellow
	5	not used	yellow	11	2nd level	yellow
	6	not used	yellow	12	OK button	yellow
	~					

2nd level: Beam collimation, inverse mode, light-on/dark-on switching, reset factory setting, signal tracking

251331\_eng.xml 2015-02-26 Date of issue: Release date: 2015-02-26 15:08

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



www.pepperl-fuchs.com

Technical data		Accessories
General specifications		
Effective detection range	Standard : 0.3 6 m	OMH-SLCT-01
Threshold detection range	7.5 m	Quick clamp and adjustment system
Light source	IRED	OMH-SLCT-06
Light type	modulated infrared light, 850 nm	Swivel Bracket
Field height	see Table 1, max. 2100 mm	
Beam crossover	Factory setting: three beam crossing, deactivateable	V19-G-EMV-BK0,3M-PVC-V19-G
Beam blanking	adjustable max. 2 fixed suppressible beam areas (blanking)	Double-ended cordset, M12 to M12, with
Beam spacing	8.33 mm	EMC filter, 8-pin, PVC cable
Number of beams Operating mode	see Table 1, max. 253 Emitter: Emitter power adjustable in two ranges	OMH-SLCT-03
Optical resolution	Emitter: Emitter power adjustable in two ranges without beam crossover: 8 mm	Mounting bracket including adjustment
Oplicariesolution	with beam crossover: 4 mm with in 25% and 75% of the range	
Angle of divergence	10 °	OMH-SLCT-04
Ambient light limit	> 50000 Lux (if external light source is outside the opening	Mounting bracket including adjustment
	angle)	(with loose bearing)
Functional safety related paramete		OMH-SLCT-05
MTTF <sub>d</sub>	21 a	
Mission Time (T <sub>M</sub> )	20 a	Mounting bracket including adjustment
Diagnostic Coverage (DC)	60 %	AA SLCT-01
Indicators/operating means		Profile alignment aid; simplified alignment
Operation indicator	LED green: constantly on - power-on	of the SLCS and SLCT safety light cur-
	double pulse flashing (0.8 Hz) - undervoltage	tains
	flashing (4 Hz) - short circuit	kano
	flashing with short interruptions (1 Hz) - IO-Link mode	V1-G-BK2M-PUR-U
Status indicator	Emitter: LED yellow constantly on - high emitter power	Female cordset, M12, 4-pin, PUR cable
	constantly off - low emitter power	V1-G-BK5M-PUR-U
	flashing (8 Hz) - error message	
	Receiver: LED yellow: constantly on - object detected	Female cordset, M12, 4-pin, PUR cable
	constantly off - no object detected	V1-G-BK10M-PUR-U
	flashing (4 Hz) - below stability control limit	Female cordset, M12, 4-pin, PUR cable
Control elemente	flashing (8 Hz) - error message	
Control elements	Receiver: 2 touch buttons for programming	V1-G-BK15M-PUR-U
Electrical specifications	10 00 1/ 00	Female cordset, M12, 4-pin, PUR cable
Operating voltage U Ripple	B 1830 V DC 10 %	V19-G-BK10M-PUR-IEC
No-load supply current		Female cordset, M12, 8-pin, PUR-cable
	Receiver: $\leq$ 150 mA (without outputs)	
Time delay before availability t <sub>v</sub>	see Table 1, max. 3.8 s	V19-G-BK2M-PUR-IEC
Interface		Female cordset, M12, 8-pin, PUR-cable
Interface type	IO-Link ( pin 4 )	V19-G-BK5M-PUR-IEC
IO-Link Revision	1.0	
COM-Mode	COM 2 (38.4 kBaud)	Female cordset, M12, 8-pin, PUR-cable
Min. cycle time	2.3 ms	V19-G-BK2M-PUR-U-V1-G
Process data witdh	16 bit	Connection cable, M12 to M12, 8/4-pin,
SIO mode support Device ID	yes 1050369 1050389(0x100701 0x100715)	PUR cable
Input Test input	Emitter switch-off with +UB or 0 V at pin 4 (emitter)	IO-Link-Master02-USB
Function input	Range input activation from 1.6 m with +UB or 0 V on pin 2 (emit-	IO-Link master, supply via USB port or se-
i anotori inpat	ter)	parate power supply, LED indicators, M12
	Teach-In input for parameterization on pin 8 (receiver)	plug for sensor connection
Output		IO-Link-Master-USB DTM
Pre-fault indication output	Stability Control (SC) 1 PNP, short-circuit protected, reverse polarity protected on pin 2 (receiver)	Communication DTM for use of IO-Link-
Switching type	Factory setting: dark ON , Switchable to light ON mode	Master
Signal output	Command interface: Pin 4 IO-Link interface C or used as swit-	
eignal output	ching output Q; 1 short-circuit proof reverse polarity protected	PACTware 4.X
	push-pull output (receiver)	FDT Framework
	Switch output: Pin 5 switching output Q; 1 short-circuit proof reverse polarity protected push-pull output (receiver) synchroni-	
	zed with pin 4	IODD Interpreter DTM Software for the integration of IODDs in a
Switching threshold	Factory setting: The signal tracking for the threshold value is	
	deactivated, increasing the optical resolution by a maximum of	frame application (e. g. PACTware)
Switching voltage	4 mm; switchable to active signal tracking max. 30 V DC	LGM-Serie IODD
Switching current	max. 30 V DC max. 100 mA	IODD for communication with LGM-IO-
Voltage drop U		Link sensors
Switching frequency f	see Table 1, max. 118 Hz	
Response time	see Table 1, max. 20 ms	LGM-Serie DTM
Timer function	Off-delay programmable from 0 1.25 s in 5 ms steps (adjust-	DTM for communication with LGM sen-
	ment via IO-Link only)	sors
Ambient conditions		Other suitable accessories can be found at
Ambient temperature	-30 60 °C (-22 140 °F)	www.pepperl-fuchs.com
Storage temperature	-30 70 °C (-22 158 °F)	
		1

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com


Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Mechanical specifications	
Housing length L	see Table 1, max. 2260 mm
Degree of protection	IP67
Connection	Emitter: 200 mm connecting cable with 4-pin, M12x1 connector Receiver: 200 mm connecting cable with 8-pin, M12 x 1 connec- tor Cable cross section min. 0.25 mm2 Max. cable length 30 m
Material	
Housing	extruded aluminum section , Silver anodized
Optical face	Plastic pane , Polycarbonate
Mass	see Table 1, max. 1200 g (per profile)
Compliance with standards and directives	
Directive conformity	
EMC Directive 2004/108/EC	EN 60947-5-2:2007
Standard conformity	
Product standard	EN 60947-5-2:2007 IEC 60947-5-2:2007
Approvals and certificates	
Protection class	III ( IEC 61140:2009 )
UL approval	cULus Listed
CCC approval	CCC approval / marking not required for products rated ${\leq}36~\text{V}$

# **Curves/Diagrams**



## **Additional Information**

#### Table 1:

Switch-on delay, maximum switching frequency, and maximum time delay before availability:

Field height [mm]		Switch-on delay Q [ms] Without object parameterization		Switch-on delay Q [ms] - With object parameterization - Updated measured value		Maximum swit- ching frequency [Hz]	Maximum time delay before avai- lability tv [s]
		typ.	max.	typ.	max.		
F	100	3	5	5	7	118	0.9
ng.xr	200	3	5	6	9	101	1.0
251331_eng.xml	300	3	6	7	10	88	1.2
5133	400	4	7	7	12	78	1.3
	500	4	8	8	13	70	1.5
02-2	600	5	8	9	15	63	1.6
Date of issue: 2015-02-26	700	5	9	10	16	58	1.8
le: 2	800	5	10	10	18	53	1.9
fissi	900	6	11	11	19	49	2.0
ate o	1000	6	11	12	21	46	2.2
	1100	6	12	13	22	43	2.3
2:08	1200	7	13	13	24	41	2.5
-26 1	1300	7	14	14	25	38	2.6
2-02	1400	8	14	15	27	36	2.8
201	1500	8	15	16	28	35	2.9
date:	1600	8	16	16	30	33	3.0
aase date: 2015-02-26 15:08	1700	9	17	17	31	31	3.2

www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1000

1050

1100

1150

1200

Field height Switch-on de [mm] Without object pa		- With object parameterization		arameterization	Maximum swit- ching frequency [Hz]	Maximum time delay before avai- lability tv [s]	
1800	9	17	18	33	30	3.3	
1900	9	18	19	34	29	3.5	
2000	10	19	19	36	28	3.6	
2100	10	20	20	37	27	3.8	
Number of bear	ns, housing length,	and weight:				·	
Field height [mm]	Number of beams	Overall length of the transmitter/receiver unit [mm]		Weight of transmitter/receiver unit [g]			
100	13	260			200		
200	200 25		360			250	
300	300 37		460			300	
400	400 49		560		350		
500	61		660		400		
600	73		760	760		450	
700			860		500		
800	97	960			550		
900	109	1060			600		
1000	1000 121		1160			650	
1100	133	1260			700		
1200 145		1360		750			
1300 157		1460		800			
1400 169		1560	1560		850		
1500 181		1660	1660		900		
1600	193 1760				950		
		1 1					

#### **Design and Function**

#### Safety information

1700

1800

1900

2000

2100

The device must be operated only at low protective voltage where there is safe electrical isolation. Modifications and repairs must be carried out only by your supplier!

1860

1960

2060

2160

2260

The system must be maintained and inspected on a regular basis.

A soft, clean cloth may be used to clean the system. Do not use any aggressive or abrasive cleaning agents that will corrode the surfaces. The device must not be subjected to severe impacts or vibrations.

## Commissioning

#### Prerequisites

- The transmitter unit and receiver unit have been mounted and aligned correctly.
- The electrical connection has been established as per the information in the connection diagram.
- The signal output responds to object measurement.

205

217

229

241

253

If at least one beam of light is interrupted, the output remains active for as long as the object is detected.

#### Troubleshooting

- Measure operating voltage
- Check cabling.
- Check transmitter and receiver unit for dirt. Clean if necessary.

#### **Function indicators**

A green LED for indicating the operating status "Power ON" and a yellow status indication LED are fitted on the connection side of the profiles, behind the lens cover.

## **Transmitter Unit**

Δ

Function	Description of Diagnosis	
Green LED to display operating status permanently illuminated	Power On	
Green LED to display operating status is not illuminated. Yellow LED to indicate status is flashing	Energy-saving mode	
Yellow LED to indicate status is not illuminated	Transmission power of transmitter is low	
Yellow LED to indicate status is permanently illuminated	Transmission power of transmitter is high	
Yellow LED to indicate status is flashing rapidly (approx. 8 Hz)	Fault state	

www.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



**Receiver** Unit

Function	Description of Diagnosis
Yellow LED to indicate status — brief change in light emitted	Test input is activated

Function	Description of Diagnosis				
Green LED to display operating status permanently illuminated	Power On				
Green LED to display operating status is not illuminated	Energy-saving mode				
Green LED to display operating status is flashing at brief inter- vals	IO-Link mode active. Possible to parameterize the device only via IO-Link				
Green LED to display operating status is flashing (4 Hz)	Fault status: short circuit at the outputs				
Yellow LED to indicate status is permanently illuminated	Detection field interrupted				
Yellow LED to indicate status is not illuminated	Detection field is clear.				
Yellow LED to indicate status is flashing (approx. 4 Hz)	Insufficient stability control				
Yellow LED to indicate status is flashing rapidly (approx. 8 Hz)	Fault state: fault during signal measurement				

#### **Resolution and Beam Gap**

The optical resolution of the light grid corresponds to the size of the object that can be detected.


The values specified in the technical data under "Optical Resolution" apply if signal tracking for the threshold value is activated. Where the system is parameterized via the touch field menu (level 2, "Signal Tracking"), the value is automatically set to 60%. It is not possible to set other values. To parameterize the system via IO-Link, a threshold value of at least 60% must be entered. Signal tracking for the threshold value is deactivated by default, increasing the optical resolution by a maximum of 4 mm. By selecting 3-way crossover of the light beams, the resolution of the light grid is refined.

The switching outputs respond to any instance in which the beam is interrupted by an object. Selective object detection can also be parameterized using predefined or taught-in objects. Up to 2 beam areas can be suppressed (blanking).

The devices are supplied without object detection programmed, with signal tracking of the threshold value deactivated, and with a beam path with a 3-way crossover.

#### **Resolution of the Crossed Beam Arrangement**

If 3-way beam crossover is programmed, the resolution is refined. In the case of 3-way crossover, this means that the increased resolution is offered once 25% of the transmitter unit range or receiver unit range has been covered. It is therefore necessary to ensure that all objects pass the transmitter or receiver with such a gap.




## **IO-Link**

The sensor parameters are device-specific and are described in the standardized IO Device Description file (IODD). The IODD can be read into different engineering tools using IODD support from different system providers. The sensor can then be configured or diagnosed using the relevant tool and a user interface generated from the IODD.

The IODD interpreter are available in the corresponding product description on our homepage, www.pepperl-fuchs.com. For the IODD description contact the P+F support.





www.pepperl-fuchs.com



6