



Model Number

OBE2000-R3-SE2-0,2M-V31

Thru-beam sensor with fixed cable and 4-pin, M8 connector


Features

- 45° cable outlet for maximum mounting freedom under extremely tight space constraints
- Improvement in machine availability with abrasion-resistant, antistatic glass front
- Extremely large detection range in Long Range Mode
- Option of switching to high precision mode for greater switching accuracy


Product information


The R3 series nano sensor has been developed for a broad range of applications. It offers excellent durability and is exceptionally easy to install. The housing is compact and, with its 45° cable outlet, can be installed in the smallest spaces. New functional principles and functionality open up a range of new options. The abrasion-resistant lens allows long operating times close to the moving object.

Dimensions




Electrical connection





Indicators/operating means





1	Operating display	green
2	Signal display	yellow
3	Emitter	
4	Receiver 1	
5	Receiver 2	

Technical data			
System components			
Emitter		OBE2000-R3-0,2M-V31	
Receiver		OBE2000-R3-E2-0,2M-V31	
General specifications			
Effective detection range		Long range mode: 0 2 m High precision mode: 0 200 mm	
Threshold detection range		Long range mode: 2.5 m High precision mode: 300 mm	
Light source		LED	
Light type		modulated visible red light, 630 nm	
Angle deviation		approx. 2 °	
Diameter of the light spot		Long range mode: 150 mm at a distance of 2000 mm High precision mode: 0.5 mm at a distance of 50 mm	
Angle of divergence		approx. 2 °	
Optical face		frontal	
Ambient light limit		EN 60947-5-2 : 30000 Lux	
Functional safety related parameters			
MTTF _d		806 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
ndicators/operating means			
Operation indicator		LED green, statically lit Power on , short-circuit : LED green flashing (approx. 4 $\rm Hz)$	
Function indicator		Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control; OFF when light beam is interrupted	
Electrical specifications			
Operating voltage	U _B	10 30 V DC , class 2	
No-load supply current	0	Emitter: ≤ 11 mA	
		Receiver: ≤ 8 mA	
nput			
Control input		Emitter selection BK: not connected, Long Range mode BK: 0 V High Precicion Mode	
Switching threshold		Teach-In input	
Output			
Switching type		NO contact	
Signal output		1 PNP output, short-circuit protected, reverse polarity protected open collector	
Switching voltage		max. 30 V DC	
Switching current		max. 50 mA	
Voltage drop l	U _d	≤ 1.5 V DC	
Switching frequency f	f	approx. 800 Hz	
Response time		600 μs	
Ambient conditions			
Ambient temperature		-25 60 °C (-13 140 °F)	
Storage temperature		-30 70 °C (-22 158 °F)	
Mechanical specifications			
Degree of protection		IP67	
Connection		200 mm fixed cable with 4-pin, M8x1 connector	
Material		, ,	
Housing		PC/ABS and TPU	
Optical face		glass	
Cable		PUR	
Mass		approx. 20 g Per sensor	
Cable length		200 mm	
Compliance with standards and directives			
Directive conformity			
EMC Directive 2004/108/EC		EN 60947-5-2:2007	
Approvals and certificates			
UL approval		cULus Recognized, Class 2 Power Source	

Accessories

MH-R2-01

Bracket for mounting R2 series sensors

MH-R2-02

Bracket for mounting R2 series sensors

MH-R2-03

Bracket for mounting R2 series sensors

MH-R2-04

Bracket for mounting R2 series sensors

V31-GM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR

Female cordset, M8, 4-pin, PUR cable


Other suitable accessories can be found at www.pepperl-fuchs.com


EPPERL+FUCHS


CCC approval


CCC approval / marking not required for products rated ≤36 V


Curves/Diagrams














Teach-In Methods


The thru-beam sensor enables the switching points to be taught in for optimum adaptation to specific applications. This eliminates the need for additional components such as apertures.

Essentially, all Teach-in methods can be used in both "High Precision" and "High Power" operating modes.

The sensitivity of the thru-beam sensor can be adjusted using three Teach-in methods:

Position Teach

- The gain is set to an optimum value
- The signal threshold is set to a minimum



Recommended application:

This method enables extremely small differences in contrast to be detected, as well as minuscule particles in the beam path, and provides exceptional positioning accuracy.


The best results are achieved in "High Precision" mode.


- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- 3. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 4. The end of the Teach-in process is indicated when the green LED indicator lights up sold and yellow LED blinks.

Two-Point Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to an optimum value
- The signal threshold is set in the center between the two taught signal values





Recommended application:

Enables detection of transparent objects.


The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- 3. Position the object in the beam path.
- 4. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 5. The end of the Teach-in process is indicated when the green LED indicator lights up sold.

Maximum Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to a maximum
- The signal threshold is set to a minimum





Recommended application:

Enables an object to be detected with a high excess gain. This can be useful if there is severe environmental contamination or to achieve long operating times.

The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Cover the receiver or transmitter.
- 3. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver.
 The green and yellow LED indicators flash alternately at 2.5 Hz
- 5. The end of the Teach-in process is indicated when the green LED indicator lights up sold.

269696 eng.xml

8