Features

- Interface between the I/O modules and the DCS/PLC
- · Com unit for 80 analog or 184 digital channels
- Communication via PROFIBUS DP
- HART communication via PROFIBUS DP V1 or service bus
- · Configuration via GSD parameters from the control system
- Non-volatile memory for configuration and parameter settings
- · Self configuration in redundant systems
- · Permanently self-monitoring
- · Outputs drive to safe state in case of failures
- Installation in suitable enclosures in Zone 1 or Zone 21
- Module can be exchanged under voltage (hot swap)

Function


The Remote I/O Com Unit or Gateway links intrinsically safe and safe inputs and outputs from sensors and actuators to the PROFIBUS.

It makes use of all regular I/O modules and thus transports signals to and from NAMUR sensors, mechanical contacts, high power IS solenoids, power relays, sounders, and alarms LEDs.

The Com Unit supports online configuration, redundancy, and HART. It is well integrated into all renowned DCS and PLC systems.


Assembly

Front view





Connection



Supply		
Connection		backplane bus
Rated voltage	Un	5 V DC , only in connection with the power supplies FB92**
Power consumption		2 W
Fieldbus interface		
Fieldbus type		PROFIBUS DP/DP-V1
PROFIBUS DP		THOUSE BIT DIT VI
Connection		wired to Evia terminals via healthlane
•••••••		wired to Ex e terminals via backplane
Baud rate		up to 1.5 MBit/s
Protocol		PROFIBUS DP/DP V1 read/write services
Number of stations per bus line		≤125 (PROFIBUS), ≤119 (service bus)
Number of channels per station		≤ 80 analog, ≤ 184 digital (standard configuration)
Number of stations per bus segment		≤ 31 (RS-485 standard)
Number of repeaters between Master and Slave		max. 3
Supported I/O modules		all FB remote I/O modules
Bus length		≤ 1000 m (FOL, 1.5 MBaud), ≤ 1000 m (copper cable, 187.5 kBd), ≤ 200 m (copper cable, 1.5 MBd)
Addressing		via configuration software
PROFIBUS address		0 126 (ex works standard: 126)
GSE file		CGV61711.gsd/gse
HART communication		via PROFIBUS or service bus
Internal bus		
Connection		backplane bus
Redundancy		via front connector
Indicators/settings		THE HOTE CONTROLLS
LED indicator		LED green (power supply): On = operating, fast flash = cold start LED red (collective alarm): On = internal fault, flashing = no PROFIBUS connection LED yellow (operating mode): flashing 1 (1:1 ratio) = active, normal operation; flashing 2 (7:1 ratio) = active, simulation
Directive conformity		
Electromagnetic compatibility		
Directive 2004/108/EC		EN 61326-1
Conformity		
Electromagnetic compatibility		NE 21
Degree of protection		IEC 60529
Fieldbus standard		IEC 61158-2
Environmental test		EN 60068-2-14
Shock resistance		EN 60068-2-27
Vibration resistance		EN 60068-2-6
Damaging gas		EN 60068-2-42
		EN 60068-2-56
Relative humidity Ambient conditions		LIV 00000-2-00
		20 60 °C (4 140 °E)
Ambient temperature		-20 60 °C (-4 140 °F)
Storage temperature		-25 85 °C (-13 185 °F)
Relative humidity		95 % non-condensing
Shock resistance		shock type I, shock duration 11 ms, shock amplitude 50 m/s ² , number of shock directions 6, number of shocks per direction 100
Vibration resistance		frequency range 5 500 Hz, amplitude 5 13.2 Hz \pm 1.5 mm, 13.2 100 Hz 1g, sweep rate 1 octave/min, duration 10 sweeps 5 Hz - 100 Hz - 5 Hz
Damaging gas		for plugs: 21 days in 25 ppm SO ₂ , at 25 °C and 75 % rel. humidity, device G3
Mechanical specification	ons	
Degree of protection		IP20 (module), a separate housing is required acc. to the system description
Connection		via backplane
		approx. 750 g
Mass		57 x 107 x 132 mm (2.2 x 4.2 x 5.2 in)
Mass Dimensions Data for application in with Ex-areas	connection	
Dimensions Data for application in with Ex-areas		
Dimensions Data for application in	rtificate	PTB 97 ATEX 1074 U , PTB 97 ATEX 1075 (system) , for additional certificates see www.pepperl-fuchs.com



Directive 94/9/EC	EN 60079-0:2009 EN 60079-1:2007 EN 60079-11:2007 EN 60079-26:2007 EN 61241-11:2006
General information	
System information	The module has to be mounted in appropriate backplanes (FB92**) in Zone 1, 2, or outside hazardous areas. Here, the corresponding EC-Type Examination Certificate has to be observed.
Supplementary information	EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperlfuchs.com.

Versions

Bus couplers are available with different firmware versions. The type code extension * designates the firmware version.